# Page 2

Reset, oscillators, JTAG I2C-E2PROM, SPI-Flash

### Page 3

Power supplies

#### Page 4

DDR RAM, NAND FLASH, buffers

### Page 5

Peripheral interface

## Page 6

Ethernet interface

# Page 7

USB interface

## Page 8

SODIMM edge connector interface

UL = UnLoaded = normally not mounted component.

Default jumper settings are indicated in the schematic. However, always check jumper positions on actual boards since there is no guarantee that all jumpers are in default place.

#### **Rev 1.3**

Added U19 (74LVC1G125) and C114 (100nF), and changed R17 to 33K (from UL), see schematic page 2.

#### **Rev 1.2**

Added R95, R96 pulldows. Clarified U10 part number. Added R97-R99, C112, C113 to prepare for LPC3250 DDR errata, but not needed. R17 not mounted.

#### **Rev 1.1**

Changed control pins for LED3-5 to P2.10-12. Added voltage test points.

#### Rev 1.0

Original revision



Document Number:

(C) Embedded Artists AB


TITLE: LPC32x0 OEM Board v1.3


------


Date: 2010-02-23 20:38:41


Sheet: 1/8


REV:












### **OTG USB Channel**





(C) Embedded Artists AB

TITLE: LPC32x0 OEM Board v1.3

Document Number:

REV:

Date: 2010-02-23 20:38:41

Sheet: 7/8

### SODIMM-200 Edge Connector

