BEFORE TAKEOFF - CIGAR	CRUISE		
Controls free & correct	Throttle 2200-2700 RPM (<75% MCP)		
Airspeed indicator 0, or wind speed	Elevator trim adjust to cruise speed	FIRE DURING START	ENGINE POWER LOSS
Attitude indicator centered	Fuel selector both		
Altimeter set to ATIS	Mixture lean above 3,000 ft	CRANKING continue	(A) AVIATE — BEST GLIDE:
Turn coordinator level & ball centered	Circuit breakers in		• •
Heading indicator mag. compass	Landing light off, as needed		- best glide speed 65 KIAS
Vertical speed indicator 0	Engine instruments in green	ENGINE STARTS:	(flaps down @ 60 KIAS)
Fuel selector both	Instrumentscheck, H.I. to compass	- power 1700 RPM a few seconds	
Elevator trim takeoff	DESCENT - A MICE ATM	- engine shutdown, check damage	(B) BEST PLACE TO LAND:
Mixture full rich	Altimeter set to ATIS		- select field — 1.5 NM ≈ 1000 ft
RUN - UP:	App. briefing complete	ENCINE FAIL C TO CTART	
- Primer in & locked	Mixture richen	ENGINE FAILS TO START:	- turn towards area
- Oil pressure / temp in green, warm	Carburetor heat as required	- cranking continue	 select best approach for wind
- Brakes apply	Instruments check, H.I. to compass	- fire extinguisher obtain	- use NEAREST
- Throttle	BEFORE LANDING - GUMPFS	- engine shutdown	use NEARLEOT
- Suction gauge in green, 5 psi		- fire extinguisher use	(C) CHECK LIST - RESTART:
- Ammeter positive load	Seat belts adjust & secure	- fire extinguisheruse	,
- Magnetos 125 drop / 50 diff.	Fuel selector both		- fuel selector on
- Carburetor heat	Landing light on	FIRE DURING FLIGHT	- mixture full rich
- Throttle	Carburetor heat		- carburetor heat on
= Throttle friction tighten	Mixture full rich below 3,000 ft	- fuel Selector off	
Radios / Nav / XPDR set, ALT + SQWK	Flaps as required	- mixture cut - off	- ignition switch both
Doors / Windows / Belts secure	DMMS70 KIAS	- master switch off	- primer in & locked
HOLDING SHORT	Short Final flaps down, 60 - 70 KIAS	- vents / cabin air / heat off	
Fuel selector both	GO-AROUND		(D) DISTRESS CALL:
Elevator trim takeoff	Throttle full open	- airspeed 100 KIAS	- transponder 7700
Carburetor heat off	Carburetor heat off		- tune current ATC, 121.5, or 122.2
Mixture full rich below 3,000 ft	Flaps retract to 20°	ELECTRICAL FIRE	- announce aircraft id, position
Flaps 0° to 10°	Airspeed 55 KIAS		•
Dep. briefing T.O. abort plan & turn dir.	Flaps 10° until obstacles cleared		
I WILL LOOF THE ENGINE	-	- master switch off	problem, intentions
I WILL LOSE THE ENGINE,	CLEAR OF RUNWAY	- master switch off - all electrical switches off	•
I WILL LOSE THE ENGINE,	-	- all electrical switches off	SETUP APPROACH:
I WILL PUSH IMMEDIATELY	CLEAR OF RUNWAY Elevator trim takeoff Flaps up	- all electrical switches off - vents / cabin air / heat off	SETUP APPROACH: - downwind abeam 1,500 ft AGL
I WILL PUSH IMMEDIATELY ON RUNWAY	CLEAR OF RUNWAY Elevator trim takeoff Flaps up Carburetor heat off	- all electrical switches off	SETUP APPROACH: - downwind abeam
ON RUNWAY TIMENOTE	CLEAR OF RUNWAY Elevator trim takeoff Flaps up Carburetor heat off Mixture lean for taxi	- all electrical switches off - vents / cabin air / heat off - fire extinguisher use	SETUP APPROACH: - downwind abeam 1,500 ft AGL
I WILL PUSH IMMEDIATELY ON RUNWAY	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam
ON RUNWAY TIME NOTE Lights strobe & landing on Camera XPDR ALT / H.I. to rwy hdg	CLEAR OF RUNWAY Elevator trim takeoff Flaps up Carburetor heat off Mixture lean for taxi Lights strobe & landing off Radios / XPDR set, ALT + SQWK	- all electrical switches off - vents / cabin air / heat off - fire extinguisher use	SETUP APPROACH: - downwind abeam
ON RUNWAY TIME NOTE Lights strobe & landing on Camera XPDR ALT / H.I. to rwy hdg Action full throttle > 2270 RPM	CLEAR OF RUNWAY Elevator trim takeoff Flaps up Carburetor heat off Mixture lean for taxi Lights strobe & landing off Radios / XPDR set, ALT + SQWK ENGINE SHUTOFF	 all electrical switches	SETUP APPROACH: - downwind abeam
ON RUNWAY TIME NOTE Lights strobe & landing on Camera XPDR ALT / H.I. to rwy hdg Action full throttle > 2270 RPM NORMAL TAKEOFF	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam
NORMAL TAKEOFF NORMAN NOTE	CLEAR OF RUNWAY Elevator trim takeoff Flaps up Carburetor heat off Mixture lean for taxi Lights strobe & landing off Radios / XPDR set, ALT + SQWK ENGINE SHUTOFF TIME STOP TIMER Lights (except beacon) off	 all electrical switches	SETUP APPROACH: - downwind abeam
ON RUNWAY TIME NOTE Lights strobe & landing on Camera XPDR ALT / H.I. to rwy hdg Action full throttle > 2270 RPM NORMAL TAKEOFF Rotate (V _R) 50 - 55 KIAS Lift-off (V _X) 60 - 65 KIAS	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam
I WILL PUSH IMMEDIATELY ON RUNWAY TIME NOTE Lights strobe & landing on Camera XPDR ALT / H.I. to rwy hdg Action full throttle > 2270 RPM NORMAL TAKEOFF Rotate (VR) 50 - 55 KIAS Lift-off (Vx) 60 - 65 KIAS Climb-out (Vy) 70 - 85 KIAS	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam
NOTE NOTE	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam
NOTE NOTE	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam
NOTE NOTE	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam
NOTE NOTE	CLEAR OF RUNWAY Elevator trim	 all electrical switches	SETUP APPROACH: - downwind abeam


ACRONYMS

CIGAR - Controls, Instruments, Gas, Attitude 1800wxbrief (Leidos Flight Service) (Takeoff Trim), Run-up

A MICE ATM - ATIS; Marker beacons (ON+TEST), Identify (set radios + nav); Course (set final or next approach course; Entry type (full, or straight-in approach? Course reversal? Vectors?); Altitudes (current, FAF, DA/MDA); Time (FAF to MAP); Missed approach procedure briefed.

GUMPFS - Gas; Undercarriage, Mixture, Prop. Flaps, Safety Belts

CRUISE PERFORMANCE



MAXIMUM GLIDE

20 kt.

40 kt.

RANGE in NM @ 65 KIAS, FLAPS UP

Zero

AGL	Wind	Headwind	Headwind
10,000	15	11	6.4
9000	13.5	9.9	5.8
8000	12	8.8	5.1
7000	10.5	7.7	4.5
6000	9	6.6	3.9
5000	7.5	5.5	3.2
4000	6	4.4	2.6
3000	4.5	3.3	1.9
2000	3	2.2	1.3
1000	1.5	1.1	0.6

AIRSPEEDS (KIAS @ GROSS WEIGHT)

	En route climb, sea level. At 10,000 ft.	80 - 90 70 - 80	VY	Best ROC, sea level. At 10,000 ft.	78 68
V _S	Stall speed, flaps up. Stall speed, flaps down.	49 43	Vx	Best AOC, sea level. At 10,000 ft. Obstacle speed, flaps up. SF TO w/ obst. & 10° flaps.	64 62 59 55
1975	C172M - N9693Q (C172/G)		v.01/06	/202

EN ROUTE WEATHER

- Input: Route / flight plan
- Output: "Standard Brief," en route METAR, TAF. Winds Aloft

VERIFY EFB & PHONE WEATHER IS UP-TO-DATE!!!

AIRCRAFT PERFORMANCE

Performance requirements along route C172 Performance App

- Input: Route leg, weight and balance data, latest METAR for departure and destination, en route altitude, en route temperature, en route headwind/tailwind, and desired cruise power setting (% MCP)
- Verify: Weight and balance in limits, winds at departure and destination in limits
- Output: V_R, V_X, V_Y, departure wind components, cruise power RPM, estimated fuel used, ETE, destination wind components

OTHER EMERGENCY

EXCESSIVE RATE OF CHARGE: turn both sides of master switch OFF, then ON. If light comes on again, terminate flight.

INSUFFICIENT RATE OF CHARGE: Nonessential electric OFF. Terminate flight.

RADIO OUT: Check circuit breakers & VOLUME. Recycle alternator switch. If in B, C, or D airspace, squawk 7600. Terminate flight.

TWR SIGNALS	ON GROUND	IN FLIGHT
Steady Green	Cleared To Takeoff	Cleared To Land
Flashing Green	Cleared To Taxi	Return For Landing
Steady Red	STOP	Yield & Continue Circling
Flashing Red	Taxi Clear of Landing Area	Airport Unsafe — Do Not Land
Flashing White	Return To Starting Point	-
Alternating Red & Green	Use Extreme Caution	Use Extreme Caution

_	At 10,000 ft.	68
	Best AOC, sea level.	64
K	At 10,000 ft.	62
	Obstacle speed, flaps up.	59
	SF TO w/ obst. & 10° flaps.	55
	v.01/06	/2021

PREFIGHT - CARIN

PREFLIGHT - CABIN	ı
Pitot cover remove	l
Papers (A.R.O.W.) valid	l
Control lock remove	l
Ignition switch off, keys on dash	l
Avionics master & elec off	l
Circuit breakers in	Ì
Master switch on	l
Gyros no unusual noise	l
Fuel gauges note level	l
Flaps lower in stages	l
Avionics master switch on	l
Navigational instruments (IFR) :	l
- Marker beacons test hi / low	l
- VOR test	l
- GPS database valid / self test OK	ļ
- Transponder test, set ALT + 1200	l
Radios copy ATIS	ĺ
Avionics master switch off	

Pitot heat on, te	st, off
Lights (beacon, strobe, nav) all wo	orking
Master switch	
ADHRS mount, secure be	attery
EFB (inc. phone) mount, secure ba	attery,

Pitot verify cover off

Set Level

connect ADHRS, reset level, update weather from Internet display taxi diagram

Windshield clean

PREFLIGHT - NOSE

Spinner	check for security,
	no cracks
Propeller	check for nicks, max. 1/8"
Cooling air intake	free of restrictions
Carburetor air filter	free of restrictions
Muffler	check for security
Landing light(s)	check condition & clean
Nose wheel strut	inspect & check inflation
Tire	check wear & inflation
Static source opening	ng check for stoppage

PREFLIGHT - LEFT WING

Follows which a selft of	
Fuel tank check quantity & s	secure cap
Tire inspect for wear	& inflation
Brakes inspect for leaks &	k pad wear
Pitot tube check intake	es (2) clear
Fuel vent	clear
Tie down	remove
Wingtip check lights, rivet lir	ne & shake
Aileron check hinges	, pushrod,
counterweights &	movement
Flaps check pushrod &	movement
Fuel drain check f	uel quality

PREFLIGHT - EMPENNAGE

Fuselage	no structural damage
Elevator	hinges, links & counterweights
Rudder	hinges, links & counterweights
Antennae	no damage
Tie down	remove

PREFLIGHT - RIGHT WING

Fuel drain	check fuel, paper napkin test
Flaps	hinge, pushrod & movement
Aileron	. hinge, pushrod & counterweight
Wingtip	lights, rivet line & shake wing
Tie down	remove
Tire	inspect for wear & inflation
Brakes	inspect for leaks & pad wear
Fuel tank	check quantity & secure cap

PREFLIGHT - NOSE RIGHT

Oil level	no less than 6 quarts
Fuel strainer	check fuel quality
Airplane	free to roll & no bald-spots
Overall	FINAL WALK-AROUND,
n	o openinas, no forgotten objects

BEFORE STARTING ENGINE

Preflight inspection COMP	LETE
Seat & seat beltsse	ecure
Fuel selector	both
Avionics master switch	off
Circuit breakers	in
Brakes test an	d set

STARTING ENGINE

Mixture full rich
Carburetor heat off
Prime as required (< 3 strokes)
Primer in & locked
Throttle open 1/8 inch
Rotating beacon on
Master switch on
Brakes set
Propeller area "CLEAR"
Ignition start (30s, 2m intervals)
Throttle < 1000 RPM
Oil pressure green in 30 sec, or stop

TIME START TIMER

BEFORE TAXIING

Mixture lean for taxi
Flaps retract
Heading indicator (H.I.) mag. compass
Avionics master switch on
Radios / Nav / XPDR on, set, ALT + 1200
Communications as required
Brakes test