The Resilience and Disaster Recovery Tool Suite

Run Checklist Version 2023.2

Volpe Project: OS20A121

November 15, 2023

VNTSC-OST-22-04 Rev. 3

DOI: 10.21949/1527574 Rev. 3

Prepared for:

United States Department of Transportation
Office of Research, Development, and Technology
Washington, D.C.



The Federal Highway Administration Office of Natural Environment Washington, D.C.



Recommended citation:

Jonathan Badgley, Andrew Breck, Juwon Drake, Daniel Flynn, Olivia Gillham, Michelle Gilmore, Kristin C. Lewis, Alexander Oberg, Gretchen Reese, Scott Smith, Kevin Zhang. The Resilience and Disaster Recovery Tool Suite: Run Checklist Version 2023.2. Volpe National Transportation Systems Center, Cambridge, MA, 2023. DOI: 10.21949/1527574 Rev. 3.

Notice

This document is disseminated under the sponsorship of the Department of Transportation in the interest of information exchange. The United States Government assumes no liability for the contents or use thereof.

The United States Government does not endorse products or manufacturers. Trade or manufacturers' names appear herein solely because they are considered essential to the objective of this report.

REPORT DOCUMENTATION PAGE				Form Approved OMB No. 0704-0188	
Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.					
1. AGENCY USE ONLY (Leave blank)	2. REPORT DATE	. REPORT DATE 3. REPOR		TYPE AND DATES COVERED	
	November 15, 202	November 15, 2023		Report (6/2021-11/2023)	
4. TITLE AND SUBTITLE The Resilience and Disaster Recovery Tool Suite: Run Checklist Version 2023.2			5	ia. FUNDING NUMBERS OS20A121	
6. AUTHOR(S)			5	b. CONTRACT NUMBER	
Jonathan Badgley, Andrew Breck, Juwon Drake, Daniel Flynn, Olivia Gillham, Michelle Gilmore, Kristin C. Lewis (Project Manager), Alexander Oberg, Gretchen Reese, Scott Smith, Kevin Zhang			693JK421NT800008		
7. PERFORMING ORGANIZATION NAME U.S. Department of Transportatio				8. PERFORMING ORGANIZATION REPORT NUMBER	
John A Volne National Transportation Systems Center			VNTSC-OST-22-04 Rev. 3		
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) 10. SPONSORING/MONITORING AGENCY REPORT NUMBER			.0. SPONSORING/MONITORING AGENCY REPORT NUMBER		
US Dept. of Transportation Office of Research, Development and Technology 1200 New Jersey Ave, SE, Washington, DC 20590			DOI: 10.21949/1527574 Rev. 3		
11. SUPPLEMENTARY NOTES					
12a. DISTRIBUTION/AVAILABILITY STATEMENT 12b. DISTRIBUTION CODE			.2b. DISTRIBUTION CODE		
This document is available to the public at https://volpeusdot.github.io/RDR-Public .					
13. ABSTRACT (Maximum 200 words)					
Volpe developed the Resilience and Disaster Recovery (RDR) Tool Suite in support of the USDOT Office of Research, Development and Technology in collaboration with the Federal Highway Administration's Office of Natural Environment. The RDR Tool Suite enables transportation practitioners to assess the return-on-investment of resilient infrastructure across a range of potential hazard conditions to help prioritize resilience investments. This Run Checklist provides users with a comprehensive summary of input files and parameters to be reviewed before running an RDR analysis. It is complemented by the RDR Tool Suite Technical Document, User Guide, and Quick Start Tutorial.					
14. SUBJECT TERMS 15. NUMBER OF PAGES			15. NUMBER OF PAGES		
				8	
				16. PRICE CODE	
17. SECURITY CLASSIFICATION OF REPORT	18. SECURITY CLASSIFICATION OF THIS PAGE	19. SECURITY CLASSIFICAT OF ABSTRACT	TION	20. LIMITATION OF ABSTRACT Unlimited	
Unclassified					
NSN 7540-01-280-5500				Standard Form 298 (Rev. 2-89)	

Prescribed by ANSI Std. 239-18

298-102

RDR Run Checklist

This document provides a high-level overview of the input files required to run a custom analysis with the RDR Tool Suite. For more details on the RDR input files, see the RDR Tool Suite User Guide.

Required Files

The fol	lowing i	nput files are required before the tool suite can be run for analysis:
	Batch 1	file (run_rdr_full.bat OR run_rdr_analysis.bat)
		Line 17 – Provide the full file path to the configuration file for the analysis.
	_	uration file ({User-Defined}.config, filename left up to user)
	param	llowing parameters must be modified by the user before running a scenario. All other eters in the configuration file have default values provided, which can be modified by the
		s needed.
		Line 18 – Provide the full file path to your input data folder.
		Line 19 – Provide the full file path to where you want output data to be created. (RDR will automatically create this folder.)
		Line 23 – Provide a text string identifier for your run; output files are labeled with this run ID.
		Line 26 – Specify the beginning year of the ROI analysis period.
		Line 28 – Specify the final year of the ROI analysis period.
		Line 32 – Specify the base year for core model runs, corresponding to user-provided base year trip tables.
		Line 35 – Specify the future year for core model runs, corresponding to user-provided future year trip tables.
		Line 53 – Specify the number of scenarios to run in the AequilibraE core model to build the regression model.
		Line 59 – Specify whether the run is a full run or an additional run.
		Line 64 – If line 59 is set to True, specify the number of additional scenarios to run in the AequilibraE core model.
		Line 106 – Provide the column name in the exposure analysis input files defining exposure level.
		Line 143 – Specify the largest node ID in the user's network designating a centroid node.
		Line 232 – Specify what type of ROI analysis (BCA, Regret, or Breakeven) to run.
		Line 241 – Specify the year in which all monetary units are inputted and reported. All
		default values are provided in 2021 dollars.
	Model	parameters file (Model_Parameters.xlsx)
	Uncert	aintyParameters tab
		Column A ("Hazard Events") – List all hazard events as text strings for the RDR Metamodel (RDRM).

	Column B ("Recovery Stages") – List all hazard recovery stages as nonnegative numbers (e.g., 0, 1, 2,) for the RDRM.
	Column C ("Economic Scenarios") – List all economic futures as text strings for the RDRM.
	Column D ("Trip Loss Elasticities") – List all elasticity values as numbers (ranging from -1 to 0) for the RDRM.
	Column E ("Project Groups") – List all resilience project groupings as text strings for the RDRM.
Projec	tGroups tab
	Make sure every resilience project for the RDRM is listed in Column B ("Resiliency Projects") and assigned to exactly one project group in Column A ("Project Groups").
Hazard	ds tab
	Make sure every hazard event in Column A of the UncertaintyParameters tab is listed as a row in this tab.
	Required columns – "Hazard Event", "Filename", "HazardDim1", "HazardDim2", "Event Probability in Start Year"
	puts file (UserInputs.xlsx) puts tab
	Column A ("Hazard Events") – List all hazard events as text strings for the RDR ROI
	Analysis Module.
	Column B ("Economic Scenarios") – List all economic futures as text strings for the RDR ROI Analysis Module.
	Column C ("Trip Loss Elasticities") – List all elasticity values as numbers (ranging from -1 to 0) for the RDR ROI Analysis Module.
	Column D ("Resiliency Projects") – List all resilience projects as text strings for the RDR ROI Analysis Module.
	Column E ("Event Frequency Factors") – List all hazard event frequency multiplicative factors as numbers for the RDR ROI Analysis Module.
	Make sure every entry in columns A through D is included in the model parameters file.
Exposu	re analysis files ({Filename}.csv for each hazard event)
	Make sure there is a CSV file in the "Hazards" subdirectory with the designated filename (specified in the model parameters file) for each hazard event.
	Required columns – "link_id", "A", "B", "Value" (or string corresponding to line 106 of the configuration file)
	Make sure all impacted road and transit network links are included. Centroid connectors and transit boarding/transfer links are not required to be included.
	rk attribute files (node.csv AND {econ}{projgroup}.csv for each economic scenario oject group)

	Make sure there is a CSV file named node.csv in the "Networks" subdirectory.
	Required columns – "node_id", "x_coord", "y_coord", "node_type"
	Confirm that node IDs are unique.
	Label centroid nodes in the network as "centroid" (case-sensitive) in node_type column.
	Confirm that centroid nodes have smaller node IDs than non-centroid nodes.
Link file	es
	Make sure there is a CSV file in the "Networks" subdirectory for each project group-
	economic scenario combination.
	Required columns – "link_id", "from_node_id", "to_node_id", "directed", "length", "facility_type", "capacity", "free_speed", "lanes", "allowed_uses", "toll", "travel_time"
	Confirm that link IDs are unique. Confirm there are no missing values in the "link_id", "from_node_id", and "to_node_id" columns.
	Confirm the directed column is always equal to 1.
	Confirm the allowed_uses column is always equal to "c".
	Confirm the units of the capacity column is in vehicles / day / lane, the units of the toll column is in cents, and the units of the travel time column is in minutes.
	If the RDR run includes trip tables for households owning vehicles and households without cars, "toll_nocar" and "travel_time_nocar" are also required columns.
	If using the default repair cost and/or repair time tables, make sure the facility type column aligns with the numerical codes described in the documentation (e.g., 100 for light rail service links, 600 for light rail boarding links, etc.).
Demar	nd files ({econ}_demand_summed.omx for each economic scenario)
	Make sure there is an open matrix (OMX) file in the "AEMaster/matrices" subdirectory for each economic scenario with a trip table matrix labeled "matrix".
	If the RDR run includes trip tables for households owning vehicles and households without cars, the OMX file should include two trip tables matrices labeled "matrix" and "nocar" for each, respectively.
SQLite	database (project_database.sqlite)
	Confirm this file exists in the "AEMaster" subdirectory. Otherwise, copy the template SQLite database from the "config" directory to the "AEMaster" subdirectory.
	ear core model runs file (Metamodel_scenario_SP_baseyear.csv OR odel_scenario_RT_baseyear.csv)
	Create a row with base year core model run outputs for each hazard event-recovery
Ц	stage combination.
	Required columns – "hazard", "recovery", "trips", "miles", "hours"
	If calculating transit-specific metrics (calc_transit_metrics parameter in configuration file on line 85 set to 1), "Ir_trips", "hr_trips", "bus_trips", "car_trips", "lr_miles", "hr_miles", "bus_miles", "car_miles", "Ir_hours_wait", "hr_hours_wait",

		"bus_hours_wait", "Ir_hours_enroute", "hr_hours_enroute", "bus_hours_enroute", and "car_hours" are also required columns. See documentation for more information.
		If using the base year run helper tool, make sure there is a CSV file named
		baseyear.csv in the "Networks" subdirectory specifying network links for the base
		year and an OMX file named baseyear_demand_summed.omx in the
		"AEMaster/matrices" subdirectory specifying trip tables for the base year.
		, , , , , , , , , , , , , , , , , , , ,
	☐ Resilience projects files (project_info.csv AND project_table.csv) Project info file	
		Make sure there is a CSV file named project_info.csv in the "LookupTables"
		subdirectory.
		Required columns – "Project ID", "Project Name", "Asset", "Project Cost", "Project Lifespan"
		Make sure resilience project costs are provided in the dollar year units specified on line 241 of the configuration file.
		If using the optional "Annual Maintenance Cost" and "Redeployment Cost" columns,
		make sure "maintenance" and "redeployment" parameters, respectively, are set to True in the configuration file.
Project table file		
		Make sure there is a CSV file named project_table.csv in the "LookupTables" subdirectory.
		Required columns – "link_id", "Project ID", "Category"
		If using default repair cost and/or repair time tables, confirm Category column is either "Highway" "Bridge", or "Transit".
		Make sure all road and transit network links covered by the resilience project (e.g., including bus links) are included.
		If using the optional "Exposure Reduction" column for resilience project partial
		mitigation modeling, make sure "Manual" is specified on line 149 of the configuration file and the units used in the column match units of the exposure analysis files.
Optio	onal Fi	les
The fol	lowing ir	nput files provide optional functionality for a custom analysis:
П	True sh	ape file (TrueShape.csv)
_	П	If used, make sure there is a CSV file named TrueShape.csv in the "LookupTables"
		subdirectory.
		Required columns – "link_id", "WKT"
	Link typ	pes look-up table (link_types_table.csv)
		If used, make sure there is a CSV file named link_types_table.csv in the "LookupTables" subdirectory.
		Required columns - "facility type" "alpha" "heta"

	Exposu	re-disruption look-up table If used, make sure "Manual" is specified on line 101 of the configuration file for link availability approach and the full path of the CSV file is specified on line 116 of the configuration file.
		Required columns – "min_inclusive", "max_exclusive", "link_availability"
☐ Exposure-damage look-up table		re-damage look-up table
		If used, make sure "Manual" is specified on line 187 of the configuration file for exposure damage approach and the full path of the CSV file is specified on line 192 of the configuration file.
		Required columns – "Asset Type", "min_exposure", "max_exposure", "Damage (%)"
	Repair	cost look-up table
		If used, make sure "User-Defined" is specified on line 199 of the configuration file for repair cost approach and the full path of the CSV file is specified on line 208 of the configuration file.
		Required columns – "Asset Type", "Facility Type", "Damage Repair Cost", "Total Repair Cost"
		Make sure costs are defined per lane-mile for all asset types except "Bridge", which has costs defined per square foot.
	Repair time look-up table	
		If used, make sure "User-Defined" is specified on line 215 of the configuration file for repair time approach and the full path of the CSV file is specified on line 219 of the configuration file.
		Required columns – "Asset Type", "min_inclusive", "max_exclusive", "repair_time"
RDR	Input	Validation Helper Tool
	Run the input validation tool from the "helper_tools" subfolder of the RDR directory (e.g., "C:\GitHub\RDR\helper_tools").	
		t errors identified in the Input Validation Helper Tool log file. ¹

¹ Note that the input validation helper tool is not a comprehensive check of all possible user input errors. In particular, the script does not check for errors in the batch file, the configuration file, or optional input files.