The Resilience and Disaster Recovery (RDR) Tool Suite Run Checklist Version 2024.1

Volpe Project: OS70D123

May 22, 2024

VNTSC-OST-24-06 Rev. 1

DOI: 10.21949/1530981 Rev. 1

Prepared for:

United States Department of Transportation
Office of Research, Development, and Technology
Washington, D.C.



The Federal Highway Administration Office of Natural Environment Washington, D.C.



Recommended citation:

Jonathan Badgley, Andrew Breck, Juwon Drake, Daniel Flynn, Olivia Gillham, Michelle Gilmore, Kristin C. Lewis, Alexander Oberg, Gretchen Reese, Scott Smith, Kevin Zhang. The Resilience and Disaster Recovery (RDR) Tool Suite: Run Checklist Version 2024.1. Volpe National Transportation Systems Center, Cambridge, MA, 2024. DOI: 10.21949/1530981 Rev. 1.

Notice

This document is disseminated under the sponsorship of the Department of Transportation in the interest of information exchange. The United States Government assumes no liability for the contents or use thereof.

The United States Government does not endorse products or manufacturers. Trade or manufacturers' names appear herein solely because they are considered essential to the objective of this report.

REPORT DOCUMENTATION PAGE			Form Approved OMB No. 0704-0188
Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.			
1. AGENCY USE ONLY (Leave blank)	2. REPORT DATE	3. REP	ORT TYPE AND DATES COVERED
	May 22, 2024		Report (6/2021-5/2024)
4. TITLE AND SUBTITLE The Resilience and Disaster Recove	ry (RDR) Tool Suite: Run Checklist V	ersion 2024.1	5a. FUNDING NUMBERS OS20A121, OS70D123
6. AUTHOR(S)			5b. CONTRACT NUMBER
Jonathan Badgley, Andrew Breck, Juwon Drake, Daniel Flynn, Olivia Gillham, Michelle Gilmore, Kristin C. Lewis (Project Manager), Alexander Oberg, Gretchen Reese, Scott Smith, Kevin Zhang			693JK421NT800008 693JK423NT800029
7. PERFORMING ORGANIZATION NAME U.S. Department of Transportation	on .		8. PERFORMING ORGANIZATION REPORT NUMBER
John A Volpe National Transportation Systems Center 220 Binney, Cambridge, MA 02142-1093			VNTSC-OST-24-06 Rev. 1
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) 10. SPONSORING/MONITORING AGENCY REPORT NUMBER			10. SPONSORING/MONITORING AGENCY REPORT NUMBER
US Dept. of Transportation Office of Research, Development and Technology 1200 New Jersey Ave, SE, Washington, DC 20590			DOI: 10.21949/1530981 Rev. 1
11. SUPPLEMENTARY NOTES			
12a. DISTRIBUTION/AVAILABILITY STAT	EMENT		12b. DISTRIBUTION CODE
This document is available to the public at https://volpeusdot.github.io/RDR-Public .			
13. ABSTRACT (Maximum 200 words)			
Technology in collaboration with transportation practitioners to as help prioritize resilience investments.	ents. This Run Checklist provides use analysis. It is complemented by the	n's Office of Natural Environment silient infrastructure across a ran ers with a comprehensive summa	The RDR Tool Suite enables ge of potential hazard conditions to ry of input files and parameters to be
14. SUBJECT TERMS			15. NUMBER OF PAGES
			8
			16. PRICE CODE
17. SECURITY CLASSIFICATION OF REPORT	18. SECURITY CLASSIFICATION OF THIS PAGE	19. SECURITY CLASSIFICATION OF ABSTRACT	20. LIMITATION OF ABSTRACT Unlimited
Unclassified	Unclassified	Unclassified	Standard Form 298 (Rev. 2-89)
NSN 7540-01-280-5500			Standard FUITH 230 (NEV. 2-83)

Prescribed by ANSI Std. 239-18

RDR Run Checklist

This document provides a high-level overview of the input files required to run a custom analysis with the ROI Analysis Tool in the RDR Tool Suite. Several of these input files are also used by the Equity and Benefits Analysis Tool. For more details on the RDR input files, see the RDR Tool Suite User Guide.

Required Files

The fol	lowing i	nput files are required before the tool suite can run an ROI analysis:
		file (run_rdr_full.bat) If using the RDR User Interface, this file is generated automatically. Line 17 – Provide the full file path to the configuration file for the analysis.
	The folin the o	lowing parameters must be modified by the user before running a scenario. All other parameters configuration file have default values provided, which can be modified by the user as needed. If using the RDR User Interface, this file is not required. Instead, a JSON configuration file (with ension . save) is generated upon saving in the User Interface. Line 18 – Provide the full file path to your input data folder. Line 19 – Provide the full file path to where you want output data to be created. (RDR will automatically create this folder.) Line 23 – Provide a text string identifier for your run; output files are labeled with this run ID. Line 26 – Specify the beginning year of the ROI analysis period. Line 28 – Specify the final year of the ROI analysis period. Line 32 – Specify the base year for core model runs, corresponding to user-provided base year trip tables. Line 35 – Specify the future year for core model runs, corresponding to user-provided future year trip tables. Line 53 – Specify the number of scenarios to run in the AequilibraE core model to build the regression model. Line 96 – Provide the column name in the exposure analysis input files defining exposure level. Line 133 – Specify the largest node ID in the user's network designating a centroid node. Line 222 – Specify the year in which all monetary units are inputted and reported. All default values are provided in 2022 dollars.
	NOTE: the JSC	parameters file (Model_Parameters.xlsx) If using the RDR User Interface, this file is not required. These parameters are instead included in DN configuration file. aintyParameters tab Column A ("Hazard Events") – List all hazard events as text strings for the RDR Metamodel (RDRM).

		Column B ("Recovery Stages") – List all hazard recovery stages as nonnegative numbers (e.g., 0, 1, 2,) for the RDRM.
		Column C ("Economic Scenarios") – List all economic futures as text strings for the RDRM.
		Column D ("Trip Loss Elasticities") – List all elasticity values as numbers (ranging from -1 to 0) for the RDRM.
		Column E ("Project Groups") – List all resilience project groupings as text strings for the RDRM.
	Project	Groups tab
		Make sure every resilience project for the RDRM is listed in Column B ("Resiliency Projects") and assigned to exactly one project group in Column A ("Project Groups").
	Hazara	Is tab
		Make sure every hazard event in Column A of the UncertaintyParameters tab is listed as a row in this tab.
		Required columns – "Hazard Event", "Filename", "HazardDim1", "HazardDim2", "Event Probability in Start Year"
	User in	puts file (UserInputs.xlsx)
	NOTE: the JSC	If using the RDR User Interface, this file is not required. Instead, these parameters are included in DN configuration file and assumed to be identical to the model parameters.
		Column A ("Hazard Events") – List all hazard events as text strings for the RDR ROI Analysis Tool.
		Column B ("Economic Scenarios") – List all economic futures as text strings for the RDR ROI Analysis Tool.
		Column C ("Trip Loss Elasticities") – List all elasticity values as numbers (ranging from -1 to 0) for the RDR ROI Analysis Tool.
		Column D ("Resiliency Projects") – List all resilience projects as text strings for the RDR ROI Analysis Tool.
		Column E ("Event Frequency Factors") – List all hazard event frequency multiplicative factors as numbers for the RDR ROI Analysis Tool.
		Make sure every entry in columns A through D is included in the model parameters file.
	Evnocu	ure analysis files ([Filename]) say for each hazard event)
		re analysis files ({Filename}.csv for each hazard event) Make sure there is a CSV file in the "Hazards" subdirectory with the designated filename
	Ш	(specified in the model parameters file) for each hazard event.
		Required columns – "link_id", "from_node_id", "to_node_id", "Value" (or string corresponding
	_	to line 96 of the configuration file)
		Make sure all impacted road and transit network links are included. Centroid connectors and transit boarding/transfer links are not required to be included.
	NI - I	where the state of
Ш	project	rk attribute files (node.csv AND {econ}{projgroup}.csv for each economic scenario and group)
	Node f	
		Make sure there is a CSV file named node.csv in the "Networks" subdirectory.

	Required columns – "node_id", "x_coord", "y_coord", "node_type"
	Confirm that node IDs are unique.
	Label centroid nodes in the network as "centroid" (case-sensitive) in node_type column.
	Confirm that centroid nodes have smaller node IDs than non-centroid nodes.
Link file	es
	Make sure there is a CSV file in the "Networks" subdirectory for each project group-economic scenario combination.
	Required columns – "link_id", "from_node_id", "to_node_id", "directed", "length", "facility_type", "capacity", "free_speed", "lanes", "allowed_uses", "toll", "travel_time"
	Confirm that link IDs are unique. Confirm there are no missing values in the "link_id", "from_node_id", and "to_node_id" columns.
	Confirm the directed column is always equal to 1. Confirm the allowed_uses column is always equal to "c". Confirm the lanes column contains no zeroes.
	Confirm the units of the length column is in miles, the units of the capacity column is in vehicles / day / lane, the units of the free speed column is in miles per hour, the units of the toll column is in cents, and the units of the travel time column is in minutes.
	If the RDR run includes trip tables for households owning vehicles and households without cars, "toll_nocar" and "travel_time_nocar" are also required columns.
	If using the default repair cost and/or repair time tables, make sure the facility type column aligns with the numerical codes described in the documentation (e.g., 100 for light rail service links, 600 for light rail boarding links, etc.).
Demar	nd files ({econ}_demand_summed.omx for each economic scenario)
	Make sure there is an open matrix (OMX) file in the "AEMaster/matrices" subdirectory for each economic scenario containing a trip table matrix labeled "matrix".
	If the RDR run includes trip tables for households owning vehicles and households without cars, the OMX file should include two trip tables matrices labeled "matrix" and "nocar" for each, respectively.
SQLite	database (project_database.sqlite)
	Confirm this file exists in the "AEMaster" subdirectory. Otherwise, copy the template SQLite database from the "config" directory to the "AEMaster" subdirectory.
•	ear core model runs file (Metamodel_scenario_SP_baseyear.csv OR odel_scenario_RT_baseyear.csv)
	Create a row with base year core model run outputs for each hazard event-recovery stage combination. The base year run helper tool can help you construct this file.
	Required columns – "hazard", "recovery", "trips", "miles", "hours"
	If calculating transit-specific metrics (calc_transit_metrics parameter in configuration file on line 74 set to 1), "Ir_trips", "hr_trips", "bus_trips", "car_trips", "Ir_miles", "hr_miles", "bus_miles", "car_miles", "Ir_hours_wait", "hr_hours_wait", "bus_hours_wait", "Ir_hours_enroute",

		"hr_hours_enroute", "bus_hours_enroute", and "car_hours" are also required columns. See documentation for more information.
		If using the base year run helper tool, make sure there is a CSV file named baseyear.csv in the "Networks" subdirectory specifying network links for the base year and an OMX file named baseyear_demand_summed.omx in the "AEMaster/matrices" subdirectory specifying trip tables for the base year.
		nce projects files (project_info.csv AND project_table.csv)
	_	tinfo file
		Make sure there is a CSV file named project_info.csv in the "LookupTables" subdirectory.
		Required columns – "Project ID", "Project Name", "Asset", "Project Cost", "Project Lifespan"
		Make sure resilience project costs are provided in the dollar year units specified on line 231 of the configuration file.
		If using the optional "Annual Maintenance Cost" and "Redeployment Cost" columns, make sure "maintenance" and "redeployment" parameters, respectively, are set to True in the configuration file.
	Project	table file
		Make sure there is a CSV file named project_table.csv in the "LookupTables" subdirectory.
		Required columns – "link_id", "Project ID", "Category"
		If using default repair cost and/or repair time tables, confirm Category column is either "Highway" "Bridge", or "Transit".
		Make sure all road and transit network links covered by the resilience project (e.g., including both road/passenger vehicle links and bus transit links) are included.
		If using the optional "Exposure Reduction" column for resilience project partial mitigation modeling, make sure "Manual" is specified on line 139 of the configuration file and the units used in the column match units of the exposure analysis files.
Opti	onal F	iles
•		nput files provide optional functionality for a custom analysis:
	True sh	nape file (TrueShape.csv)
		If used, make sure there is a CSV file named TrueShape.csv in the "LookupTables" subdirectory.
		Required columns – "link_id", "WKT"
	Link ty	pes look-up table (link_types_table.csv)
		If used, make sure there is a CSV file named link_types_table.csv in the "LookupTables" subdirectory.
		Required columns – "facility_type", "alpha", "beta"

	Exposu	re-disruption look-up table
		If used, make sure "Manual" (or "Facility_Type_Manual") is specified on line 91 of the configuration file for link availability approach and the full path of the CSV file is specified on line 106 of the configuration file.
		Required columns for "Manual" – "min_inclusive", "max_exclusive", "link_availability"
		Required columns for "Facility_Type_Manual" – "facility_type", "min_inclusive", "max_exclusive", "link_availability"
	Exposu	re-damage look-up table
		If used, make sure "Manual" is specified on line 177 of the configuration file for exposure damage approach and the full path of the CSV file is specified on line 182 of the configuration file.
		Required columns – "Asset Type", "min_exposure", "max_exposure", "Damage (%)"
☐ Repair cost look-up table		cost look-up table
		If used, make sure "User-Defined" is specified on line 189 of the configuration file for repair cost approach and the full path of the CSV file is specified on line 198 of the configuration file.
		Required columns – "Asset Type", "Facility Type", "Damage Repair Cost", "Total Repair Cost"
		Make sure costs are defined per lane-mile for all asset types except "Bridge", which has costs defined per square foot.
☐ Repair time look-up table		time look-up table
		If used, make sure "User-Defined" is specified on line 205 of the configuration file for repair time approach and the full path of the CSV file is specified on line 209 of the configuration file.
		Required columns – "Asset Type", "min_inclusive", "max_exclusive", "repair_time"
RDR	Input	Validation Helper Tool
		e input validation tool from the "helper_tools" subfolder of the RDR directory (e.g., thub\RDR\helper_tools").
		errors identified in the Input Validation Helper Tool log file. ¹

¹ Note that the input validation helper tool is not a comprehensive check of all possible user input errors. In particular, the script does not check for errors in the batch file, the configuration file, or optional input files.