
From last time

Sources


Type


- Inductive
- Grounded

Waveform




- Location
 - Airborne
 - Ground
 - Borehole





Transmitter considerations


Time or frequency?



Key factor is moment


$$m = I$$
 (current) A (area) N (# of turns)

$$\mathbf{B}(\mathbf{r}) = \frac{\mu_0}{4\pi} \left(\frac{3\mathbf{r}(\mathbf{m} \cdot \mathbf{r})}{|\mathbf{r}|^5} - \frac{\mathbf{m}}{|\mathbf{r}|^3} \right)$$



Airborne Survey







Resolve


SkyTEM


Large Loop



Applications for different systems









Skin Depth

- EM waves decay when propagating in a conducting earth
- Skin depth

$$\delta \approx 500 \sqrt{\frac{\rho}{f}} \quad \mathrm{meter}$$





where ρ is resistivity in Ωm and f is frequency in Hz

Today's Topics


- Data and Processing
 - Sounding curves
 - Apparent conductivity/resistivity
 - In-phase and quadrature maps
 - 1D Inversion
- Examples
 - Sand and gravel quarries
 - Bookpurnong
- Recap of EM Methods

Data and Processing


Data: Sounding Curve

Data obtained at a single location


Time




SkyTEM



Sampling times



Sounding curve




Frequency




Resolve



Sampling frequencies




Sounding curve





FEM sounding curve example


- Coincident loop system
- VMD source and receiver measuring Bz(f)



FEM sounding curve example








Information about conductivity is captured by the sounding curve

FEM sounding curve example

- 3 layers + air,
- ρ_2 varies



- Four different cases:
 - Halfspace

$$\rho_2 = 100 \Omega m$$

Resistive

$$\rho_2 = 1000 \ \Omega m$$

- Conductive


$$\rho_2 = 10 \Omega m$$


- Very conductive


$$\rho_2 = 1 \Omega m$$


- Fields
 - J_y imag
 - Secondary B imag

Curves for different layer conductivities










Data: Apparent Conductivity

For horizontal coplanar FEM systems

$$\delta \approx 500 \sqrt{\frac{\rho}{f}}$$



• If $s \ll \delta$ and $Re[Hs] \sim 0$ then for a half-space:

$$rac{H_s}{H_p} \simeq i rac{\omega \mu_0 \sigma s^2}{4}$$


Apparent conductivity:


$$\sigma_a = \frac{4}{\omega \mu_0 s^2} \mathrm{Im} \left\{ \frac{H_s}{H_p} \right\}$$

- Could compute apparent resistivity
- Could turn sounding curve into apparent resistivity curve for background response


Processing: Apparent Conductivity Map

- Lateral variability in near surface conductivity from EM 31
- Taken for two different transmitter-receiver orientations






Processing: Apparent Conductivity and In-Phase Data



- Apparent conductivity (mS/m): lateral changes in conductivity
- In-phase (ppm): Large value highlights buried conductors

EM-31 and Pipe



Easting (m)

20


Easting (m)

EM-31 and Conductors




Finding good conductors


High induction number over a conductor




Finding metallic objects



Inversion




1D Inversion example




1D Inversion example


Frequency sounding



Time sounding



Estimated earth resistivity




Example: Sand and Gravel Quarries

Sand and Gravel Quarries


- **Setup:** Find sand and gravel quarries. Area has granitic mountains, rolling hills and lakes. Glacial deposits are responsible for potential sand and gravel resources. Some of the area is bog and agricultural land. (Picture)
- **Properties**: Bog material is wet and conductive. Gravel deposits are resistive (low conductivity). Gravels are unconsolidated and have a low seismic velocity.
- **Survey**: Preliminary EM survey (EM31) Logistically easy and gives an estimate of ground conductivity in the top few meters. Good reconnaissance tool. More detailed follow-up using DC resistivity to get 2D conductivity structure and seismic to find the base of the gravel.
- Data: EM31data. Also DC and seismic are acquired along selected line profiles.






Sand and Gravel Quarries


- Processing: EM31 data is converted to ground conductivity. (Picture). DC
 resistivity data is inverted to get a 2D cross section. Seismic data are inverted to
 provide location of refracting interfaces.
- **Interpretation:** Areas of low conductivity are identified from the EM survey. The inversion of DC and seismic data outline a gravel lens along one of the transects. Gravel lens is 5-8 meters in thickness and 40-50 meters in length.
- **Synthesis**: Seems successful. Have found gravel lenses and results have helped assess the potential tonnage across the site.





Example: Bookpurnong

Viezzoli et al., 2009











Properties

Location map for salinity measurements




Unit	Conductivity
Saline water	High, 3 - 5 S/m
Fresh water	Low, 0.01 S/m

Conductivity from salinity measurements



Survey

Resolve system (2008)



Horizontal Co-planar (HCP) frequencies:

- 382, 1822, 7970, 35920 and 130100 Hz


Vertical Co-axial (VCA) frequencies: - 3258 Hz

Flight lines







Vertical Co-axial




Horizontal Co-planar (HCP) data









Quadrature (Imaginary)







Sounding curve




Response curve




Processing: 1D inversion



Data fit




Conductivity model (stitched)




Interpretation


Conductivity model (stitched)



Losing Stream



Gaining Stream




- 1 Water table 2 Unsaturated zone
- 3 Saturated zone 4 Flow direction

Synthesis


Hydrological model

Conductivity model (stitched)




EM Recap

EM Survey & Physical Properties





Physical Properties




Basic Experiment


- Source (Tx):
 Current loop makes primary magnetic field
- Induction:
 Time-varying magnetic fields
 induce electric fields everywhere
 - → Large induced currents in conductors
- Secondary Fields: Induced currents in conductors produce secondary magnetic fields
- Receiver (Rx):
 Measures magnetic fields





EM Response from Targets





Coupling coefficient:

Depends on loop geometry


$$M_{12} = \frac{\mu_0}{4\pi} \oint \oint \frac{dl_1 \cdot dl_2}{|\mathbf{r} - \mathbf{r}'|^2}.$$

Magnetic field at the receiver

$$\frac{H^s}{H^p} = -\frac{M_{12}M_{23}}{M_{13}L} \underbrace{\left[\frac{\alpha^2 + i\alpha}{1 + \alpha^2}\right]}_{Q}$$


Induction Number


• Depends on properties $\alpha = \frac{\omega L}{R}$ of target






Response over target






Attenuation of EM Signal




Data: Sounding Curve

Data obtained at a single location


Time




SkyTEM



Sampling times



Sounding curve




Frequency




Resolve




Sampling frequencies



Sounding curve



Apparent Conductivity and In-Phase Data



- Apparent conductivity (mS/m): lateral changes in conductivity
- In-phase (ppm): Large value highlights buried conductors

Unit Activities

- Labs: (EM I)
 - Monday, November 4th
 - Tuesday, November 5th
- Labs: (EM II)
 - Monday, November 18th
 - Tuesday, November 19th
- TBL:
 - Friday, November 15th
- Quiz:
 - Wednesday, November 20th