Algorithms in OpenFAST v2 $\,$

Bonnie Jonkman

April 20, 2020

1 Definitions and Nomenclature

Abbreviation	Abbreviation
in Module	in this Document
ED	ED
BD	BD
AD14	AD14
AD	AD
SrvD	SrvD
SD	SD
HydroDyn	HD
MAPp	MAP
FEAM	FEAM
MD	MD
Orca	Orca
IfW	IfW
IceFloe	IceF
IceD	IceD
SlD	SlD
	in Module ED BD AD14 AD SrvD SD HydroDyn MAPp FEAM MD Orca IfW IceFloe IceD

Table 1: Abbreviations for modules in FAST v8

2 Initializations

3 Input-Output Relationships

3.1 Input-Output Solves (Option 2 Before 1)

This algorithm documents the procedure for the Input-Output solves in FAST, assuming all modules are in use. If an individual module is not in use during a particular simulation, the calls to that module's subroutines are omitted and the module's inputs and outputs are neither set nor used.

```
1: procedure Calcoutputs_And_SolveForInputs()
 2:
 3:
       y\_ED \leftarrow \text{ED\_CALCOUTPUT}(p\_ED, u\_ED, x\_ED, xd\_ED, z\_ED)
       u\_BD \leftarrow \text{TransferOutputsToInputs}(y\_ED)
 4:
 5:
       y\_BD \leftarrow BD\_CALCOUTPUT(p\_BD, u\_BD, x\_BD, xd\_BD, z\_BD)
 6:
 7:
       u\_AD(no IfW) \leftarrow TransferOutputsToInputs(y\_ED)
       u\_IfW \leftarrow TransferOutputsToInputs(y\_EDatu\_ADnodes)
 8:
 9:
       y\_IfW \leftarrow IfW\_CalcOutput(u\_IfW and other IfW data structures)
10:
       u_-AD(InflowWind only) \leftarrow TransferOutputsToInputs(y_-IfW)
11:
12:
       u\_SrvD \leftarrow \text{TransferOutputsToInputs}(y\_ED, y\_IfW)
13:
       y\_AD \leftarrow AD\_CALCOUTPUT(p\_AD, u\_AD, x\_AD, xd\_AD, z\_AD)
14:
       y\_SrvD \leftarrow SrvD\_CALCOUTPUT(p\_SrvD, u\_SrvD,
15:
                                           x\_SrvD, xd\_SrvD, z\_SrvD)
       u\_ED \leftarrow \text{TransferOutputsToInputs}(y\_AD, y\_SrvD)
16:
17:
       u\_BD \leftarrow \text{TransferOutputsToInputs}(y\_AD)
18:
       u\_HD \leftarrow \text{TransferMeshMotions}(y\_ED)
19:
       u\_SD \leftarrow \text{TransferMeshMotions}(y\_ED)
20:
       u\_MAP \leftarrow \text{TransferMeshMotions}(y\_ED)
21:
       u\_FEAM \leftarrow \text{TransferMeshMotions}(y\_ED)
22:
       u\_MD \leftarrow \text{TransferMeshMotions}(y\_ED)
23:
       u\_Orca \leftarrow TransferMeshMotions(y\_ED)
24:
25:
       u\_SlD \leftarrow \text{TransferMeshPosition}(y\_SD)
26:
27:
       SOLVEOPTION1()
28:
29:
       u\_IfW \leftarrow \text{TransferOutputsToInputs}(u\_AD, y\_ED)
30:
       u\_AD \leftarrow \text{TransferOutputsToInputs}(y\_ED)
31:
       u\_SrvD \leftarrow TransferOutputsToInputs(y\_ED, y\_AD)
32:
33: end procedure
```

Note that inputs to *ElastoDyn* before calling CalcOutput() in the first step are not set in CalcOutputs_And_SolveForInputs(). Instead, the *ElastoDyn* inputs are set depending on where CalcOutputs_And_SolveForInputs() is called:

- At time 0, the inputs are the initial guess from *ElastoDyn*;
- On the prediction step, the inputs are extrapolated values from the time history of ElastoDyn inputs;
- On the first correction step, the inputs are the values calculated in the prediction step;
- On subsequent correction steps, the inputs are the values calculated in the previous correction step.

3.2 Input-Output Solve for HydroDyn, SubDyn, MAP, FEAMooring, IceFloe, and the Platform Reference Point Mesh in ElastoDyn

This procedure implements Solve Option 1 for the accelerations and loads in Hy-droDyn,SubDyn,MAP,FEAMooring,OrcaFlexInterface,MoorDyn,SoilDyn, and ElastoDyn (at its platform reference point mesh). The other input-output relationships for these modules are solved using Solve Option 2.

```
1: procedure SolveOption1()
 2:
        y\_MAP \leftarrow \text{CALCOUTPUT}(p\_MAP, u\_MAP, x\_MAP, xd\_MAP, z\_MAP)
 3:
        y\_MD \leftarrow \text{CALCOUTPUT}(p\_MD, u\_MD, x\_MD, xd\_MD, z\_MD)
 4:
        y\_FEAM \leftarrow \text{CalcOutput}(p\_FEAM, u\_FEAM, x\_FEAM, xd\_FEAM, z\_FEAM)
 5:
        y\_IceF \leftarrow CALCOUTPUT(p\_IceF, u\_IceF, x\_IceF, xd\_IceF, z\_IceF)
 6:
        y\_IceD(:) \leftarrow CALCOUTPUT(p\_IceD(:), u\_IceD(:), x\_IceD(:), x\_IceD(:), x\_IceD(:))
 7:
 8:
       \triangleright Form u vector using loads and accelerations from u\_HD, u\_BD u\_SD,
 9:
    and platform reference input from u\_ED
10:
        u \leftarrow U\_VEC(u\_HD, u\_SD, u\_ED)
11:
        k \leftarrow 0
12:
13:
                  ▷ Solve for loads and accelerations (direct feed-through terms)
           y\_ED \leftarrow \text{ED\_CALCOUTPUT}(p\_ED, u\_ED, x\_ED, xd\_ED, z\_ED)
14:
           y\_SD \leftarrow \text{SD\_CALCOUTPUT}(p\_SD, u\_SD, x\_SD, xd\_SD, z\_SD)
15:
           y\_HD \leftarrow \text{HD\_CALcOutput}(p\_HD, u\_HD, x\_HD, xd\_HD, z\_HD)
16:
           y\_BD \leftarrow BD\_CALCOUTPUT(p\_BD, u\_BD, x\_BD, xd\_BD, z\_BD)
17:
18:
           y\_Orca \leftarrow ORCA\_CALCOUTPUT(p\_Orca, u\_Orca, x\_Orca, xd\_Orca, z\_Orca)
           y\_SlD \leftarrow \text{SLD\_CALCOUTPUT}(p\_SlD, u\_SlD, x\_SlD, xd\_SlD, z\_SlD)
19:
           if k \ge k \text{-}max then
20:
               exit loop
21:
           end if
22:
23
           u_BD_tmp \leftarrow \text{TransferMeshMotions}(y_ED)
24:
           u\_MAP\_tmp \leftarrow \text{TransferMeshMotions}(y\_ED)
           u\_FEAM\_tmp \leftarrow TransferMeshMotions(y\_ED)
25:
           u\_IceF\_tmp \leftarrow \text{TransferMeshMotions}(y\_SD)
26:
            u\_IceD\_tmp(:) \leftarrow TransferMeshMotions(y\_SD)
27:
28:
            u\_SlD\_tmp \leftarrow \text{TransferMeshMotions}(y\_SD)
```

```
u\_HD\_tmp \leftarrow \text{TransferMeshMotions}(y\_ED, y\_SD)
29:
            u\_SD\_tmp \leftarrow \text{TransferMeshMotions}(y\_ED)
30:
                            \cup TransferMeshLoads(y\_SD,
                                                           y_-HD, u_-HD_-tmp,
                                                           y\_IceF, u\_IceF\_tmp,
                                                           y\_IceD(:), u\_IceD\_tmp(:),
                                                            y_-SlD, u_-SlD_-tmp)
            u\_ED\_tmp \leftarrow \text{TransferMeshLoads}(y\_ED,
31:
                                                         y\_HD, u\_HD\_tmp,
                                                         y_-SD, u_-SD_-tmp,
                                                         y_-MAP, u_-MAP_-tmp,
                                                         y_FEAM, u_FEAM_tmp)
32:
            U_Residual \leftarrow u_{U_VEC}(u_HD_tmp, u_SD_tmp, u_ED_tmp, u_SlD_tmp)
33:
34:
            if last Jacobian was calculated at least DT_-UJac seconds ago then
35:
                Calculate \frac{\partial U}{\partial u}
36:
            end if
37:
            Solve \frac{\partial U}{\partial u}\Delta u = -U_{-}Residual for \Delta u
38:
39:
            if \|\Delta u\|_2 < \text{tolerance then}
                                                            ▷ To be implemented later
40:
                exit loop
41:
            end if
42:
43:
            u \leftarrow u + \Delta u
44:
45:
            Transfer u to u_HD, u_SD, and u_ED\triangleright loads and accelerations only
            k = k + 1
46:
        end loop
47:
                        > Transfer non-acceleration fields to motion input meshes
48:
49:
        u\_HD(\text{not accelerations}) \leftarrow \text{TransferMeshMotions}(y\_ED, y\_SD)
50:
51:
        u\_SD(\text{not accelerations}) \leftarrow \text{TransferMeshMotions}(y\_ED)
52:
        u\_MAP \leftarrow \text{TransferMeshMotions}(y\_ED)
53:
        u\_MD \leftarrow \text{TransferMeshMotions}(y\_ED)
54:
        u\_FEAM \leftarrow TRANSFERMESHMOTIONS(y\_ED)
55:
        u\_IceF \leftarrow TransferMeshMotions(y\_SD)
56:
57:
        u\_IceD(:) \leftarrow TransferMeshMotions(y\_SD)
        u\_SlD \leftarrow \text{TransferMeshPosition}(y\_SD)
59: end procedure
```

SoilDyn The motion inputs to SoilDyn are the position and orientation of the mesh points. The SoilDyn module expects changes in position to be in the order

of 10^{-3} m, or angular changes of 10^{-4} radians or less throughout the duration of the simulation with response terms on the order of 10^{12} N/m (or N-m/radians). To simplify the mathematics in the Jacobian, an Euler angle extraction is performed to get rotations about the x, y, and z axis (the angles are small enough that order does not matter in this context). So the u input vector for SoilDynis a 6-vector for each mesh point. The resulting reaction forces from SoilDyn are roughly characterized as $F_{\text{react}} \approx kx$ where k is a stiffness matrix and x is the 6-vector of translational and rotational displacements (note that there may be some damping or drift terms, but of much lower magnitude). This creates a situation where $u_SD \leftarrow y_SlD \leftarrow y_SD$ is a feed back loop of SubDyn node displacements (stored in states) of a given mesh point directly through SoilDyn to the input force on that node point. Without including this calculation in the Jacobian, the accelerations of the SubDyn nodes will be missing the reaction force and likely cause non-convergence or large oscillations. For this reason we include the SoilDyn input / output into the Jacobian. However this does cause some of the Jacobian to differ by as many as six orders of magnitude, which is numerically non-ideal for the solve.

3.3 Implementation of line2-to-line2 loads mapping

The inverse-lumping of loads is computed by a block matrix solve for the distributed forces and moments, using the following equation:

Because the forces do not depend on the moments, we first solve for the distributed forces, F^D :

$$\left[F^{DL}\right] = \left[A\right]\left[F^{D}\right] \tag{2}$$

We then use the known values to solve for the distributed moments, M^D :

$$\begin{bmatrix} M^{DL} \end{bmatrix} = \begin{bmatrix} B & A \end{bmatrix} \begin{bmatrix} F^D \\ M^D \end{bmatrix} = [B] [F^D] + [A] [M^D]$$
 (3)

or

$$\left[M^{DL}\right] - \left[B\right] \left[F^{D}\right] = \left[A\right] \left[M^{D}\right] \tag{4}$$

Rather than store the matrix B, we directly perform the cross products that the matrix B represents. This makes the left-hand side of Equation 4 known, leaving us with one matrix solve. This solve uses the same matrix A used to obtain the distributed forces in Equation 2; A depends only on element reference positions and connectivity. We use the LU factorization of matrix A so that the second solve does not introduce much additional overhead.

4 Solve Option 2 Improvements

4.1 Input-Output Solves inside AdvanceStates

This algorithm documents the procedure for advancing states with option 2 Input-Output solves in FAST, assuming all modules are in use. If an individual module is not in use during a particular simulation, the calls to that module's subroutines are omitted and the module's inputs and outputs are neither set nor used.

```
1: procedure FAST_ADVANCESTATES()
       ED_UPDATESTATES(p\_ED, u\_ED, x\_ED, xd\_ED, z\_ED)
 2:
       y\_ED \leftarrow \text{ED\_CALCOUTPUT}(p\_ED, u\_ED, x\_ED, xd\_ED, z\_ED)
 3:
 4:
       u\_BD(hub and root motions) \leftarrow TRANSFEROUTPUTSTOINPUTS(y\_ED)
 5:
 6:
       BD_UPDATESTATES(p\_BD, u\_BD, x\_BD, xd\_BD, z\_BD)
       y\_BD \leftarrow \text{BD\_CALCOUTPUT}(p\_BD, u\_BD, x\_BD, xd\_BD, z\_BD)
 7:
 8:
       u\_AD(not InflowWind) \leftarrow TransferOutputsToInputs(y\_ED, y\_BD)
 9:
       u\_IfW \leftarrow \text{TransferOutputsToInputs}(y\_ED, y\_BD \text{ at } u\_AD \text{ nodes})
10:
11:
       IFW_UPDATESTATES(p\_IfW, u\_IfW, x\_IfW, xd\_IfW, z\_IfW)
12:
       y\_IfW \leftarrow IfW\_CALCOUTPUT(u\_IfW \text{ and other } IfW \text{ data structures})
13:
       u\_AD(InflowWind only) \leftarrow TransferOutputsToInputs(y\_IfW)
14:
       u\_SrvD \leftarrow \text{TransferOutputsToInputs}(y\_ED, y\_BD, y\_IfW)
15:
       AD\_UPDATESTATES(p\_AD, u\_AD, x\_AD, xd\_AD, z\_AD)
16:
       SRVD\_UPDATESTATES(p\_SrvD, u\_SrvD, x\_SrvD, xd\_SrvD, z\_SrvD)
17:
18:
       All other modules (used in Solve Option 1) advance their states
19:
20: end procedure
```

Note that AeroDyn and ServoDyn outputs get calculated inside the $CalcOutputs_And_SolveForInputs$ routine. ElastoDyn, BeamDyn, and InflowWind outputs do not get recalculated in $CalcOutputs_And_SolveForInputs$ except for the first time the routine is called (because CalcOutput is called before UpdateStates at time 0).

5 Linearization

5.1 Loads Transfer

The loads transfer can be broken down into four components, all of which are used in the Line2-to-Line2 loads transfer:

- 1. Augment the source mesh with additional nodes.
- 2. Lump the distributed loads on the augmented Line2 source mesh to a Point mesh.
- 3. Perform Point-to-Point loads transfer.

4. Distribute (or "unlump") the point loads.

The other loads transfers are just subsets of the Line2-to-Line2 transfer:

- Line2-to-Line2: Perform steps 1, 2, 3, and 4.
- Line2-to-Point: Perform steps 1, 2, and 3.
- Point-to-Line2: Perform steps 3 and 4.
- Point-to-Point: Perform step 3.

Each of the four steps can be represented with a linear equation. The linearization of the loads transfers is just multiplying the appropriate matrices generated in each of the steps.

5.1.1 Step 1: Augment the source mesh

The equation that linearizes mesh augmentation is

$$\left\{ \begin{array}{l} \vec{u}^D \\ \vec{u}^{SA} \\ \vec{f}^{SA} \\ \vec{m}^{SA} \end{array} \right\} = \begin{bmatrix} I_{N_D} & 0 & 0 & 0 \\ 0 & M^A & 0 & 0 \\ 0 & 0 & M^A & 0 \\ 0 & 0 & 0 & M^A \end{bmatrix} \left\{ \begin{array}{l} \vec{u}^D \\ \vec{u}^S \\ \vec{f}^S \\ \vec{m}^S \end{array} \right\}$$
(5)

where $M^A \in \mathbb{R}^{N_{SA},N_S}$ indicates the mapping of nodes from the source mesh (with N_S nodes) to the augmented source mesh (with N_{SA} nodes). The destination mesh (with N_D nodes) is unchanged, as is indicated by matrix I_{N_D} .

5.1.2 Step 2: Lump loads on a Line2 mesh to a Point mesh

The equation that linearizes the lumping of loads is

where $M_{li}^{SL}, M_{uS}^{SL}, M_f^{SL} \in \mathbb{R}^{N_{SA},N_{SA}}$ are block matrices that indicate the mapping of the lumped values to distributed values. M_{li}^{SL} is matrix A in Equation 2, which depends only on element reference positions and connectivity. Matrices M_{uS}^{SL} and M_f^{SL} also depend on values at their operating point.

5.1.3 Step 3: Perform Point-to-Point loads transfer

The equation that performs Point-to-Point load transfer can be written as

where $M_{li}^D, M_{uS}^D, M_f^D \in \mathbb{R}^{N_D,N_S}$ are block matrices that indicate the transfer of loads from one source node to a node on the destination mesh. $M_{uD}^D \in \mathbb{R}^{N_D,N_D}$ is a diagonal matrix that indicates how the destination mesh's displaced position effects the transfer.

5.1.4 Step 4: Distribute Point loads to a Line2 mesh

Distributing loads from a Point mesh to a Line2 mesh is the inverse of step 2. From Equation 6 the equation that linearizes the lumping of loads on a destination mesh is

$$\left\{ \begin{array}{l} \vec{u}^{D} \\ \vec{F}^{D} \\ \vec{M}^{D} \end{array} \right\} = \begin{bmatrix} I_{N_{D}} & 0 & 0 \\ 0 & M_{li}^{DL} & 0 \\ M_{uD}^{DL} & M_{f}^{DL} & M_{li}^{DL} \end{bmatrix} \left\{ \begin{array}{l} \vec{u}^{D} \\ \vec{f}^{D} \\ \vec{m}^{D} \end{array} \right\}$$
(8)

where $M_{li}^{DL}, M_{uD}^{DL}, M_f^{DL} \in \mathbb{R}^{N_D,N_D}$ are block matrices that indicate the mapping of the lumped values to distributed values. It follows that the inverse of this equation is

$$\left\{ \vec{f}^{D}_{\vec{I}} \right\} = \begin{bmatrix} I_{N_{D}} & 0 & 0 \\ 0 & [M_{li}^{DL}]^{-1} & 0 \\ -[M_{li}^{DL}]^{-1} M_{uD}^{DL} & -[M_{li}^{DL}]^{-1} M_{f}^{DL} [M_{li}^{DL}]^{-1} & [M_{li}^{DL}]^{-1} \end{bmatrix} \left\{ \vec{r}^{D}_{\vec{I}} \right\}$$

$$\left\{ \vec{f}^{D}_{\vec{I}} \right\}$$

The only inverse we need is already formed (stored as an LU decomposition) from the loads transfer, so we need not form it again.

5.1.5 Putting it together

To form the matrices for loads transfers for the various mappings available, we now need to multiply a few matrices to return the linearization matrix that converts loads from the source mesh to loads on the line mesh:

• Line2-to-Line2: Perform steps 1, 2, 3, and 4.

$$\begin{cases} \vec{f}^{D} \\ \vec{m}^{D} \end{cases} = \begin{bmatrix} 0 & \left[M_{li}^{DL} \right]^{-1} & 0 \\ -\left[M_{li}^{DL} \right]^{-1} M_{uD}^{DL} & -\left[M_{li}^{DL} \right]^{-1} M_{f}^{DL} \left[M_{li}^{DL} \right]^{-1} & \left[M_{li}^{DL} \right]^{-1} \end{bmatrix}$$

$$\begin{bmatrix} I_{N_{D}} & 0 & 0 & 0 \\ 0 & 0 & M_{li}^{D} & 0 \\ 0 & 0 & M_{li}^{D} & 0 \end{bmatrix} \begin{bmatrix} I_{N_{D}} & 0 & 0 & 0 \\ 0 & I_{N_{SA}} & 0 & 0 \\ 0 & 0 & M_{li}^{SL} & 0 \\ 0 & 0 & M_{li}^{SL} & 0 \end{bmatrix}$$

$$\begin{bmatrix} I_{N_{D}} & 0 & 0 & 0 \\ 0 & M_{uS}^{SL} & M_{f}^{SL} & M_{li}^{SL} \end{bmatrix}$$

$$\begin{bmatrix} I_{N_{D}} & 0 & 0 & 0 \\ 0 & M^{A} & 0 & 0 \\ 0 & 0 & M^{A} & 0 \\ 0 & 0 & 0 & M^{A} \end{bmatrix} \begin{cases} \vec{u}^{D} \\ \vec{v}^{S} \\ \vec{m}^{S} \end{cases}$$

$$(11)$$

$$M_{li} = (M_{li}^{DL})^{-1} M_{li}^{D} M_{li}^{SL} M_A \tag{12}$$

$$M_{uD} = (M_{li}^{DL})^{-1} [M_{uD}^{D} - M_{uD}^{DL}]$$
(13)

$$M_{uS} = (M_{li}^{DL})^{-1} \left[M_{uS}^D + M_{li}^D M_{uS}^{SL} \right] M_A \tag{14}$$

$$M_{f} = \left(M_{li}^{DL}\right)^{-1} \left(\left[M_{f}^{D} - M_{f}^{DL} \left(M_{li}^{DL}\right)^{-1} M_{li}^{D}\right] M_{li}^{SL} + M_{li}^{D} M_{f}^{SL} \right) M_{A}$$
(15)

• Line2-to-Point: Perform steps 1, 2, and 3.

$$\begin{cases}
\vec{F}^{D} \\
\vec{M}^{D}
\end{cases} = \begin{bmatrix}
0 & 0 & M_{li}^{D} & 0 \\
M_{uD}^{D} & M_{uS}^{D} & M_{f}^{D} & M_{li}^{D}
\end{bmatrix} \begin{bmatrix}
I_{N_{D}} & 0 & 0 & 0 & 0 \\
0 & I_{N_{SA}} & 0 & 0 & 0 \\
0 & 0 & M_{li}^{SL} & 0 & 0 \\
0 & M_{uS}^{SL} & M_{f}^{SL} & M_{li}^{SL}
\end{bmatrix} \\
\begin{bmatrix}
I_{N_{D}} & 0 & 0 & 0 & 0 \\
0 & M^{A} & 0 & 0 & 0 \\
0 & 0 & M^{A} & 0 & 0 \\
0 & 0 & 0 & M^{A}
\end{bmatrix} \begin{pmatrix}
\vec{u}^{D} \\
\vec{u}^{S} \\
\vec{f}^{S} \\
\vec{m}^{S}
\end{cases} (16)$$

The linearization routine returns these four matrices:

$$M_{li} = M_{li}^D M_{li}^{SL} M_A \tag{17}$$

$$M_{uD} = M_{uD}^D (18)$$

$$M_{uS} = \left[M_{uS}^D + M_{li}^D M_{uS}^{SL} \right] M_A \tag{19}$$

$$M_f = \left[M_f^D M_{li}^{SL} + M_{li}^D M_f^{SL} \right] M_A \tag{20}$$

• Point-to-Line2: Perform steps 3 and 4.

$$\begin{cases} \vec{f}^D \\ \vec{m}^D \end{cases} = \begin{bmatrix} 0 & \left[M_{li}^{DL} \right]^{-1} & 0 \\ -\left[M_{li}^{DL} \right]^{-1} M_{uD}^{DL} & -\left[M_{li}^{DL} \right]^{-1} M_f^{DL} \left[M_{li}^{DL} \right]^{-1} & \left[M_{li}^{DL} \right]^{-1} \end{bmatrix}$$

$$\begin{bmatrix} I_{N_D} & 0 & 0 & 0 \\ 0 & 0 & M_{li}^D & 0 \\ M_{uD}^D & M_{uS}^D & M_f^D & M_{li}^D \end{bmatrix} \begin{cases} \vec{u}^D \\ \vec{u}^S \\ \vec{F}^S \\ \vec{M}^S \end{cases}$$
 (21)

The linearization routine returns these four matrices:

$$M_{li} = (M_{li}^{DL})^{-1} M_{li}^{D} (22)$$

$$M_{uD} = (M_{li}^{DL})^{-1} [M_{uD}^{D} - M_{uD}^{DL}]$$
 (23)

$$M_{uS} = \left(M_{li}^{DL}\right)^{-1} M_{uS}^{D} \tag{24}$$

$$M_f = (M_{li}^{DL})^{-1} [M_f^D - M_f^{DL} M_{li}]$$
 (25)

• Point-to-Point: Perform step 3.

The linearization routine returns these four matrices:

$$M_{li} = M_{li}^D \tag{27}$$

$$M_{uD} = M_{uD}^D \tag{28}$$

$$M_{uS} = M_{uS}^D \tag{29}$$

$$M_f = M_f^D (30)$$