# Lua for RePhone (Xadow GSM+BLE)

## **Programming Manual**



Ver.: LuaRephone 0.9.3 Beta LoBo 07/2016

## table of contents

table of contents	
os module	3
copy(from_file, to_file)	3
mkdir(name)	3
rmdir(name)	3
exists(name)	3
list(filespec)	3
compile(name)	4
sys module	5
sys.ver()	5
mem()	5
battery()	5
ledblink([led_id])	5
usb()	6
wdg([wdg_tmo])	6
noacttime([noact_tmo])	6
shutdown()shutdown()	6
reboot()	7
wkupint([wkup_int])	7
schedule(val)	7
onshutdown(cb_func)	7
onreboot(cb_func)	8
onalarm(cb_func)	8
onkey(cb_func)	8
retarget(stdio_id)	8
gpio module	10
mode(pin, mode)	11
write(pin, level)	11
toggle(pin)	
read(pin)	11
pwm_start(pin)	11
pwm_stop(pin)	12
pwm_clock(pin, clksrc, div)	12
pwm_count(pin, count, tresh)	12
pwm_freq(pin, freq, duty)	12
eint_open(pin, [tpar])	13
eint_close(pin)	13
eint_mask(pin, mask)	13
eint_on(cb_func)	14
adc_config(chan, [period, count])	14
adc_start(chan, [repeat], [cb_func])	14
adc_stop(chan)	15
i2c module	
setup(addr [,speed])	
write(data1 [,data2] [,dataN])	16
read(size [,format])	
txrx(data1 [,data2] [,dataN], size [,format])	
close()	17
spi module	

setup([config])	
write(data1 [,data2] [,dataN])	18
read(size [,format])	18
txrx(data1 [,data2] [,dataN], size [,format])	19
close()	
net module	
tcp_create(host, port, cb_func, [data])	
tcp_connect(tcp_ref, host, port, [data])	
tcp write(tcp ref, data)	
tcp_read(tcp_ref, size)	
udp_create(port, cb_func)	
udp_write(udp_ref, host, port, data)	
udp_read(udp_ref, size)udp_read(udp_ref, size)	
close(ref)	
ntptime(tz, [cb_func])	
setapn(ref)	
https module	
get(url)	
post(url)	
on(method [,cb_func])	
cancel()	
email module	
send(param)	
ftp module	
connect(param)	
disconnect()	
list(file [,option])	
recv(remote_file [,local_file])	28
send(file_name [,remote_file] [,"*append"])	
chdir(remote_dir)	
getdir(remote_dir)	
mqtt module	30
create(config)	
connect(mqtt_id [,check_int] [,ka_int])	
disconnect(mqtt_id)	30
addtopic(mqtt_id, topic [,qos])	31
subscribe(mqtt_id)	
unsubscribe(mqtt_id [,topic])	31
publish(mqtt_id, topic, message [,qos])	31
sms module	
send(num, msg [,cb_func])	33
numrec([box_type])	
list([msg_state] [cb_func])	
read(msg_id [,cb_func])	
delete(msg_id [,cb_func])	
onmessage([cb_func])	
sim info()	
timer module	
create(interval, cb_func)	
delete(timer id)	
pause(timer_id)	
resume(timer id)	
changecb(timer_id, cb_func)	
	·············

## **OS** module

All standard Lua os module functions are supported and some additional functions are added:

### copy(from\_file, to\_file)

#### res = os.copy(from\_file, to\_file)

Copy file "from\_file" to "to\_file". If the destination file exists, it will be overwritten.

Params:

from file: string, file name

to\_file: string, name of the new file

Returns:

res: 0 on success, error code otherwise

#### mkdir(name)

## res = os.mkdir(name)

Create new directory.

Params:

name: string, new directory name

Returns:

res: 0 on success, error code otherwise

#### rmdir(name)

#### res = os.rmdir(name)

Remove existing directory.

Params:

name: string, directory name

Returns:

res: 0 on success, error code otherwise

#### exists(name)

#### res = os.exists(name)

Check if the file exists.

Params:

name: string, file name

Returns:

res: 0 if file exists, error code otherwise

## list(filespec)

#### os.list(filespec)

List content of the file system directory to stdio

optional; string, file specification, can contain dir names and wildchars filespec:

("MRE\\\*.vxp")

Returns:

None

## compile(name)

## os.compile(name)

Compile lua source file to bytecode file. Creates ".lc" file with the same base name as lua source file

Params:

string, lua source file name, must have ".lua" extension name:

Returns: none

## **SYS** module

#### Functions specific to RePhone/Xadow GSM+BLE.

#### sys.ver()

### lv, fh, bd = sys.ver()

Returns version information.

Params: none Returns:

lv string, lua version

fh string, firmware host version bd string, firmware build date

#### mem()

#### lua\_used, lua\_total, c\_heap = sys.mem()

Returns memory information.

Params: none Returns:

lua\_used currently used memory for Lua stack in bytes lua\_total total memory available for Lua stack in bytes c\_heap total heap size available for C functions in bytes

## battery()

### bat = sys.battery()

Returns battery level in %. ADC module can be used to get precise battery voltage.

Params: none Returns:

bat battery level in % of full charge

## ledblink([led\_id])

#### led = sys.ledblink([led\_id])

Set or get current system LED blink. System LED blinks once per second. Any of the RGB leds can be selected.

led id optional; LED gpio pin,

predefined constants REDLED, BLUELED, GREENLED can be used

Value 0 can be used to disable LED blink Without parameter returns current led used.

Returns:

led currently used LED

#### usb()

#### res = sys.usb()

Returns the USB cable status, connected or not.

Params: none Returns:

res USB cable status: 0 not connected; 1 connected

## wdg([wdg\_tmo])

#### res = sys.wdg([wdg\_tmo])

Set or get watchdog timeout.

Watchdog timer can be set to the values  $10 \sim 3600$  seconds. After setting the new value, system must be rebooted to take effect. If called without parameters, the current wdg timeout is returned.

Params:

wdg\_tmo optional; watchdog timeout in seconds

Returns:

res current or new watchdog timeout in seconds

## noacttime([noact\_tmo])

## res = sys.noacttime([noact\_tmo])

Set, reset or get no activity timeout.

If no activity is detected in Lua shell (no user input), the system is shutdown after no activity timer expires.

If called without parameters, the current no activity timeout is returned.

Params:

noact\_tmo optional; > 0 set no activity timeout in seconds

0 reset no activity timeout

no parameter: return current value

Returns:

res current or new no activity timeout in seconds

## shutdown()

#### sys.shutdown()

Shutdown system.

If wakeup interval is defined, system wakeup will be automatically scheduled to next interaval.

Warning: if USB is connected, the system will automatically reboot after shutdown!

Params: none

Returns:

none

#### reboot()

#### sys.reboot()

Reboot system.

In Lua shell Ctrl+D can be also used to reboot.

Short pres on power button can be also used to reboot.

Params:

none

Returns:

none

## wkupint([wkup\_int])

### res = sys.wkupint([wkup\_int])

Set or get wakeup interval.

Wake up interval can be set to enable automatic wakeup in regular intervals.

Params:

wkup int optional; wakeup interval in minutes (values > 0 are accepted)

no parameter: return current value

Returns:

res current or new wakeup interval in minutes

## schedule(val)

#### sys.schedule(val)

Schedule next wakeup or alarm.

Params:

val wakeup or alarm time

0: wakeup or alarm on next wakeup interval> 0 wakeup or alarm after 'val' seconds

table wakeup or alarm on specific time, table format:

{year=yyyy, month=mm, day=dd, hour=hh, min=mn, sec=ss}

Returns:

none (logs info if enabled)

#### onshutdown(cb\_func)

## sys.onshutdown(cb\_func)

Set callback function to be executed before shutdown. If called without parameter, disables the callback.

cb func lua function to be executed on shutdown, prototype

function cb\_func(res)

res integer, shutdown reason

Returns:

none

#### onreboot(cb\_func)

## sys.onreboot(cb\_func)

Set callback function to be executed before reboot.

If called without parameter, disables the callback.

Params:

cb func lua function to be executed on reboot, prototype

function cb\_func(res)

res integer, reboot reason

Returns:

none

### onalarm(cb\_func)

#### sys.onalarm(cb\_func)

Set callback function to be executed on RTC alarm. If called without parameter, disables the callback.

Params:

cb\_func lua function to be executed on RTC alarm, prototype

function cb func(res)

res integer, always 0

Returns:

none

## onkey(cb\_func)

#### sys.onkey(cb\_func)

Set callback function to be executed on powr ker UP or DOWN.

If called without parameter, disables the callback.

Warning: LONG press (> 2 sec) will shutdown/reboot the system!

Params:

cb\_func lua function to be executed on power key up/down, prototype

function cb func(res)

res integer; 1: key UP, 2: key down

Returns:

none

## retarget(stdio\_id)

#### sys.retarget(stdio\_id)

Change stdio (input/output device). All input and output will be redirected to the new device.

stdio\_id id of the new device

- redirect to **usb serial port** ( /dev/ttyACM0 on Linux )
  redirect to **hw UART port**redirect to **bluetooth SPP** (must be configured)
- 2

Returns:

none

## gpio module

GPI0	Function in gpio module	Voltage (V)	Connector			
			11	35	6(0.1")	Breakout
0	IO, EINTO, UART3_RX (*)	2.8	-	-	-	-
1	IO, EINT1, ADC13, UART3_TX, CTP_SCL	2.8		3		D1
2	IO, EINT2, PWMO, ADC11, CTP_SDA	2.8		2		E2
3	IO, PWM1, ADC12	2.8		5		B1
18	IO, EINT13	2.8, 3.3	5,7		4	
13	IO, EINT11, PWM0	2.8, 3.3	6		5	
46	IO, EINT20	1.8		1		D6
30	IO, EINT16	2.8		25		
27	IO, SPI_SCK	2.8		4		C1
28	IO, SPI_MOSI	2.8		8		E2
29	IO, SPI_MISO	2.8		7		A1
43	IO, I2C_SCL	2.8, 3.3	3,9	30	2	B6
44	IO, I2C_SDA	2.8, 3.3	4,8	32	1	B5
10	IO, UART1_Rx	2.8		33		A5
11	IO, UART1_TX	2.8		34		A6
17	IO, RED LED	2.8				
15	IO, GREEN LED	2.8				
12	IO, BLUE LED	2.8				
19	IO, PWM1	2.8		31		D5
47	IO, TFT LSCK0	1.8		19		D4
48	IO, TFT LSDA0	1.8		21		B4
49	IO, TFT LSA0	1.8		22		A4
50	IO, TFT LPTE, EINT22	1.8		20		C4
25	IO, EINT15	2.8		35		

<sup>(\*)</sup> ADC, Battery voltage

#### mode(pin, mode)

#### gpio.mode(pin, mode)

Set the operating mode for selected GPIO pin.

Params:

pin: GPIO pin number, see GPIO table for available pins

mode: pin mode, use global constants:

INPUT, OUTPUT, INPUT PULLUP, INPUT PULLDOWN

Returns:

none, error if not valid pin or mode

## write(pin, level)

#### gpio.write(pin, level)

Set the pin output to HIGH (1) or LOW (0). Pin mode must be set to output.

Params:

pin: GPIO pin number, see GPIO table for available pins level: pin level, use global constants: HIGH or LOW

Returns:

none, error if not valid pin or mode

#### toggle(pin)

#### gpio.toggle(pin)

Toggle the pin output HIGH -> LOW or LOW -> HIGH. Pin mode must be set to output.

Params:

pin: GPIO pin number, see GPIO table for available pins

Returns:

none, error if not valid pin or mode

### read(pin)

## state = gpio.read(pin)

Set the pin output to HIGH (1) or LOW (0). Pin mode must be set to output.

Params:

pin: GPIO pin number, see GPIO table for available pins

Returns:

state: pin state: 0 or 1

error if not valid pin or mode

## pwm\_start(pin)

## gpio.pwm\_start(pin)

#### Configure selected GPIO pin for PWM operation.

Params:

pin: GPIO pin number, see GPIO table for available pins

Returns:

none, error if PWM mode not available on pin

## pwm\_stop(pin)

#### gpio.pwm\_stop(pin)

Stop PWM on selected pin.

Params:

pin: GPIO pin number, see GPIO table for available pins

Returns:

none, error if pin not opened for PWM

#### pwm\_clock(pin, clksrc, div)

#### gpio.pwm\_clock(pin, clksrc, div)

Set the main PWM clock source.

Main PWM clock (pwm\_clk) is set to 13000000 / div or 32768 / div!!

Params:

pin: GPIO pin number, see GPIO table for available pins clksrc: PWM clock source: 0 -> 13MHz; 1 -> 32.768 kHz

div: division 0->1, 1->2, 2->4, 3->8

Returns:

none, error if pin not opened for PWM

#### pwm\_count(pin, count, tresh)

#### gpio.pwm\_count(pin, count, tresh)

Set PWM in count mode.

PWM FREQUENCY is: pwm\_clk / count

Params:

pin: GPIO pin number, see GPIO table for available pins

count: the <u>pwm</u> cycle: 0 ~ 8191

tresh: treshold: value at which pwm gpio goes to LOW state: 0 ~ count

Returns:

none, error if pin not opened for PWM

#### pwm\_freq(pin, freq, duty)

## gpio.pwm\_freq(pin, freq, duty)

Set PWM in frequency mode. PWM FREQUENCY is: freq

pin: GPIO pin number, see GPIO table for available pins

freq: the pwm frequency in Hz: 0 ~ pwm clk

duty: PWM duty cycle: 0 ~ 100

Returns:

none, error if pin not opened for PWM

#### eint\_open(pin, [tpar])

#### res = gpio.eint\_open(pin, [tpar])

Configure selected GPIO pin for external interrupt (EINT) operation.

Not all parameters have to be present in tpar, is some parameter is missing, default value is used.

Note: use gpio.mode() to configure the pin as input and if pullup/pulldown is used.

Params:

pin: GPIO pin number, see GPIO table for available pins

tpar: optional; Lua table with eint parametersmode(pin, mode)

autounmask: 1: unmask after callback; default 0

autopol: 1: auto change polarity after callback; default 0
 sensitivity: 0: level sesitive; 1: edge sensitive; default 1
 polarity: 0: high->low trigger; 1: low->high trigger; default 0
 deboun: 1: enable HW debounce, 0: disable it; default 1

debountime: HW debounce time in msec: default 10

count: if >0, callback function will be executed after 'count' interrupts

Returns:

res: 0 if OK, negative number on error

#### eint\_close(pin)

#### res = gpio.eint\_close(pin)

Close selected GPIO pin as external interrupt (EINT) pin.

Params:

pin: GPIO pin number, see GPIO table for available pins

Returns:

res: 0 if OK, negative number on error

#### eint\_mask(pin, mask)

#### res = gpio.eint\_mask(pin, mask)

Mask selected GPIO pin EINT.

If autounmask option is not set, next interrupt must be enabled in callback function.

pin: GPIO pin number, see GPIO table for available pins

mask: 0: mask (disable) EINT operation; 1: unmask (enable) EINT operation

Returns:

res: mask value if OK, negative number on error

#### eint\_on(cb\_func)

#### gpio.eint\_on(cb\_func)

Set Lua callback function to be executed on external interrupt (EINT).

If called without parameter, disables the callback.

Params:

cb func lua function to be executed on EINT, prototype

function cb\_func(pin, value, count, time)

pin integer, pin number on which interrupt occurred

value pin level

count total number of interrupts

time

Returns:

none

## adc\_config(chan, [period, count])

#### res = gpio.adc\_config(chan, [period, count])

Configure selected ADC channel pin for ADC operation.

ADC channel must be configured before start function can be used.

Available channels are:

0: Battery voltage

1: ADC value on GPIO-1 (ADC15)

2: ADC value on GPIO-2 (ADC13)

ADC value on GPIO-3

Params:

chan: adc channel

period: optional; measurement period in msec; default 5 msec

Count: optional; how many measurement to take before issuing the result,

time between measurements is 'period'; default 1

time between results is 'period' \* 'count'

Returns:

res: 0 if OK, negative number if error

## adc\_start(chan, [repeat], [cb\_func])

## res = gpio.adc\_start(chan, [repeat], [cb\_func])

Start ADC measurement on selected channel and return result if no callback function is given..

chan: adc channel configured with gpio.adc\_configure repeat: optional; repeat the measurement 'repeat' times;

1: measure only once

>1000: continuous measurement

default 1; only valid when callback function is given

cb\_func: optional; Lua callback function to be executed on adc result

function cb\_func(ival, fval, chan)
ival integer ADC value
fval float ADC result

chan channel on which the measurement is taken

Returns:

res: negative number if error

float ADC result if no callback function is given in V

0 if callback function given and no error

#### adc\_stop(chan)

#### res = gpio.adc\_stop(chan)

Stop ADC measurement on selected channel if the channel was configured for continuous/repeat measurement.

Params:

chan: adc channel configured with gpio.adc\_configure

Returns:

Res:0 if ok, negative number if error

2 channel was not configured for repeat measurement

## i2c module

I2c supports hardware i2c on GPIO43&GPIO44.

3.3V interface is available on 0.1" pins and 11pin connector with pullup resistors (10K) included. On 35pin connector, the pins are 2.8V and pullup resistors must be externally provided.

#### setup(addr [,speed])

#### speed = i2c.setup(addr [,speed])

Configures i2c interface. Slave address is 7-bit.

Fast mode or high speed mode is automatically selected based on 'speed' argument. For speed <= 400 fast mode is selected, for speed > 400 high speed mode is selected. Maximum speed is 6500 kHz, minimum 12 kHz.

Params:

addr: slave device 7-bit address

speed: optional; transfer speed i kHz, 12~6500; default 100

Returns:

speed: actual transfer speed, negative number on error

#### write(data1 [,data2] [,dataN])

#### res = i2c.write(data1 [,data1] [,dataN])

Send data to i2c slave.

Data can be given as 8-bit number, table of 8-bit numbers or string. Up to 10K bytes can be sent at once.

Params:

data: data to be sent to i2c device; number, lua table or lua string

Returns:

res: number of bytes sent to device, negative number on error

## read(size [,format])

#### res = i2c.read(size [,format])

Receive data from i2c slave.

Data can be received to lua string, string of hex values or lua table. Up to 10K bytes can be received at once.

size: number of bytes to receive, 1 ~ 10240

format: optional; if not given, data are received to lua string

"\*h"receive to string of hex values separated by ";"

"\*t" receive to lua table

Returns:

res: lua string or lua table containing received data

nil on error

#### txrx(data1 [,data2] [,dataN], size [,format])

### res = i2c.txrx(data1 [,data1] [,dataN], size [,format])

Send data to i2c slave and receive data.

Data can be given as 8-bit number, table of 8-bit numbers or string. Maximum of 8 bytes can be sent, up to 10240 bytes can be received.

Params:

data: data to be sent to i2c device; number, lua table or lua string, max 8 bytes

size: number of bytes to receive, 1 ~ 10240

format: optional; if not given, data are received to lua string

"\*h"receive to string of hex values separated by ";"

"\*t" receive to lua table

Returns:

res: lua string or lua table containing received data

nil on error

#### close()

#### res = i2c.close()

Close i2c interface.

Params:

nil

Returns:

res: status; 0 if OK, negative number on error

## Spi module

spi module supports hardware spi on GPIO27-29.

SPI pins are available only on 35pin connector (or expansion board) as 2.8V interface.

Use level shifters if connecting to higher voltage device!

CS output pin can be defined in setup, if defined it is automatically activated during the transfer.

Additional output pin (DC) can also be defined. If defined, its state (defined by *setdc()* function) is set before transfer.

## setup([config])

#### res = spi.setup([config])

Configures SPI interface.

Configuration options are given in form of lua table.

#### Params:

```
config: lua table containing configuration options in form option=value
```

mode spi transfer mode, 0 ~ 3; default 0 endian endianess; 0: little; 1: big; default 0

msbbit transfer mode; 0: send LSB first; 1: send MSB first; default 1

speed SPI transfer speed in kHz; 86 ~ 22000; default 4400 CS (chip sellect) output gpio pin; default: not used

dc DC output gpio pin; default: not used

#### Returns:

res: result: 0 if OK, negative number on error

#### write(data1 [,data2] [,dataN])

#### res = spi.write(data1 [,data1] [,dataN])

Send data to SPI device.

Data can be given as 8-bit number, table of 8-bit numbers or string.

#### Params:

data: data to be sent to spi device; number, lua table or lua string

Returns:

res: number of bytes sent to device, negative number on error

## read(size [,format])

#### res = spi.read(size [,format])

Receive data from SPI slave.

Data can be received to lua string, string of hex values or lua table.

size: number of bytes to receive, 1 ~ 10240

format: optional; if not given, data are received to lua string

"\*h"receive to string of hex values separated by ";"

"\*t" receive to lua table

Returns:

res: lua string or lua table containing received data

nil on error

#### txrx(data1 [,data2] [,dataN], size [,format])

#### res = spi.txrx(data1 [,data1] [,dataN], size [,format])

Send data to SPI slave then receive data in same transaction. Data can be given as 8-bit number, table of 8-bit numbers or string.

Params:

data: data to be sent to SPI device; number, lua table or lua string

size: number of bytes to receive

format: optional; if not given, data are received to lua string

"\*h" receive to string of hex values separated by ";"

"\*t" receive to lua table

Returns:

res: lua string or lua table containing received data

nil on error

#### close()

#### res = spi.close()

Close SPI interface.

Params:

nil

Returns:

res: status; 0 if OK, negative number on error

## net module

To get the status of the UDP or TCP connection execute print(ref).

To enable garbage collector to free the data used by the connection, execute **ref=nil**. ref is the reference to tcp or udp connection obtained by tcp\_create or udp\_create function. GPRS must be configured with setapn() function before using any of net functions.

#### tcp\_create(host, port, cb\_func, [data])

#### Tcp\_ref = net.tcp\_create(host, port, cb\_func, [data])

Creates TCP connection and connects to 'host' on 'port'.

'host' can be IP address or domain name.

If string 'data' is given, it will be sent to host after connection.

Params:

host: host IP or domain name

port: integer, tcp port to connect to (1 ~ 65535)

cb\_func:Lua callback function, prototype:

function cb\_func(tcp\_ref, event)
tcp\_ref tcp\_connection

event tcp event which caused the call:

1: tcp is connected, can send data

2: more date can be sent

3: data ready for read

4: pipe broken, disconnected

5: host not found, not connected

6: connection closed

data: optional; string data to send after connection

Returns:

tcp\_ref: reference to tcp connection to be used in other function

## tcp\_connect(tcp\_ref, host, port, [data])

## res = net.tcp\_connect(tcp\_ref, host, port, [data])

Connects to already created tcp connection. If tcp connection is connected, it is disconnected first. 'host' can be IP address or domain name.

If string 'data' is given, it will be sent to host after connection.

Params:

tcp\_ref: tcp reference obtained with *net.tcp\_create()* 

host: host IP or domain name

port: integer, tcp port to connect to (1 ~ 65535) data: optional; string data to send after connection

Returns:

res: 0 if OK, negative number if error

### tcp\_write(tcp\_ref, data)

#### res = net.tcp\_write(tcp\_ref, data)

Send data to tcp connection. Tcp connection must in connected state.

tcp\_ref: tcp reference obtained with net.tcp\_create()

data: string data to send

Returns:

res: 0 if OK, negative number if error

#### tcp\_read(tcp\_ref, size)

#### res, data = net.tcp\_read(tcp\_ref, size)

Read data from tcp connection.

This function can be used from callback function on read event.

Params:

tcp ref: tcp reference obtained with net.tcp create()

size: maximum size of data to read

Returns:

res: size or read data, negative number if error

data: string, read data; nil if error

#### udp\_create(port, cb\_func)

#### udp ref = net.udp create(port, cb func)

Creates UDP connection on local port 'port'. No connection is made.

Params:

port: integer, local port (1 ~ 65535) cb\_func:Lua callback function, prototype:

function cb\_func(udp\_ref, event)
udp\_ref\_\_udp\_connection

event udp event which caused the call:

2: more date can be sent3: data ready for read4: pipe broken, disconnected

6: connection closed

data: optional; string data to send after connection

Returns:

udp\_ref: reference to udp connection to be used in other function

#### udp\_write(udp\_ref, host, port, data)

### res = net.udp\_write(tcp\_ref, host, port, data)

Connect to 'host' on UDP port 'port' and send data using udp connection 'udp\_ref'. Response will be handled by callback function.

udp ref: udp reference obtained with net.udp create()

host: host IP or domain name

port: integer, udp port to connect to (1 ~ 65535)

data: string data to send

Returns:

res: 0 if OK, negative number if error

#### udp\_read(udp\_ref, size)

## res, data = net.udp\_read(udp\_ref, size)

Read data from udp connection. This function can be used from callback function on read event.

Params:

udp\_ref: udp reference obtained with net.udp\_create()

size: maximum size of data to read

Returns:

res: size or read data, negative number if error

data: string, read data; nil if error

#### close(ref)

## res = net.close(ref)

Close TCP or UDP connection. TCP connection will be disconnected if connected. To enable garbage collector to free the data used by the connection, execute **ref=nil**, where ref if the reference to tcp or udp connection obtained by tcp create or udp create function.

Params:

ref: udp | tcp reference obtained with net.tcp\_create() or net.udp\_create()

Returns:

res: 0 if OK, negative number if error

## ntptime(tz, [cb\_func])

### net.ntptime(tz, [cb\_func])

Update RTC date-time from ntp server.

The function runs in background until it gets the time from ntp server or timeout (30 sec) expires. If callback function is given, it is executed after the time is set or error. If no callback function is given, debug info is printed.

tz: time zone, -12 <= tz <= 14

cb func: optional; Lua callback function, prototype:

function cb func(res)

res integer, 0 if time updated, -1 on error

Returns: None

#### setapn(ref)

#### res = net.setapn(apn\_par)

Configure GPRS APN.

GPRS connection parameters can be obtained from mobile provider.

Params:

apn\_par: Lua table with APN parameters:

apn: GPRS provider APN

useproxy: optional; proxy needed for connection;

1 use proxy; 0 do not useproxy; default 0

Used only if *useproxy=1*:

proxy: proxy IP or domain name proxyport: proxy port (1 ~ 65535)

proxytype: optional; the type of the proxy connection; default 0

0: The 'not specified' type

The WSP, Connection less type
 The WSP, Connection oriented type

3: The WSP, Connection less, security mode type
4: The WSP, Connection oriented, security mode type
5: The WTA. Connection less, security mode type

6: The WTA type, Connection oriented, security mode type

7: The HTTP type

8: The HTTP - enable TLS type

9: The STARTTLS type

proxyuser: optional; proxy user name; default ""
proxypass: optional; proxy password; default ""

Returns:

res: 0 if OK, negative number if error

## https module

This module supports the tcp communication using http protocol. It can be used to communicate with http server with or without SSL. GPRS must be configured with setapn() function before using any of https functions.

#### get(url)

#### res = https.get(url)

Connect to http(s) server and get the response.

The response is handled by Lua callback function. If no callback function is given, the response is printed to standard output. See *https.on()* for details.

Params:

url: string; server url, can contain parameters

Returns:

res: 0 if OK, negative number on error

#### post(url)

#### res = https.post(url, post\_data)

Connect to http(s) server, post data and get the response.

The response is handled by Lua callback function. If no callback function is given, the response is printed to standard output. See <a href="https://doi.org/10.1001/journal.com/">https://doi.org/10.1001/journal.com/</a> for details.

If *post\_data* is string, the data is posted as **Content-Type: application/**x-www-form-urlencoded This way you can post json string.

If *post\_data* is Lua table, the data is posted as *multipart* data. The table must contain parameters in the form *param\_name = value*, where *value* can be string or number.

If *param\_name* is "file", then the file with name given in *value* is posted. Only one file can be included in post data.

Params:

url: string; server url, can contain parameters

post\_data: string or Lua table containing post datag\_https\_response\_cb\_ref

Returns:

res: 0 if OK, negative number on error

### on(method [,cb\_func])

## https.on(method [, cb\_func])

Declare Lua callback function which will be executed on received data event. If no cb\_func is given, existing (if any) callback function is unreferenced.

```
Params:
method:event on which the function will be executed

"header" execute function when response header is received
"response" execute function when response data is received
cb_func: optional; Lua callback function, prototype:
function cb_func(hdr) (for header method)
hdr string; received response header
function cb_func(data, more) (for response method)
data string; received response data
```

1: more data will fallow; 0: all data received

Returns: nil

## cancel()

#### https.cancel()

Cancel http(s) unfinished function.

more

Params: nil

Returns: nil

## email module

This module supports sending email.

If port parameter is 25, the function uses regular smtp protocol, otherwise SSL connection is used.

GPRS must be configured with setapn() function before using any of email functions.

#### send(param)

#### res = email.send(param)

Connect to SNTP server and send email to recipient.

```
param: Lua table containing email parameters
            "host"
                             SMTP server domain or IP address
            "port"
                             SMTP server connection port
            "user"
                             optional; user name
            "pass"
                             optional; user password
            "to"
                         recipient's email address
            "from"
                             sender's email
            "from name"
                             optional; sender's name; default: same as "from"
            "subject"
                             optional if msg is given; email subject
            "msg"
                             optional if subject is given; email message body
Returns:
    res:
            0 if OK, negative number on error
Example:
eml = {
    host="smtp.gmail.com",
    port=465,
    user="mygmail@gmail.com",
    pass="my_gmail_password",
    to="recipient@gmail.com",
    from="mygmail@gmail.com",
    from name="rephone",
    subject="Test",
msg="test email message from RePhone" }
res = email.send(eml)
```

## ftp module

This module supports FTP communication. Uses PASV mode for communication. GPRS must be configured with *setapn()* function before using any of ftp functions.

#### connect(param)

#### res = ftp.connect(param)

Connect to ftp server and log in.

Params:

param: Lua table containing ftp connection parameters
"host" FTP server domain or IP address

"port" optional; FTP server connection port; default: 21

"user" user name
"pass" user password

Returns:

res: 0 if OK, negative number on error

#### disconnect()

#### res = ftp.disconnect()

Log out and disonnect from ftp server.

Params: nil

....

Returns:

res: 0 if OK, negative number on error

## list(file [,option])

```
len, slist = ftp.list(file)
```

```
res = ftp.list(file, file_name])
```

## nlin, tlist = ftp.list(file, "\*totable")

List files on current directory of the connected ftp server.

file: file specification ("\*", "\*.lua", data/\*.\*", etc)

option: optional;

not given: the result is returned as Lua string "file\_name": the result is written to the file "file\_name" "\*totable": the result is returned as Lua table

Returns:

res: 0 if save to file OK, negative number on error

tlist: Lua table containing the listing slist: Lua string containing the listing

len: string length if listing returned as string, negative number on error

nlin: number of items in table, negative number on error

## recv(remote\_file [,local\_file])

res = ftp.recv(remote\_file, local\_file)

len, str\_file = ftp.recv(file, "\*tostring")

Receive remote file from ftp server to local file or string.

Params:

remote file: remote file name to receive

local\_file: local file name

If "\*tostring" the result is returned as Lua string

Returns:

res: 0 if save to file OK, negative number on error

str\_file: Lua string containing the remote file

len: the length of the file received to string, negative number on error

## send(file\_name [,remote\_file] [,"\*append"])

res = ftp.send(file\_name)

res = ftp.send(string, remote\_file [,"\*append"])

res = ftp.send(file\_name, "\*append")

res = ftp.send(file\_name, remote\_file)

res = ftp.send(file\_name, remote\_file, "\*append")

Send local file or string to ftp server.

file name: local file name or string to send

If file with that name exists on local file system, the file is sent,

otherwise the content of this parameter is sent

and remote\_file parameter is mandatory

remote\_file: optional; remote file name

"\*append" optional; append the file or string to remote file,

if not given overwrite remote file

Returns:

res: 0 if OK, negative number on error

#### chdir(remote\_dir)

#### res = ftp.chdir(remote\_dir)

Set current directory on ftp server.

Params:

remote\_dir: new remote directory to set as current

Returns:

res: 0 if save to file OK, negative number on error

### getdir(remote\_dir)

#### len, res = ftp.chdir()

Get current directory on ftp server.

Params:

nil

Returns:

res: string; ftp server remote dir

len: length of res, negative number on error

## mqtt module

This module supports MQTT communication. Multiple mqtt connections are supported. GPRS must be configured with *setapn()* function before using any of ftp functions.

#### create(config)

#### mqtt\_id = mqtt.create(config)

Create and configure new mqtt client connection. Returns mqtt connection id which is used in other functions.

No connection is established.

Client status can be checked with *print(mqtt\_id)*.

To destroy the client and free memory set mgtt id to **nil**.

```
Params:
```

```
config: Lua table containing mqtt client connection parameters
        "host"
                        MQTT broker domain or IP address
        "port"
                        optional; MQTT broker connection port; default: 1883
        "user"
                        optional; user name
        "pass"
                        optional; user password, mandatory if user name given
        "qos"
                        optional; QoS (Quality of Service); default 0
                        optional; Lua callback function to be executed on new message
        "onmessage"
                             function cb func(len, topic, msg)
                                         received message length
                                 len
                                         string; message topic
                                 topic
                                         string; received message
                                 msa
        "ondisconnect" optional; Lua callback function to be executed on disconnect
                             function cb_func(host)
                                         the host from which the client was disconnected
                                 host
```

#### Returns:sms module

matt id: matt client id to be used in other matt functions or **nil** on error

## connect(mqtt\_id [,check\_int] [,ka\_int])

#### res = mqtt.connect(mqtt\_id [,check\_int] [,ka\_int])

Connect to mgtt broker, set check for message and keep alive intervals.

```
Params:
```

```
mqtt_id mqtt id obtained with create function
check_int optional; interval in seconds to check for messages; default 30
5 <= check_int <= 300 & check_int <= (ka_int/2)
optional; keep alive interval in seconds; default 60
30 <= ka_int <= 600
```

#### Returns:

res: 0 if connected; negative number on error

### disconnect(mqtt\_id)

#### res = mqtt.disconnect(mqtt\_id)

#### Disconnect from mqtt broker.

Params:

mgtt id mgtt id obtained with *create* function

Returns:

res: 0 if disconnected; negative number on error

#### addtopic(mqtt\_id, topic [,qos])

#### mqtt.addtopic(mqtt\_id ,topic [,qos])

Set mqtt client topic. Up to 5 topics can be added per client.

Params:

mqtt\_id mqtt id obtained with *create* function topic string; topic name, max length 31

qos optional; topic's QoS; default: client's QoS

Returns:

nil

### subscribe(mqtt\_id)

#### mqtt.subscribe(mqtt\_id)

Subscribe to topics added with addtopic() function.

Params:

mqtt\_id mqtt id obtained with *create* function

Returns:

res: 0 if subscribed; negative number on error

## unsubscribe(mqtt\_id [,topic])

#### mqtt.unsubscribe(mqtt\_id [,topic])

Unsubscribe from topics added with addtopic() function or from all topics.

Params:

mgtt id mgtt id obtained with create function

topic optional; topic name to unsubscribe from; if none given, unsubscribe from all topics

Returns:

res: 0 if unsubscribed; negative number on error

## publish(mqtt\_id, topic, message [,qos])

#### mqtt.publish(mqtt\_id ,topic, message [,qos])

Publish to matt topic.

mqtt\_id mqtt id obtained with *create* function topic string; topic name, max length 31

message string; message to publish

qos optional; topic's QoS; default: client's QoS

Returns:

res: 0 if OK; negative number on error

## **SMS** module

Functions for manipulating SMS message.

Maximum sms message length (send and receive) is 640 bytes.

### send(num, msg [,cb\_func])

#### res = sms.send(num, msg [,cb\_func])

Send sms message to gsm number.

Wait for message to be sent if no cb\_func is given.

#### Params:

num: string; gsm phone number to which to send the message

msg: string; message body

cb func:optional; Lua callback function to be executed after message is sent

function cb func(stat)

stat 0 if OK, negative number on error

#### Returns:

res: 0 if OK, negative number on error

### numrec([box\_type])

#### res = sms.numrec([box\_type])

Check the number of received sms messages.

#### Params:

box\_txpe: optional; message box type, default 1

0x01 <u>Inbox</u>. 0x02 <u>Outbox</u>. 0x04 Daft box.

0x08 Unsent box. Messages to be sent.

0x10 SIM card.
0x20 Archive box.

#### Returns:

res: number of messages, negative number on error

### list([msg\_state] [cb\_func])

## res = sms.list([msg\_state] [cb\_func])

Get the list of available message id's.

#### Params:

```
msg_state: optional; message state, default 1
```

0x01 Unread. 0x02 Read. 0x04 Sent.

0x08 Unsent (to be sent).

0x10 Draft.

cb\_func:optional; Lua callback function to be executed after message list ready

function cb func(tlist)

tlist Lua table containing message id's

which can be used to read or delete the message

Returns:

res: *if cb\_func is not given*:

Lua table containing message id's which can be used to read or delete the message

*if cb func is not given:* 

Message list query result; 0: OK

#### read(msg\_id [,cb\_func])

```
time, msg = sms.read(msg_id)
```

#### res = sms.read(msg\_id ,cb\_func)

Read the message at index msg id.

Params:

msg id: message index from which to read the message

cb\_func:optional; Lua callback function to be executed message is read

function cb\_func(time, msg)

time Lua table containing message sent time

Table keys are: sec, min, hour, day, month, year

msg Lua string, the message body

Returns:

res: 0 if OK, negative number on error

time: string; message sent time msg: string; message body

## delete(msg\_id [,cb\_func])

#### res = sms.delete(msg\_id [,cb\_func])

Delete sms message at index msg\_id.

Wait for message to be deleted if no cb\_func is given.

Params:

msg id: message index from which to delete

cb\_func:optional; Lua callback function to be executed after message is deleted

function cb\_func(stat)

stat 0 if OK, negative number on error

Returns:

res: 0 if OK, negative number on error

## onmessage([cb\_func])

## res = sms.onmessage([cb\_func])

Set Lua callback function to be executed when new message arrives. If called without parameter, removes exiting callback function reference.

cb func:optional; Lua callback function to be executed after new message arrives

function cb func(msg id, gsm num, msg)

msg id massage id

string; phone number from which message is received gsm\_num

msg string; message body

Returns:

0 if OK, negative number on error res:

#### sim\_info()

## stat, imei, imsi = sms.siminfo()

Returns SIM card status, IMEI and IMSI numbers.

Params:

nil

Returns:

SIM card status: stat:

-2 No active SIM card detected.

Failed to get status.
No SIM card is detected or the SIM card is not working.

The SIM card is working.

IMEI number, returned only if stat=1 imei: IMSI number, returned only if stat=1 imsi:

## timer module

Timer related functions. Multiple timers can be created.

Minimal timer interval is 1 msec.

Be careful when using small interval timers, it can affect performance.

#### create(interval, cb\_func)

#### timer\_id = timer.create(interval, cb\_func)

Create and start new timer. Returns timer id which is used in other timer functions.

Timer status can be checked with print(timer id).

To destroy the timer and free memory set timer\_id to **nil**.

Params:

interval: timer interval in msec

cb func Lua callback function to be executed on timer interval

function cb\_func(timer\_id)

timer idid of the timer for which the function is called

Returns:

timer id: timer id to be used in other timer functions

#### delete(timer\_id)

#### res = timer.delete(timer id)

Stop and delete.

To destroy the timer and free memory set timer\_id to **nil**.

Params:

timer id: timer id obtained with create function

Returns:

res: 0 if OK, negative number on error

## pause(timer\_id)

#### timer.pause(timer\_id)

Pause the timer. Callback function is not executed while paused.

Params:

timer id: timer id obtained with create function

Returns:

## resume(timer\_id)

#### timer.resume(timer\_id)

Resume paused timer. Callback function is executed.

timer\_id: timer id obtained with create function

Returns:

nil

## changecb(timer\_id, cb\_func)

## timer.changecb(timer\_id, cb\_func)

Change timer's callback function.

Timer is paused first, callback function is changed, timer is resumed.

Params:

timer\_id: timer id obtained with create function

cb\_func:new Lua callback function

Returns:

nil