# **Sprayer Calibration Lab**

#### A. Four major questions to answer:

- 1) How much water is to be applied per acre?
- 2) How many acres should a tank of spray solution cover?
- 3) How much herbicide should be added to the tank?
- 4) How much spray solution should be collected per nozzle to be properly calibrated?

#### B. Calibrating a Sprayer

Calibration is the mathematical determination of the amount of spray solution (water) applied per unit area expressed in GPA necessary to insure the appropriate rate of herbicide or other pesticide. Physically calibrating a sprayer is certainly of paramount importance but no more important than proper sprayer adjustment or calculating the appropriate rate of herbicide to be applied. Both physical calibration and calculations concerning rate of delivery, rates, etc. are involved in what we normally refer to as calibration. Proper calibration of herbicide application equipment is essential for safe, economical, and effective pest control. Sprayers should be calibrated several times during the year.

An understanding of how a sprayer operates and especially the factors influencing the amount of liquid applied is essential in getting a sprayer set up for a specific job and for properly calibrating the unit for the application rate desired. The amount of liquid that a sprayer applies to a given area can be varied by changing one or more of the following:

- Pressure that forces liquid through the spray nozzle
- Nozzle size
- Ground speed
- Spacing of nozzles on boom

Pressure should be used only to make very minor adjustments in spray volume. It takes approximately a four-fold increase in pressure to double sprayer output. Pressure changes output rate proportional to the square root of the pressure (psi).

#### new psi = old psi x square root (new psi/old psi)

The use of pressure to adjust output is strongly discouraged because operators tend to rely on pressure and invariably use excessively high pressure. First select the appropriate nozzle and then make very minor adjustments in pressure to obtain the needed flow rate.

Pressure should be high enough to insure proper distribution of the solution from nozzles. This can depend on nozzle type. Low-pressure nozzles are available that allow acceptable spray patterns at low pressure. If pressures in excess of 50 psi are required to give the desired delivery rate of a herbicide, then a larger nozzle should be used. Consequently, the pressure can be reduced. Remember that higher pressure increases off-target drift of the herbicide.

The proper alignment of fan nozzles is necessary for uniform coverage. Improper alignment can result in strips of (1) uncontrolled weeds and (2) crop/turfgrass injury. Nozzle spacing and height are also important. Space nozzles a distance apart (usually 20 inches) on the boom and adjust the height to give a uniform spray pattern.

The proper height for a given spacing can be calculated mathematically but 'trial and error' is simpler. Spray on concrete, asphalt, or other smooth surface and adjust the height of the boom to give a uniform overlap and distribution of the spray solution on the surface. The drying pattern is an exceptionally good 'eyeball' indicator. Improper height will result in strips where herbicide rate may be either too low or too high. Adjust height according to information provided from nozzle manufacturer, which should discuss proper overlap for different nozzles.

Nozzle tips are subject to wear over time depending on the pesticide being used, length of use, etc. Wettable powder formulations are particularly abrasive. Nozzles should be checked periodically for wear. Replace a nozzle tip if the discharge rate varies more than 5 to 10%. Do not operate a nozzle above or below the pressure listed by the manufacturer.

Ground speed is a major variable in sprayer calibration. Application rate is inversely proportional to the speed. By doubling speed, output is reduced by half.

#### new rate = old rate x (old mph/new mph)

Day to day maintenance and operation of sprayers is important if successful pest control with chemicals is to be achieved. Inspect sprayers daily when using and follow routine servicing and storage instructions contained in the operation and maintenance manuals supplied by the sprayer manufacturer.

#### C. Calibration Exercise

1) Determine the gallons per minute (GPM) you need to catch from a nozzle for your specific gallons per acre, speed, and nozzle spacing. Using the formula below, when starting the process to determine delivery rate per nozzle may be easier to catch one fourth of this in 15 seconds (1/4 of a minute). This will save you some time when calibrating, but will sacrifice accuracy somewhat.

$$mL / 15$$
seconds =  $\underline{(GPA)(Speed in mph)(Nozzle spacing in inches) (3785)}$ 
(5940) (4)

- 2) Begin by making sure all the fittings are sealed. Check the pressure gauge on the CO<sub>2</sub> canister. The pressure needle should not be in the red zone.
- 3) The spray can should be full of water (and only water). Make sure the seal on the can is airtight. Open the air release valve to release air into the can. You should not be able to hear air leaking from the can.
- 4) Use a screwdriver to adjust the pressure initially to 25 psi. This is the starting point.
- 5) Have a partner hold and operate the boom. You should have a stopwatch, holding the catch cup near the nozzle.
- 6) Have your partner turn on the sprayer to allow the pressure to build. Have them keep it on until you are finished catching.
- 7) At the same instant, start your stopwatch and move the cup under the nozzle. Do not allow any liquid to escape from the cup. If some does, or your timing was off, dump the cup *COMPLETELY* out and begin again.
- 8) After exactly 15 seconds, remove cup from the spray pattern and shut off the sprayer.
- 9) Carefully pour the contents of the cup in a graduated cylinder. Measure the amount you caught to the nearest mL.
- 10) You want the amount that you caught to be the same as the amount you calculated in step 1:
- If you caught a little too much, lower the pressure a few psi and try again.
- If you caught slightly under what you calculated, raise the psi slightly.
- If you caught a great deal too much, you may need to change the nozzle tips to a lower output range (orifice size).
- If your volume is a great deal too little, change the nozzle tips to a higher output (orifice size).
- 11) Remember that the higher the pressure, the smaller the droplet size (more drift).
- 12) Repeat steps 6-10 until the desired volume of water is caught.

#### D. Three calibration techniques:

- 1) Common sense method
- 2) Baby bottle method
- 3) Formula method

#### **Common Sense Method**

36 ft x 100 ft = 3600 ft<sup>2</sup> (area covered) 3600 / 43560 = 0.08264 acre

1. 
$$\underline{10 \text{ Gal}}$$
 = X/ 0.08264 acre

2. Travel time: 22.6 sec. to travel 100 feet

3. 
$$\frac{0.8264 \text{ gal}}{24 \text{ nozzles}} = \frac{0.0344 \text{ gal}}{\text{nozzle}}$$




Figure 1. Common sense calibration method

- 4. 0.0344 Gal x 3785 ml/Gal = 130 ml/nozzle
- 5. To be properly calibrated at 10 GPA, you must catch 130 ml/nozzle in 22.6 sec.

```
Speed = \frac{100 \text{ ft}}{22.6 \text{ sec}} \times \frac{60 \text{ sec}}{1 \text{ min}} \times \frac{1 \text{ mile}}{1 \text{ hour}} = 3.02 \text{ MPH}

or

1 MPH = 88 ft/min 60 sec / 22.6 sec = 2.65(100)

Traveled 100 ft in 22.6 sec = 265 ft in 60 sec (1 min)

\frac{265 \text{ ft}}{88 \text{ ft}} = 3.02 \text{ MPH}
```

Figure 2. Speed determination

#### **Baby Bottle Method**

Does not require you to know the speed of the tractor in MPH, just the setting of the throttle so that you can maintain that speed. This method is also referred as the one  $1/128^{th}$  of an acre method.

1. Use the chart for the distance to drive in the field and the nozzle spacing for the boom.

- 2. Set the throttle for spraying and operating all equipment and note the seconds required to drive a measured distance.
- 3. Ifyou are using a broadcast boom with Nozzles spread evenly, catch the output From one nozzle for the time noted in Step 2. the row width value is used catch Spray from all nozzles per single row for The time noted in step 2.
- 4. Ounces collected will equal gallon per acre.

Nozzle Spacing or	
Row width in inches	Distance in feet
40	102
38	107
36	113
34	120
32	127
30	136
28	146
26	157
24	170
22	185
20	204
18	227
16	255
14	291

Figure 3. Baby bottle calibration method

#### Formula Method

- 1. GPM = (<u>GPA) (MPH) (NS" or Band Width")</u> 5940
- 2. Catch the amount from one nozzle (or all nozzles if swath width is used)
- 3. Usually much easier if gallons are converted to milliliters and minutes into 15 second intervals

#### E. Calculation of Herbicide Rates

Solid formulations: 
$$\underline{\text{Rate}}_{\frac{9}{6}} = \text{Amount to apply}$$

If formulation is 75 WP, DF, DG, or G, then % = 75% or 0.75 Want to apply 1 lb ai/A. What is the pounds of product to be applied / acre?

$$\frac{1 \text{ lb ai/A}}{0.75}$$
 = 1.33 lb of product /A

Liquid formulations: 
$$\underline{\text{Rate}}_{\text{lb ai/gal}} = \text{Amount to apply}$$

If formulation is 4 L, EC, or F, then lb ai/gal = 4 Want to apply 1 lb ai/A. What is the lb of product to be applied A?

 $\frac{1 \text{ lb ai/A}}{4 \text{ lb ai/gal}} = 0.25 \text{ gal prod./A or 1 quart/A (4 lb per gal so 1 lb per quart)}$ 

#### F. Broadcast vs. Banding

Broadcast – Application of a herbicide to the entire field Banding – Application of a herbicide to only a portion of the field

Band applications are usually made directly over the center of the row, while the middles between the rows are left untreated.

For clarification use the terminology of traveled vs. treated acreage:

- *Broadcast application* when sprayer travels over 1 acre of land, 1 acre has been treated (treated = traveled acres)
- Banding application the sprayer may still travel over 1 acre of land, however, only a percentage of the traveled acre is treated (treated does not equal traveled acres).

Example 1. Banding a herbicide on a 20 inch band. Row spacing is 40 inches. How many treated acres will be covered when the sprayer has traveled over 1 acre?

$$\underline{20" \text{ band}}$$
 x 1 acre = 0.5 acres  $\underline{40" \text{ row}}$ 

0.5 acres will have been treated

*Example 2.* You are spraying Asulox on a 36" band on 72" a sugarcane row. Your sprayer is calibrated to deliver 20 GPA.

- 1. Visualize that you are only treating half the acre that you travel over.
- 2. Broadcast rate of 4 quarts / treated acre, then band rate is

$$(0.5 \text{ acres}) = 2 \text{ qts / acre (traveled)}.$$

3. If you have a 200 gallon spray tank and your sprayer is calibrated to deliver 20 GPA broadcast, how many traveled acres will you be able to cover with the band per load?

$$\underline{200 \text{ gallons water}} = 10 \text{ acres broadcast per load}$$
 $\underline{20 \text{ GPA}}$ 

$$\frac{10 \text{ acres traveled}}{0.5} = 20 \text{ traveled acres per load}$$

4. Important to remember that the concentration of Asulox in the water in the tank is the same regardless of whether you broadcast or band. Difference is that more acreage is traveled with the sprayer when herbicide is applied on a band.

# **Calibration Examples**

## Example 1

A local farmer has a rhizome johnsongrass problem in his cotton fields. You recommend that he use Assure II 0.88 EC to control this problem at a rate of 0.069 lb ai/A. You also recommend the addition of a crop oil concentrate at a rate of 1% volume per volume (v/v). His sprayer is equipped with a 300 gallon spray tank. He has not calibrated his sprayer, but he wants to apply the solution at 15 GPA at 3.0 MPH. His boom has 40 nozzles spaced 20 inches apart.

- A. What is the GPM in mls that should be caught from each nozzle to be properly calibrated?
- B. How many acres can be treated per tank load?
- C. How much Assure II should the farmer add to the spray tank? (oz.)
- D. How much crop oil should he add to the 300 gal. tank.

## Example 2

T-Jim Griffineaux has decided to use Aatrex 4L and Sinbar 80 WP for preemergence weed control in his sugarcane. Because of cost, he plans to band his herbicides on a 30" band and cultivate the middles of his 72" rows. He plans on using Aatrex at 1.25 lb ai/A and Sinbar at 2 lb ai/A on a band. His sprayer has two 200 gallon tanks and he wants to apply the herbicide solution in 20 GPA. He hasn't had time to calibrate his sprayer, but he knows that in 100 ft it takes him 13.62 sec.

- A. What is the speed of his sprayer? (MPH)
- B. How many mls must he catch/nozzle in 60 sec to be calibrated correctly?
- C. How much of each herbicide must he use per acre to apply the correct lb ai/A?
- D. How many traveled acres can he cover with the two 200 gallon tanks? How many treated acres?
- E. How many pounds of Sinbar and gallons of AAtrex must he add to each tank?

## Useful Formulas

CALIBRATION FORMULAS				
gpm/nozzle =		7.5		
		sec/pt		
=	=	gpa X s X w		
		5,940		
gpa =	=	5,940 X gpm/nozzle		
gpa _		s X w		
_	=	44,500		
_	_	s X w X sec/pt		
		43,560 X gal discharged		
	-	swath width (ft) X length of run (ft)		
		0.682 X length of run (ft)		
mph =	=	time (sec)		
	~~	Hone per sere breedeset hasis		
1 -	gpagalions per acre, broadcast basis			
1		llons per minute		
mphmiles per hour				
secseconds				
ptpints				
ftfeet				
sground speed (miles per hour)				
wnozzle spacing on boom or band width (inches)				

#### **DETERMINING VOLUME**

Volume of a cylinder is radius squared  $\times$  3.1416  $\times$  length of cylinder.

Volume of cone is radius squared  $\times$  1.0472 (e.g., round hopper bottom).

Volume of pyramid is area of base  $\times$  1/3 the height. (e.g., square hopper bottom).

#### **VOLUME CONVERSION FACTORS:**

(U.S. Customary Measures)

Cu. ft. × 7.48 equals gallons.

Cu. ft.  $\times$  62.4 equals pounds water.

Gallons  $\times$  8.330 equals pounds water.

Gallons × 0.1337 equals cu. ft.

Cu. in.  $\div$  1,728 = cu. ft.

Cu. yd.  $\times$  27 = cu. ft.

Cu. ft.  $\div$  27 = cu. yds.

-				
CALIBRATION FORMULAS (METRIC)				
	-			
L/min/nozzle =	60 sec/L			
_	L/ha X s X w			
	600,000			
L/ha =	600,000 X L/min/nozzle			
	s X w			
=	10 000 X L discharged			
	swath width (m) X length of run (m)			
km/h =	3.6 X length of run (m)			
	time (sec)			
L/halite	ers per hectare, broadcast basis			
L/minlite	ers per minute			
km/hKilometers per hour				
secseconds				
mmeters				
sground speed (kilometers per hour)				
wnozzle spacing on boom or band width (centimeters)				

#### **DETERMINING AREA**

To find circumference of a circle when diameter is known, multiply diameter by 3.1416 (approx. 3-1/7).

To find diameter when circumference is known, divide circumference by 3.1416 or multiply by 0.3183.

Area of circle = radius squared  $\times$  3.1416; or diameter squared  $\times$  0.7854.

Area of rectangle or square = length  $\times$  width.

Area of right triangle = length  $\times$  width  $\div$  2.

Area of other triangles = baxe  $\times$  height at right angle to base  $\div$  2 (see diagram).

# Conversion Tables U.S. to Metric

U.S. System Metric Equivalent					
LENGTH	Metric Equivalent				
Unit	Abbreviation	Facilitation to College 11 to			
Mile		Equivalents In Other Units			
Rod	mi rd	5280 feet, 320 rods, 1760 yards 5.50 yards, 16.5 feet	1.609 kilometers		
Yard	yd .	3 feet, 36 inches	5.029 meters 0.914 meters		
Foot	ft. or '	12 inches, 0.333 yards	30.480 centimeters		
Inch	in or "	0.083 feet, 0.027 yards	2.540 centimeters		
AREA	· · · · · · · · · · · · · · · · · · ·				
Unit	Abbreviation	Equivalents In Other Units			
Square Mile	sq mi or m²	640 acres, 102,400 square rods	2.590 square kilometers		
Acre	A	4840 square yards, 43,560 square feet	0.405 hectares, 4047 square meters		
Square Rod	sq rd or rd <sup>2</sup>	30.25 square yards, 0.006 acres	25.293 square meters		
Square Yard Square Foot	sq yd or yd²	1296 square inches, 9 square feet	0.836 square meters		
Square Foot Square Inch	sq ft or ft² sq in or in²	144 square inches, 0.111 square yards	0.093 square meters		
	ad in or in.	0.007 square feet, 0.00077 square yards	6.451 square centimeters		
VOLUME					
Unit	Abbreviation	Equivalents In Other Units			
Cubic Yard	cu yd or yd <sup>3</sup>	27 cubic feet, 46,656 cubic inches	0.765 cubic meters		
Cubic Foot	cu ft or ft <sup>3</sup>	1728 cubic inches, 0.0370 cubic yards	0.028 cubic meters		
Cubic Inch	cu in or in <sup>3</sup>	0.00058 cubic feet, 0.000021 cubic yards	16.387 cubic centimeters		
CAPACITY					
Unit	Abbreviation	U.S. Liquid Measure			
Gallon	gal	4 quarts (231 cubic inches)	3.785 liters		
Quart	qt	2 pints (57.75 cubic inches)	0.946 liters		
Pint Gill	pt ci	4 gills (28.875 cubic inches)	0.473 liters		
Fluidounce	gi fl oz	4 fluidounces (7.218 cubic inches) 8 fluidrams (1.804 cubic inches)	118.291 milliliters		
Fluidram	fl dr	60 minims (0.225 cubic inches)	29.573 milliliters 3.696 milliliters		
Minim	min	1/60 fluidram (0.003759 cubic inches)	0.061610 milliliters		
		U.S. Dry Measure			
Bushel	bu	4 pecks (2150.42 cubic inches)	35.238 liters		
Peck Quart	pk	8 quarts (537.605 cubic inches)	8.809 liters		
Pint	qt pt	2 pints (67.200 cubic inches)  ½ quart (33.600 cubic inches)	1.101 liters 0.550 liters		
MASS AND WEIGHT	h.	72 quart (00.000 capic inches)	U.330 Hiers		
Unit	Abbroviation	Savinatanta I. O. I. I.			
Ton	Abbreviation	Equivalents In Other Units			
short ton	tn (seldom used)	20 short hundredweight, 2000 pounds	0.007 metric tere		
long ton		20 long hundredweight, 2240 pounds	0.907 metric tons 1.016 metric tons		
Hundredweight	cwt		to mound tons		
short hundredweight		100 pounds, 0.05 short tons	45.359 kilograms		
long hundredweight	11 11	112 pounds, 0.05 long tons	50.802 kilograms		
Pound Ounce	lb or lb av also #	16 ounces, 7000 grains	0.453 kilograms		
Dram	oz or oz av dr or dr av	16 drams, 437.5 grains 27.343 grains, 0.0625 ounces	28.349 grams		
Grain	gr	0.036 drams, 0.002285 ounces	1.771 grams		
	J	Titte alamo, closecoo dunces	0.0648 grams		

# Conversion Tables

Metric to U.S.

	Metric Syst	em	U.S. Equivalent		
LENGTH					
Unit	Abbreviation	Number of Meters			
Kilometer km Hectometer hm Decameter dkm Meter m Decimeter dm Centimeter cm		1,000 100 10 1 0.1 0.01	0.62 mile 109.36 yards 32.81 feet 39.37 inches 3.94 inches 0.39 inch		
Millimeter	mm	0.001	0.04 inch		
AREA					THE STATE OF THE S
Unit	Abbreviation	Number of Square Meters			8
Square Kilometer Hectare Are Centare Square Centimeter	sq km or km² ha a ca sq cm or cm²	1,000,000 10,000 100 1 0.0001	0.3861 square mile 2.47 acres 119.60 square yards 10.76 square feet 0.155 square inch		ds
VOLUME					
Unit	Abbreviation	Number of Cubic Meters			
Stere s 1 Decistere ds 0.10			1.31 cubic yards 3.53 cubic feet 0.061 cubic inch		
CAPACITY					
Unit	Abbreviation	Number of Liters	Cubic	Dry	Liquid
Kiloliter Hectoliter Decaliter Liter Deciliter Centiliter Milliliter	kl hl dkl l dl cl ml	1,000 100 10 1 0.10 0.01 0.001	1.31 cubic yards 3.53 cubic feet 0.35 cubic foot 61.02 cubic inches 6.1 cubic inches 0.6 cubic inch 0.06 cubic inch	2.84 bushels	
MASS AND WEIGH	Т				2
Unit	Abbreviation	Number of Grams			
Metric Ton         MT or t         1,000,000           Quintal         q         100,000           Kilogram         kg         1,000           Hectogram         hg         100           Decagram         dkg         10           Gram         g or gm         1           Decigram         dg         0.10           Centigram         cg         0.01           Milligram         mg         0.001		1.1 tons 220.46 pounds 2.2046 pounds 3.527 ounces 0.353 ounce 0.035 ounce 1.543 grains 0.154 grain 0.015 grain			