
NIM, CAMAC and VME Standards

There have been three major data acquisition standards used in modern nuclear physics. The first to be introduced was the NIM standard and was used to provide power to for the electronics. CAMAC went further and allowed data transfer on the crates backplane. The current standard is VME, expanded on CAMAC by providing more options and a faster bus speed. In today's modern labs you are likely to find any or all of these standards coexisting. For that reason it is necessary to have a working understanding of all three


NIM Nuclear Instrument Module

The NIM standard is the first crate standard widely accepted by physicists. It provided a way to organize and distribute power to their electronics. The power was distributed by a series of connectors on the back of the crate. A low voltage power supply is either behind the crate or sat in the crate along side the other modules. Typical voltages distributed were +/-6V, +/-12V, and +/-24V, although many custom power supplies have been built for NIM crates. NIM crates have 12 slots. Today NIM crates are often used for small setups with only a handful of detectors because their low overhead makes setup easy. They are often used in larger experiments for setup and to handle logic signals and analog electronics. Some of the most often used modules are amplifiers, gate and delay generators, discriminators, high voltage modules, and linear fan-in fan-out units.



NOTES:-

- A. CONNECTORS ARE IN ACCORDANCE WITH DRAWING NO. ND-519.
- B. RESERVED PINS ARE FOR FUTURE ASSIBNMENT BY THE COMMITTEE AND SHALL NOT BE USED UNTIL SUCH ASSIGNMENTS ARE MADE.
- C. GP-I * GUIDE PIN 66P * GROUND GUIDE PIN 05-I * GUIDE SOCKET GGS * GROUND GUIGE SOCKET
- D. SEE ALSO SECTION F OF THIS REPORT



FRONT FACES



CAMAC

Computer Automated Measurement and Control


CAMAC answers many of the shortcomings of NIM. CAMAC offers a back-plane that could transfer data. That means the parameters for each channel can be adjusted via the backplane and data can be readout the same way, opening the front panel up for more channels of input. Each CAMAC crate has 25 slots, which meant twice as many modules than a NIM crate. The last two slots in the crate are always reserved for the CAMAC crate controller, which interfaces the crate with a computer. The backplane had one card style connector for each slot, which the modules plugged into.

CAMAC Description

CAMAC is more overhead intensive than NIM because even for small setups programs had to be written and tested. For many years most medium to large-scale nuclear physics were done using CAMAC modules. Typical modules used in a CAMAC crates are ADC's and TDC's.

As experiments grew and more modules were needed with a higher channel density the CAMAC bus was not able to keep up. There were several extensions made to the CAMAC modules to help them keep up, FERA bus being the most popular.

Most of the CAMAC crates and modules found in experiments today are there because they were already owned, or the software had already been developed, making the experiment cheaper and/or easier.



CAMAC Card




CAMAC Crate




CAMAC Basics (Node addresses)

CAMAC addresses are node (niche) specific they don't therefore

have DIL switches that select a particular address, the programmer must specify a slot when addressing a module.



CAMAC Basics (Connecting crates)



CAMAC Basics addressing a module

Branch (only single branches at ING always 0 or 6)

Crate (crate addresses range from 0 to 3 at ING the maximum possible is 7)

Node (or Niche!) 25 stations or nodes are available in an a standard CAMAC crate, the rightmost, station 25 is reserved for a crate controller, addressed modules may be plugged into stations 1 – 24

Subaddress used for addressing registers in inside modules, 4 bits are available giving 16 possible subaddresses.

Function used for controlling the available functions within a module, 5 bits are available giving 32 possible functions for diagnostic purposes F 0 read and F 16 write are worth remembering.


CAMAC Basics B C N A F

To communicate with a particular CAMAC module a 4 word address and a 5 bit function code must be specified. The TCS programme reads or writes to most modules at 20Hz. A diagnostic programme is available on the Alpha TCS computer (CAMTEST) for either writing to or examining the contents of module registers

Familiarity with the use of CAMTEST is essential for duty engineers apart from the PLOT program it is the most important tool you have for tackling telescope problems

Remember:- Branch Crate Node Address Function

CAMAC bus architecture



VME Versa Module Europa

VME like CAMAC offered a rear backplane for fast and efficient data transfer.

However, VME offered a faster and more versatile bus. The VME bus is industry standard used in physics this means that there is a larger variety of crates and modules commercially available at low prices than for CAMAC.

The faster bus also meant that more data could be transferred and channel density increased. This makes VME a very attractive alternative to CAMAC.

VME System

VME crate have slots for 21 modules, the first is reserved for a crate controller. The VME backplane has two 3-row connectors (J1 & J2) per module, these are for both data and power distribution. VME also offers options for incorporating CAMAC crates into a VME setup this is done with a VME to CAMAC bridge and allows experimenters to use CAMAC modules and crates they already have keeping experiment cost down.

VME is currently the used in most large-scale experiments and is becoming more popular in smaller scale experiments.

VME has several extensions. VME 430 added a third, smaller, connector to the backplane, called Jaux this connector is used for additional power distribution and user defined operations. VME 64X is an extension of VME 430 and adds two rows of connectors to each of the three connectors, the extra rows were added in such away that a regular VME module would be compatible with VME 64X.




Figure 5. I/O Interface Driver Connector Pincut

CAEN VME VME-USB2.0 Bridge

- No boot required, ready at power ON
- Up to 30 MByte/s sustained data transfer rate
- VME Master (arbiter or requester)
- VME Slave (register and test RAM access)
- Cycles: RW, RMW, BLT, MBLT, IACK, ADO, AE
- Addressing: A16, A24, A32, CR/CSR, LCK
- Data width: D8, D16, D32, D64
- System Controller capabilities
- Interrupt handler
- Front panel Dataway Display (available also from PC and VME)


CAEN VME VME-PCI Optical Link Bridge

- No boot required, ready at power ON
- PC control through A2818/A3818 Optical Controllers
- CONET1 OR CONET2 CAEN Proprietary Optical link Compatible
- PCI 32bit / 33MHz (A2818) PCIe x8 (A3818)
- Daisy chain capability
- Up to 100 MByte/s sustained data transfer rate (with CONET2)
- VME Master (arbiter or requester)
- VME Slave (register and test RAM access)
- Cycles: RW, R

CAEN VME

- <u>Digitizers</u>
- ADCs (Peak Sensing)
- QDCs
- ADCs C-RAMS (CAEN Readout for Analog Multiplexed Signals)
- Amplifiers (Fast)
- Attenuators
- Sequencer
- HS Caenet Controllers
- Controller (VME)
- Discriminators
- Fan In Fan Out Units
- <u>Coincidence/Logic/Trigger Units</u>
- I/O Registers
- Scalers
- TDCs
- Timing Units
- Translators
- VME High Voltage Power Supplies

CAEN VME Addressing





CAENVMELib Library

Interface library for CAEN VME Bridges

Set of functions for the control and the use of CAEN VME Bridges

Available for C/C++ environment (Windows, Linux) and LabView environment (Windows)


Supported Boards:

Mod. V1718 / VX1718 - VME-USB2.0 Bridge

Mod. V2718 / VX2718 - VME-PCI Optical Link Bridge

Mod. A2818 - PCI CONET Controller

Mod. A3818 - PCI Express CONET2 Controller




```
if
 (CAENVME_WriteCycle(vme_handle,V1290_BA
 SE_ADDRESS+CVT_V1190_MICRO ADD,&wo
 ,cvA32_U_DATA,cvD16)!= cvSuccess)
 MessageBox(_T("Eroare la scrierea Micro
 Register"));
 if
 (CAENVME_ReadCycle(vme_handle,V1290_BA
 SE ADDRESS+CVT V1190 MICRO HND AD
 D,&data,cvA32_U_DATA,cvD16) != cvSuccess)
 MessageBox (_T(" V1290 Eroare la citirea Micro
 Hanshake Register"));
```


```
if(CAENVME_BLTReadCycle(
   vme_handle,V1290_BASE_ADDRESS+C
   VT_V1190_OUT_BUFFER_ADD,&block_
   buffer[0],in_contor,cvA32_U_BLT,cvD32,&
   out_contor) != cvSuccess)
   AfxMessageBox(_T("V1290 Eroare la
   citirea block"));
```

Positron Life Time Spectroscopy

NIM system



Coincidence Doppler Broadening Spectroscopy VME system




Positron Annihilation Spectroscopy Detectors




- Multi Branch System
- Standard Data Acquisition System at GSI
- Based on Real-time OS LynxOS (v2.5, v3.0)
- Written entirely in C
- CAMAC, Fastbus, VME, VXI GSI trigger

• M68k CPUs (CVC, Eltec).



T9-PS Experimental setup



FPGA - Field Programmable Gate Array

 An integrated circuit designed to be configured by a customer or a designer after manufacturing—hence "fieldprogrammable". The FPGA configuration is generally specified using a hardware description language (HDL), similar to that used for an application-specific integrated circuit (ASIC)


FPGA - Field Programmable Gate Array

Contemporary FPGAs have large resources of logic gates and RAM blocks to implement complex digital computations. As FPGA designs employ very fast IOs and bidirectional data buses it becomes a challenge to verify correct timing of valid data within setup time and hold time.

FPGA Evolution of implementation technologies

- Logic gates (1950s-60s)
- Regular structures for two-level logic (1960s-70s)
 - muxes and decoders, PLAs
- Programmable sum-of-products arrays (1970s-80s)
 - PLDs, complex PLDs
- Programmable gate arrays (1980s-90s)
 - densities high enough to permit entirely new class of application, e.g., prototyping, emulation, acceleration

Gate Array Technology (IBM - 1970s)



construct any circuit

Field-Programmable Gate Arrays

Logic blocks

to implement combinational and sequential logic

Interconnect

wires to connect inputs and outputs to logic blocks

I/O blocks

special logic blocks at periphery of device for external connections

Digital FPGA Solutions

Advantages

- Reduction in size (compact)
- Higher resolution
- Lower deadtime
- Multifunctional
- Upgradable
- Possible automation of entire acquisition process
- Remote acquisition

Disadvantages

- Signal requires prefiltering due to ADC limitations
- Complex design procedure (requires knowledge of
- C/C++, VHDL/Verilog, Matlab)
- • Expensive hardware and software

Digital FPGA Solutions

Unlike microprocessors, FPGAs have to ability to run processes in parallel achieving greater performance


Strict timing constraints allows precise data flow control and time stamping

Fast reprogramming allows for multi parameter measurements with single setup Wide range of experiment parameters can be

changed in real time


"Analog" FPGA Solutions

- FPGA devices are considered belonging to digital world while ADC is an analog measurement function.
- ADC can be implemented directly with FPGA plus a few passive (resistors and capacitors) components.
- Bench tests are done for ADC 6-bit@22.5 MHz and 9-bit@2MHz. Other speed/resolution combinations are possible.
- The ADC is based on ramp & compare with TDC implemented inside FPGA with 0.69 ns LSB (200ps RMS).
- More than 32 channels of TDC are tested in Altera Cyclone (EP1C6Q240C6, \$20) devices.




ADC Using FPGA

- Analog signals from AMP & Shapers are directly fed to FPGA pins.
- FPGA output and passive RC network are used to generate ramping reference voltage V_{REF}.
- The input voltages and V_{REF} are compared using FPGA differential input receiers.
- The times of transitions representing input voltage values are digitized by TDC blocks in FPGA.




TDC Using FPGA (LSB 1ns+-)




4x Sampling:

250 MHz: 1ns(LSB), 288ps(RMS)

400 MHz: 625ps(LSB), 180ps(RMS)




Digital FPGA Solutions Spartan 6 SP 605



Digital FPGA Solutions Virtex 6 ML605

FMC FMC (HPC)



Free running mode FPGA based Data Acquisition



FPGA Programming

VHDL (VHSIC Hardware Description Language) is a hardware description language used in electronic design automation to describe digital and mixedsignal systems such as fieldprogrammable gate arrays and integrated circuits. VHDL can also be used as a general purpose parallel programming language.

FPGA Programming

- VHDL is commonly used to write text models that describe a logic circuit. Such a model is processed by a synthesis program, only if it is part of the logic design. A simulation program is used to test the logic design using simulation models to represent the logic circuits that interface to the design. This collection of simulation models is commonly called a *testbench*.
- VHDL has file input and output capabilities, and can be used as a general-purpose language for text processing, but files are more commonly used by a simulation testbench for stimulus or verification data. There are some VHDL compilers which build executable binaries. In this case, it might be possible to use VHDL to write a *testbench* to verify the functionality of the design using files on the host computer to define stimuli, to interact with the user, and to compare results with those expected.

Suggested Reading

- Glenn F. Knoll, Radiation Detection and Measurement, John Wiley & Sons.
- Hernam Cember, Introduction to Health Physics, McGraw Hill.
- Nicholas Tsoulfanidis, Measurement and Detection of Radiation, Taylor & Francis.
- C.H. Wang, D.L.Willis, W.D. Loveland, Radiotracer Methodology in the Biological, Environmental and Physical Sciences, Prentice-Hall

Întrebări

- Denumiti standardele de achizitie existente.
- Care este diferenta la adresarea modulelor CAMAC si VME ?
- Ce înseamnă FPGA ?
- Care sunt principalele 3 componente ale unei FPGA ?
- Care este denumirea limbajului de programare principal pentru FPGA ?