## ZSPD AD 2.1 机场地名代码和名称 Aerodrome location indicator(ICAO / IATA) and name

ZSPD/PVG-上海/浦东 SHANGHAI/Pudong

## ZSPD AD 2.2 机场地理位置和管理资料 Aerodrome geographical and administrative data

1	机场基准点坐标及其在机场的位置	N31°08.7′ E121°47.6′	
1	ARP coordinates and site at AD	Center of RWY17L/35R	
2	机场基准点与城市的位置关系	108 °GEO, 32.3km from city center	
2	Direction and distance from city	100 GEO, 32.5km nom city center	
	机场标高、基准温度、低温均值		
3	ELEV/Reference temperature/Mean low	3.8 m/30.4°C(JUL)/1.4°C(JAN)	
	temperature		
4	机场标高位置的大地水准面波幅		
4	Geoid undulation at AD ELEV PSN		
5	磁差(测量年份)及年变率	5°47′W(2017)/-42″	
3	VAR(Year)/Annual change	3 47 W(2017)1-42	
		Shanghai Airport (Group) CO. LTD.	
	机场管理部门、地址、电话、传真、AFS 地	Nr. 900 Qi Hang street, Shanghai, China Post code:201207	
6	址、电子邮箱、网址	TEL:86-21-68347571[H24]; 86-21-68330073	
	AD administration/Address/Telephone/Telefax/	FAX:86-21-68347537[H24]; 86-21-68347281	
	AFS/ E-mail/Website	AFS:ZSPDYDYX	
		Website:www.shanghaiairport.com	
7	允许飞行种类	IFR-VFR	
,	Types of traffic permitted(IFR/VFR)		
8	机场性质/飞行区指标	CIVIL/RWY16L/34R, RWY16R/34L, RWY17R/35L: 4F; RWY17L/35R: 4E	
	Military or civil airport/Reference code	CIVILIKW 110L/JTK, KW 110K/JTL, KW 11/K/JJL. TI, KW 11/L/JJK. 4E	
9	备注	Nil	
9	Remarks	1411	

## ZSPD AD 2.3 工作时间 Operational hours

1	机场开放时间 AD Operational hours	H24
2	海关和移民 Customs and immigration	HS or O/R
3	卫生健康部门 Health and sanitation	HS or O/R
4	航空情报服务讲解室 AIS Briefing Office	H24
5	空中交通服务报告室 ATS Reporting Office	H24

6	气象服务讲解室 MET Briefing Office	H24
7	空中交通服务 Air Traffic Service	H24
8	加油服务 Fuelling	HS or O/R
9	地勤服务 Handling	HS or O/R
10	安保服务 Security	HS or O/R
11	除冰服务 De-icing	H24
12	备注 Remarks	Nil

## ZSPD AD 2.4 地勤服务和设施 Handling services and facilities

1	货物装卸设施	Lift(7t, 14t, 30t), platform trailer, container trailer, tow-tractor, cargo trailer,	
1	Cargo-handling facilities	container baggage trailer, conveyor truck	
2	燃油牌号	Jet Fuel No.3,Jet A-1	
2	Fuel types	Jet Fuel No.5, Jet A-1	
3	滑油牌号	(i t f -:1)	
3	Oil types	(various types of oil)	
	加油设施/能力	Tank refueller(65000L: 63L/s);	
4	Fuelling facilities & Capacity	hydrant dispenser: 63L/s;	
	ruching facilities & Capacity	hydrant pipeline and pit: 1000L/s	
5	除冰设施	De-icing apron(stands Nr. 510-512, 585, 586, 589, 590), 10 de-icers, de	
3	De-icing facilities	fluid(I, II, IV)	
6	过站航空器机库	AVBL	
0	Hangar space for visiting aircraft	AVDL	
7	过站航空器的维修设施	Airline repair: B737, B747, B767, B777, B787, A300, A320, A330, A340,	
/	Repair facilities for visiting aircraft	A350, A380	
		Air preconditioning unit, oxygen filling vehicle, aircraft traction rod(for	
8	备注	B737-A380), potable water vehicle, sewage disposal vehicle, garbage truck,	
8	Remarks	ferry vehicle, the disabled lift car, no power source car, forklift, bridge	
		equipment(400Hz), air-conditioning equipment	

## ZSPD AD 2.5 旅客设施 Passenger facilities

1	宾馆 Hotels	At AD and in the city
2	餐饮 Restaurants	At AD

3	交通工具 Transportation	Passenger's coaches,taxis, magnetic aero train	
4	医疗设施 Medical facilities	First-aid, 6 ambulances and medical center at AD	
5	银行和邮局 Bank and Post Office	At AD	
6	旅行社 Tourist Office	At AD TEL: 86-21-68346452	
7	备注 Remarks	Nil	

## ZSPD AD 2.6 援救与消防服务 Rescue and fire fighting services

1	机场消防等级 AD category for fire fighting	CAT 10	
2	援救设备 Rescue equipment	Fire fighting facilities: rapid intervention vehicle, primary foam tender, disassembly rescue truck, heavy-duty foam tender, medium-load foam tender, illumination truck, dry-chemical tender, lift rescue truck, small-scale foam tender, command car, rescue command car, logistics truck.  Rescue equipment: uplift air cushion, tethered hoisting equipment, damaged aircraft trailer, forklift, mobile pavement, tethered hoisting equipment, lifting equipment, wheelbarrow, towing rack and accessories, rubber cushion block, assault boat, narrow body aircraft rescue trailer, executive airplane rescue trailer, jack.	
3	搬移受损航空器的能力 Capability for removal of disabled aircraft	MTWA up to A380	
4	备注 Remarks	Nil	

## ZSPD AD 2.7 可用季节- 扫雪 Seasonal availability-clearing

1	可用季节及扫雪设备类型 Seasonal availability/Types of clearing equipment	All seasons Snow blowers, snow fluid truck
2	扫雪顺序 Clearance priorities	RWY→TWY→APN
3	备注 Remarks	Nil

## ZSPD AD 2.8 停机坪、滑行道及校正位置数据 Aprons, taxiways and check locations data

1	停机坪道面和强度 Apron surface and strength	道面 Surface	CONC
		强度 Strength	PCR 1060/R/B/W/T : 50-65, 67, 69, 71, 73, 75, 77, 79-98, 801-816 PCR 990/R/A/W/T : 501-509

PCR 990/R-BW/T: 611-626 PCR 990/R-W/T: 301-308 PCR 940/R/W/T: 501-1424 PCR 930/R/A-W/T: 201-211 PCR 920/R-BW/T: 110-341, 346, 347, Z11-Z16, Z21-Z26, Z31-Z38 PCR 790/R/A-W/T: 511-519 PCR 790/R/A-W/T: 511-519 PCR 790/R/A-W/T: 511-519 PCR 790/R/A-W/T: 401-AB, 402AB, 403AB, 404AB, 405-407, 408A/B, 409AB, 410AB, 411-418, 451-453, 458, 459  6m: V8 56m: K1, F2, S1, V7 46m: B6 4m: Q1-Qe 43.5m: J1, J2 40m: B2 34.5m: P6 34m: B1, B7 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 20m: A, A1-A6, B, C1, C2, C3, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, E, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7 ASPH: G(N of TWY G exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/341), R3(B of TWY D), P3(E of TWY G), P3(E of TWY D), P3(E of TWY D), P3(E of TWY G), P4(E of TWY G), P3(E of TWY G), P4(E of TWY G), P4(E of TWY G), P3(E of TWY G), P4(E of TWY G)	-		•	
PCR 940/R/A/WT: 6-12, 14-24 PCR 930/R/A/WT: 201-211 PCR 920/R/B/WT: 310-341, 346, 347, Z11-Z16, Z21-Z26, Z31-Z38 PCR 790/R/A/WT: 11-5, 25-322 PCR 770/R/A/WT: 101-190 PCR 750/R/A/WT: 510-512 PCR 740/R/A/WT: 510-512 PCR 740/R/A/WT: 510-512 PCR 710/R/A/WT: 510-512 PCR 710				PCR 990/R/B/W/T : 611-626
PCR 930/R/A/WT: 201-211 PCR 920/R/B/WT: 310:341, 346, 347, Z11-Z16, Z21-Z26, Z31-Z38 PCR 770/R/A/WT: 1-15, 25-32 PCR 770/R/A/WT: 150:190 PCR 750/R/A/WT: 581-586, 589, 590, 551-572 PCR 740/R/A/WT: 510:512 PCR 740/R/A/WT: 510:512 PCR 710/R/A/WT: 510:512 PCR 710/R/A/WT: 401A/B, 402A/B, 403A/B, 404A/B, 405-407, 408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459  69m: V8 56m: E1, E2, S1, V7 46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, E71-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-R6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/235R), P2-P6(BTN TWY A, AD), R1(BTN TWY G & RWY16R/34L), R2(B of TWY T8, R5(BTN TWY G & RWY16R/34L), R6(BTN TWY D, BTN TWY G & RWY16R/34L), R2(B of TWY D), P3(E of TWY A), P4(E of TWY Y D), P5(E of TWY Y D), P3(E of TWY A), P4(E of TWY G & W of RWY16R/34L), R6(E of TWY D), P3(E of TWY A), P4(E of TWY G & W of RWY16R/34L), R6(E of TWY D), P3(E of TWY A), P4(E of TWY G & W of RWY16R/34L), R6(E of TWY A), P4(E of TWY G & W of RWY16R/34L), R6(E of TWY B, R6(E of TWY G & W of RWY16R/34L), R6(E of TWY B, R6(E of TWY G & W of RWY16R/34L), R6(E of TWY B, R6(E of TWY G & W of RWY16R/34L), R6(E of TWY B, R6(E of TWY G & W of RWY16R/34L), R6(E of TWY B, R6(E of TWY G & W of RWY16R/34L), R6(				PCR 960/R/A/W/T : 301-308
PCR 920/R/B/WT: 310-341, 346, 347, Z11-Z16, Z21-Z26, Z31-Z38 PCR 790/R/A/WT: 1-5, 25-32 PCR 790/R/A/WT: 101-190 PCR 750/R/A/WT: 581-586, 589, 590, 551-572 PCR 740/R/A/WT: 581-586, 589, 590, 551-572 PCR 710/R/A/WT: 401A/B, 402A/B, 403A/B, 404A/B, 405-407, 408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459  69m: V8 56m: E1, E2, S1, V7 46m: B6 44m: Q1-Q6 43-5m: J1, J2 40m: B2 33-5m: B4 Width 33.5m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, E, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7 ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R2(E of TWY F), R4(E of TWY F), R5(E of TWY C6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, E, F1-F4, GBIT TWY G & RWY16R/34L), R2(E of TWY D), P3(E of TWY A), P4(E of TWY A), P4(E of TWY D), D1-Q6, R1(E of TWY E), R2(E of TWY C6, R2), P1 C6, P1 C7				PCR 940/R/A/W/T : 6-12, 14-24
PCR 790/R/A/WT: 1-5, 25-32 PCR 770/R/A/WT: 581-586, 589, 590, 551-572 PCR 740/R/A/WT: 581-586, 589, 590, 551-572 PCR 740/R/A/WT: 581-586, 589, 590, 551-572 PCR 740/R/A/WT: 401A/B, 402A/B, 404A/B, 405-407, 408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459 66m: V8 56m: E1, E2, S1, V7 46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C3, D4, E4, E4, E4, E4, E4, E4, E4, E4, E4, E				PCR 930/R/A/W/T : 201-211
PCR 770/R/A/W/T : 101-190 PCR 750/R/A/W/T : 581-586, 589, 590, 551-572 PCR 740/R/A/W/T : 581-586, 589, 590, 551-572 PCR 740/R/A/W/T : 581-586, 589, 590, 551-572 PCR 740/R/A/W/T : 401-A/B, 402A/B, 403A/B, 404A/B, 405-407, 408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459  69m : V8 56m : E1, E2, S1, V7 46m : B6 44m : Q1-Q6 43.5m : J1, J2 40m : B2 34.5m : P6 34m : B1, B7 33.5m : B4 33m : B5 31.5m : B8, P1 29.5m : B3 29m : A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m : C3, C4, D3, D4 25m : C3, C4, D3, D4 25m : C1, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m : V1-V6, W1, W4-W7  ASPH : G(n of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY D, BTN TWY D, BTN TWY G & W of TWY D), P3(E of TWY A & W of TWY D), P3(E of TWY A & W of TWY D), P3(E of TWY A & W of TWY D), P3(E of TWY Y A & W of TWY D), P3(E of TWY Y A & W of TWY Y D), P3(E of TWY Y A & W of TWY Y D), P3(E of TWY Y A & W of TWY Y D), P3(E of TWY Y A & W of TWY D), P3(E of TWY Y A & W of TWY D), P3(E of TWY Y A & W of TWY D), P3(E of TWY Y A & W of TWY D), P3(E of TWY Y A & W of TWY D), P3(E of TWY Y A & W of TWY D), P3(E of TWY Y A & W of TWY B), R3(E of TWY Y B), P3(E of TWY Y A & W of TWY B), R3(E of TWY Y B), P3(E of TWY B				PCR 920/R/B/W/T : 310-341, 346, 347, Z11-Z16, Z21-Z26, Z31-Z38
PCR 750/R/A/W/T:581-586, 589, 590, 551-572 PCR 740/R/A/W/T:510-512 PCR 710/R/A/W/T:401A/B, 402A/B, 403A/B, 404A/B, 405-407, 408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459  69m: V8 56m: E3l. E2, S1, V7 46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 34.5m: P6 34m: B1, B7 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, Al-A6, B, Cl, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exid, P1(BTN TWY D & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R3(E of TWY D), P3(E of TWY A), P4(E of TWY G1 & W of TWY D), P3(E of TWY A), P4(E of TWY G1 & W of TWY D), P3(E of TWY G2, W of TWY G3, W of TWY D), P3(E of TWY G2, W of TWY G3, W of TWY G3, W of TWY F), R4(E of TWY G2, W of RWY16R/34L), R3(E of TWY F), R2(E of TWY G3, W of RWY16R/34L), R3(E of TWY F), R2(E of TWY G3, W of RWY16R/34L), R3(E of TWY F), R2(E of TWY G3, W of RWY16R/34L), R3(E of TWY F), R3(E of TWY G3, W of RWY16R/34L), R3(E of TWY F), R3(E of TWY G3, W of RWY16R/34L), R3(E of TWY G4, W of RWY16R/34L), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R4(W of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R4(W of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R4(W of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R4(W of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY G4, N), R3(E of TWY F), R3(E of TWY				PCR 790/R/A/W/T : 1-5, 25-32
PCR 740/R/A/W/T: 510-512 PCR 710/R/A/W/T: 510-512 PCR 710/R/A/W/T: 401A/B, 403A/B, 404A/B, 405-407, 408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459 69m: V8 56m: E1, E2, S1, V7 46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 34.5m: B4 33m: B1, B7 33.5m: B4 33m: B1, B7 33.5m: B4 33m: B3, B1 29m: A, Al-A6, B, Cl, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, ED, E3-E8, E, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7 ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R3(E of TWY D), P3(E of TWY A, W of TWY D), P3(E of TWY A, W of TWY D), P3(E of TWY A, W of TWY D), P3(E of TWY G, W of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(E of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(E of TWY G, W of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(E of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(E of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(E of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(E of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(E of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G, W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G, W of RWY16R/34L), R5(E of TWY F), R5(E of TWY G, W of RWY16R/34L), R5(E of TWY F), R5(E of TWY G, W of RWY16R/34L), R5(E of TWY G, W OF RWY16R				PCR 770/R/A/W/T : 101-190
PCR 710/R/A/W/T: 401A/B, 402A/B, 403A/B, 404A/B, 405-407, 408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459  69m: V8 56m: E1, E2, S1, V7 46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 34.5m: B1, B7 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY A, B A, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G, BTN TWY G, BTN TWY G, BTN TWY G, W of TWY D), P3(E of TWY A, B A, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G, B, W of TWY D), P3(E of TWY A, B A, B), P3(E of TWY G, B, W of TWY D), P3(E of TWY G, B, W of TWY G, B), P4(E of TWY G, B, W of TWY G, B), P5(E of TWY F), R4(W of TWY F), R5(E of TWY G, B, W of RWY16R/34L), R3(E of TWY F), R5(E of TWY G, B, W of RWY16R/34L), R3(E of TWY F), R4(W of TWY F), R5(E of TWY G, B, W of RWY16R/34L), R3(E of TWY F), R4(W of TWY F), R5(E of TWY G, B, W of RWY16R/34L), R3(E of TWY F), R4(W of TWY F), R5(E of TWY G, B, W of RWY16R/34L), R3(E of TWY F), R4(W of TWY F), R5(E of TWY G, B, W of RWY16R/34L), R3(E of				PCR 750/R/A/W/T : 581-586, 589, 590, 551-572
409A/B, 410A/B, 411-418, 451-453, 458, 459  69m: V8 56m: E1, E2, S1, V7 46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 34.5m: P6 34m: B1, B7 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY G & RWY16R/34L), R3(B of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY G1, A), A, G, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G, & G(BTN TWY G1, C2), C0, C1, C2, C3, C4, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1, C2), C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1, C4), C2, C3, C4, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1, C4), C2, C3, C4, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1, C4), C4, C4, C4, C4, C5, C5, C6, D1, D2, D4, D4, D4, D4, D4, D4, D4, D4, D4, D4				PCR 740/R/A/W/T : 510-512
69m : V8   56m : E1, E2, S1, V7   46m : B6   44m : Q1-Q6   43.5m : J1, J2   40m : B2   34.5m : P6   34m : B1, B7   33.5m : B4   33m : B5   31.5m : B8, P1   29.5m : B3   29m : A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6   28m : C3, C4, D3, D4   25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3   23m : V1-V6, W1, W4-W7   ASPH : G(n of TWy G6 exit & S of TWy G1 exit), P1(BTN TWy D & RWY17L/35R), P2-P6(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R8(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY G1, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, GBTN TWY G1 & RWY17L/35R), P2(E of TWY A), P4(E of TWY A), P4(E of TWY A), P4(E of TWY D), P3(E of TWY A), P4(E of TWY C1, R3(W), P5(E of TWY A), P4(E of TWY C1, R3(W), P5(E of TWY C1, R3(E), P3, P3, P3, P4, P4), P3(W) of TWY D), P3(E of TWY C1, R3(E), P3, P4, P4), P3(W) of TWY D), P3(E) of TWY G1, R3(W) of TWY D				PCR 710/R/A/W/T : 401A/B, 402A/B, 403A/B, 404A/B, 405-407, 408A/B,
S6m : E1, E2, S1, V7   46m : B6   44m : Q1-Q6   43.5m : J1, J2   40m : B2   34.5m : P6   34m : B1, B7   33.5m : B4   33m : B5   31.5m : B8, P1   29.5m : B3   29m : A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6   28m : C3, C4, D3, D4   25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3   23m : V1-V6, W1, W4-W7   ASPH : G(n of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY G& RWY16R/34L), R3(E of TWY F), R3(E of TWY F), R5(BTN TWY G& RWY16R/34L), R3(E of TWY F), R4(E of TWY G1, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1& G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D), BTN TWY B& RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY D), P3(E of TWY G1& G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D), BTN TWY B& RWY17L/35R), P2(E of TWY A & W of TWY D), P5(E of TWY D), P3(E of TWY G1& G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D), P4(E of TWY G1& G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D), P4(E of TWY G1& W of RWY16R/34L), R3(W of TWY F), R3(E of TWY G1& W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G1& W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G1& W of RWY16R/34L), R6(E				409A/B, 410A/B, 411-418, 451-453, 458, 459
46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 34.5m: P6 34m: B1, B7 33.5m: B4 33.5m: B4 33.5m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R2(E of TWY F), R4(E of TWY F), R4(E of TWY F), R4(E of TWY F), R4(E of TWY G, R4), P4(E of TWY G, R4),				69m : V8
46m: B6 44m: Q1-Q6 43.5m: J1, J2 40m: B2 34.5m: P6 34m: B1, B7 33.5m: B4 33.5m: B4 33.5m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R2(E of TWY F), R4(E of TWY F), R4(E of TWY F), R4(E of TWY F), R4(E of TWY G, R4), P4(E of TWY G, R4),				56m : E1, E2, S1, V7
第度 Width 第2 34.5m: J1, J2 40m: B2 34.5m: P6 34m: B1, B7 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R2(E of TWY A), P4(E of TWY A), P4(E of TWY A), P4(E of TWY A), P4(E of TWY A), P5(E of TWY A), P6(E of TWY G), R5(E of TWY G), R1(E of TWY G), R4(W of TWY F), R5(E of TWY G), R3(L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G), R5(E of TWY G), R6(E of TWY G), W of RWY16R/34L), R2(E of TWY G), S1, S2(N of TWY F), R4(W of TWY F), R5(E of TWY G), S1, S2(N of TWY TS), T1-T6, V1-V8, W1-W7				
第度 Width 第2 34.5m: J1, J2 40m: B2 34.5m: P6 34m: B1, B7 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R2(E of TWY A), P4(E of TWY A), P4(E of TWY A), P4(E of TWY A), P4(E of TWY A), P5(E of TWY A), P6(E of TWY G), R5(E of TWY G), R1(E of TWY G), R4(W of TWY F), R5(E of TWY G), R3(L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G), R5(E of TWY G), R6(E of TWY G), W of RWY16R/34L), R2(E of TWY G), S1, S2(N of TWY F), R4(W of TWY F), R5(E of TWY G), S1, S2(N of TWY TS), T1-T6, V1-V8, W1-W7				
第度				
34.5m : P6 34m : B1, B7 33.5m : B4 33m : B5 31.5m : B8, P1 29.5m : B3 29m : A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m : C3, C4, D3, D4 25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m : V1-V6, W1, W4-W7  ASPH : G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, A & W of TWY D), P3(E of TWY A), P6(E of TWY G1&G6 exit), R3(W of TWY D), P3(E of TWY G1&G6 exit), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G2&W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G3&W of RWY16R/34L), R6(E of TWY G2&W of RWY16R/34L), R6(E of TWY G3&W of RWY16R/34L), R1-T6, V1-V8, W1-W7				
党度 Width  34m: B1, B7 33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, A&W of TWY D), Q1-Q6, R1(E of TWY A&W of TWY D), P3(E of TWY A&W of TWY D), R5(E of TWY G2&W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G2&W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G3&W of RWY16R/34L), R6(E of TWY G2&W of RWY16R/34L), R5(E of TWY G3&W of RWY16R/34L), R5(				
選及 Width  33.5m: B4 33m: B5 31.5m: B8, P1 29.5m: B3 29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY G& RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), R6(BTN TWY D, BTN TWY G & RWY16R/34L), R6(BTN TWY D, BTN TWY G1 & G1 TWY				
Width   33m : B5   31.5m : B8, P1   29.5m : B3   29m : A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6   28m : C3, C4, D3, D4   25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3   23m : V1-V6, W1, W4-W7   ASPH : G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)   CONC : A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1 & G exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D), BTN TWY B & RWY17L/35R), P2(E of TWY A), P4(E of TWY A), P4(E of TWY A), P4(E of TWY A), P4(E of TWY G2 & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G2 & W of RWY16R/34L), R3(W of TWY G3 & W of RWY16R/34L), R4(W of TWY G3 & W of RWY16R/34L), R5(E of TWY G4 & W of RWY15B, T1-F6, V1-V8, W1-W7				
31.5m : B8, P1 29.5m : B3 29m : A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m : C3, C4, D3, D4 25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m : V1-V6, W1, W4-W7  ASPH : G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY D), P3(E of TWY A), P4(E of TWY A), P5(E of TWY A), P5(E of TWY A), P4(E of TWY B), P5(E of TWY B				
29.5m : B3 29m : A, Al-A6, B, Cl, C2, C5, C6, Dl, D2, D5, D6 28m : C3, C4, D3, D4 25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m : V1-V6, W1, W4-W7  ASPH : G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC : A, Al-A6, B, Bl-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R3(W of TWY G & W of RWY16R/34L), R6(E of TWY G & W of				
29m: A, A1-A6, B, C1, C2, C5, C6, D1, D2, D5, D6 28m: C3, C4, D3, D4 25m: C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY G& RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G& RWY16R/34L), R6(BTN TWY G& RWY16R/34L), S2(S of TWY T5) CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1& G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B& RWY17L/35R), P2(E of TWY A), P4(E of TWY A), P4(E of TWY A) & W of TWY D), P5(E of TWY A), P6(E of TWY A), P4(E of TWY G), R1(E of TWY G), R1(E of TWY G), R2(E of TWY G), R3(E				
28m : C3, C4, D3, D4 25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m : V1-V6, W1, W4-W7  ASPH : G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R2(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), R2(S of TWY T5) CONC : A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A) & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
25m : C, D, E, E0, E3-E8, F, F1-F4, G, G1-G6, H, H1-H6, P2-P5, R1-R6, S2, T1-T6, W2, W3 23m : V1-V6, W1, W4-W7  ASPH : G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC : A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R1-F6, V1-V8, W1-W7		Taxiway width, surface		
T1-T6, W2, W3 23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), P3(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R5(E of TWY G & W of RWY16R/34L), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R5(E of TWY G				
23m: V1-V6, W1, W4-W7  ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R1-T6, V1-V8, W1-W7	2			
ASPH: G(N of TWY G6 exit & S of TWY G1 exit), P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7	2			
RWY17L/35R), P2-P6(BTN TWY A&D), R1(BTN TWY G & RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
RWY16R/34L), R2(BTN TWY G & RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
of TWY F), R5(BTN TWY G & RWY16R/34L), R6(BTN TWY G & RWY16R/34L), S2(S of TWY T5)  CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
RWY16R/34L), S2(S of TWY T5)  CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
CONC: A, A1-A6, B, B1-B8, C, C1-C6, D, D1-D6, E, E0-E8, F, F1-F4, G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
道面 Surface  G(BTN TWY G1&G6 exit), G1-G6, H, H1-H6, J1, J2, P1(W of TWY D, BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
Surface  BTN TWY B & RWY17L/35R), P2(E of TWY A & W of TWY D), P3(E of TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), R5(E of TWY G & W of RWY16R/34L), R5(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7			道面	
TWY A), P4(E of TWY A & W of TWY D), P5(E of TWY A), P6(E of TWY A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
A & W of TWY D), Q1-Q6, R1(E of TWY G & W of RWY16R/34L), R2(E of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
of TWY G & W of RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
R5(E of TWY G & W of RWY16R/34L), R6(E of TWY G & W of RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7				
强度 PCR 1780/F/C/X/T: P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY				RWY16R/34L), S1, S2(N of TWY T5), T1-T6, V1-V8, W1-W7
			强度	PCR 1780/F/C/X/T : P1(BTN TWY D & RWY17L/35R), P2-P6(BTN TWY

		C441.	4 8 70)	
		Strength	A&D)	
			PCR 1680/F/C/X/T: R1(BTN TWY G & RWY16R/34L), R2(BTN TWY G	
			& RWY16R/34L), R3(E of TWY F), R4(E of TWY F), R5(BTN TWY G &	
			RWY16R/34L), R6(BTN TWY G & RWY16R/34L)	
			PCR 1620/F/C/X/T: G(N of TWY G6 exit & S of TWY G1 exit)	
			PCR 1100/R/A/W/T : B7	
			PCR 1030/R/B/W/T: S1, S2, T5, T6	
			PCR 1000/R/A/W/T : A1-A4	
			PCR 980/R/A/W/T : B2-B6, F1-F4	
			PCR 960/R/A/W/T : B8	
			PCR 950/R/A/W/T : B1, C1, C2, C5, C6, D1, D2, D5, D6	
			PCR 940/R/A/W/T : A5, A6	
			PCR 910/R/A/W/T : A, B	
			PCR 900/R/A/W/T : P1(BTN TWY B & RWY17L/35R)	
			PCR 890/R/A/W/T : H1-H6, J1, J2	
			PCR 880/R/A/W/T : Q1-Q6	
			PCR 870/R/A/W/T : E0-E8, W1-W7	
			PCR 860/R/A/W/T : G2-G5	
			PCR 850/R/A/W/T : G1, G6	
			PCR 840/R/A/W/T : P3(E of TWY A), P4(E of TWY A & W of TWY D)	
			PCR 820/R/A/W/T : H, P2(E of TWY A & W of TWY D), P5(E of TWY A)	
			PCR 810/R/A/W/T : C3, C4, D3, D4, R2(E of TWY G & W of	
			RWY16R/34L), R3(W of TWY F), R4(W of TWY F), R5(E of TWY G & W	
			of RWY16R/34L)	
			PCR 790/R/A/W/T : C, D, E, F, T3, T4, V3-V8	
			PCR 780/R/A/W/T : G(BTN TWY G1&G6 exit)	
			PCR 770/R/A/W/T : P6(E of TWY A & W of TWY D)	
			PCR 750/R/A/W/T : R1(E of TWY G & W of RWY16R/34L), R6(E of TWY	
			G & W of RWY16R/34L)	
			PCR 740/R/A/W/T : P1(W of TWY D), T1, T2, V1, V2	
	高度表校正点的位置及			
2	其标高	NU		
3	ACL location and	Nil		
	elevation			
	VOR 校正点			
4	VOR checkpoints	Nil		
	INS 校正点			
5	INS checkpoints	Nil		
	备注			
6		Nil		
	Remarks			

## ZSPD AD 2.9 地面活动引导和管制系统与标识 Surface movement guidance and control system and markings

		Taxiing guidance signs at all intersections of TWY and RWY.			
	航空器机位号码标记牌、滑行道引导	Taxiing guidance signs at all holding positions.			
		Aircraft stand identification sign boards at stands Nr. 1-12, 14-32, 50-65, 67, 69,			
		71, 73, 75, 77, 79	-98, 101-190, 201-211, 301-308, 310-341, 346, 347, 401A, 401B,		
	线、航空器目视停靠引导系统的使用	402A, 402B, 403A, 403B, 404A, 404B, 405, 408A, 408B, 409A, 409B, 410A,			
1	Use of aircraft stand ID signs, TWY	410B, 501-509, 5	410B, 501-509, 551-572, 581-586, 589, 590, 611-626, 801-816.		
	guide lines and visual docking / parking	Guide lines at all	Guide lines at all TWYs.		
	guidance system of aircraft stands	Guide lines at all aprons.			
		Visual docking gu	sidance system at aircraft stands Nr. 1-12, 14-32, 50-65, 67, 69,		
		71, 73, 75, 77, 79	-89, 91-94, 97, 98, 101-110, 112-123, 125-129, 131-156, 158,		
		159, 161-177, 179	9-190, Marshalling assistance for other aircraft stands.		
		跑道标志	THR, RWY designation, edge line, RWY center line, TDZ,		
		RWY markings	aiming point		
		跑道灯光	RTHL, WBAR, REDL, RCLL, RTZL(16R, 17L, 34L, 35R),		
		RWY lights	RENL		
	跑道和滑行道标志及灯光 RWY and TWY marking and LGT		Edge line, center line, TWY shoulder marking, No-entry,		
2		滑行道标志 TWY markings	mandatory instruction marking, information signs, RWY		
			holding position, intermediate holding position		
			Edge line lights, center line lights, No-entry bar(A1-A6, C1-C6,		
		滑行道灯光	D1-D6, F1-F4, G1-G6, H1-H6) , RETILs(A1-A6 , C1-C6 ,		
		TWY lights	D1-D6、F1-F4、G1-G6、H1-H6), intermediate holding position		
			lights		
		Stop bar lights: 16	5R/34L: Type B RWY holding position of TWY E(BTN TWY		
		E0&R1) on the W of RWY.			
		17L/35R: Type B RWY holding position of TWYs P1, P2, P4, P6, B1, B7, B8 on			
3	停止排灯和跑道警戒灯	1	pe B RWY holding position of TWY P1-P6 on the W of RWY.		
	Stop bars and runway guard lights		hts: Type A(vertical): both sides of type A RWY holding position		
		and stop bars lights of fast exit TWY.			
		Type B(embedded): the cross-taxiway at type A RWY holding position.			
	其它跑道保护措施				
4	Other runway protection measures	Nil			
		Temporary stand	taxiline is bule; dedicated stand taxiline is yellow dotted line.		
_	备注	Stop bars lights only works when RVR < 550m or CIG < 60m and is controlled			
5	Remarks	by TWR.			
		Runway guard lights works when RWY operating.			

## ZSPD AD 2.10 机场障碍物 Aerodrome obstacles

Obstacles within a circle with a radius of 15km (centered on the ARP)							
障碍物名称 或编号 Obstacle ID/ Designation	障碍物类型 Obstacle type	障碍物位置 磁方位( 9/距离(m) Obstacle position MAG BRG(degree)/DIST(m)	标高或 (高) Elevation /(Height) (m)	障碍物标志, 灯光 类型及颜色 Obstacle marking /Lighting Type & Colour	影响的飞行程序及 起飞航径区/备注 Flight procedure/take-off path area affected & Remarks		
1	2	3	4	5	6		
BLDG 001	BLDG	009/2375	54.0	LGT			
Pole 002	Pole	010/2180	40.5				
BLDG 003	BLDG	012/2121	51.6	LGT			
Antenna 004	Antenna	062/2485	18.4				
Antenna 005	Antenna	063/2661	17.1	LGT			
Control TWR 006	Control TWR	099/931	106.3	LGT	CAT A/B/C Circling		
Control TWR 007	Control TWR	099/3734	67.9	LGT			
Antenna 008	Antenna	107/681	48.9	LGT			
Antenna 009	Antenna	122/3584	17.5	LGT			
Antenna 010	Antenna	123/3440	18.5	LGT			
CRANE 011	CRANE	128/5882	54.4	LGT			
CRANE 012	CRANE	128/6114	54.4	LGT			
CRANE 013	CRANE	132/6136	50.0		RWY16L TKOF path		
CRANE 014	CRANE	134/5953	50.0		RWY16L/R TKOF path		

Obstacles within a c	•	dius of 15km (centered on t	he ARP)		
障碍物名称 或编号 Obstacle ID/ Designation	障碍物类型 Obstacle type	障碍物位置 磁方位( 9/距离(m) Obstacle position MAG BRG(degree)/DIST(m)	标高或 (高) Elevation /(Height) (m)	障碍物标志, 灯光 类型及颜色 Obstacle marking /Lighting Type & Colour	影响的飞行程序及 起飞航径区/备注 Flight procedure/take-off path area affected & Remarks
CRANE 015	CRANE	134/6087	50.0		RWY16L/R TKOF path
TOWER 016	TOWER	144/5211	36.8		RWY16R TKOF path
WATER_TOWER 017	WATER_T OWER	145/5514	33.1		RWY16R TKOF path
Pole 018	Pole	147/5857	40.1		RWY16R TKOF path
Pole 019	Pole	147/6109	28.9		
WINDMILL 020	WINDMI LL	150/13625	116.8		
WINDMILL 021	WINDMI LL	150/14044	117.3		
WINDMILL 022	WINDMI LL	150/14483	117.3		
WINDMILL 023	WINDMI LL	151/13231	117.0		
WINDMILL 024	WINDMI LL	151/13815	116.5		
TOWER 025	TOWER	153/13209	33.4		
WINDMILL 026	WINDMI LL	153/13399	117.3		
WINDMILL 027	WINDMI LL	153/14009	117.5		RWY34L/R GP INOP Final approach; RWY35R VOR/DME Final approach
WINDMILL 028	WINDMI LL	153/17501	122.8	LGT	RWY34L/R traditional Initial and Intermediate approach; RWY35L/R traditional Initial approach
Pole 029	Pole	154/12953	28.9		

Obstacles within a	circle with a ra	dius of 15km (centered on t	he ARP)		
障碍物名称 或编号 Obstacle ID/ Designation	障碍物类型 Obstacle type	障碍物位置 磁方位( %)距离(m) Obstacle position MAG BRG(degree)/DIST(m)	标高或 (高) Elevation /(Height) (m)	障碍物标志, 灯光 类型及颜色 Obstacle marking /Lighting Type & Colour	影响的飞行程序及 起飞航径区/备注 Flight procedure/take-off path area affected & Remarks
TOWER 030	TOWER	156/10803	50.5	LGT	RWY34L/R GP INOP Final approach
TOWER 031	TOWER	158/8357	50.2	LGT	
TOWER 032	TOWER	158/8566	43.7	LGT	
TOWER 033	TOWER	165/13275	47.0	LGT	
Pole 034	Pole	167/13269	39.3		
TOWER 035	TOWER	167/14883	60.7	LGT	RWY35R GP INOP approach
TOWER 036	TOWER	170/10258	54.8		RWY35L/R GP INOP Final approach
TOWER 037	TOWER	171/11848	49.0		
Antenna 038	Antenna	172/1691	18.1	LGT	
TOWER 039	TOWER	172/4624	36.6		RWY17L/R TKOF path
TOWER 040	TOWER	172/5136	48.0	LGT	RWY17L/R TKOF path
TOWER 041	TOWER	175/13498	61.8	LGT	RWY35L GP INOP Final approach
Antenna 042	Antenna	179/1713	18.6	LGT	
Pole 043	Pole	179/11216	35.3		
TOWER 044	TOWER	182/5734	48.7	LGT	
TOWER 045	TOWER	185/7785	62.1		RWY35R VOR/DME Final approach

ircle with a rac	lius of 15km (centered on t	he ARP)		
障碍物类 型 Obstacle type	障碍物位置 磁方位( 9/距离(m) Obstacle position MAG BRG(degree)/DIST(m)	标高或 (高) Elevation /(Height) (m)	障碍物标志, 灯光 类型及颜色 Obstacle marking /Lighting Type & Colour	影响的飞行程序及 起飞航径区/备注 Flight procedure/take-off path area affected & Remarks
BLDG	204/10161	149.9	LGT	CAT D Circling
TOWER	208/10851	108.2	LGT	
Pole	220/7001	58.5		
STACK	230/5637	65.6		
TOWER	241/4467	52.7	LGT	
TOWER	242/4695	47.8	LGT	
Antenna	279/4475	23.7	LGT	
TRANSM ISSION_L INE	289/4814	47.9		
Antenna	295/3883	46.5	LGT	
Antenna	307/10918	98.8	LGT	
Antenna	331/1154	18.6	LGT	
TOWER	332/9212	43.7	LGT	
Antenna	332/12732	59.0		
TOWER	337/5628	29.7	LGT	
Antenna	338/10042	32.8		
	障碍物类型Obstacle type BLDG TOWER Pole STACK TOWER TOWER Antenna TRANSM ISSION_L INE Antenna Antenna TOWER Antenna TOWER	障碍物失 型	下降時代   一般方位(今)距离(m)	障碍物美型   (高)

Obstacles within a circle with a radius of 15km (centered on the ARP)

Obstacies within a c	ircie with a rad	dius of 15km (centered on t	ne ARP)		
障碍物名称 或编号 Obstacle ID/ Designation	障碍物类型 Obstacle type	障碍物位置 磁方位( 9/距离(m) Obstacle position MAG BRG(degree)/DIST(m)	标高或 (高) Elevation /(Height) (m)	障碍物标志, 灯光 类型及颜色 Obstacle marking /Lighting Type & Colour	影响的飞行程序及 起飞航径区/备注 Flight procedure/take-off path area affected & Remarks
TOWER 061	TOWER	339/11172	50.3	LGT	
BLDG 062	BLDG	341/8818	54.2		
TOWER 063	TOWER	342/7009	55.8	LGT	RWY17R GP INOP Final approach
Pole 064	Pole	343/12894	34.8		
Antenna 065	Antenna	344/1691	18.0		
TOWER 066	TOWER	345/4724	41.4	LGT	RWY35R TKOF path
TOWER 067	TOWER	346/7947	39.3		
STACK 068	STACK	347/13608	64.6	LGT	RWY17L/R GP INOP, RWY17L VOR/DME Final approach
TOWER 069	TOWER	348/5002	46.8	LGT	RWY35R TKOF path
TOWER 070	TOWER	349/5267	46.7	LGT	RWY35R TKOF path
TOWER 071	TOWER	350/4313	33.8	LGT	RWY35R TKOF path
Pole 072	Pole	354/7780	57.3		RWY17L GP INOP, VOR/DME Final approach
Antenna 073	Antenna	356/3766	47.9	LGT	

半径 15 千米-50 千米内主要障碍物 (相对机场 ARP)

Obstacles between two circles with the radius of 15km and 50km (centered on the ARP)

障碍物名称 或编号 Obstacle ID/ Designation	障碍物类型 Obstacle type	障碍物位置 磁方位( %)距离(m) Obstacle position MAG BRG(degree)/DIST(m)	标高或 (高) Elevation /(Height) (m)	障碍物标志、灯光 类型及颜色 Obstacle marking /Lighting Type & Colour	影响的飞行程序及 起飞航径区/备注 Flight procedure/take-off path area affected & Remarks				
STACK 074	STACK	154/16233	51						
TOWER 075	TOWER	155/16966	93						
STACK 076	STACK	259/32421	215	LGT					
Pole 077	Pole	272/31600	222	LGT					
Pole 078	Pole	290/28475	156	LGT					
BLDG 079	BLDG	292/34055	284	LGT					
BLDG 080	BLDG	293/17859	324	LGT	RWY16L/R, 17L/R traditional Initial approach				
BLDG 081	BLDG	296/29419	494	LGT					
BLDG 082	BLDG	296/29564	635		Sector				
Pole 083	Pole	296/29603	423	LGT					
Antenna 084	Antenna	297/30332	466	LGT					
Pole 085	Pole	303/27289	230	LGT					
STACK 086	STACK	327/30036	245	LGT	RWY16L/R, 17L/R Initial approach				
BLDG 087	BLDG	357/32273	216	LGT	Sector; RWY16L/R, 17L/R Initial approach				
备注: Other obstac	备注: Other obstacles refer to AD OBST chart.								

## ZSPD AD 2.11 提供的气象情报、气象观测和报告 Meteorological information provided & meteorological observations and reports

提供的	的气象情报	
	prological information provided	
1	相关气象台的名称 Associated MET Office	MET Center of Shanghai Pudong AD MET Office
2	气象服务时间、服务时间以外的责任气象台 Hours of service/MET Office outside hours	H24
3	负责编发 TAF 的气象台、有效时段、发布间隔 Office responsible for TAF preparation/Periods of validity/Interval of issuance	MET Center of East ATMB MET Center;9h(important guarantee), 30h;3h(important guarantee), 6h
4	趋势预报及发布间隔 Trend forecast/Interval of issuance	trend 30min
5	所提供的讲解或咨询服务 Briefing/Consultation provided	Briefing provided: P, T
6	飞行文件及其使用语言 Flight documentation/Language(s) used	Chart, INTL MET Codes, Abbreviated Plain Language TXT;Ch,En
7	讲解或咨询服务时可利用的图表和其它信息 Charts and other information available for briefing or consultation	Synoptic charts, real-time data, FCST, satellite and radar material, data FCST product
8	提供气象情报的辅助设备 Supplementary equipment available for providing information	FAX, MET SER Terminal
9	提供气象情报的空中交通服务单位 ATS units provided with information	Pudong Tower, Shanghai ACC, Shanghai Approach
10	其他信息 Additional information	Nil
气象		
Meteo	prological observations and reports	
1	机场观测类型与频率、自动观测设备 Type & frequency of observation /Automatic observation equipment	Half hourly plus special observation plus special observation/Yes
2	气象报告类型及所包含的补充资料 Type of MET Report/Supplementary information included	METAR, SPECI
3	观测系统及安装位置 Observation system/Site(s)	RVR EQPT A: 100m W of RCL16L/34R, 323m inward THR16L; B: 100m W of RCL16L/34R, 1660m inward THR34R; C: 100m W of RCL16L/34R, 323m inward THR34R; D: 110m E of RCL16R/34L, 340m inward THR16R;

		E: 120m E of RCL16R/34L, 1900m inward THR34L;
		F: 110m E of RCL16R/34L, 340m inward THR34L;
		G: 120m W of RCL17L/35R, 330m inward THR17L;
		H: 120m W of RCL17L/35R, 2000m inward THR17L;
		J: 120m W of RCL17L/35R, 330m inward THR35R;
		K: 100m E of RCL17R/35L, 340m inward THR17R;
		L: 100m E of RCL17R/35L, 1660m inward THR35L;
		M: 100m E of RCL17R/35L, 310m inward THR35L.
		SFC wind sensors
		16R: 120m E of RCL, 336m inward THR;
		34L: 120m E of RCL, 336m inward THR;
		16L: 110m W of RCL, 343m inward THR;
		34R: 110m W of RCL, 343m inward THR;
		16L/34R center: 110m W or RCL, 1650m inward THR34R;
		17L: 120m W of RCL, 330m inward THR;
		35R: 120m W of RCL, 330m inward THR;
		17L/35R center: 125m W of RCL, 2000m inward THR35R;
		17R: 107m E of RCL, 325m inward THR;
		35L: 107m E of RCL, 325m inward THR;
		17R/35L center: 107m E of RCL, 1650m inward THR35L.
		Ceilometer
		16R: 1040m N of RCL extension line;
		34L: 1040m S of RCL extension line;
		17L: N end MM;
		35R: S end MM;
		17R: 115m E of RCL, 335m inward THR;
		35L: 115m E of RCL, 335m inward THR;
		16L: 8m E of RCL, 905m outward THR;
		34R: 8m E of RCL, 905m outward THR.
	观测系统的工作时间	
4	Hours of operation for meteorological observation	H24
	system	
	气候资料	
5	Climatological information	Climatological tables AVBL
	其他信息	
6	Additional information	Nil

# ZSPD AD 2.12 跑道物理特征 Runway physical characteristics

跑道号码 RWY Designator	真方位和 磁方位 TRUE & MAG BRG	跑道长宽 Dimensions of RWY(m)	跑道强度、跑道和停 止道道面 RWY strength/ Surface of RWY/SWY	跑道入口坐标、 跑道未端坐标、 跑道入口大地水 准面波幅 THR coordinates & RWY end coordinates & THR geoid undulation	跑道入口标高和 精密进近跑道接 地带最高标高 THR elevation & highest elevation of TDZ of precision APP RWY	跑道和停止道坡 度 Slope of RWY/SWY
1	2	3	4	5	6	7
16L	162.01 °GEO 168 °MAG	3800×60	PCR 980/R/B/W/T CONC/-	Nil	THR 3.6m	0.01%(1900m)/-0 .01%(1900m)
34R	342.02 °GEO 348 °MAG	3800×60	PCR 980/R/B/W/T CONC/-	Nil	THR 3.6m	0.01%(1900m)/-0 .01%(1900m)
16R	162.01 °GEO 168 °MAG	3800×60	PCR 960/R/B/W/T CONC/-	Nil	THR 3.4m	0.02%(1900m)/-0 .02%(1900m)
34L	342.02 °GEO 348 °MAG	3800×60	PCR 960/R/B/W/T CONC/-	Nil	THR 3.4m	0.02%(1900m)/-0 .02%(1900m)
17L	162 °GEO 168 °MAG	4000×60	PCR 890/R/A/W/T CONC/-	Nil	THR 3.0m	0.00%
35R	342 °GEO 348 °MAG	4000×60	PCR 890/R/A/W/T CONC/-	Nil	THR 3.1m	0.00%
17R	161.99 °GEO 168 °MAG	3400×60	PCR 930/R/A/W/T CONC/-	Nil	THR 3.6m	0%
35L	342.1 °GEO 348 °MAG	3400×60	PCR 930/R/A/W/T CONC/-	Nil	THR 3.6m	0%
跑道号码 RWY Designator	停止道长宽 SWY dimensions (m)	净空道长宽 CWY dimensions (m)	升降带长宽 Strip dimensions (m)	跑道端安全区 长宽 RESA dimensions (m)	拦阻系统的 位置及描述 Location& Description of arresting system	无障碍物区 OFZ
1	8	9	10	11	12	13
16L	Nil	Nil	3920×280	240×150	Nil	Nil
34R	Nil	Nil	3920×280	240×150	Nil	Nil
16R	Nil	Nil	3920×280	235×150	Nil	Nil
34L	Nil	Nil	3920×280	235×150	Nil	Nil
17L	Nil	Nil	4120×280	235×150	Nil	Nil
35R	Nil	Nil	4120×280	235×150	Nil	Nil

跑道号码 RWY Designator	停止道长宽 SWY dimensions (m)	净空道长宽 CWY dimensions (m)	升降带长宽 Strip dimensions (m)	跑道端安全区 长宽 RESA dimensions (m)	拦阻系统的 位置及描述 Location& Description of arresting system	无障碍物区 OFZ
1	8	9	10	11	12	13
17R	Nil	Nil	3520×280	230×150	Nil	Nil
35L	Nil	Nil	3520×280	230×150	Nil	Nil

Remarks: 1. RWYs grooved at full LEN, WID 60m;

 $2. \quad DIST \ BTN \ RCL16R/34L \ and \ RCL17L/35R \ is \ 2260m; \ THR16R \ is \ 1000m \ S \ of \ THR17L; \ THR34L \ is \ 800m \ S \ of \ THR35R; \ DIST \ BTN \ RCL16R/34L \ and \ RCL16R/34L \ is \ 440m.$ 

## ZSPD AD 2.13 公布距离 Declared distances

跑道号码	可用起飞滑跑距离	可用起飞距离	可用加速停止距离	可用着陆距离	备注
RWY Designator	TORA(m)	TODA(m)	ASDA(m)	LDA(m)	Remarks
1	2	3	4	5	6
16L	3800	3800	3800	3800	Nil
16L	3700	3700	3700	3800	FM J2
16L	3263	3263	3263	3800	FM R5
34R	3800	3800	3800	3800	Nil
34R	3700	3700	3700	3800	FM J1
34R	3176	3176	3176	3800	FM R2
16R	3800	3800	3800	3800	Nil
16R	3700	3700	3700	3800	FM E5
16R	3320	3320	3320	3800	FM R5
34L	3800	3800	3800	3800	Nil
34L	3700	3700	3700	3800	FM E0
34L	3230	3230	3230	3800	FM R2
17L	4000	4000	4000	4000	Nil
17L	3780	3780	3780	4000	FM B7
17L	3386	3386	3386	4000	FM P6
35R	4000	4000	4000	4000	Nil
35R	3780	3780	3780	4000	FM B1
35R	3200	3200	3200	4000	FM P2
17R	3400	3400	3400	3400	Nil
17R	3200	3200	3200	3400	FM Q6
35L	3400	3400	3400	3400	Nil
35L	3200	3200	3200	3400	FM Q1

# ZSPD AD 2.14 进近和跑道灯光 Approach and runway lighting

跑道 号码 RWY Desig nator	进近灯 类型、长 度、强度 APCH LGT type/ LEN/ /INTST	入口灯 颜色、翼 排灯 THR LGT colour/ WBAR	目视进近坡度 指示系统类 型、位置、仰 角、跑道入口 最低眼高 Type of VASIS/Position /Angle/MEHT	接地 带 灯长 度 TDZ LGT LEN	跑道中线灯长度、 间隔、颜色、强度 RWY center line LGT LEN/Spacing /Colour/INTST	跑道边灯长度、间隔、颜色、强度 RWY edge LGT LEN/Spacing /Colour/INTST	跑道末端灯 颜色 RWY end LGT colour	停止道灯长 度、颜色 SWY LGT LEN /Colour
1	2	3	4	5	6	7	8	9
16L	PALS CAT I SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 454m inward THR16L 3° 20.9m	Nil	3800 m spacing 15m 0-2900m, WHITE 2900-3500m, RED/WHITE 3500-3800m, RED VRB LIH	3800 m spacing 60m 0-3200m, WHITE 3200-3800m, YELLOW VRB LIH	RED	Nil
34R	PALS CAT I SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 455m inward THR34R 3° 21.5m	Nil	3800 m spacing 15m 0-2900m, WHITE 2900-3500m, RED/WHITE 3500-3800m, RED VRB LIH	3800 m spacing 60m 0-3200m, WHITE 3200-3800m, YELLOW VRB LIH	RED	Nil
16R	PALS CAT II/III SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 452m inward THR16R 3° 21.9m	900 m	3800 m spacing 15m 0-2900m, WHITE 2900-3500m, RED/WHITE 3500-3800m, RED VRB LIH	3800 m spacing 60m 0-3200m, WHITE 3200-3800m, YELLOW VRB LIH	RED	Nil
34L	PALS CAT II/III SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 452m inward THR34L 3° 22.4m	900 m	3800 m spacing 15m 0-2900m, WHITE 2900-3500m, RED/WHITE 3500-3800m, RED VRB LIH	3800 m spacing 60m 0-3200m, WHITE 3200-3800m, YELLOW VRB LIH	RED	Nil

跑道 号码 RWY Desig nator	进近灯 类型、长 度、强度 APCH LGT type/ LEN/ /INTST	入口灯 颜色、翼 排灯 THR LGT colour/ WBAR	目视进近坡度 指示系统类 型、位置、仰 角、跑道入口 最低眼高 Type of VASIS/Position /Angle/MEHT	接地 带 发 TDZ LGT LEN	跑道中线灯长度、 间隔、颜色、强度 RWY center line LGT LEN/Spacing /Colour/INTST	跑道边灯长度、间隔、颜色、强度 RWY edge LGT LEN/Spacing /Colour/INTST	跑道末端灯 颜色 RWY end LGT colour	停止道灯长 度、颜色 SWY LGT LEN /Colour
17L	PALS CAT II/III SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 464m inward THR17L 3° 21.7m	900 m	4000 m spacing 15m 0-3100m, WHITE 3100-3700m, RED/WHITE 3700-4000m, RED VRB LIH	4000 m spacing 60m 0-3400m, WHITE 3400-4000m, YELLOW VRB LIH	RED	Nil
35R	PALS CAT II/III SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 464m inward THR35R 3° 22.5m	900 m	4000 m spacing 15m 0-3100m, WHITE 3100-3700m, RED/WHITE 3700-4000m, RED VRB LIH	4000 m spacing 60m 0-3400m, WHITE 3400-4000m, YELLOW VRB LIH	RED	Nil
17R	PALS CAT I SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 452m inward THR17R 3° 21.4m	Nil	3400 m spacing 30m 0-2500m, WHITE 2500-3100m, RED/WHITE 3100-3400m, RED VRB LIH	3400 m spacing 60m 0-2800m, WHITE 2800-3400m, YELLOW VRB LIH	RED	Nil
35L	PALS CAT I SFL 900 m VRB LIH	GREEN Yes	PAPI LEFT 452m inward THR35L 3° 21.0m	Nil	3400 m spacing 30m 0-2500m, WHITE 2500-3100m, RED/WHITE 3100-3400m, RED VRB LIH	3400 m spacing 60m 0-2800m, WHITE 2800-3400m, YELLOW VRB LIH	RED	Nil
Remark	ks:							

# ZSPD AD 2.15 其它灯光,备份电源 Other lighting, secondary power supply

1	机场灯标或识别灯标位置、特性和工作时间 ABN/IBN location, characteristics and hours of operation	Nil
2	着陆方向标和风向标位置和灯光 LDI/ WDI location and LGT	WDI:  16L: 100m E of RCL, 405m inward THR, LGT;  34R: 100m W of RCL, 405m inward THR, LGT;  16R: 100m W of RCL, 350m inward THR, LGT;  34L: 100m W of RCL, 350m inward THR, LGT;  17L: 115m E of RCL, 350m inward THR, LGT;  35R: 115m E of RCL, 350m inward THR, LGT;  17R: 120m E of RCL, 350m inward THR, LGT;  35L: 120m W of RCL, 350m inward THR, LGT.
3	滑行道边灯和滑行道中线灯 TWY edge and center line lighting	All TWYs: green center line lights, blue edge line lights
4	备份电源及转换时间 Secondary power supply/Switch-over time	Standby PWR supply AVBL; 1s for RWY LGT, APCH LGT and stop bars LGT of RWY17L/35R and 16R/34L; 15s for other LGTs of RWY17L/35R and 16R/34L; 15s for all LGTs of RWY17R/35L and 16L/34R.
5	备注 Remarks	Nil

## ZSPD AD 2.16 直升机着陆区域 Helicopter landing area

_		
1	TLOF 坐标或 FATO 入口坐标及大地水准 面波幅 Coordinates TLOF or THR of FATO, Geoid undulation	Nil
2	TLOF 和(或)FATO 标高 TLOF and/or FATO elevation	Nil
3	TLOF 和 FATO 区域范围、道面、强度和标志 TLOF and FATO area dimensions, surface, strength, marking	Nil
4	FATO 的真方位和磁方位 True and MAG BRG of FATO	Nil
5	公布距离 Declared distance available	Nil
6	进近灯光和 FATO 灯光 APP and FATO lighting	Nil
7	备注 Remarks	Nil

# ZSPD AD 2.17 空中交通服务空域 ATS airspace

	名称和水平范围 tion and lateral limits	垂直范围 Vertical limits	空域分类 Airspace class	空中交通服务单位 呼号和使用语言 ATS unit callsign Language	工作时间 Hours of applicability	备注 Remarks
1	2	3	4	5	6	7
Shanghai/Pu dong tower control area	10km range beside landing path after RWY aligned					
Fuel Dumping Area	N3113E12300-N3130E 12400-N3100E12400-N 3100E12300-N3113E12 300	3000m and ABV				See Fuel Dumping Area Chart
Restricted Area	N311449E1212726-N31 1214E1212547-N31120 1E1212554-N311223E1 212730-N311224E1213 008-N311519E1213234 -N311557E1213156-N3 11449E1212726	SFC-QNH1500m(exclu sive)				
Altimeter setting region and TL/TA	SASAN-PIKAS-'NTG' VOR-N315826E121255 4-UDOXI-IBEGI-N314 611E1224630-EMSAN- DUMET-N311241E122 4630 -BONGI-PONAB-N301 500E1221200-'AND' VOR-'NXD' VOR-SASAN	TL 3600m TA 3000m 3300m(QNH≥1031hPa) 2700m(QNH≤979hPa)				Aircraft taking-off or landing in ZSSS/ZSPD shall follow the rules: 1. above 900m: use ZSPD QNH; 2. at 900m or below: use QNH of the taking-off or landing aerodrome. 3. above TA: do as usual.

## ZSPD AD 2.18 空中交通服务通信设施 ATS communication facilities

服务名称 Service designation	呼号 Callsign	频率 Frequency (MHz)	卫星话音通信 号码 SATVOICE number	登录地址 Logon address	工作时间 Hours of operation	备注 Remarks
1	2	3	4	5	6	7
ATIS		127.85 (English)			H24	D-ATIS available
AHS		128.65 (Chinese)			H24	D-ATIS available
		APP01:120.3 (119.75)			by ATC	
		APP02:125.4 (124.05)			H24	
		APP03:125.85 (119.2)			by ATC	
		APP04:123.8 (119.2)			by ATC	
		APP05:126.65 (128.05)			H24	
		APP06:126.3 (120.65)			by ATC	
ADD	Shanghai	APP07:121.1 (119.75)			by ATC	
APP	Approach	APP08:127.75 (124.05)			by ATC	
		APP09:121.375 (128.05)			by ATC	
		APP10:125.625 (120.65)			by ATC	
		APP11:119.075 (128.05)			by ATC	
		APP12:119.975 (120.65)			by ATC	
		APP13:120.825 (124.875)			by ATC	Contact APP09 when APP13 U/S.
		APP14:124.725 (119.75)			by ATC	
TWR	Pudong Tower	TWR01:118.8 (118.325)			H24	For RWY 17L/35R,17R/35L

服务名称 Service designation	呼号 Callsign	频率 Frequency (MHz)	卫星话音通信 号码 SATVOICE number	登录地址 Logon address	工作时间 Hours of operation	备注 Remarks
1	2	3	4	5	6	7
		TWR02:118.4 (118.725)			H24	For RWY 16L/34R,16R/34L
		TWR03:124.35 (118.325)			0030-130 0(UTC)	For RWY17L/35R
		TWR04:118.575 (118.725)			0030-130 0(UTC)	For RWY16R/34L
		GND01:121.7			H24	
		GND02:121.8			H24	
	Pudong Ground	GND03:121.875			0030-130 0(UTC)	CTC GND01 when U/S.
GND		GND04:121.625			0030-130 0(UTC)	CTC GND02 when U/S.
	Pudong Delivery	121.95 (121.625)			H24	DCL AVBL, no readback required when the delivery CLR has been RECd THRU DCL.
		APN01:121.65 (122.125)			H24	
APN	Dudona Amen	APN02:121.975 (122.125)			H24	
Arn	Pudong Apron	APN03:122.7 (122.125)			H24	
		APN04:122.6 (122.125)			H24	
EMG		121.5			H24	

# ZSPD AD 2.19 无线电导航和着陆设施 Radio navigation and landing aids

设施名称及类型、磁差、支持运行类别、 VOR/ILS 磁偏角 Name and type of aid, VAR,Type of supported OPS, Declination of VOR/ILS	识别 ID	频率、波道 Frequency/ Channel number	工作时 间 Hours of operation	发射天线坐标 及相对位置 Coordinates of transmitting antenna/ Position	DME 发射 天线标高 Elevation of DME transmitting antenna	备注 Remarks
--------------------------------------------------------------------------------------------------------------------------	----------	------------------------------------------	-----------------------------------	------------------------------------------------------------------------	------------------------------------------------------------------	---------------

设施名称及类型、磁差、支持运行类别、 VOR/ILS 磁偏角 Name and type of aid, VAR,Type of supported OPS, Declination of VOR/ILS	识别 ID	频率、波道 Frequency/ Channel number	工作时 间 Hours of operation	发射天线坐标 及相对位置 Coordinates of transmitting antenna/ Position	DME 发射 天线标高 Elevation of DME transmitting antenna	备注 Remarks
1	2	3	4	5	6	7
Andong VOR/DME	AND	114.8 MHz CH 95X	H24	N30°15.4′ E121°13.3′	32 m	
Hengsha VOR/DME	HSH	114.4 MHz CH 91X	H24	N31°22.1′ E121°50.8′ 017 MAG/25420m FM ARP	24 m	
Pudong VOR/DME	PUD	116.9 MHz CH 116X	H24	N31°10.3′ E121°47.0′ 348 MAG/1090m FM THR17L	15 m	
Shuyuan VOR/DME	XSY	112.7 MHz CH 74X	H24	N30°55.9′ E121°52.4′ 168 MAG/22636m FM THR35R	27 m	
Liuzao VOR/DME	PDL	109.4 MHz CH 31X	H24	N31°07.8′ E121°40.3′	4 m	
LOC 16L ILS CAT I	IHL	111.5 MHz		168 MAG/315m FM end RWY16L		
GP 16L		332.9 MHz		120m W of RCL,313m inward THR16L		Angle 3°, RDH 15 m
DME 16L	IHL	CH 52X (111.5 MHz)			6m	Co-located with GP 16L
LOC 34R ILS CAT I	IPR	108.9 MHz		348 MAG/315m FM end RWY34R		
GP 34R		329.3 MHz		120m W of RCL,313m inward THR34R		Angle 3°, RDH 15 m
DME 34R	IPR	CH 26X (108.9 MHz)			7m	Co-located with GP 34R
MM 16R		75 MHz		348 MAG/1050m FM THR16R		

设施名称及类型、磁差、支持运行类别、 VOR/ILS 磁偏角 Name and type of aid, VAR,Type of supported OPS, Declination of VOR/ILS	识别 ID	频率、波道 Frequency/ Channel number	工作时 间 Hours of operation	发射天线坐标 及相对位置 Coordinates of transmitting antenna/ Position	DME 发射 天线标高 Elevation of DME transmitting antenna	备注 Remarks
IM 16R		75 MHz		348 MAG/350m FM THR16R		
LOC 16R ILS CAT I	IZZ	108.7 MHz		168 MAG/288m FM end RWY16R		
GP 16R		330.5 MHz		120m E of RCL,312m inward THR16R		Angle 3°, RDH 15 m
DME 16R	IZZ	CH 24X (108.7 MHz)			4m	Co-located with GP 16R
MM 34L		75 MHz		168 MAG/1050m FM THR34L		
IM 34L		75 MHz		168 MAG/350m FM THR34L		
LOC 34L ILS CAT III	IDD	108.3 MHz		348 MAG/288m FM end RWY34L		In operation CAT II/III
GP 34L		334.1 MHz		120m E of RCL,310m inward THR34L		Angle 3°, RDH 15 m In operation CAT II/III
DME 34L	IDD	CH 20X (108.3 MHz)			4m	Co-located with GP 34L
MM 17L		75 MHz		348 MAG/1070m FM THR17L		
IM 17L		75 MHz		348 MAG/313m FM THR17L		
LOC 17L ILS CAT II	IPD	110.7 MHz		168 MAG/295m FM end RWY17L		In operation CAT II
GP 17L		330.2 MHz		120m W of RCL,307m inward THR17L		Angle 3°, RDH 15 m In operation CAT II
DME 17L	IPD	CH 44X (110.7 MHz)			8m	Co-located with GP 17L
MM 35R		75 MHz		168 MAG/1030m FM THR35R		
IM 35R		75 MHz		168 MAG/313m FM THR35R		

设施名称及类型、磁差、支持运行类别、 VOR/ILS 磁偏角 Name and type of aid, VAR,Type of supported OPS, Declination of VOR/ILS	识别 ID	频率、波道 Frequency/ Channel number	工作时 间 Hours of operation	发射天线坐标 及相对位置 Coordinates of transmitting antenna/ Position	DME 发射 天线标高 Elevation of DME transmitting antenna	备注 Remarks
LOC 35R ILS CAT II	INN	111.9 MHz		348 MAG/295m FM end RWY35R		In operation CAT II
GP 35R		331.1 MHz		130m W of RCL,314m inward THR35R		Angle 3°, RDH 15 m In operation CAT II
DME 35R	INN	CH 56X (111.9 MHz)			8m	Co-located with GP 35R
LOC 17R ILS CAT I	IKM	111.1 MHz		168 MAG/285m FM end RWY17R		Beyond 32 °rightside of front CRS U/S.
GP 17R		331.7 MHz		120m E of RCL,310m inward THR17R		Angle 3°, RDH 15 m
DME 17R	IKM	CH 48X (111.1 MHz)			11m	Co-located with GP 17R
LOC 35L ILS CAT I	IBD	108.1 MHz		348 MAG/285m FM end RWY35L		
GP 35L		334.7 MHz		120m E of RCL,310m inward THR35L		Angle 3°, RDH 15 m
DME 35L	IBD	CH 18X (108.1 MHz)			11m	Co-located with GP 35L

### ZSPD AD 2.20 本场规定

### **ZSPD AD 2.20 Local aerodrome regulations**

### 1. 机场使用规定

### 1.1 禁止未安装二次雷达应答机的航空器起降;

- 1.2 所有技术试飞需事先申请,并在得到空中交通管 制部门批准后方可进行;
- 1.3 可使用最大机型: A380 及同类机型。

### 2. 跑道和滑行道的使用

## 1.Airport operations regulations

- 1.1 TKOF/LDG of aircraft WO SSR transponder are forbidden;
- 1.2 Each and EV technical test FLT shall be filed in advance and shall be made only AFT CLR has been obtained FM ATC;
- 1.3 MAX aircraft to be AVBL: A380 and equivalent.

### 2. Use of runways and taxiways

- 2.1 可以通过地面管制申请引导车和拖车服务;
- 2.1.1 专机滑行路线以管制员指令为准;
- 2.1.2 为减少波道占用时间, 航空器起飞离地后自动 与塔台管制席位脱波 (不需要通话脱波), 脱波后, 航空器应该联系塔台管制指定的频率。

离场航空器应在预计开车前 10min 内联系放行管制,取得放行许可;

2.1.3 一组近距跑道的仪表着陆系统同时开放,为防止航空器落错跑道, 航空器驾驶员应通过本场自动情报通播系统掌握落地所使用的跑道, 在进近过程中, 仔细检查管制指令中的落地跑道号, 建议将顺序闪光 灯作为重要的目视参考。

#### 2.1.4 平行滑行道使用原则

- 2.1 Follow-me vehicle SER and towing SER are AVBL via GND CTL:
- 2.1.1 TAX RTEs of special FLT will be instructed by ATC;
- 2.1.2 In ORD to avoid FREQ congestion, pilot shall LVE TWR FREQ WO radiotelephony instruction FM ATC as soon as airborne and CTC the FREQ assigned by TWR CTL IMT.

DEPing aircraft shall CTC Delivery CTL for delivery CLR WI 10min prior to the start-up;

2.1.3 A set of ILS for CLSD RWYs are SIMUL OPN,in ORD to prevent aircraft LDG on the wrong RWY,pilot shall master the used LDG RWY by ATIS. DRG APCH, pilot shall carefully CK the LDG RWY NR by ATC ORD. It is suggested that use SFL as an important visual references.

2.1.4 GEN rules for the use of PARL TWYs:

使用跑道/RWY in use	停靠候机楼/DCKG TML	运行方向/OPR direction	主用滑行道/Mainly via TWY
All RWYs	Nr.1	To S	A
All RW 18	Nr. 1	To N	В
All RWYs	Nr.2		F
DEP FM 17L/35R			A
DEP FM 34L			Е
DEP FM 16R			F

- 2.2 跑道运行规则
- 2.2.1 跑道 16L/34R 与 17L/35R 或跑道 16L/34R
  与 17R/35L 或跑道 16R/34L 与 17L/35R 或跑道
  16R/34L与 17R/35L 可实施相关或独立平行进近以
  及独立平行离场;
- 2.2.2 跑道 17L/35R 主要用于离港, 跑道 17R/35L 主要用于进港;
- 2.2.3 跑道 16R/34L 主要用于离港, 跑道 16L/34R 主要用于进港;
- 2.2.4 当停靠在 3 号货机坪停机位 310-341, 346, 347 的重型航空器需使用跑道 17R/35L 起飞时,机组应在申请放行许可时向 ATC 申请。
- 2.2.5 着陆航空器脱离跑道前须在塔台频率保持长守。

通常情况下,落地航空器接地后占用跑道的时间应控制在 50s 以内,使用第一或第二快速脱离道脱离跑道。如不能执行上述要求时,需要使用最后一条快速脱离道及远道口脱离跑道时,航空器驾驶员应在与塔台管制员建立首次联系时进行通报说明,管制员将根据空中和地面交通情况视情指挥航空器继续进近、落地、中止进近或复飞(湿跑道或污染跑道除外);

2.2.6 起飞航空器从等待位置到对正跑道的时间应控制在 60s 以内,如不能满足要求应在进跑道前报告 塔台管制员(湿跑道或污染跑道除外);

- 2.2 GEN rules for using RWYs
- 2.2.1 RWY 16L/34R & 17L/35R or RWY 16L/34R & 17R/35L or RWY 16R/34L & 17L/35R or RWY 16R/34L & 17R/35L can be used for independent or dependent PARL APCHes and independent PARL DEPs;
- 2.2.2 RWY 17L/35R are mainly used for DEP; RWY 17R/35L are mainly used for ARR;
- 2.2.3 RWY 16R/34L are mainly used for DEP; RWY16L/34R are mainly used for ARR;
- 2.2.4 If the HVY-aircraft PRKG at cargo APNNr.3(stands Nr. 310-341, 346, 347) intends to DEP FMRWY17R/35L, an application shall be made and the permission shall be obtained FM Delivery CTL.
- 2.2.5 FLT crew shall MNT TWR FREQ TIL vacating RWY.

NMLly, all LDG aircraft shall fully vacate RWY via the FST or second rapid exit TWY WI 50s AFT touchdown. If can not fulfill the ABV RQMNTS and need to vacate RWY via further TWY or the last rapid exit TWY, the pilot shall inform TWR on the FST CTC. TWR will CTL aircraft to CONT APCHing, LDG, stopping APCH or missed APCH according to air and GND TFC CONDs(EXC for wet or contaminated RWY);

2.2.6 DEP aircraft shall finish RWY alignment WI 60s FM HLDG PSN. If FLT crew considers that they can not fulfill the process WI the required time, pilot shall inform TWR BFR entering the RWY(EXC for wet or

2.2.7 更换跑道运行方向过程中,当跑道顺风分量超过 3m/s 但不大于 5m/s 时,管制员可以短时指挥航空器顺风起飞或着陆。当航空器驾驶员根据机型性能或者运行手册不能执行顺风跑道起飞或者着陆时,应明确告知管制员。

2.2.8 着陆航空器落地许可的最晚发布时机可以在着陆航空器飞越跑道入口前。

2.2.9 为调整离港航班放飞次序,管制员可以指挥航空器使用 B1、B7、E0、E5、Q1、Q6、J1、J2 联络道进入相对应跑道起飞,若航空器驾驶员不能接受,须在进入上述联络道前主动报告管制员。

2.3 穿越跑道规定

contaminated RWY);

2.2.7 DRG changing the direction of RWY in use, if downwind speed is more than 3m/s and not exceeding 5m/s, ATC may instruct aircraft downwind TKOF or downwind LDG for short time. Pilot shall inform ATC if decide not to TKOF or LDG on downwind RWY allocated according to aircraft PER or operation handbook.

2.2.8 The latest time to issue LDG CLR BFR aircrafts FLY over THR is AVBL.

2.2.9 ATC may instruct aircraft to enter RWY via TWYL B1, B7, E0, E5, Q1, Q6, J1, J2 for TKOF. If not AVBL, pilots shall inform ATC BFR entering the TWYL.

#### 2.3 RWY XNG rules:

穿越跑道时使用的滑行道 TWYs used for XNG	FM stands Nr. 310-341, 346, 347, Z11-Z16, Z21-Z26, Z31-Z38 to RWY16R/34L for DEP	When northward operation, mainly use TWY P2 for XNG RWY17R/35L, then join TWY D and hold out of TWY P1, and then use TWY P1 for XNG RWY17L/35R then join TWY T2. When southward operation, mainly use TWY P4 for XNG RWY17R/35L, then join TWY D and hold out of TWY P6, and then use TWY P6 for XNG RWY17L/35R then join TWY B.
-------------------------------	----------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

	FM stands Nr. 310-341, 346, 347, Z11-Z16, Z21-Z26, Z31-Z38 to	When northward operation, mainly
		use TWY P2 for XNG
		RWY17R/35L, then join TWY D
		and hold out of TWY P1.
		When southward operation, mainly
		use TWY P4 for XNG
	RWY17L/35R for DEP	RWY17R/35L, then join TWY D
	LDG on RWY17R/35L and XNG	and hold out of TWY P6. Aircraft
		that can not ACPT TWY P6 for
		DEP, should use TWY P6 for XNG
		RWY17L/35R, then join TWY A
		and hold out of TWY B8.
		Mainly use TWY P1/P6 for XNG,
	RWY17L/35R	and then join TWY A/B.
	LDG on RWY16L/34R to stands Nr.	Mainly use TWY P2/P4 for XNG
	310-341, 346, 347, Z11-Z16,	RWY 17L/35R & 17R/35L, and then
	Z21-Z26, Z31-Z38	join TWY C.
	LDG on RWY16L/34R and XNG	Mainly use TWY R1/R6 for XNG,
	RWY16R/34L	and then join TWY F/E.
	机组在穿越跑道前需向塔台提出穿越申请,收到塔台管制员穿越许可	
	后,需尽快实施穿越并加入相应滑行道; 机组应注意完整复诵管制员有	
	关穿越跑道指令。穿越结束后,机组需向塔台报告"已脱离跑道"。	
字越程序	FLT crew shall CTC TWR for XNG CLR; repeat all the ATC instructions	
PROCs for XNG	for clarity, then put in practice ASAP; finally, REP to TWR 'RWY vacated'.	
PROCs for XNG	穿越跑道时, 机组必须意监听塔台频率中其他有关跑道的指令或信息通	
	报,并注意观察跑道及附近的活动。	
	FLT crew must MNT the TWR FREQ and watch the activities on the RWY	
	and around;	

	当机组观察到跑道上有其他航空器活动时, 需再次向管制员证实是否穿	
	越当前跑道。 When watching other aircraft moving on the RWY, aircrew should CTC	
	TWR to make sure whether to X.	
	紧跟在起飞航空器后穿越跑道时,机组自行负责其与起飞航空器之间的 距离以免受起飞航空器喷流的影响。	
	While XNG RWY AFT the TKOF aircraft, FLT crew shall be responsible	
	for the safety DIST with the aircraft to avoid the effect of wake TURB.	
	使用跑道 17L/35R 落地的航空器,不得使用滑行道 P2/P3/P4/P5 向西脱	
	离跑道。	
	Aircraft LDG on RWY17L/35R are forbidden to vacate to the W via TWY	
穿越限制	P2/P3/P4/P5.	
Limits for XNG	当跑道 17L/35R,17R/35L 有落地航空器使用时,不得使用滑行道 P1	
	或 P6 穿越跑道。	
	Aircraft are forbidden to use TWY P1 or P6 for XNG RWY 17L/35R or	
	17R/35L where exists LDG aircraft.	

### 2.4 滑行道的滑行限制

2.4.1 航空器在地面滑行期间,航空器驾驶员必须依 照管制员指令滑行并加强地面观察,当观察到不明活 动情况时应及时通知地面管制。

2.4.2 禁止航空器在滑行道上做 180 、转弯;

#### 2.4 TAX limits

2.4.1 When aircraft taxiing, pilot should follow theATC's instructions and strengthen ground observation.Notify the ground control when unknown activities are observed.

 $2.4.2\ 180\ ^{\circ}$ turnaround on TWY is strictly forbidden for all aircraft;

滑行道/TWYs	航空器翼展限制(m)/Wing span limits for aircraft(m)	
A, A1-A6, B, B1, B3-B6(W of TWY B), B7, B8, C, C1,	< 90	
C2, C5, C6, D, D1, D2, D5, D6, E, E0-E8, F, F1-F4, G,	< 80	

G1-G6, H, H1-H6, J1, J2, L02, L04(S of TWY B4), L09, L15, L18, L23, P1-P3, P4-P6(W of TWY B), Q1-Q6, R1-R6, S1, S2(BTN TWY T5&T6), T2-T4, V1, V2, V8, W1, W7	
B2, B3-B6(E of TWY B), L04(N of TWY B4), L08, L16, L17, L17A, L19, L20, L20A, L21, L21A, L22, L24, L25, L25A, L26, L26A, P4-P6(E of TWY B), T1, T5, T6, V3-V7, W2, W3, W4(S of TWY T4), W5(S of TWY T4), W6	< 68.5
C3, C4, D3, D4, L05, L06, L06A, L10-L12, L12A, W4(N of TWY T4), W5(N of TWY T4)	< 52
L03, L03A, L07, S2(S of TWY T5)	< 36
L15B, L15C	<31
L15D	< 24

2.4.3 在多跑道混合运行模式下,T1、T3 滑为自东向 西单向滑行; T2、T4 滑为自西向东单向滑行。T3、 T4 滑在 W1 滑设有 1 条单向地面服务车道,机长在 通过上述路段时,应注意减速并观察车辆活动。

2.4.4 在脱离跑道首次与地面管制联系时,尤其在低能见度情况下,必须向地面管制报告脱离的跑道和所使用的滑行道。

2.5 A380 本场运行规则

2.5.1 A380 运行跑道: 16L/34R、16R/34L、17R/35L。 2.5.2 A380 在 A、B 滑之间调头转弯时须采用偏置 滑行方式,若配置机上滑行监视系统须开启。

2.4.3 In multiple RWY operation mode, TWY T1, T3 only AVBL for aircraft FM E to W, TWY T2, T4 only AVBL for aircraft FM W to E. Pilot shall pay ATTN to the GND SER vehicle nearby the intersections of TWYs T3, T4 & W1, and keep SLW speed PSG THRU.

2.4.4 AFT vacating RWY, FLT crew shall REP the RWY vacated and the TWY in use to GND CTL at the FSTCTC, especially under low VIS operation.

2.5 Operation rules for A380

2.5.1 RWY for A380: 16L/34R, 16R/34L, 17R/35L.

2.5.2 A380 shall offset TAX when turnaround 180 °BTN TWY A & B. A380 TAX Camera System shall

turn on.

2.6 B747-8 本场运行规则

2.6.1 使用跑道 17L/35R 进近时, I 类运行须配置并使用航迹保持导航系统直至落地。

2.6.2 L16、L17、L17A 仅限空载时的 B747-8 运行。

2.7 An124 本场运行规则

2.7.1 使用跑道 17L/35R 进近时, I 类运行须配置并使用航迹保持导航系统直至落地。

2.8 A340 本场运行规则

2.8.1 A340-600 机型在 A 滑行道滑行, 向西转弯进入 P1、B1、B7、B8 滑行道时, 需采用"过滑偏置转弯"。

2.8.2 A340-600 机型在 B 滑行道滑行,向东转弯进入 B3、B4、P4、B5、P5、B6、P6 滑行道时,需采用"过 滑偏置转弯"。

2.8.3 A340-600 机型在 P1、B1、B7、B8 滑行道滑行,由西向东滑行转向进入 A 滑行道时,需采用"过滑偏置转弯"。

2.8.4 A340-600 机型在 L17 滑行道滑行,向北转弯进入 L16 滑行道时,需采用"过滑偏置转弯"。

2.8.5 A340-600 机型在 L16 滑行道滑行,由北向南滑行转向进入 L17 滑行道时,需采用"过滑偏置转弯"。

2.6 Operation rules for B747-8

2.6.1 For CAT I operation, TR CTL system(TCS) shall be INSTL on aircraft and be used in the APCHes to RWY17L/35R TIL LDG.

2.6.2 TXL L16, L17, L17A only used for unladen WT B747-8.

2.7 Operation rules for AN124

2.7.1 For CAT I operation, TR CTL system(TCS) shall be INSTL on aircraft and be used in the APCHes to RWY17L/35R TIL LDG.

2.8 Operation rules for A340

2.8.1 When A340-600 taxiing on TWY A and turning west to TWYs P1, B1, B7, B8, aircraft should use Judgemental Oversteering Method.

2.8.2 When A340-600 taxiing on TWY B and turning east to TWYs B3-B6, P4-P6, aircraft should use Judgemental Oversteering Method.

2.8.3 When A340-600 taxiing on TWYs B1, B7, B8, P1 and entering TWY A from west to east, aircraft should use Judgemental Oversteering Method.

2.8.4 When A340-600 taxiing on TWY L17 and turning north to TWY L16, aircraft should use JudgementalOversteering Method.

2.8.5 When A340-600 taxiing on TWY L16 and entering TWY L17 from north to south, aircraft should use Judgemental Oversteering Method.

2.8.6 A340-600 机型在 B3、B4、P4、B5、P5、B6、P6 滑行道与 L04 滑行道交叉道口滑行时,需采用"过滑偏置转弯"。

2.9 机场冲突多发地带运行要求

2.9.1 机动区冲突多发地带位置见 ZSPD

AD2.24-1A, 2;

2.9.2 为减少运行差错,降低地面冲突和跑道入侵事件的发生概率,在机场活动区内运行的航空器需严格按照下述的要求运行:

HS1: 滑行道 E、F与 T3、T4的交叉区域 该区域为进、离港航空器的交汇处,通常情况下,T2 候机楼离港航空器使用 E滑,在 T4 滑前等待,确认 没有冲突后继续滑行。如因疏忽滑错道口,必须立即 停止滑行并向管制员报告。

HS2: 滑行道 A、B与T3、T4的交叉区域 通常情况下,经T3滑至跑道17L/35R、T1候机楼时, 需在B滑前等待,确认没有冲突后继续滑行。由于 T3滑与A2快速脱离道相连,在上A滑时特别注意 观察道口、标志牌,避免连续滑行而误入运行跑道。

HS3: 频繁穿越跑道区域

P2与P4滑是穿越跑道的主用垂直联络道, 航空器穿越跑道时需特别注意管制指令, 没有收到明确穿越跑道的指令, 严禁擅自穿越跑道。

HS4: 频繁穿越跑道区域

P2与P4滑是穿越跑道的主用垂直联络道, 航空器穿越跑道时需特别注意管制指令, 没有收到明确穿越跑道的指令, 严禁擅自穿越跑道。

HS5: 滑行道 P6与 A、B的交叉区域,频繁穿越跑

2.8.6 When A340-600 taxiing at the intersection ofTWYs B3-B6, P4-P6 and TWY L04, aircraft should useJudgemental Oversteering Method.

2.9 Hot spot PROC

2.9.1 REF ZSPD AD2.24-1A, 2;

2.9.2 For the purpose of reducing errors that lead toGND conflicts and RWY incursions, aircraft OPR WIthe maneuvering area must follow the RQMNTS BLW:

HS1: INTs of TWYs E, F & T3, T4

HS1 is the conjunction area of ARR and DEP aircrafts.

NMLly, the DEPing aircraft LVE TML Nr.2 shall use

TWY E, and hold out of TWY T4 to ensure no conflict

BFR go on. If TAX into wrong way by mistake, stop

IMT and inform ATC.

HS2: INTs of TWYs A, B & T3, T4

PCD with extreme CTN when OPR near this area.

NMLly, when TAX via TWY T3 to RWY17L/35R and

TML Nr.1, aircraft shall hold out of TWY B to ensure no conflict BFR go on. Because TWYs T3 & A2 are connected,

when TAX into TWY A, pay ATTN to TFC situation and TWY guidance signs to avoid RWY incursion.

HS3:RWY XNG busy area

TWYLs P2 & P4 are the main VER TWYLs for RWY XNG. When XNG RWY, aircraft shall strictly follows the ATC CLR. WO CLR instructions, any kind of RWY XNG operation is forbidden.

道区域

P6 滑是塔台与机坪之间的重要移交点,出港航空器从 P6 滑上 A 滑时,在此区域应注意观察标志,避免由于连续滑行误入跑道。P6 滑是穿越跑道的主用联络道,航空器穿越跑道时需特别注意管制指令,如没有收到明确穿越跑道的指令,严禁擅自穿越跑道,P6 滑上穿越航空器穿越跑道后应及时联系下一个管制席位。

HS6: 频繁穿越跑道区域

R6 滑是穿越跑道的主用垂直联络道, 航空器穿越跑道时需特别注意管制指令, 如没有收到明确穿越跑道的指令, 严禁擅自穿越跑道。使用 F 滑的航空器在 E5 滑前等待, 确认没有冲突后继续滑行。向南运行时, 此区域为放飞排序的繁忙区域, 管制员可以根据运行实际情况灵活使用 E、F 滑进行航空器的调配, 加速流量。

HS7: 频繁穿越跑道区域

R1 滑是穿越跑道的主用垂直联络道, 航空器穿越跑道时需特别注意管制指令, 如没有收到明确穿越跑道的指令, 严禁擅自穿越跑道。

HS8: 滑行道 E、F与联络道 E7的交叉区域 该区域为进、离港航空器的交汇处,同时也是塔台与 机坪之间重要移交点,进港航空器使用 E 滑在 E6 滑前等待,确认没有冲突后继续滑行。出港航空器使用 F 滑在 E7 滑前等待,确认没有冲突后继续滑行。

HS9: 滑行道 E、F与 T1、T2、L19的交叉区域 该区域为进、离港航空器的交汇处,通常情况下,使用 T2 滑的航空器在 E 滑前等待,确认没有冲突后继

HS4:RWY XNG busy area

TWYLs P2 & P4 are the main VER TWYLs for RWY XNG. When XNG RWY, aircraft shall strictly follows the ATC CLR. WO CLR instructions, any kind of RWY XNG operation is forbidden.

HS5 :INTs of TWYL P6 & TWYs A, B, RWY XNG busy area

TWYL P6 is important handover point BTN TWR & APN. Aircarft for DEP shall take CTN with guidance signs to avoid RWY incursion when TAX via TWYL P6 into TWY A. TWYL P6 is the main TWYL for RWY XNG. When

XNG RWY, aircraft shall strictly follow the ATC instructions. WO CLR instructions, any kind of RWY XNG operation is forbidden. Aircraft shall CTC the NXT CTL unit IMT AFT XNG RWY via TWYL P6.

HS6:RWY XNG busy area

TWYL R6 is the main TWYL for RWY XNG. When XNG RWY, aircraft shall strictly follow the ATC instructions. WO CLR instructions, any kind of RWY XNG operation is forbidden. When using TWY F, aircraft shall hold short

of TWY E5 to ensure no conflict BFR go on. HS6 is the aircraft sequencing busy area for TKOF, ATC can use TWY E, F to expedite the flow of TFC, when in southward operation.

HS7:RWY XNG busy area

TWYL R1 is the main VER TWYL for RWY XNG.

续滑行。使用 E 滑加入 T1 滑的航空器在 L19 滑前等待,确认没有冲突后继续滑行。为了避免地面滑行冲突,管制员可以灵活使用 L19 滑。

HS10: 滑行道 P1 与 A、B、T1、T2 的交叉区域, 频繁穿越跑道区域

该区域为进、离港航空器的交汇处,通常情况下,使用 T1 滑的航空器在 B 滑前等待,确认没有冲突后继续滑行。P1 滑是穿越跑道的主用垂直联络道,航空器穿越跑道时需特别注意管制指令,如没有收到明确穿越跑道的指令,严禁擅自穿越跑道,如 P1 滑有等待穿越的航空器,塔台应该及时空出 P1 滑道口,保证航空器及时穿越,穿越后的航空器在 B 滑前等待,确认没有冲突后继续滑行。为了避免地面滑行冲突,管制员可以灵活使用 L19 滑。

HS11:滑行道 R1 与 G 的交叉区域, 频繁穿越跑道区域

R1 滑是穿越跑道的主用垂直联络道, 航空器穿越跑 道时需特别注意管制指令, 如没有收到明确穿越跑道 的指令, 严禁擅自穿越跑道。

HS12: 滑行道 B8与 A、B 的交叉区域, 频繁进入 跑道区域

停机位 301 的航空器机头朝南推出开车时,推出过程中需临时占用 B8 滑,得到管制员许可后,推至 B8 滑后需立刻沿滑行道中线标志拖曳至 B 滑。

When XNG RWY, aircraft shall strictly follow the ATC instructions. WO CLR instructions, any kind of RWY XNG operation is forbidden.

HS8:INTs of TWYs E, F & E7

HS8 is the conjunction area of ARR and DEP aircrafts, and also the handover point BTN TWR & APN. The arriving aircraft shall use TWY E, and hold short of TWY E6 to ensure no conflict BFR go on. The DEPing aircraft shall use TWY F, and hold short of TWY E7 to ensure no conflict BFR go on.

HS9:INTs of TWYs E, F & T1, T2, TXL L19
HS9 is the conjunction area of ARR and DEP aircrafts.

NMLly, when using TWY T2, aircraft shall hold short of TWY E to ensure no conflict BFR go on. When using
TWY E to jion TWY T1, aircraft shall hold short of TXL
L19

to ensure no conflict BFR go on. ATC can use TXL L19 to avoid TAX conflict.

HS10 :INTs of TWYL P1 & TWYs A, B, T1, T2, RWY
XNG busy area

HS10 is the conjunction area of ARR and DEP aircrafts.

NMLly, aircraft shall hold short of TWY B to ensure no conflict BFR go on when using TWY T1. TWYL P1 is the main VER TWYL for RWY XNG. When XNG RWY,

aircraft shall strictly follow the ATC instructions. WO CLR instructions, any kind of RWY XNG operation is forbidden. TWR shall ensure TWYL P1 AVBL and

instruct the aircraft HLDG short of TWYL P1 X the RWY IMT, aircraft shall hold short of TWY B to ensure no conflict BFR go on, AFT RWY XNG. ATC can use TXL L19 to avoid TAX conflict.

HS11: INT of TWYL R1 TWY G, RWY XNG busy area

TWYL R1 is the main VER TWYL for RWY XNG. When XNG RWY, aircraft shall strictly follow the ATC instructions. WO CLR instructions, any kind of RWY XNG operation is forbidden.

HS12: INTs of TWYL B8 TWYs A, B, RWY entering busy area

When aircraft on stand Nr.301 face to S push-back and start-up, push-back shall TEMPO occupy TWYL B8. Aircraft shall be towed IMT along TWY CL to TWY B with ATC CLR AFT being pushed to TWYL B8.

2.10 ILS OPS mode

2.10.1 CAT-I/HUD-I OPS

RWY 17L, 35R, 17R, 35L, 16R, 34L, 16L and 34R OPN.

2.10.2 CAT-II/III OPS

2.10.2.1 向南运行: 17L、17R、35L、16R、34L、16L 2.10.2.1 LDG to S: RWY 17L, 17R, 35L, 16R, 34L, 16L and 34R OPN, 35R CLSD.

> 2.10.2.2 LDG to N: RWY 35R, 17R, 35L, 34L, 16L and 34R OPN, 17L and 16R CLSD.

#### 3. Use of aprons and parking stands

3.1.1 Push-back of aircraft on its own PWR is strictly forbidden WO AOC CLR;

### 2.10 ILS 开启模式

2.10.1 CAT-I/HUD-I运行时

17L、35R、17R、35L、16R、34L、16L 和 34R 全 部开启。

2.10.2 CAT-II/III运行时

和 34R 开启, 35R 关闭。

2.10.2.2 向北运行: 35R、17R、35L、34L、16L和 34R 开启, 17L 和 16R 关闭。

#### 3. 机坪和机位的使用

3.1.1 未经浦东国际机场运行指挥中心同意,严禁航 空器利用自身动力倒滑;

3.1.2 所有停靠廊桥机位的航空器必须使用桥载设备,关闭 APU;如需使用 APU,航空公司必须向机电信息保障部客桥调度电话申请(第一航站楼/卫星厅电话:86-21-68343126/68343195;第二航站楼/卫星厅电话:86-21-68343297/68343231),经批准后方可使用。以下特殊情况可使用 APU(无需申请):a.桥载设备发生故障,不能提供服务;b. 航空器因启动发动机而需开启 APU;c. 航空器进行 APU 的维修检测;d. 天气预报环境温度超过 35℃;e. 航班过站时间不足 45min。

3.1.3 廊桥机位 24 的桥载设备仅满足翼展小于 65m 航空器的使用需求。

3.1.4 机坪和机位的使用

3.1.4.1 机坪划分

3.1.2 All aircraft PRKG on boarding bridge stands shall turn off APU, and use bridge EQPT. If aircraft require to use APU, airlines shall CTC department of AP EQPT and INFO (for TML Nr.1/Satellite: 86-21-68343126/68343195, for TML Nr.2/Satellite: 86-21-68343297/68343231) to get apply, and use with permission. In following situations, aircraft can use APU w/o getting permission:a. Bridge EQPT is not AVBL;b. Aircraft need APU to start up ENG;c. APU is under MAINT;d. FCST T is more than 35°C;e. FLT transition

3.1.3 Bridge EQPT for boarding bridge stand Nr.24 is only AVBL for aircraft with wingspan less than 65m.

3.1.4 Use of aprons and parking stands

3.1.4.1 Existing APNs at ZSPD:

time is less than 45min

机坪名称/APN name	停机位/Stands
APN Nr.1(T1)	Nr. 1-12, 14-32
APN Nr.2	Nr. 201-211
Cargo APN Nr.3	Nr. 301-308, 310-341, 346, 347, Z11-Z16, Z21-Z26,
Cargo APN NI.5	Z31-Z38
APN Nr.4(MAINT)	Nr. 401A/B, 402A/B, 403A/B, 404A/B, 405-407,
	408A/B, 409A/B, 410A/B, 411-418, 451-453, 458, 459
APN Nr.5	Nr. 501-512, 551-572, 581-586, 589, 590
Cargo APN Nr.6	Nr. 611-626
APN Nr.7(T2)	Nr. 50-65, 67, 69, 71, 73, 75, 77, 79-98
APN Nr.8	Nr. 801-816

Satellite APN	Nr. 101-190
---------------	-------------

3.1.4.2 停机位使用限制

3.1.4.2 Limits for aircraft PRKG on the following stands:

停机位/Stands	航空器翼展限制/Wing span limits for aircraft
Nr. 24, 71, 75, 119, 121, 168, 170, 173, 310, 314, 315,	<80m
320, 325, 328, 333, 338, 504, 507, 612-614, 616-618	COULI
Nr. 17, 19, 21, 101, 102, 131-140, 148-156, 174, 175,	
177, 189, 190, 205, 208, 303, 305, 307, 510, 511, 806,	<68.5m
809, 810, 816	
Nr. 6-12, 14-16, 18, 20, 22, 23, 57, 59, 61, 63, 65, 67,	
69, 73, 77, 79, 81, 83, 85, 87, 89, 91, 112-118, 120, 122,	
125, 130, 166, 167, 169, 204, 206, 209, 210, 301, 302,	
304, 306, 311-313, 316-319, 321-324, 326, 327,	<65m
329-332, 334-337, 339-341, 346, 347, 406, 407,	
411-418, 451, 452, 458, 459, 505, 508, 553, 554, 557,	
558, 581-585, 590, 615, 619, 620, 807, 811, 813, 814	
Nr. 1-5, 50, 55, 56, 58, 60, 62, 82, 84, 86, 88, 90, 93,	<52m
207, 211, 308, 401A/B, 611, 801, 802, 804, 805	<b>\( \)</b> \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \) \( \
Nr. 25-32, 51-54, 64, 80, 92, 94-98, 103-111, 123, 124,	
126-129, 141-147, 157-165, 171, 172, 176, 178-188,	
201-203, 402A/B, 403A/B, 404A/B, 405, 408A/B,	<36m
409A/B, 410A/B, 453, 501-503, 506, 509, 512, 551,	Som
552, 555, 556, 559-572, 586, 589, 621-626, 803, 808,	
812, 815	

## 3.1.4.33 号货机坪公务机位使用限制

# 3.1.4.3 Limits for business stands on APN Nr.3(cargo):

停机位/Stands	机身长度限制/Fuselage limits	航空器翼展限制/Wing span limits
Nr. Z11-Z16, Z21-Z26	<31m	<31m
Nr. Z31-Z38	<28m	<24m

## 3.1.5 滑入及滑出停机坪的规定

## 3.1.5 Rules for entering/exiting APN:

停机坪/APN	停机位/Stands	滑入/Entry by TWY	滑出/Exit by TWY
	Nr. 50-54, 56, 58, 60, 62, 64	E7	E6
	Nr. 55, 57, 59, 61, 63, 65, 806-809	R6	E5
APN Nr. 7, 8	Nr. 67, 69, 71, 73, 75	R5	
AFN NI. 7, 8	Nr. 77, 79, 81, 83, 85, 87, 89, 91, 93, 810-816	R5	R4
	Nr. 95-98	W7	W6
	Nr. 80, 82, 84, 86, 88, 90, 92, 94	W5	W4
	Nr. 174-177, 581-584	- E3	L24 face to N
Satellite APN & eastern APN Nr.5	Nr. 171-173		F2
	Nr. 168-170	- E1	E2
	Nr. 166, 167, 585, 586		L24 face to S
	Nr. 161-165, 589, 590	R3	L24 face to S
Satellite APN & western	Nr. 112, 113, 501-503	P3	L02 face to N

APN Nr.5	Nr. 114-118, 504-506	P2	
	Nr. 119-122, 507-509		L02 face to S
Nr. 123	Nr. 123-126	B2	Loz race to S
	Nr. 510-512		В
	Nr. 127-130, 157-160	L19	
	Nr. 131-135, 137, 139,	1014	
C-4-11:4- ADNI 041	567-572	L21A	L20A
Satellite APN & southern APN Nr.5	Nr. 141, 143	L21A-L20	
7H IVIVI.S	Nr. 145	L21-L20	
	Nr. 147, 149, 151-156,	L21	L20
	556-560	1.21	
	Nr. 109-111, 178-180	L22	
	Nr. 101-108, 136, 138,	L26A	L25A
Satellite APN & northern APN Nr.5	140, 561-566		
	Nr. 142, 144	L26A-L25	
	Nr. 146	L26-L25	
	Nr. 148, 150, 181-190,	L26	L25
	551-555	120	
	Nr. 1-10, 201-204	P6	
APN Nr. 1, 2, Cargo APN Nr.3	Nr. 11, 12, 14-17, 205-207	P5	follow APN ATC
	Nr. 18-22, 208-211	P4	instructions
	Nr. 23-32	B3	
	Nr. 301-308	P6/B8	B7
APN Nr.6	Nr. 611-626	L18 face to N	E8
PMKe.	•	•	•

### RMKs:

1. Pilot shall keep observing TFCs outside DRG the whole period of TAX.

- 2. Aircraft is forbidden to enter APN by TWY R5 while A380 is PRKG on or being pushed back FM stand Nr.75.
- 3. If aircraft are TAX on the TXL BTN TWY R5 & TXL L08, A380 is forbidden to be pushed back FM stand Nr.75 or TAX into stand Nr.75 via TXL L09.
- 4. A380 PRKG on stand Nr.75 shall be pushed back to TXL L09 and start up AFT the aircraft tail has passed the nose-in lane of stand Nr.75, then exit APN by TXL L09 & TWY E5.
- 5. A380 shall enter/exit stand Nr.24 via TWY W1; when pushed back, face to S.
- 6. Aircraft PRKG on stand Nr.64 shall be pushed back along with 'push-back line' to the 'push-back HLDG point'. Aircraft change into stand Nr.64 FM other stands shall be towed face to S along with 'stand alignment line' to the stand.
- 7. Aircraft PRKG on stand Nr.80 shall be pushed back along with 'push-back line' to the 'push-back HLDG point'. Aircraft change into stand Nr.80 FM other stands shall be towed face to N along with 'stand alignment line' to the stand.
- 8. When TWY A(B8 is not included) CLSD and aircraft PRKG on stand Nr.301 need be pushed back and start-up face to S, pilot shall apply for CLR in advance.
- 9. A380 can TEMPO park on stand Nr.810. In this situation, GND support activities such as PAX embarking and disembarking, refueling, cargo loading and unloading is forbidden on stand Nr.810.
- 10. Aircraft shall follow follow-me vehicle when TAX in/out APN Nr. 7, 8, Satellite APN & eastern APN Nr.5, and follow APN ATC instruction.
- 11. Aircraft shall follow follow-me vehicle when TAX in Satellite APN & southern, northern APN Nr.5, and follow APN ATC instruction.
- 12. Aircraft TAX in and out Cargo APN Nr.3 shall be guided by follow-me vehicle and pushed back on TXL L15 to start-up.
- 13. When TAX in/out APN Nr.4, aircraft shall follow follow-me vehicle and same orientation principle applied, TAX-in via TXL L16-L17A and TAX-out via TWY V2.
- 14. A380 locating at Satellite APN & eastern APN Nr.5 shall TAX into PRKG stand Nr.168 via TWY E1 and TAX into stand Nr.170 via TWY E1 & TXL L23.
- 15. A380 locating at Satellite APN & eastern APN Nr.5 shall start ENG on TXL L23 and TAX out via TWY E2. For A380 PRKG at boarding bridge stand Nr.173, its nose shall face N when pushed back and starting ENG; For A380

PRKG at boarding bridge stand Nr.168, its nose shall face S when pushed back and starting ENG; For aircraft PRKG at boarding bridge stand Nr.170, push-back direction shall be instructed by ATC. Any aircraft TAX out via TWY E2 is forbidden when A380 PRKG at stands Nr. 168, 170, 173 is pushing back.

3.1.67、8 号机坪设有 9 个机坪等待点 AH01-AH09, 5 个滑出等待点 HP01-HP05。在卫星 厅机坪及 5 号机坪东侧设有 2 个机坪等待点 AH10、AH11, 3 个滑出等待点 HP06-HP08。参见 ZSPD AD2.24-2。

3.1.6 For APN Nr. 7, 8, there are 9 HLDG points(AH01-AH09) used for entering APN and 5 HLDG points(HP01-HP05) used for exiting APN. For Satellite APN eastern APN Nr.5, there are 2 HLDG points(AH10, AH11) used for entering APN and 3 HLDG points(HP06-HP08) used for exiting APN. REF ZSPD AD2.24-2.

等待位置/HLDG point 滑行方向/TAX direction	机坪等待位置/APN	滑行方向/TAX direction	
	HLDG point	海11カ阿/IAX direction	
HP01-HP03, HP07 W to E	AH01-AH03, AH05,	E to W	
	AH10, AH11	E to W	
HP04, HP05, HP08	N to S	AH04, AH06-AH09	S to N
HP06	S to N		

- 3.2 航空器进出停机位的特殊要求:
- 3.2.1 相邻停机位禁止两架航空器同时运行,包括同 时进入、同时推出或滑出(自滑停机位)、同时一进 一出。
- 3.2.2 进港航空器和引导车应在停机位滑行通道(或 滑行道)上转入停机位引入线之前停止,观察确认无 安全运行风险的情况下,减速慢行入位。
- 3.2.3 停靠 T1 候机楼 1-12、14-32; T2 候机楼 50-65、 3.2.3 Aircraft PRKG on TML Nr. 1(stands NR.1-12,

- 3.2 RQMNTS for aircraft into and out of stands:
- 3.2.1 On ADJ PRKG stands, two aircrafts are forbidden to MOV (including TAX into/out by own PWR, pushed back) SIMUL.
- 3.2.2 ARR aircraft and follow-me vehicle shall stop on TWYs BFR turning into stands lead-in lines, then OBS and keep SLW speed to stands.

67、69、71、73、75、77、79-89、91-94、97、98; 卫星厅 101-110、112-123、125-129、131-156、158、 159、161-177、179-190 停机位的航空器须由目视停 靠引导系统引导滑进停机位,并由牵引车推出;停靠 2 号机坪、3 号货机坪、4 号维修机坪、5 号机坪、6 号机坪、8 号机坪各停机位的航空器则由人工指挥滑入,并由牵引车推出。

3.2.4 进港航空器机组发现地面引导车后关闭滑行 灯,跟随地面滑行引导车滑行。离港航空器由机坪 管制发布推出和开车指令,机组收到滑出指令后,必 须和地面机务确认航空器后方无其它安全隐患后,方 可打开滑行灯。

3.2.5 A380 滑入 71 或 75 号停机位使用 R5、L09。E5 至 R5 间的 L08 有航空器活动时,进位的 A380 需在 E 滑或 F滑的 R5 道口前平行等待,禁止转入 R5,在 A380 滑入 71 号或 75 号停机位前,禁止任何航空器 经 R5 滑入停机坪。

3.2.6 A380 推出开车须在 L09 上进行,其中停靠在 71 或 75 号停机位的 A380 推出后,牵引到机尾处于停机位 75 滑入线以北开车,滑出使用 L09、E5。R5 至 E5 间的 L08 滑行线有航空器活动时,禁止停靠在 71 或 75 号停机位的 A380 推出,在 71 或 75 号停机位的 A380 推出过程中,进位的航空器须在 E 滑或 F 滑的

14-32), TML Nr.2(stands Nr.50-65, 67, 69,71, 73, 75, 77, 79-89, 91-94, 97, 98) and Satellite(101-110, 112, 113, 125-129, 131-156, 158, 159, 161-177, 179-190) shall be guided by Visual DCKG Guidance Systems for entry (stands Nr. 90, 95, 96, 111, 124, 130, 157, 160, 178 should by marshalling assistance) and pushed back by tow tractor; aircraft PRKG on APN Nr. 2, 3(cargo), 4(MAINT), 5, 6, 8 shall be guided by marshalling assistance for entry and pushed back by tow tractor; 3.2.4 Arriving aircraft turn off TAX LGTs when follow-me vehicle in sight and follow follow-me vehicle. APN CTL release push-back and start-up, then DEP aircraft turn on TAX LGTs AFT receiving TAX instruction and CFMing with GND crew that no potential security menace in the rear of the aircraft. 3.2.5 The A380 shall taxi into stands Nr.71, 75 through R5, L09. When aircraft taxiing on taxiline L08(BTN E5 & R5), the arrival A380 must hold parallel before R5 on TWYs E or F and is prohibited from taxiing into R5. Before the A380 taxiing into stands Nr.71 or 75, any aircraft is prohibited from entering the apron through R5.

3.2.6 The pushback and engine start procedures for A380 must be conducted on L09. After pushback from stands Nr.71 or 75, the A380 shall be towed to tail and start up at noth of stand Nr.75 taxiline, and taxi out through L09, E5. When aircraft taxiing on taxiline L08(BTN R5 & E5), the A380 parking on stands Nr.71,

R5 道口前平行等待,禁止任何航空器经 R5 滑入停机坪。

3.2.7 停机位 810 可以临时停放 A380。停放期间,禁止上下客、加油、装卸货物等地面保障作业。

3.2.8 当 A380 由停机位 71 或 75 拖曳至 810 时,使用 "A380 拖曳专用线",机头朝南推出至专用线,然后 拖曳到停机位 810。L09 或 L08 滑行线 (R5 至 E5 之间)有航空器滑行时,禁止拖曳 A380 至停机位 810。在 A380 拖曳至停机位 810 过程中,进位的航空器须在 E滑或 F滑的 R5 道口前平行等待,禁止任何航空器经 R5 滑入停机坪或占用 L09。

3.2.9 当 A380 由停机位 810 拖曳至 71 或 75 时, 机头朝南推至专用线, 然后沿专用线拖曳至停机位 71 或 75。L09 或 L08 滑行线 (R5 至 E5 之间)有航空器滑行时, 禁止拖曳 A380 至停机位 71 或 75。在 A380 拖曳至停机位 71 或 75 过程中, 进位的航空器须在 E 滑或 F滑的 R5 道口前平行等待, 禁止任何航空器经 R5 滑入停机坪或占用 L09。

75 are prohibited push back. During the pushback of A380 parked on stands Nr.71 or 75, the arrival aircraft must hold parallel before R5 on TWYs E or F, any aircraft are prohibited from entering the apron through R5.

3.2.7 Stand Nr.810 can temporarily park A380. During the parking period, it is forbidden to pick up and drop off passenger, refuel, load and unload goods and other ground support work.

3.2.8 When an A380 is going to be towed from the stands Nr.71 or 75 to the stand Nr.810, use the A380 towing line. A380 shall be pushback to the dedicated line with nose facing south, then be towed to the stand Nr.810. When aircrafts taxiing on apron taxiline L09 or L08(BTN R5 & E5), it is forbidden to tow A380 to the stand Nr.810. During towing an A380 to the stand Nr.810, other arrival aircraft must hold parallel before R5 on TWYs E or F, and it is forbidden for any aircraft to taxi into the apron through R5 or occupy L09.

3.2.9 When the A380 is going to be towed from stand Nr.810 to stands Nr.71 or 75, it shall be pushback to the dedicated line with nose facing south, then be towed to the stands Nr.71 or 75. When aircrafts taxiing on apron taxiline L09 or L08(BTN R5 or E5), it is forbidden to tow an A380 to stands Nr.71 or 75. During towing an A380 to the stands Nr.71 or 75, other arrival aircraft must hold parallel before R5 on TWYs E or F, and it is forbidden for any aircraft to taxi into the apron through

- 3.2.10 "A380 拖曳专用线"为蓝色虚线。
- 3.2.11 A380 停靠停机位 24 时,停机位 23 只能停放翼 展 52m 以下的航空器。
- 3.2.12 A380 使用 W1 滑入停机位 24; 推出时, 需机 头朝南, 使用 W1 滑出。
- 3.2.13 A380 滑入停机位 168 使用 E1 道口进入机坪; A380 滑入停机位 170 使用 E1、L23 进入机坪。
- 3.2.14 卫星厅机坪及 5 号机坪东侧 A380 推出开车须在 L23 上进行,均使用 E2 滑出;其中停靠停机位 173的 A380 推出开车时机头朝北,停靠停机位 168的 A380 推出开车时机头朝南,停靠停机位 170 的航空器推出开车朝向根据管制员指令执行。在停靠停机位 168、170、173的 A380 推出时,禁止任何航空器使用 E2 滑出。
- 3.2.15 停机位 64 的航空器推出时必须沿"航空器推出 线"推行,鼻轮不得推过"推出等待点"; 其他停机位 的航空器调整至该停机位时,必须机头朝南沿"航空 器停机位引入线"拖曳至停机位,不允许推行至该停 机位。
- 3.2.16 停机位80的航空器推出时必须沿"航空器推出 线"推行, 鼻轮不得推过"推出等待点"; 其他停机位

- R5 or occupy L09.
- 3.2.10 The A380 towing line is blue dotted line.
- 3.2.11 When the A380 parked on stand Nr.24, stand Nr.23 is only AVBL for aircraft with wingspan less than 52m.
- 3.2.12 The A380 taxi into/out stand Nr.24 through W1, and when push back, the aircraft nose faces south.
- 3.2.13 The A380 taxi into stand Nr.168 through E1 and stand Nr.170 through E1, L23.
- 3.2.14 The pushback and engine start procedures for A380 parked on Satellite Apron or Apron Nr.5 must be conducted on L23, and taxi out through E2. When an A380 parked on stand Nr.173 is pushed out, the nose is facing noth, when an A380 parked on stand Nr.168 is pushed out, the nose is facing south, the nose direction of the aircraft parked on stand Nr.170 shall be in accordance with the instructions of the ATC. When the A380 parked on stands Nr.168, 170, 173 push back, it is forbidden for any aircraft to use E2.
- 3.2.15 When the aircraft of stand Nr.64 is pushed back, it must be towed along the aircraft push-back line, the nosegear must not push over the push-back holding point. When other aircraft are adjusted to stand Nr.64, it must be towed to the stand along the aircraft stand lead-in line with nose facing south, and it is not allowed to be pushed to the stand.
- 3.2.16 When the aircraft of stand Nr.80 is pushed back, it must be towed along the aircraft push-back line, the

的航空器调整至该停机位时,必须机头朝北沿"航空器停机位引入线"拖曳至停机位,不允许推行至该停机位。

3.2.17 正常情况下,停机位 301 的航空器需机头朝北推出。在A滑关闭(不含B8)情况下,停机位 301 的航空器推出需机头朝南开车,机组在推出申请时需通报管制员"推出过程中需临时占用B8滑行道",得到管制员许可后机组才能通知地面机务人员开始推出;推至B8道口后,需立刻沿地面滑行线将航空器拖曳至B滑开车,不得长时间占用B8。

3.2.18 在 3 号货运公务机停机区东侧 L15 上有航空器活动时,禁止滑入、滑出停机位 Z11、Z12、Z21、Z22、Z31、Z32。

3.2.19 机场地面管制向塔台管制移交航空器时,管制 员将使用"守听"或"联系"两种管制指令。

3.2.20 目视停靠引导系统的使用规定: 详见 ZSPD AD2.24-2V01/2V02;

#### 3.3 试车限制

3.3.1 在未得到批准的情况下,严禁航空器在停机位 上进行任何类型的发动机试车工作,试车工作应有足

nosegear must not push over the push-back holding point. When other aircraft are adjusted to stand Nr.80, it must be towed to stand along the aircraft stand lead-in line with nose facing north, and it is not allowed to be pushed to the stand.

3.2.17 Normally, aircraft parked on stand Nr.301 are required to push back with the nose facing north. When TWY A(TWY B8 exclusive) close, aircraft parked on stand Nr.301 are required to push back with the nose facing south and start engines in this direction, when applying for push back, the crew must notify the controller that "temporary occupation of TWY B8 is required during the push back procedure", only after obtaining the controller's clearance, the crew can notify the ground maintenance personnel to commence the push back. After pushing the aircraft to B8, immediately tow it along the ground taxiline to TWY B, and must not occupy B8 for a long time.

3.2.18 When aircraft MOV on TXL L15, other aircraft are forbidden to TAX in/out on stands Nr. Z11, Z12, Z21, Z22, Z31, Z32.

3.2.19 CTL instructions "MNT" or "CTC" will be used when aircraft transfered FM GND CTL to TWR CTL.
3.2.20 OPR provisions for Visual DCKG Guidance
System: REF ZSPD AD2.24-2V01/2V02 for details;
3.3 ENG run-ups limits

3.3.1 ENG run-ups on stands are strictly forbidden without permission. There should be sufficient safety

够的安全保护措施, 试车时严格按照有关规定程序进行。

3.3.2 凡需试车的航空器,试车前必须向机场运行指挥中心 AOC 提出申请,由其给出试车机位,再报机坪管制同意后,方可牵引(滑行)到指定机位。慢车测试及冷转测试的试车,经机场运行指挥中心 AOC 和机坪管制批准后,可在指定机位进行。

3.3.3.4 号机坪的停机位 418 为航空器试大车机位: 使用时,一般为机头朝北放置; 当吹南风,且风速 ≥5m/s 时,可向运行指挥中心 AOC 提出申请并得到 批准后,可以机头向东放置,同时停机位 417 不能停 有航空器。

3.4 当停放在近机位的航空器 APU 发生故障推出时,在廊桥处于回位状态下,航空器可以在近机位启动发动机,地面保障人员必须严格按规定程序操作,禁止地面保障人员和各类保障车辆在预推出航空器后侧穿行。

### 3.5 除冰规则

需要除冰的航空器应及早向公司代理申请除冰车在停机位或于指定除冰机位除防冰,除冰开始前需要向机坪管制申请;浦东机场实行全天候定点除防冰,除霜同于除冰。其中,除冰机位分别为510-512、585、586、589、590。

3.5.1 机组应严格遵守机坪管制和机务代表的指令实施各项操作,保持与除冰航空器的安全距离。

protection measures in ENG run-ups, and ENG run-ups should be carried out in strict accordance with the relevant regulations and procedures.

3.3.2 ENG run-ups are SUBJ AOC CLR, test stands given by AOC and approval by APN CTL, and may only be carried out at a designated LCA. AFT approval by AOC and APN CTL, ENG idle test and cool running test may be carried out at designated stands.

3.3.3 Stands Nr.418 on APN Nr.4 can be used to conduct fast ENG run-ups: aircraft shall face to N in NML situation; when the S WSPD more than 5m/s, aircraft shall face to E AFT getting a permission of AOC, while stand Nr.417 shall not be used.

3.4 If aircraft APU is not AVBL, aircrew may start the ENG when boarding bridge is retracted. GND staff shall OPR according to specific PROCs. GND staff and security vehicles are forbidden to go THRU the rear of the aircraft.

3.5 Rules for deicing

CTC the agent of airline as early as POSS for deicing WI the stand or designated stand, CTC APN
CTL BFR starting the progress; Pudong AP implements all-day F-point deicing, defrost equals deicing. Stands
Nr. 510-512, 585, 586, 589, 590 are deicing stands.

3.5.1 FLT crew shall strictly follow APN CTL and aircraft MAINT instructions to carry out various OPS and keep a certain DIST FM the deicing aircraft for safety.

3.6 本场实施机坪运行管制。机坪管制职责:负责该 区域航空器的推出、开车、滑行和其他涉及航空器运 行的指挥工作。

3.6.1 机场机坪管制责任区域范围: 详见 ZSPD AD2.24-1A, 2, 具体管制移交点及移交方式听从管制员指令执行。

3.6.2 离场航空器应在推出开车前联系机坪管制,取得开车许可并在 5min 内执行,否则,重新申请此许可;

3.6.3 航空器滑入、滑出卫星厅东机坪时, 需跟随地面引导车滑行, 推出时均需推到 L24 滑行线上开车。

3.6.4 卫星厅北港湾使用 L26/L26A 进入机坪,使用 L25/L25A 滑出机坪; 卫星厅机坪南港湾使用 L21/L21A 进入机坪,使用 L20/L20A 滑出机坪;停靠 卫星厅机坪南北港湾的航空器进出机坪根据管制员 指令跟随引导车滑行。

3.6.5 本场共设立 10 个滑行强制等待点, 航空器滑行 至该点前必须等待, 并通报地面管制员。参见航图 ZSPD AD2.24-2。 3.6 APN operation CTL implemented. APN CTL duties: Responsible for aircraft push back, ENG on, TAX and other OPS in the area.

3.6.1 机场机坪管制责任区域范围: 详见 ZSPD AD2.24-1A, 2, 具体管制移交点及移交方式听从管制员指令执行。

3.6.2 BFR push-back and start-up, DEPing aircraft shall CTC APN CTL for push-back and start-up CLR and conduct WI 5min, otherwise, apply the CLR once more; 3.6.3 Aircraft TAX in and out Satellite eastern APN shall

be guided by follow-me vehicle and pushed back on

TXL L24 to start-up.

3.6.4 Aircraft use TXL L26/L26A entering and TXL L25/L25A exiting Satellite northern APN; aircraft use TXL L21/L21A entering and TXL L20/L20A exiting Satellite southern APN; aircraft PRKG on Satellite northern/southern APN shall be guided by follow-me vehicle.

3.6.5 There are 10 compulsory HLDG points established for TAX, FLT crew shall hold BFR these points and CTC GND CTL. REF ZSPD AD2.24-2.

强制等待位置			
/Compulsory HLDG point	滑自/TAX on TWY	滑行方向/TAX direction	止于/HLDG BFRTWY
(TWY-TWY)			
A-T3	A	S to N	Т3
В-Т3	В	Story	15

B-T4		N to S	T4
ТЗ-В	Т3	E to W	В
W1-T4	W1	N to S	T4
Т4-Е	T4	W to E	Е
E-T4	F.	N to S	T4
E-T3	E	S to N	Т3
F-T4	F	N to S	T4
F-T3		S to N	Т3

机坪管制将在适当时通知航空器联系塔台管制, 获取 后续管制指令;

3.6.6 本场离港航空器机组可向放行机务申请实施 "边推边开"程序,即边启动内侧发动机(慢车功率) 边推出程序。其中航空器 APU 故障时,可不受"边推 边开"程序限制。本场以下机型及机位禁止实施"边推 边开"程序:

### a. A380 机型;

b. 4 号机坪, 3 号货机坪 Z11-Z16、Z21-Z26、Z31-Z38 机位,卫星厅机坪102、133、134、153机位。

### 4. 低能见度运行

- 4.1 低能见度运行 (II/IIIA 类)
- 4.1.1 低能见度运行程序的准备、实施和结束

4.1.1.1 当跑道视程 RVR 数值降至 1000m 且气象 预报能见度呈下降趋势,或者云底高降至 90m 且气 show a decrease trend, or CIG is FCST to DES 90m

APN CTL will notify the aircraft at appropriate time to CTC TWR CTL for further ATC instructions;

3.6.6 The departure aircraft can apply to the delivery maintenance for implementing "pushback and startup" procedure, which means to startup the inside engines(in idle power) when pushback. Aircraft with APU failure is not subject to this restriction. The following aircraft and stands are prohibited from implementing the "pushback and startup" procedure:

a. A380;

b. Apron Nr.4, stands Nr. Z11-Z16, Z21-Z26, Z31-Z38 of Cargo Apron Nr.3, stands Nr. 102, 133, 134, 153 of Satellite Apron.

### 4. Low visibility operation

- 4.1 LVP OPS(CAT II/IIIA)
- 4.1.1 Preparation, implement and closure of LVP OPS
- 4.1.1.1 When RVR is FCST to DES 1000m and FCST

象

预报云底高呈下降趋势时, 浦东塔台宣布启动低能见 度运行准备程序;

4.1.1.2 当跑道视程 RVR 小于 550m, 或云底高小于 60m 时, 经确认机场和空管具备低能见度运行条件, 浦东塔台通过 D-ATIS 宣布正式实施低能见度运行 (II/IIIA 类);

4.1.1.3 当跑道视程 RVR 大于等于 550m 且气象预 报呈好转趋势,或云底高大于等于 60m 且气象预报 呈好转趋势时, 或机场或空管不具备低能见度运行条 件, 浦东塔台结束低能见度运行。

4.1.2 跑道的使用

4.1.2.1 跑道的运行等级

and FCST show a decrease trend, LVP OPS will be implemented.

4.1.1.2 When RVR < 550m or CIG < 60m, AD and ATC satisfy the RQMNTS of LVP OPS, CAT II/IIIA OPS will be implemented.

4.1.1.3 When RVR≥550m and FCST show a IMPR trend, or CIG≥60m and FCST show a IMPR trend, or AD or ATC cannot satisfy the RQMNTS of LVP OPS, LVP OPS CLSD.

4.1.2 GEN rules for using RWYs

4.1.2.1 The operation grade of RWY:

Operation standard	RWY
ILS CAT II	17L/35R, 34L
ILS CAT IIIA	34L
Low Visibility DEP	17L/35R, 34L

### 4.1.2.2 跑道的运行模式

4.1.2.2 The operation mode of RWY:

Operation direction	RWY
Northward	34L mainly used for ARR, 35R mainly used for DEP
Southward	17L for DEP and ARR

4.1.2.3 浦东机场实施低能见度运行时, A380 应听从 4.1.2.3 When LVP OPS implemented, RWY34L is ATC 指令使用跑道 34L。

AVBL for A380, instructions by ATC.

4.1.3 低能见度运行区域

4.1.3 LVP OPS area

II类/IIIA 类运行区域: 跑道 16R/34L(含)与 17L/35R CAT II/IIIA OPS area: The area BTN

(含)之间区域; 跑道 17L/35R 以西的 P2、P4、L15 RWY16R/34L(include RWY16R/34L) and

滑。

RWY17L/35R(include RWY17L/35R); TWY P2,

P4,TXL L15(W of RWY17L/35R).

4.2 低能见度程序和护卫

4.2 LVP OPS and protection

4.2.1 进场航空器

4.2.1 ARR aircraft:

RWY	TAX RTE
17L	rapid exit TWY A1/A2/A3 or TWY B1/P1→TWY B
34L	rapid exit TWY F3/F4 or TWY R5/E5/R6→TWY F

RMKs: 1. Follow ATC instructions for practical TAX RTE;

2. Aircraft TAX on rapid exit TWY shall REP the ATC "aircraft already vacate RWY" AFT into the PARL TWYs.

4.2.2 离场航空器

4.2.2 DEP aircraft:

RWY	TAX RTE			
17L	TWY A→TWY B7/B8→RWY17L			
35R TWY B→TWY P1/B1→RWY35R				
RMK: When CAT II/IIIA OPR, DEP aircraft shall follow ATC instructions.				

4.2.3 低能见度地面滑行路线:详见

4.2.3 LVP OPS TAX RTE: REF ZSPD

ZSPD AD2.24-2R01/2R02, 2R03/2R04, 2R05/2R06,

AD2.24-2R01/2R02, 2R03/2R04, 2R05/2R06, 2R07.

2R07。

4.3 飞行员应该获得如下信息:

4.3 Aircrew shall acquire INFO as follow:

4.3.1 气象预报

4.3.1 WX FCST;

4.3.2 低能见度程序正在实施

4.3.2 LVP OPS are implementing.

4.4 准备实施II/IIIA 类进近的机组应在与进近管制的首次联系中提出申请。

### 5. 直升机飞行限制,直升机停靠区

无

### 6. 警告

当飞越上海市限制区时,应严格按限制区飞行高度执行,即 QNH1500m(含)以上。

### ZSPD AD 2.21 减噪程序

- 1 噪音限制规定
- 1.1 航空器起飞减噪操作程序,用于起飞爬升阶段,目的是在确保飞行安全的前提下,尽量减少噪音对地面的影响。
- 1.2 浦东机场采用国际民航组织制定的消噪声离场程序 1 (NADP-1), 旨在降低起飞跑道末端附近区域的噪音。
- 2 减噪程序
- 2.1 在保证安全超障和飞行程序最低爬升梯度的条件下,执行如下起飞减噪程序。
- 2.1.1 在航空器起飞性能允许的情况下,尽可能使用 减推力起飞;
- 2.1.2 在高度 450m(1500ft)时,调整和保持发动机爬升功率/推力,保持爬升速度 V2+20km/h(10kt),保持起飞襟翼和缝翼继续爬升;
- 2.1.3 高度 910m(3000ft)以上时, 转为正常航路爬升

- 4.4 Aircrew prepared for CAT II/IIIA APCH shall apply to APP at the FST CTC.
- 5. Helicopter operation restrictions and helicopter parking/docking area

Nil

#### 6. Warning

Aircraft FLY over Shanghai Restricted Area(REF AD2.17) shall keep ALT QNH1500m or ABV.

### **ZSPD AD 2.21 Noise abatement procedures**

- 1 Noise restrictions
- 1.1 Aircraft TKOF NADP is used for TKOF and climbing phase. The purpose is to minimize the impact of noise on GND in the permise of ensuring FLT safety.
- 1.2 Pudong AP adopts the ICAO NADP-1 to reduce noise in the area near DER.
- 2 NADP
- 2.1 In COND of complying with the RQMNTS of OBST CLR and climb gradient required by FLT PROC, the following NADP shall be implemented.
- 2.1.1 The derated TKOF is strongly recommended if the TKOF PER of aircraft permit;
- 2.1.2 At ALT 450m(1500ft), adjust ENG PWR/thrust to climb PWR/thrust and MNTN it, MNTN climbing speed at V2+20km/h(10kt) with flaps and slats in the TKOF configuration;
- 2.1.3 ABV ALT 910m(3000ft), MNTN a positive ROC,

速度并按规定收襟翼/缝翼。

2.2 由于非管制原因不执行减噪飞行操作程序,飞行员须在起飞前告知 ATC 并说明理由(校验飞行等特殊飞行除外)。

### ZSPD AD 2.22 飞行程序

### 1. 总则

- 1.1 本场以 RNAV-1 飞行程序为主用程序(仅提供水平引导),传统飞行程序为备份程序,航空公司原则上只能执行 RNAV-1 飞行程序。
- 1.2 除经上海进近或浦东塔台(适用时)特殊许可外,在上海进近管制区和浦东机场管制地带的飞行,均须按照仪表飞行规则进行。

### 2. 起落航线

17R/35L 起落航线在跑道西侧进行,16L/34R 起落航线在跑道东侧进行; C、D 类航空器高度 QNH450m,A、B 类航空器高度 QNH300m。

### 3. 仪表飞行程序

- 3.1 严格按照航图中公布的进、离场程序和进近程序 飞行。当 ATC 指令高度与进离场程序中各类限制高 度有冲突时,以 ATC 部门的指令高度为准。
- 3.2 上海进近管制区和浦东机场管制地带内的 IFR 飞行程序

accelerate to NML en-route climb speed and retract flaps/slats on SKED.

2.2 If the PROCs can not be implemented due to any reason EXC ATC, pilot shall inform ATC with a reasonable explanation (EXC for special FLT such as CLBR FLT).

## **ZSPD AD 2.22 Flight procedures**

#### 1. General

- 1.1 RNAV-1 FLT PROCs are PRI PROCs(only horizontal guidance AVBL), pilot shall execute these PROCs WO special reasons. Traditional PROCs are SRY PROCs.
- 1.2 FLTs WI Shanghai APP Area and Pudong TWR CTL
  Area shall OPR under IFR unless special CLR has been
  obtained FM Shanghai APP or Pudong TWR(if AVBL)
  CTL.

#### 2. Traffic circuits

TFC circuits shall be made to the W of RWY17R/35L and to the E of RWY16L/34R, at ALT 450m for aircraft CAT C/D, and ALT 300m for aircraft CAT A/B.

### 3. IFR flight procedures

- 3.1 Strict adherence is required to the relevant

  ARR/DEP/APCH PROCs published in the aeronautical
  charts. Follow ATC instructions when the instructions
  have a conflict with the ALT limits in the charts.
- 3.2 IFR FLT PROCs WI Shanghai APP Area and Pudong TWR CTL Area

在上海/杭州进近管制区内严格按 ATC 指挥飞行;如有需要,航空器由 ATC 部门指挥在指定的航路、导航台或点上空等待或做机动飞行。

### 4. 雷达程序和/或 ADS-B 程序

4.1 上海进近管制区域内实施雷达管制。航空器最小水平间隔为 6km;

4.2 距进近跑道末端 18.5km (10NM) 范围内,向同一跑道做最后进近的航空器之间无尾流间隔要求且接地后能在 50s 内脱离跑道时,航空器之间的最小雷达间隔缩短为 5km (湿跑道或污染跑道除外);

通常情况下航空器接地后占用跑道的时间应控制在50s以内。如不能执行上述要求,驾驶员应在不晚于接地前5min通报管制员,管制员将根据空中和地面交通情况视情指挥航空器中止进近或复飞(湿跑道或污染跑道除外);

4.4 通常, 航空器从庵东 VOR(AND)、SASAN、横沙 VOR(HSH)等报告点得到雷达引导和排序, 直至最后 进近航迹(ILS、PAR、VOR/DME), 以加速空中交通 流量。考虑到航空器的性能,按需要发出雷达引导和飞行高度层/高度指令,使航空器之间有一定的距离,以保持正确的着陆间隔。

速度调控:实施 RNAV ILS/DME 进近时,机组应当 严格遵守速度限制。机组应尽可能准确地执行所有的 FLTs WI Shanghai/Hangzhou APP Area shall strictly follow ATC instructions. Aircraft may, if necessary, hold or maneuver on an AWY, over a NAV facility or a fix designated by ATC.

### 4. Radar procedures and/or ADS-B procedures

4.1 Radar CTL WI Shanghai APP has been implemented. The MNM horizontal radar separation is 6km;

4.2 WI 18.5km(10NM) FM APCHing RWY end, if there is no wake TURB BTN two aircrafts APCHing to the same RWY in FNA, and the preceding aircraft is able to vacate RWY WI 50s AFT touchdown, the MNM radar separation can be reduced to 5km (EXC for wet or contaminated RWY);

The RWY occupation time for aircraft AFT touchdown should be WI 50s. If can not meet such STDs, pilot should inform ATC no later than 5min BFR touchdown. ATC will direct the aircraft to abort APCH or go around according to actual TFC situation(EXC for wet or contaminated RWY);

4.4 NMLly, aircraft will be vectored and sequenced FM Andong VOR 'AND', SASAN and Hengsha VOR 'HSH' to the appropriate FNA TR(ILS, PAR, VOR/DME), so as to ensure an expeditious flow of TFC. Instructions ABT radar vectors and FLT LVL/ALT will be issued, as required, for spacing and separating the aircraft so that correct LDG intervals are MNTNed, taking into account aircraft characteristics.

速度限制。如果航空器不能执行上述速度限制,机组 Speed CTL: When OPR RNAV ILS/DME APCH, 应及时通知 ATC 可用的速度。

### 4.5 最低监视引导高度图

参见上海/虹桥机场 ZSSS AD2.22 飞行程序中第 4.4 节以及 ZSPD AD2.24-6B。

### 5. 无线电通信失效程序

- 5.1 航空器单向通信失效
- 5.1.1 如果航空器只具有信号接收能力,根据接收到 的管制指令继续飞行,同时管制员将向沿途有关管制 单位发送有关通信失效的情报;
- 5.1.2 如果航空器只具有信号发送能力, 航空器驾驶 员应立即将飞行意图告知管制员,并及时报告位置和 高度信息,管制员根据航空器驾驶员报告的意图迅速 调配其他飞机避让,如有可能,管制员将通知航空器 运营人使用其内部通信方式与该航空器联系。
- 5.2 航空器双向通信失效
- 5.2.1 航空器进场
- 5.2.1.1 如果本场不具备落地条件, 航空器驾驶员可自 行决定返航或备降。
- 5.2.1.2 收到管制员进港程序指令的航空器,按照程序 飞行和下降,之后根据最后收到的通播选择就近的跑 道着陆;
- 5.2.1.3 未收到管制员进港程序指令的航空器,按照现 行飞行计划航路飞至上海浦东机场提供服务的定位 点,在该定位点等待直到按照或尽可能接近于最后确 认收到的预计进近时刻开始下降,并按照规定的程序

aircrew should execute at all speed limit. If can not, they shall inform ATC of AVBL speed IMT.

4.5 Surveillance MNM ALT SECTs

REF SHANGHAI/Hongqiao ZSSS AD2.22 item 4.4, and ZSPD AD2.24-6B.

### 5. Radio communication failure procedures

- 5.1 Aircraft COM partly failure
- 5.1.1 If the RDO REC AVBL, aircraft shall follow the instruction to FLY. ATC should inform the concerned ATC unit at the same time.
- 5.1.2 If the RDO TRANS AVBL, aircraft pilot shall notify her/his FLT intention to ATC and REP aircraft PSN. ATC will conduct the TFC accordingly. If POSS, ATC shall CTC the AO to establish inner COM with the aircraft.
- 5.2 Aircraft COM totally failure
- 5.2.1 ARR for ZSPD
- 5.2.1.1 When COND of AD not AVBL for LDG, the aircraft can decide to RTN or ALTN.
- 5.2.1.2 Aircraft with ATC ARR instruction shall follow the PROC to FLY and descend, choose LDG RWY according to the last RECd ATIS.
- 5.2.1.3 Aircraft WO ATC ARR instruction shall follow FPL RTE FLY to the fix in SER WI AD. HLDG at the fix TIL the last RECd EAT as nearly as POSS, descend and follow the PROC to land. RWY choosing shall

和根据最后收到的通播选择就近的跑道着陆。

5.2.2 航空器离场

according to the last RECd ATIS.

5.2.2 DEP FM ZSPD

Nil

5.2.2.1 航空器应按照最后接收到的管制指令(程序) 继续离场,管制员将迅速组织其它航空器进行避让; 5.2.2.1 Aircraft shall follow the last RECd instruction(PROC) to DEP, others should IMT give way to this aircraft by ATC;

5.2.2.2 如航空器驾驶员选择返回起飞机场飞行,则应按照标准仪表离场(SID)至少飞至 SID 终点,之后根据最后收到的通播中着陆跑道选择标准仪表进场(STAR)和落地跑道,并从 STAR 起点加入程序。

5.2.2.2 If the aircraft decide to RTN, shall follow SID TIL the end, then choose STAR and RWY to land according to the last RECd ATIS. Aircraft shall join the STAR FM the start.

End of	PIKAS	SASAN	NXD	AND	HSN	ADBA	MIGOL	LAME	SURA	ODUL
SID	TIKAS	SASAN	NAD	AND	11511	S	MIGOL	N	K	О
Start of										
STAR(r	SASAN		AND				DUMET			MATN
ecomm	SASAN		AND				DUMEI			U
ended)										

5.2.2.3 如果航空器驾驶员判断无法继续实施离场飞行,且需至放油区放油的,可在放油完成后,自行根据当时的运行方向选择进近着陆方法,管制员将迅速组织其它航空器进行避让。

### 5.2.3 本场通信失效

本场无线电收发功能失效, 航空器无法与管制单位建立有效的通讯联系时, 航空器应联系上一管制单位, 并按照接收管制单位的管制指令继续飞行;

5.2.4 无线电通信恢复

5.2.2.3 If DEP is unsustainable and aircraft need to dump fuel in the fuel dumping area, the FLT crew can choose way to APCH and land AFT dumping fuel.

Others should IMT give way to this aircraft by ATC.

### 5.2.3 AD COM failure

If aircraft cannot establish COM with the AD CTL unit, aircraft shall CTC the previous CTL unit, and follow the instruction to CONT;

5.2.4 RDO COM RTN to NML

失去通信联络的航空器已经着陆,或者已经恢复联络的,可恢复正常的管制运行,并立即通知相关管制单位。

### 6. 目视飞行程序

- 6.1 航空器得到仪表进近的指令后,应根据机载设备或目视监控周边航空器的运行状态,并尽最大可能建立目视间隔;同时在管制员通报其它航空器的相对位置时,向管制员报告已建立目视间隔。若飞行员不能目视相关航空器,管制员将视情况指挥该航空器中止进近或复飞。
- 6.2 机场实施多跑道目视进近,实施目视进近的航空器应控制表速,预计飞行航迹距接地点 7NM 时速度 180kt,如机组不能按照上述速度执行时,应及时通知管制员。航空器应遵守目视间隔飞行规定。
- 6.3 当浦东机场能见度不小于 5km, 云底高不低于 300m 时, 将实施目视进近和目视间隔。
- 6.4 浦东机场实施目视进近和目视间隔前, 航空器驾驶员需向管制员报告是否看到机场、跑道或者前续落地的航空器。
- 6.5 当实施目视进近的航空器驾驶员明确表示能够目视另一架航空器并接受目视间隔时,航空器驾驶员应当负以下职责:
- 6.5.1 始终保持对相关航空器的目视监控,并保持与

It is AVBL to resume activities when the aircraft that lose touch via COM CH has landed or get in touch AGN. Inform the ATC office IMT.

### 6. Procedures for VFR flights

- 6.1 Upon receipt of APCH CLR, pilot shall MNT the OPR situations of other aircraft in the VCY using airborne EQPT or visual and establish the visual separation as practicable, then REP 'visual separation established' when ATC notifies the relative PSNs of other aircraft. If pilot can not visual the relative aircraft, ATC will direct the aircraft to abort APCH or go around according to actual TFC situation.
- 6.2 PARL RWYs visual APCH implemented in AP. Pilot shall CTL IAS, and IAS shall be 180kt when the DIST of projected FLT path to touchdown is 7NM. If speed RQMNTS cannot implemented, pilot shall inform ATC. Pilot shall obey separation of VFR.
- 6.3 If VIS is no less than 5km and CIG is no less than 300m, visual APCH and visual separation will be implemented.
- 6.4 BFR implementation of visual APCH and visual separation, pilot shall REP to ATC whether visual the AP, the RWY or the preceding aircraft.
- 6.5 When pilot implementing the visual APCH indicates that another aircraft is in sight and ACPTs the visual separation, the pilot shall take the following responsibilities:
- 6.5.1 MNTN visual surveillance and safe separation

相关航空器间的安全间隔;

6.5.2 为保持与相关航空器的安全间隔作必要的调速、机动飞行及避开尾流影响区域;

6.5.3 当无法目视相关航空器或为保持与相关航空器 间的安全间隔所采取的各种措施必须及时通报管 制员,以便重新为其配备其他的安全间隔。

6.6 在仪表进近程序的最后进近阶段使用目视间隔时,航空器驾驶员应按照仪表程序进近,并保持目视判断与其他相关航空器间的安全间隔。

6.6.1 当航空器进近至决断高度时,会遇到在同一跑 道上前面着陆的航空器正在着陆滑跑,或者正在起飞 的航空器即将离地的情况。当航空器驾驶员认为必要 时,随时可以复飞并立即通报管制员。

6.6.2 近距跑道运行时,当航空器进近至决断高度时, 会遇到相邻近距跑道上的航空器正在起飞滑跑,航空 器驾驶员需加强目视观察。当航空器驾驶员认为必要 时,随时可以复飞并立即通报管制员。

### 7. 目视飞行航线

无

## 8. 其它规定

8.1 机组收到进入跑道指令后,必须在确保安全的前提下,在前机滑跑后,立即按照标准运行程序从等待

continously with relevant aircrafts.

6.5.2 Necessary speed adjustment, maneuvering and avoiding the wake TURB affected area.

6.5.3 Notify ATC IMT of UNA to visual relevant aircrafts or take measures to MNTN the safety separation with relevant aircrafts then wait for new separation assignment.

6.6 When visual separation is applied DRG the FNA of IAP, pilot should follow the PROC and MNTN visual judgement ABT the safety separation with other relevant aircrafts.

6.6.1 hen aircraft DES DA, some situations may be OBS, such as the preceding aircraft is rolling out the same RWY, or the DEP aircraft is lifting off. Under such situation, pilot can make a missed APCH at any moment if it is considered to be necessary and notify ATC IMT.
6.6.2 When aircraft DES DA, some situations may be OBS, such as the preceding aircraft is vacating the ADJ RWY, or the DEP aircraft FM the ADJ RWY is lifting off. Under such situation, pilot shall be careful and can make a missed APCH at any moment if it is considered to be necessary and notify ATC IMT.

### 7. VFR route

Nil

#### 8. Other regulations

8.1 Upon receiving the instruction of entering RWY and observing the preceding aircraft start to roll, pilot shall

位置滑行至跑道内正确位置。

8.2 如果接到立即起飞指令,飞行员必须向 ATC 确认 是否可以执行立即起飞。

## ZSPD AD 2.23 其它资料

### 鸟情资料

全年有鸟类活动,机场当局采取了驱赶措施,以减少 鸟群活动。鸟的活动情况如下: make sure the safety DIST with the preceding aircraft and TAX FM the HLDG PSN to the right place of the RWY following the STD OPR PROC IMT.

8.2 Upon receiving the instruction of TKOF IMT, pilot must CFM whether IMT TKOF can be implemented.

### **ZSPD AD 2.23 Other information**

### Bird's information

Activities of bird flocks are found all the year round, AD

Authority resorts to dispersal methods to reduce bird

activities. The details of bird activities as follows:

Bird name	ACT time	Residence type	FLT HGT(m)	Characteristic	
Pheasant			0-10		
Dove	The whole year	Resident	0-20	Solitary and in group	
Night heron			0-80		
Chinese Pond Heron	Apr.—Oct.		0-20		
Common Kestrel	Mar.—Oct.		0-30	Solitary	
Common Buzzard	Oct.—Mar.(next		0-50	- Solitary	
	year)				
Barn Swallow	Apr.—Sep.				
Charadriiformes	Oct.—May(next	Migrant	0-30		
Charachinonnes	year)				
Egret	Mar.—Sep.			In group	
Cattle Egret	Jun.—Sep.		0-50		
Grey-headed	Aug.—Feb.(next				
Lapwing	year)				

Anatidae	Nov.—Mar.(next	0-100	
7 Hatrode	year)	0-100	

Migratory Season		Area of migration ACT	FLT HGT(m)	
Spring	EM Mor to Moy	Around the AP	0-150	
Spring	FM Mar. to May	High ALT migration	800-3000	
Summer	FM Jun. to Aug.	Around the AP	0-150	
Autumn	FM Sep. to Nov.	Around the AP	0-150	
		High ALT migration	800-3000	
Winter	FM Dec. to Feb.(next	Around the AP	0-300	
winter	year)	High ALT migration	800-3000	