YMF825(SD-1) IF specification

Caution

Although this manual is created based on the SD-1 specifications, only the information necessary for YMF825Board is described. Therefore, please understand beforehand that it is not a complete specification of SD-1.

In addition, please understand that we will not guarantee any results by using SD-1 based on the contents posted in this manual.

Features

- 16-voice polyphonic FM synthesizer
- 29 on-chip operator-waveforms and 8 algorithms offers a whole variety of sound
- Synchronous serial data link for host controller interface
- Integrated loudspeaker driver (Also supports external amplifier connection)
- Integrated 3-band equalizer
- Integrated 16-bit monaural DAC

Interface Register

System Setting

• I_ADR#0-2, 4, 29 can be accessed even when the ALRST is "1".

As might be expected, other registers can be accessed only when the ALRST is "0".

I_ADR	Name	W/R	D7	D6	D5	D4	D3	
#0	Clock Enable	W/R	"0"	"0"	"0"	"0"	"0"	"
#1	Reset Analog Block		ALRST	"0"	"0"	"0"	"0"	11
#2	Power-down control		"0"	"0"	"0"	"0"	AP3	A
#3	Speaker Amplifier Gain Setting	W/R	"0"	"0"	"0"	"0"	"0"	"
#4	Hardware ID	R	"0"	"0"	"0"	"0"	"0"	11
#5	Interrupt	W/R R	"0"	"0"	"0"	EMP_DW	"0"	F
#6		W/R	"0"	EIRQ	"0"	EEMP_DW	"0"	E
#7	Contents Data Write Port	W	DT7	DT6	DT5	DT4	DT3	С
#8	Sequencer Setting	W/R	AllKeyOff	AllMute	AllEGRst	R_FIFOR	REP_SQ	F
#9		W/R	SEQ_Vol4	SEQ_Vol3	SEQ_Vol2	SEQ_Vol1	SEQ_Vol0	Г
#10		W/R	SIZE7	SIZE6	SIZE5	SIZE4	SIZE3	S

#11	Synthesizer Setting	W/R	"0"	"0"	"0"	"0"	CRGD_VNO3	(
#12		W	"0"	VoVol4	VoVol3	VoVol2	VoVol1	٧
#13		W	"0"	"0"	FNUM9	FNUM8	FNUM7	Е
#14		W	"0"	FNUM6	FNUM5	FNUM4	FNUM3	F
#15		W	"0"	KeyOn	Mute	EG_RST	ToneNum3	Т
#16		W	"0"	ChVol4	ChVol3	ChVol2	ChVol1	C
#17		W	"0"	"0"	"0"	"0"	"0"	Х
#18		W	"0"	"0"	"0"	INT1	INT0	F
#19		W	"0"	FRAC5	FRAC4	FRAC3	FRAC2	F
#20		W	"0"	"0"	"0"	"0"	"0"	"
#21	Control Register	W/R	RDADR_CRG7	RDADR_CRG6	RDADR_CRG5	RDADR_CRG4	RDADR_CRG3	F
	Read Port							
#22		R	"0"	RDDATA_CRG6	RDDATA_CRG5	RDDATA_CRG4	RDDATA_CRG3	F
#23	Sequencer Time unit Setting	W/R	"0"	MS_S13	MS_S12	MS_S11	MS_S10	Ν
#24	3	W/R	"0"	MS_S6	MS_S5	MS_S4	MS_S3	Ν
#25	Master Volume	W/R	MASTER_VOL5	MASTER_VOL4	MASTER_VOL3	MASTER_VOL2	MASTER_VOL1	Ν
#26	Soft Reset	W/R	SFTRST7	SFTRST6	SFTRST5	SFTRST4	SFTRST3	S
#27	Sequencer Delay, Recovery Function Setting,	W/R	"0"	DADJT	MUTE_ITIME1	MUTE_ITIME0	CHVOL_ITIME1	C
	Volume Interpolation Setting							
#28	LFO Reset	W/R	"0"	"0"	"0"	"0"	"0"	"
#29	Power Rail Selection	W/R	"0"	"0"	"0"	"0"	"0"	"
#30	Reserved							
#31	Reserved							
Note								

• Before you write I_ADR#12-19 of Synthesizer Setting, you first have to write channel number to CRGD_VNO[3:0] (I_ADR#11).

EQ Coeffcient Setting

I_ADF	R Name	W/R	D7-D0	Reset Value
#32	EQ BAND0 coefficient Write Por	tW \	W_CEQ0[7:0]	00H
#33	EQ BAND1 coefficient Write Por	tW \	W_CEQ1[7:0]	00H
#34	EQ BAND2 coefficient Write Por	tW \	W_CEQ2[7:0]	00H
#35	Equalizer Coefficient Read Ports	R (CEQ00[23:16]	10H
#36		R (CEQ00[15:8]	00H

#37	R	CEQ00[7:0] 00H
#38	R	CEQ01[23:16] 00H
#39	R	CEQ01[15:8] 00H
#40	R	CEQ01[7:0] 00H
#41	R	CEQ02[23:16] 00H
#42	R	CEQ02[15:8] 00H
#43	R	CEQ02[7:0] 00H
#44	R	CEQ03[23:16] 00H
#45	R	CEQ03[15:8] 00H
#46	R	CEQ03[7:0] 00H
#47	R	CEQ04[23:16] 00H
#48	R	CEQ04[15:8] 00H
#49	R	CEQ04[7:0] 00H
#50	R	CEQ10[23:16] 10H
#51	R	CEQ10[15:8] 00H
#52	R	CEQ10[7:0] 00H
#53	R	CEQ11[23:16] 00H
#54	R	CEQ11[15:8] 00H
#55	R	CEQ11[7:0] 00H
#56	R	CEQ12[23:16] 00H
#57	R	CEQ12[15:8] 00H
#58	R	CEQ12[7:0] 00H
#59	R	CEQ13[23:16] 00H
#60	R	CEQ13[15:8] 00H
#61	R	CEQ13[7:0] 00H
#62	R	CEQ14[23:16] 00H
#63	R	CEQ14[15:8] 00H
#64	R	CEQ14[7:0] 00H
#65	R	CEQ20[23:16] 10H
#66	R	CEQ20[15:8] 00H
#67	R	CEQ20[7:0] 00H
#68	R	CEQ21[23:16] 00H
#69	R	CEQ21[15:8] 00H
#70	R	CEQ21[7:0] 00H
#71	R	CEQ22[23:16] 00H
#72	R	CEQ22[15:8] 00H
#73	R	CEQ22[7:0] 00H
#74	R	CEQ23[23:16] 00H
#75	R	CEQ23[15:8] 00H
#76	R	CEQ23[7:0] 00H
#77	R	CEQ24[23:16] 00H
#78	R	CEQ24[15:8] 00H
#79	R	CEQ24[7:0] 00H

Software Communication Check

I_ADR Name W/R D7 D6 D5 D4 D3 D2 D1 D0 $\frac{\text{Reset}}{\text{Value}}$

#80 Software test communication W/R COMM7 COMM6 COMM5 COMM4 COMM3 COMM2 COMM1 COMM0 00H

Read/Write Accesses to Interface Registers


SPI Specification

- MSB first
- Mode 0
- max 10MHz

Single Write

2 bytes (16 bits) is needed for one write access: 1-byte write command and 1-byte write data. Be sure to access the register in two bytes (16 bits).

The /SS pin should be set to "H" for each two-byte write access.



Burst Write


In the burst write operation, data can be written into the same interface register address in succession.

Enter multiple data consecutively for one write command like this: [write command + data + data +...]. This device interprets the /SS pin being "H" as the end of the write access; therefore, be sure to set this pin to "H" after the

burst write operation.

Each data should be one byte. If the /SS pin is set to "H" at less than 1 byte, such as 6 bits, unusual operation may occur

because of an illegal write operation.




Read Access

Setting the bit WR (command) to "1" indicates a read access command.

The read data is transmitted in synchronization with the falling edges of the SCK from the 9th clock. The data is in MSB first format (D7 \rightarrow D0).

The following shows the details of the SO pin:

- During the latter 8 clock cycles, the read data (D[7:0]) is transmitted in MSB first format.
- The SO pin goes to a high-impedance state (Hi-Z) whenever the data is not being read.



Tone Parameter Memory Map

T_ADR	Name	D7	D6	D5	D4	D3	D2	D1	D0
#0+30x[tn]	Entire Tone Setting	"0"	"0"	"0"	"0"	"0"	"0"	BO1	BO0
#1+30x[tn]		LFO1	LFO0	"0"	"0"	"0"	ALG2	ALG1	ALG0
#2+30x[tn]	Operator1 Setting	SR3	SR2	SR1	SR0	XOF	"0"	"0"	KSR
#3+30x[tn]		RR3	RR2	RR1	RR0	DR3	DR2	DR1	DR0
#4+30x[tn]		AR3	AR2	AR1	AR0	SL3	SL2	SL1	SL0
#5+30x[tn]		TL5	TL4	TL3	TL2	TL1	TL0	KSL1	KSL0
#6+30x[tn]		"0"	DAM1	DAM0	EAM	"0"	DVB1	DVB0	EVB
#7+30x[tn]		MULTI3	MULTI2	MULTI1	MULTI0	"0"	DT2	DT1	DT0
#8+30x[tn]		WS4	WS3	WS2	WS1	WS0	FB2	FB1	FB0
#9+30x[tn]	Operator2 Setting	SR3	SR2	SR1	SR0	XOF	"0"	"0"	KSR
#10+30x[tn]		RR3	RR2	RR1	RR0	DR3	DR2	DR1	DR0
#11+30x[tn]		AR3	AR2	AR1	AR0	SL3	SL2	SL1	SL0
#12+30x[tn]		TL5	TL4	TL3	TL2	TL1	TL0	KSL1	KSL0
#13+30x[tn]		"0"	DAM1	DAM0	EAM	"0"	DVB1	DVB0	EVB
#14+30x[tn]		MULTI3	MULTI2	MULTI1	MULTI0	"0"	DT2	DT1	DT0
#15+30x[tn]		WS4	WS3	WS2	WS1	WS0	"0"	"0"	"0"
#16+30x[tn]	Operator3 Setting	SR3	SR2	SR1	SR0	XOF	"0"	"0"	KSR
#17+30x[tn]		RR3	RR2	RR1	RR0	DR3	DR2	DR1	DR0
#18+30x[tn]		AR3	AR2	AR1	AR0	SL3	SL2	SL1	SL0
#19+30x[tn]		TL5	TL4	TL3	TL2	TL1	TL0	KSL1	KSL0
#20+30x[tn]		"0"	DAM1	DAM0	EAM	"0"	DVB1	DVB0	EVB
#21+30x[tn]		MULTI3	MULTI2	MULTI1	MULTI0	"0"	DT2	DT1	DT0
#22+30x[tn]		WS4	WS3	WS2	WS1	WS0	FB2	FB1	FB0
#23+30x[tn]	Operator4 Setting	SR3	SR2	SR1	SR0	XOF	"0"	"0"	KSR
#24+30x[tn]		RR3	RR2	RR1	RR0	DR3	DR2	DR1	DR0

#25+30x[tn]	AR3	AR2	AR1	AR0	SL3	SL2	SL1	SL0
#26+30x[tn]	TL5	TL4	TL3	TL2	TL1	TL0	KSL1	KSL0
#27+30x[tn]	"0"	DAM1	DAM0	EAM	"0"	DVB1	DVB0	EVB
#28+30x[tn]	MULTI3	MULTI2	MULTI1	MULTI0	"0"	DT2	DT1	DT0
#29+30x[tn]	WS4	WS3	WS2	WS1	WS0	"0"	"0"	"0"

Note

- T_ADR means Tone Setting format of Cotents Format(below).
- tn: Tone Number(0-15)

Contents Format

The contents format specifies tone parameters and the sequence of data that can be played back with this device consists of melody contents.

The contents are written into the register (I_ADR#7: CONTENTS_DATA_REG) via the CPU interface.

Data format

- Header: 1byte(80H + Maximum Tone Number)
- Tone Setting 30 to 480bytes(it depends on the number of the configured tones)
- Sequence Data(any size)
- End(80H,03H,81H,80H)

Tone Setting

The tone parameters are set by the number of tones set to the Header.

The parameter consists of 30 bytes of data for one tone.

The data are transferred and assigned to the Tone parameter memory from Tone 0 in the order they are written; therefore, parameters of an intermediate Tone number cannot be written first. For details of the tone parameters, see "Tone Parameter"(fbd spec3.md).

Initialization Procedure

1. Supply the power to the device.

The power supply should be powered with RST_N pin held "L" when the power-on reset requirements cannot be satisfied.

2. Wait for 100us after supply voltages rise

up to the specified level.

This period of time is the time required for the regulator stabilization.

3. Set the RST_N pin to "H".

The hardware reset state is removed.

No need to set to "H" when this device is used with RST_N pin held "H".

4. Set DRV_SEL to "0" when this device is used in single 5-V power supply configuration.

Set DRV_SEL to "1" when this device is used in dual power supply configuration.

The power rail is selected.

- 5. Set the AP0 to "0". The VREF is powered.
- 6. Wait until the clock becomes stable.

The duration of the time required for stable crystal oscillation.

7. Set the CLKE to "1".

Clocks are supplied to the internal circuit.

8. Set the ALRST to "0".

The reset state of the internal circuits is removed.

9. Set the SFTRST to "A3H".

The synthesizer block is initialized.

- 10. Set the SFTRST to "00H".
- 11. Wait for 30ms after the step 10.

This period of time is the time required for the VREF stabilization and the SFTRST completion.

12. Set the AP1 and the AP3 to "0".

The power-down state of Audio Out is removed.

13. Wait for 10us.

This period of time is the time required for preventing pop noise. Use this time for setting the synthesizer etc.

14. Set the AP2 to "0".

The power-down state of the Audio Out is removed.