

everyday genius

MT8183 HDMI

Version: 1.0

Release date: 2019-10-16

© 2015 - 2019 MediaTek Inc.

This document contains information that is proprietary to MediaTek Inc. ("MediaTek") and/or its licensor(s). MediaTek cannot grant you permission for any material that is owned by third parties. You may only use or reproduce this document if you have agreed to and been bound by the applicable license agreement with MediaTek ("License Agreement") and been granted explicit permission within the License Agreement ("Permitted User"). If you are not a Permitted User, please cease any access or use of this document immediately. Any unauthorized use, reproduction or disclosure of this document in whole or in part is strictly prohibited. THIS DOCUMENT IS PROVIDED ON AN "AS-IS" BASIS ONLY. MEDIATEK EXPRESSLY DISCLAIMS ANY AND ALL WARRANTIES OF ANY KIND AND SHALL IN NO EVENT BE LIABLE FOR ANY CLAIMS RELATING TO OR ARISING OUT OF THIS DOCUMENT OR ANY USE OR INABILITY TO USE THEREOF. Specifications contained herein are subject to change without notice.







Specifications are subject to change without notice.



Document Revision History

Revision	Date	Description	
1.0	2019-03-04	Initial Draft	
			2 0



Table of Contents

Doci	ument l	Revision	History		3
					1
					כ
	1.1	Purpos	e		5
	1.2		ons, Acronyms and Abbreviations		
	1.3	Referer	nces		5
	1.4		ew		
2.	Spec	ific Conte	ents		ì
	2.1	Introdu	iction of MT8183 HDMI		ŝ
	2.2		3 HDMI Feature		
	2.3	MT818	3 HDMI Hardware connection	6	ò
	2.4 MT8183 HDMI software overview		3 HDMI software overview		ò
		2.4.1	Software overview 1		
		2.4.2	Software overview 2	ī	1
		2.4.3	Software overview 3		3
		2.4.4	Software overview 4		
	2.5	MT818	3 HDMI software configuration		



1. Introduction

The document is about MT8183 HDMI software configuration.

1.1 Purpose

The document is for customer to configure and use HDMI in MT8183 Project.

1.2 Definitions, Acronyms and Abbreviations

No

1.3 References

No

1.4 Overview

Section 1 is the introduction and includes a description of the project. Section 2 is about 8183 hdmi feature.



2. Specific Contents

2.1 Introduction of MT8183 HDMI

MT8183 HDMI is implemented by using companion chip(ITE66121), and use DPI I/F for video data, I2S I/F for audio data, I2C for control.

The HDMI resolution is limited by MT8183 system performance, which is 1080p@30Hz highest now.

2.2 MT8183 HDMI Feature

- a. Resolution Support (up to 74MHz)
- b. 480p,720p@60Hz,1080p@30Hz
- c. HDCP is not Supported
- d. Support RGB color space
- e. Support PCM 44.1/48K 2CH
- f. Not support CEC

2.3 MT8183 HDMI Hardware connection




Figure 2-1. hardware connection

2.4 MT8183 HDMI software overview

2.4.1 Software overview 1






Figure 2-2. software block diagram

2.4.2 Software overview 2

- a. Support resolution1080p@30Hz,720p@60Hz, 480p
- b. Note:

Resolution list depend on EDID.

It will select the resolution output if one resolution is selected and TV support

© 2015 - 2019 MediaTek Inc.

Page 7 of 12



2.4.3 Software overview 3

Receive the broadcast of HDMI states

- a. Active
 - **Enable HDMI**
 - Get EDID
 - Initialize color space / deep color / resolution
 - Show notification on status bar
- b. No device / plug-in only
 - Disable HDMI
 - Clear EDID
 - Clear notification

2.4.4 Software overview 4



Figure 2-3. kernel driver flow



2.5 MT8183 HDMI software configuration

Turn on following options to enable MT8183 HDMI feature (the words with green color depends on your project)

1. Add config

```
kernel-4.14/arch/arm64/configs/aiv8183m1_64_bsp_debug_defconfig
kernel-4.14/arch/arm64/configs/aiv8183m1_64_bsp_defconfig
CONFIG CUSTOM KERNEL HDMI="ITE66121"
```

2. Device tree configuration

kernel-4.14/arch/arm64/boot/dts/aiv8183m1_64_bsp.dts add red label code as the following picture.

```
vib timer = \langle 25 \rangle;
        vib limit = <9>;
        vib_vol= <9>;
    ite166121 hdmi: ite166121 hdmi@0
        compatible = "mediatek, mt8183-hdmitx";
    };
    mt pmic customization: mt pmic customization@0 {
        compatible = "mediatek, mt-pmic-custom-setting";
        custom-reg = <0x1c32 0x1 0x7 0x0 /* LDO VRF12 OP EN *
                   0x18ba 0x1 0x1 0x0 /* RG VPA NDIS EN *7
        disable-modem =
    };
};
&ite166121 hdmi {
    pinctrl-names = "hdmi poweron", "hdmi poweroff";
   pinctrl-0 = <&hdmi_pins_funcmode>;
    pinctrl-1 = <&hdmi pins gpiomode>;
```

Figure 2-4. device tree configuration 1

```
Confidential B
```

```
&ite166121_hdmi {
    pinctrl-names = "hdmi_poweron", "hdmi_poweroff";
    pinctrl-0 = <&hdmi_pins_funcmode>;
    pinctrl-1 = <&hdmi_pins_gpiomode>;|
    vcn33-supply = <&mt_pmic_vcn33_wifi_ldo_reg>;
    vcn18-supply = <&mt_pmic_vcn18_ldo_reg>;
    vrf12-supply = <&mt_pmic_vrf12_ldo_reg>;
    hdmi_power_gpios = <&pio 160 0>;
    status = "okay";
    ports {
        it66121_in: endpoint {
            remote-endpoint = <&dpi_out>;
        };
    };
};

&dpi {
```

Figure 2-5. device tree configuration 2

```
};
};

&dpi {
    status = "okay";
    port {
        dpi_out: endpoint {
            remote-endpoint = <&it66121_in>;
        };
};
```

Figure 2-6. device tree configuration 3



```
hdmi_pins_funcmode: hdmi pins funcmode {
    pins cmd dat {
        pinmux = <PINMUX GPIO12
                                  FUNC 12S5 BCK>,
                                          FUNC 1285
                         <PINMUX GPIO46
                                                    LRCK>,
                                          FUNC 12S5 DO>.
                         <PINMUX GPIO47
                                          FUNC DBPI DO>,
                         <PINMUX GPIO13
                         <PINMUX GPIO14
                                          FUNC DBPI D1>,
                         <PINMUX GPIO15
                                          FUNC DBPI D2>,
                         <PINMUX GPIO16
                                          FUNC DBPI
                                                    D3>,
                         <PINMUX GPIO17
                                          FUNC DBPI D4>,
                         <PINMUX GPIO18
                                          FUNC DBPI D5>,
                         <PINMUX GPIO19
                                          FUNC DBPI D6>,
                         <PINMUX GPI020
                                               DBPI D7>,
                                          FUNC
                         <PINMUX GPIO21
                                          FUNC
                                               DBPI
                                                    D8>,
                         <PINMUX GPI022
                                          FUNC DBPI
                                                    D9>.
                         <PINMUX GPI023
                                          FUNC DBPI
                                                    D10>,
                         <PINMUX GPI024
                                          FUNC DBPI D11>,
                         <PINMUX GPIO25
                                         FUNC DBPI
                                                    HSYNC>,
                         <PINMUX GPIO26
                                          FUNC DBPI
                                                    VSYNC>,
                         <PINMUX GPI027
                                         FUNC
                                               DBPI DE>,
                         <PINMUX GPIO28
                                          FUNC
                                               DBPI CK>,
                         <PINMUX GPIO113
                                           FUNC SCL6>,
```

Figure 2-7. device tree configuration 4

```
<PINMUX GPIO114 FUNC SDA6>;
    };
hdmi pins gpiomode: hdmi pins gpiomode {
    pins cmd dat
        pinmux = <PINMUX
                          GPIO12
                                   FUNC GPIO12>,
                         ≼PINMUX GPIO46
                                          FUNC GPIO46>,
                          <PINMUX GPIO47
                                          FUNC GPIO47>,
                         <PINMUX GPIO13
                                          FUNC GPI013>,
                         <PINMUX GPIO14
                                          FUNC GPIO14>,
                         <PINMUX GPIO15
                                          FUNC GPIO15>,
                          <PINMUX GPIO16
                                          FUNC
                                               GPIO16>,
                          <PINMUX GPIO17
                                          FUNC GPIO17>,
                          <PINMUX GPIO18
                                          FUNC GPIO18>,
                         <PINMUX GPIO19
                                           FUNC GPIO19>,
                                          FUNC GPIO20>,
                         <PINMUX GPIO20
                          <PINMUX GPIO21
                                           FUNC
                                               GPIO21>,
                         <PINMUX GPIO22
                                          FUNC GPI022>,
                         <PINMUX GPIO23
                                          FUNC GPIO23>,
                         <PINMUX GPIO24
                                           FUNC GPIO24>,
                         <PINMUX GPIO25
                                           FUNC GPIO25>,
                         <PINMUX GPIO26
                                          FUNC
                                               GPIO26>,
                         <PINMUX GPIO27
                                          FUNC GPIO27>,
                         <PINMUX GPIO28
                                          FUNC GPIO28>,
```

Figure 2-8. device tree configuration 5



Figure 2-9. device tree configuration 6

```
compatible = "mediatek, mt8183-disp-mutex";
```

Figure 2-10. device tree configuration 7