## 26、Image pyramid sampling algorithm

## 26.1、Use

Source code launch file path: ~/jetcobot\_ws/src/opencv\_apps/launch

Step 1: Start the camera

roslaunch jetcobot\_visual opencv\_apps.launch img\_flip:=false

• img\_flip parameter: whether the image needs to be flipped horizontally, the default is false.

Step 2: Start the corner detection function of Opencv\_apps

roslaunch opencv\_apps pyramids.launch
algorithm

# Image pyramid sampling

Each functional case will have a parameter [debug\_view], Boolean type, whether to use Opencv to display images, which is displayed by default.

If no display is required, set it to [False], for example

roslaunch opencv\_apps contour\_moments.launch debug\_view:=False

However, after starting in this way, some cases cannot be displayed in other ways, because in the source code, some [debug\_view] is set to [False], which will turn off image processing.

## 26.2、Display method

rqt\_image\_view

Enter the following command to select the corresponding topic

rqt\_image\_view

opencv

The system displays it by default, no need to do anything.

## 26.3、Effect display

Effect picture:

