PWM

PWM

Introduction wiring
Output PWM signal

Introduction

In this tutorial, we will learn how to use the K230 GPIO interface to output PWM signals.


What is PWM signal?

PWM (**Pulse-width modulation**) is the abbreviation of pulse width modulation. Pulse width modulation is a digital encoding method for analog signal levels. Pulse width modulation PWM is a way to reduce the average power transmitted by the electrical signal by dispersing the effective electrical signal into discrete forms. Therefore, according to the area equivalence law, the waveform of the corresponding amplitude and frequency required for synthesis can be equivalently obtained by changing the time width of the pulse. The PWM signal adjusts the changes in the signal, energy, etc. by adjusting the change in the duty cycle.

wiring

Since the PWM signal cannot be seen directly, an oscilloscope is needed to view it. Please bring your own oscilloscope.

Connect channel 1 of the oscilloscope to IO42, channel 2 to IO43, and GND to ground.



Output PWM signal

Copy the following code into CanMV IDE and run

```
from machine import PWM
from machine import FPIOA
import time
# 实例化FPIOA
# Instantiate FPIOA
fpioa = FPIOA()
# 设置PIN42为PWM通道0
# Set PIN42 to PWM channel 0
fpioa.set_function(42, fpioa.PWM0)
# 实例化PWM通道0,频率为1000Hz,占空比为50%,默认使能输出
# Instantiate PWM channel 0 with a frequency of 1000Hz, a duty cycle of 50%, and
enable the output by default
pwm0 = PWM(0, 1000, 50, enable = True)
# 设置PIN43为PWM通道1
# Set PIN43 as PWM channel 1
fpioa.set_function(43, fpioa.PWM1)
# 实例化PWM通道1, 频率为1000Hz, 占空比为50%, 默认使能输出
```

```
# Instantiate PWM channel 1 with a frequency of 1000Hz, a duty cycle of 50%, and
enable the output by default
pwm1 = PWM(1, 1000, 50, enable = True)
# 关闭通道1输出
# Turn off the output of Channel 1
pwm1.enable(0)
# 调整通道1频率为1000Hz
# Adjust the frequency of Channel 1 to 1000Hz
pwm1.freq(1000)
# 调整通道1占空比为80%
# Adjust the duty cycle of Channel 1 to 80%
pwm1.duty(80)
# 打开通道1输出
# Open Channel 1 for output
pwm1.enable(1)
# 阻止程序退出
# Prevent the program from exiting
while True:
   time.sleep(1)
```

Then observe the level signal on the oscilloscope. As shown in the figure below:

