Configuration instructions for each version

There are Standard Kit, Superior kit, Ultimate kit. Different kits may contain different accessories.

Configuration Differences

Version	Main controller	Depth camera	Lidar	Voice interaction module
Standard	Raspberry		SLAM A1	Without
Superior kit A	Raspberry Pi 4B JETSON NANO	Astro Pro Plus	SLAM A1	With
Ultimate kit B			YDLIDAR 4ROS	With

Packing List



Voice interaction package (optional)

	Voice interaction module (EN)	Type-c data cable
IVR	Voice Screw Pack	Speaker

Raspberry Pi Accessories(optional)

	Raspberry Pi 4B (optional)	B. Ed G	TF card
	RGB cooling HAT	8	Card reader
2	Muto Raspberry Pi accessory pack②		Type-C male- male data cable

Jetson NANO 4GB Accessories(optional)

Jetson NANO 4GB (optional)		U disk
Muto NANO 4GB accessory pack①	6	4010 fan
M.2 antennas		DC power cable

SLAM A1 Lidar (optional)

SLAM A1 Lidar	Micro USB data cable (right bend)
④ screw pack	

YDLIDAR 4ROS Lidar (Optional)

4ROS Lidar	Trongs	Lidar adapter board
Type-c data cable		④ screw pack