5. Color tracking

5. Color tracking

- 5.1. Description of program functions
- 5.2. Program Code Reference Path
 - 5.3.1. Application Startup and Web page Display
 - 5.3.2. Color Recognition and tracking
 - 5.3.3 Dynamic parameter tuning
 - 5.3.4. View the node topic communication graph
- 5.4. Core Source Code Parsing
 - 5.4.1. color_identify. Py
 - 5.4.2. color_track.py

5.1. Description of program functions

After the program starts, the image published by the camera is displayed on the web page. Select the color through the mouse box, the car will lock this color, press the [space] key to enter the tracking mode. The car will maintain a distance of 1 meter from the tracked object, and always ensure that the tracked object remains in the center of the picture.

In addition, the [L1] button on the handle locks/turns on the car's motion controls. When motion control is enabled, the function is locked; This function can be turned on when the motion control is locked.

5.2. Program Code Reference Path

#launch文件#launch file

/userdata/yahboomcar_ws/src/yahboomcar_colortrack/launch/colortrack_launch.xml

The node or launch file is explained as follows:

• color_identify: performs image processing and calculates the center coordinates of the tracked object. The code path is,

 $/userdata/yahboomcar_ws/src/yahboomcar_colortrack/yahboomcar_colortrack/color_identify.py$

 color_track: calculates the speed mainly according to the center coordinates and depth information of the tracked object, and releases the speed data to the chassis. The code path is,

/userdata/yahboomcar_ws/src/yahboomcar_colortrack/yahboomcar_colortrack/colortrack.py

- astra.launch.xml: starts the Astra camera
- yahboomcar_bringup_launch.py: starts the chassis
- rosbridge_websocket_launch.xml: Start websocket to enable ROS to interact with the Web
- rosboard_node: starts the ROSboard

5.3.1. Application Startup and Web page Display

After SSH connects to the car, terminal input,

```
ros2 launch yahboomcar_colortrack colortrack_launch.xml
```

Open the browser on the PC side (note that the computer and the Rising Sun network must be in the same LAN), enter the URL: car IP:9999, for example, my car IP is 192.168.2.67, enter the URL in the browser on the virtual machine side to open the ROSboard webpage:


```
192.168.2.67:9999
```

Select three topics: /camera/color/image_raw, /astra_binary, and /astra_roi. Only the RGB images published by the camera are displayed at this time, and no data is published for /astra_binary and /astra_roi topics.




5.3.2. Color Recognition and tracking


Press [i] or [l] on the page to enter the Identify mode, click the mouse frame twice in the RGB image to select a region (this region can only have one color).



After the box is selected, the following screen will appear: /astra_binary displays the binary image after color selection; /astra_roi displays the HSV value range of the color and the center point of the color area.



Press the [space] key in the page to enter the tracking mode, and the car will move to the position of 1 meter away from the target; Press the [q] key in the page to cancel the tracking; Press [r] in the page to clear the color selection, then press [i] to re-select the color.



Move the object slowly, the car will follow, and keep a distance of 1 meter.


The interaction between this function and the keyboard is as follows:

button	function	Remarks		
【r】 or【R】	color recognition	color selection mode, the program starts to enter the default mode		
[space]	Color tracking	the car is tracked to the position , 1 meter away from the target		
[q] or [Q]	Stop the motion	stop the motion and keep the HSV range of colors		
[i] or [l]	Reset	stops motion while clearing the HSV range of color		

5.3.3 Dynamic parameter tuning

Virtual machine terminal input,

ros2 run rqt_reconfigure rqt_reconfigure



(System message might be shown here when necessary)


The adjustable parameters are the PID of the linear speed of the car, the angular speed, and the tracking distance.

After modifying the parameters, press Enter or click the blank area of the GUI to write the parameter values.

5.3.4. View the node topic communication graph

Open the VM terminal and run the following command to view topic communication between nodes:

ros2 run rqt_graph rqt_graph



5.4. Core Source Code Parsing

5.4.1. color_identify. Py

This program mainly has the following functions:

- Open the camera and get RGB images; Here, in order to ensure speed, opency is used to read the camera (**note that the device number is video8**), rather than receiving data through the topic. However, after reading, the image data will be published through the topic web side visualization.
- Receive keyboard and mouse topic data for mode switching and color fetching.
- Process the image to calculate the central coordinates of the tracking target and publish it.

Part of the core code is as follows,

```
#创建发布者,发布追踪物体的中心坐标
# Create a publisher that publishes the center coordinates of the tracking
object
self.pub_position = self.create_publisher(Position,"/Current_point", 10)
#创建发布者,发布图像数据
# Create a publisher to publish image data
self.pub_binary = self.create_publisher(Image, '/astra_binary', 10)
self.pub_roi = self.create_publisher(Image, '/astra_roi', 10)
self.pub_image = self.create_publisher(Image, '/camera/color/image_raw', 10)
#创建订阅者,接收鼠标和键盘数据
# Create subscribers and receive mouse and keyboard data
self.sub_mouse = self.create_subscription(Polygon, '/mouse_pos',
self.MouseCallback, 1)
self.sub_keyboard = self.create_subscription(Char, '/key_value',
self.KeyCallback, 1)
#鼠标事件回调函数,确定框选位置
# Mouse event callback function to determine the box selection position
def MouseCallback(self, msg):
    start_cols = min(int(msg.points[0].x), int(msg.points[1].x))
    start_rows = min(int(msg.points[0].y), int(msg.points[1].y))
    end_cols = max(int(msg.points[0].x), int(msg.points[1].x))
    end_rows = max(int(msg.points[0].y), int(msg.points[1].y))
    self.Roi_init = (start_cols, start_rows, end_cols, end_rows)
```

```
#键盘事件回调函数,切换模式
# Keyboard event callback function, switch mode
def KeyCallback(self, key):
   data = key.data
   if data == 32: self.Track_state = 'tracking'
   elif data == ord('i') or data == ord('I'): self.Track_state = 'identify'
   elif data == ord('r') or data == ord('R'): self.Track_state = 'reset'
   elif data == ord('q') or data == ord('Q'): self.Track_state = 'cancle'
#计算中心坐标的值, self.circle存放xy值
# Calculate the value of the center coordinate, self.circle stores the xy value
rgbFrame, binary, self.circle = self.color.object_follow(rgbFrame,
self.hsv_range)
#发布中心坐标的消息
# Post the message of the center coordinates
def execute(self, x, y, z):
   position = Position()
   position.anglex = x * 1.0
   position.angley = y * 1.0
   position.distance = z * 1.0
    self.pub_position.publish(position)
```

5.4.2. color_track.py

This program mainly has the following functions: receive /Current_point and depth image topic data, calculate the speed size, and then publish the speed data.

Part of the code is as follows.

```
#定义订阅者接收需要的话题数据
# Define the topic data that subscribers need to receive
self.sub_depth =
self.create_subscription(Image,"/camera/depth/image_raw",self.depth_img_Callback
, 1)
self.sub_position
=self.create_subscription(Position,"/Current_point",self.positionCallback,1)
#定义速度发布者
# Define the speed publisher
self.pub_cmdVel = self.create_publisher(Twist, '/cmd_vel',10)
#两个重要的回调函数,获取到point_x值和dist值
# Two important callback functions that get the point_x value and dist value
def PositionCallback(self, msg):
def DepthCallback(self, msg):
#根据point_x和dist计算线速度和角速度并发布
Calculate and publish linear and angular velocities based on point_x and dist
linear_x = self.linear_pid.compute(dist, self.minDist) / 1000.0
angular_z = self.angular_pid.compute(320, point_x) / 1000.0
if abs(dist - self.minDist) < 30: linear_x = 0</pre>
if abs(point_x - 320.0) < 30: angular_z = 0
twist = Twist()
twist.linear.x = linear_x * 1.0
twist.angular.z = angular_z * 1.0
self.pub_cmdVel.publish(twist)
```