Dot Matrix Assembly Manual

For hardware revision 0.6

Power Supply

Populate C1, C3, U1, Q2. Verify that 5V test point is not connected to GND and to 3V3. If not, you can try to attach 5V to the GND and VCC pins of the J9 connector (see the other side of the PCB) and check voltage on 5V and 3V3 pins.

Reset and Boot Selection

At least C11, R13 and R16 needs to be soldered to relyably boot the MCU. Bootloader can be then started by shorting the J14, applying power and disconnectiong the short. If SW3, C10 and Q1 is populated, then SW3 can be used either to reset MCU (short press) or entering bootloader (long press). For now do not solder the SW3 yet as it will be in the way while soldering other parts.

Debug LED

Populate R5 and D5, while there solder R3 too. Keep in mind LED polarity (the green dots on the LED should align with the marked pin). Take care to not touch the LED resin blob with the soldering iron or not overheat the diode.

If the MCU (U2) is not soldered you can test LED by connecting TP6 to GND with power applied. If the MCU is already soldered, and the power is applied it should flash the LED several times.

MCU

If not presoldered solder the MCU (U2). If the preprogrammed MCU was used. You should be now skilled enough to solder the 0603 size capactiors C6, C7, C8, C9. The LED should blink if you apply the power now. If not, double check the MCU is soldered properly.

External Clock

There are two types of external clock the High Speed one, used e.g. for USB and the Low Speed Clock that is used for RTC. For HSE (High Speed Clock) Y1 is needed. LSE (Low Speed Clock), Y2, C14, C15 are needed. LSE is not needed for this workshop, but it's easier to solder now, than on the complete kit.

Led Matrix Driving

Solder U3,U4,U5 (R3 should be already in place). Use the LED matrix as the holder for soldering the "socket headers". Don't forget that the LED matrix should be on the other side of the PCB than the rest of the components. Once assmebled correctly and powered the preloaded MCU should show some demo on the matrix.

Buttons

This is optional. It makes the board more versatile and the demo can't be controlled without them. It's easier to do before the side headers are soldered but it still can be done later if you are getting short on time now.

Solder SW1 and SW2 and R2, R14, C2, C4. The resistors and capacitors form the hardwarebutton debounce. If you for some reason need a qick response on cost of doing the button debounce in software they can be ommitted (the buttons can't be used in the demo in that case).

Interface headers

The headers J1, J2, J4, J5, J6, J7, J8, J9 needs to be soldered now. The headers meed to be as perpendicular to the PCB. If possible use a jig, or pile of another PCBs to hold the headers in place.

Mechanical part

Now you should have the electrical part complete and you only need to complete the mechanical part. Insert the M3 nuts in the holes of the display support. You migh eventually need do clean the 3D part a bit. The larger central part of the support should face upwards to the Display. If mounte remove the Display, and use the four nylon spacers to secure the display support on the PCB. Pay attention to properly aligned nut in order to not damage the threading on the spacers. Reinstall the LED Display. The small 3D printed squares and small solderless breadboards are for interconnecting the boards. The nuts with washers are for mounting the board to some support.

Part	Pcs	
Printed Circuit Board	1	
Display Support	1	X
Boad Joint	2	6
Small Bread Board	4	

Part	Pcs	
M3x15+6 spacer	4	
M3x6 bolt + washer	4	6 0
M3 nut	4	

Table 1: Mechanical components

Reference	Pcs	Value	case	
C1, C10, C3	3	4u7	SMD 0805	4909
C12, C13	2	220u	EIA-7343-20	not populated
C14, C15	2	2pF	SMD 0805	0 0
C11, C2, C4	3	100n	SMD 0805	
C6, C7, C8, C9	4	100n	SMD 0805	
D1, D2	2	Shottky	SOD-123	SDD
D5	1	LED	SMD 0805	
D6	1		LED_8x8_60x6 0	
J1, J2, J4, J5, J6, J7, J8, J9	8		Hdr_1x05_2.54	*
J15	1		hdr_1x04_2.54 angled	
J3	1		USB_Micro-B	
Q1	1	BSS138	SOT-23	ANWS
Q2	1	IRLML6402	SOT-23	€ <u>9</u> 0€2

R14, R2	2	220k	SMD 0805	2203
R15, R17	2	R	SMD 0805	not populated
R16	1	820k	SMD 0805	824
R1, R13, R4	3	10k	SMD 0805	1002
R3, R5	2	1k	SMD 0805	1001
SW1, SW2, SW3	3		switch K2-1112SA	
U1	1	RT9166- 33GVL	SOT-23	G1= J40
U2	1	STM32F070C BTx	LQFP-48	600 A 199 600 A
U3	1	74HC595	SO-16-N	74HCSSS CT/CSSSS TnD1837D
U4	1	TD62783AFG	SOIC-18W	5-8226H TD62763AFB
U5	1	TLC5916	SO-16-N	7-66ACF1M TLC59161 G4
Y1	1	Resonator	CSTCE_G	ETP.
Y2	1	ABS07-120- 32.768kHz-T	ABS07-120-xx	SHILDID

Table 2: Components list