## HW0

#### Problem 1

#### $\mathbf{A}$

Yes, Q is an inductive invariant of A.

The definition of inductive invariant is: If  $Q_0 \subseteq I$  and  $Post(I) \subseteq I$  then I is an invariant, i.e.,  $Reach_A \subseteq I$ . Such invariants are called inductive invariants.

 $Q_0 \subseteq Q$  and  $Post(Q) \subseteq Q$  are true, so Q is an inductive invariant of A.

#### $\mathbf{B}$

For I to be an inductive invariant of A,  $Q_0 \subseteq I$  and  $Post(I) \subseteq I$  must be true.

To help prove safety, I should not intersect with the unsafe set U.

#### Problem 1

Yes,  $0 \le v_1(t) \le v_0$  is an invariant of A.

The vehicle starts with a speed of  $v_0$  and can only decelerate or maintain its speed. Thus, the speed of the vehicle will always be between 0 and  $v_0$ .

### Problem 2

Yes,  $timer(t) \leq v_0/a_b$  is an invariant of A.

The timer(t) represents how long the vehicle has been braking. So, we have  $timer(t) = (v_0 - v_1(t))/a_b$ . According to the invariant  $0 \le v_1(t) \le v_0$  and induction, we have  $timer(t) \le (v_0 - 0)/a_b = v_0/a_b$ .

#### Problem 3

```
SimpleCar(Dsense, v0, x10, x20, ab), x20 > x10
Initially: x1(0) = x10, x2(0) = x20, v1(0) = v0, v2(0) = 0
s(0) = 0, timer(0) = 0, timer2(0) = 0, aware(0) = 0
d(t) = x2(t) - x1(t)
if d(t)    Dsense
    s(t + 1) = 1
    aware(t + 1) = aware(t) + 1
    if aware(t + 1) >= Treact
        if v1(t)    ab
        v1(t + 1) = v1(t) - ab
        timer(t + 1) = timer(t) + 1
        timer2(t + 1) = timer2(t)
```

```
else

v1(t + 1) = 0
timer(t + 1) = timer(t)
timer2(t + 1) = timer2(t)
else

v1(t + 1) = v1(t) + as
timer(t + 1) = timer(t)
timer2(t + 1) = timer2(t) + 1
else

s(t + 1) = 0
v1(t + 1) = v1(t) + as
timer(t + 1) = timer(t)
timer2(t + 1) = timer2(t) + 1
x1(t + 1) = x1(t) + v1(t + 1)
```

# Problem 4