
Assembly Programming (II)

Lecturer: Sri Parameswaran

Notes by: Annie Guo



Week5

Lecture overview



- Assembly program structure
 - Assembler directives
 - Assembler expressions
 - Macro
- Memory access
- Assembly process
 - First pass
 - Second pass





- An assembly program basically consists of
 - Assembler directives
 - E.g. .def temp = r15
 - Executable instructions
 - E.g. add r1, r2
- An input line in an assembly program takes one of the following forms:
 - [label:] directive [operands] [Comment]
 - [label:] instruction [operands] [Comment]
 - Comment
 - Empty line

Assembly program structure (cont.)



- The label for an instruction is associated with the memory location address of that instruction.
- All instructions are not case sensitive
 - "add" is same as "ADD"
 - ".DEF" is same as ".def"

Week5

Example



```
; The program performs
                                   Two comment lines
; 2-byte addition: a+b;
                                   Empty line
.def a_high = r2;
.def a_{low} = r1;
.def b_high = r4;
                                   Six assembler directives
.def b_{low} = r3;
.def sum_high = r6;
.def sum_low = r5;
mov sum_low, r1
mov sum_high, r3
                                   Four executable instructions
add sum_low, r2
adc sum_high, r3
```

Comments



- A comment has the following form:
 - ;[Text]
 - Items within the brackets are optional
- The text between the comment-delimiter(;) and the end of line (EOL) is ignored by the assembler.





- Instructions to the assembler are created for a number of purposes:
 - For symbol definitions
 - For readability and maintainability
 - All symbols used in a program will be replaced by the real values when assembling
 - E.g. .def, .set
 - For program and data organization
 - E.g. .org, .cseg, .dseg
 - For data/variable memory allocation
 - E.g. .DB
 - For others

Summary of AVR Assembler directives

Directive	Description
BYTE	Reserve byte to a variable
CSEG	Code Segment
DB	Define constant byte(s)
DEF	Define a symbolic name on a register
DEVICE	Define which device to assemble for
DSEG	Data Segment
DW	Define constant word(s)
ENDMACRO	End macro
EQU	Set a symbol equal to an expression
ESEG	EEPROM Segment
EXIT	Exit from file
INCLUDE	Read source from another file
LIST	Turn listfile generation on
LISTMAC	Turn macro expansion on
MACRO	Begin macro
NOLIST	Turn listfile generation off
ORG	Set program origin
SET	Set a symbol to an expression

NOTE: All directives must be preceded by a period

8

Directives for symbol definitions



.DEF

Define symbols on registers

• E.g.

 Symbol temp can be used for r17 elsewhere in the program after the definition

Directives for symbol definitions (cont.)



.EQU

Define symbols on values

.EQU symbol = expression

- Non-redefinable. The symbol cannot be redefined for other value in the program
- E.g.

.EQU length=2

 Symbol length with value 2 can be used elsewhere in the program after the definition

Directives for symbol definitions (cont.)



SET

Define symbols on values

- <u>re-definable</u> . The symbol can represent other value later.
- E.g.

 Symbol input with value 5 can be used elsewhere in the program after this definition and before its redefinition.

Program/data memory organization



- AVR has three different memories
 - Data memory
 - Program memory
 - EPROM memory
- The three memories are corresponding to three memory segments to the assembler:
 - Data segment
 - Program segment (or Code segment)
 - EEPROM segment

Program/data memory organization directives



- Memory segment directives specify which memory segment to use
 - .DSEG
 - Data segment
 - .CSEG
 - Code segment
 - .ESEG
 - EPROM segment
- The **.ORG** directive specifies the start address to store the related program/data.



Example

```
.DSEG ; Start data segment
```

.ORG 0x100; from address 0x100,

; default start location is 0x0060

vartab: .BYTE 4 ; Reserve 4 bytes in SRAM

; from address 0x100

.CSEG ; Start code segment

; default start location is 0x0000

const: .DW 10, 0x10, 0b10, -1

; Write 10, 16, 2, -1 in program

; memory, each value takes

; 2 bytes.

mov r1,r0 ; Do something

Data/variable memory allocation directives



- Specify the memory locations/sizes for
 - Constants
 - In program/EEPROM memory
 - Variables
 - In data memory
- All directives must start with a label so that the related data/variable can be accessed later.





- Store data in program/EEPROM memory
 - .DB
 - Store <u>byte</u> constants in program/EEPROM memory

- expr* is a byte constant value
- .DW
 - Store <u>word</u> constants in program/EEPROM memory
 - little endian rule is used

expr* is a word constant value

Directives for Variables



- Reserve bytes in data memory
 - .BYTE
 - Reserve a number of bytes for a variable

Label: .BYTE expr

expr is the number of bytes to be reserved.

Directives for Others



- Include a file
 - .INCLUDE "m64def.inc"
- Stop processing the assembly file
 - .EXIT
- Begin and end macro definition
 - .MACRO
 - .ENDMACRO
 - Will be discussed in detail later

Implement data/variables



- With those directives, you can implement/translate data/variables into machine level descriptions
- An example of translation by WINAVR is given in the next slide.



Sample C program

```
// global variables:
const char g_course[] = "COMP";
char* g_inputCourse = "COMP";
char g_a;
static char g_b;
int main(void){
// local variables:
const char course[] = "COMP9032";
char* inputCourse = "COMP9031";
char a:
static char b;
char i;
char is COMP9032 = 1;
for(i=0; i<9; i++){
           if (inputCourse[i] != course[i]){
                      isCOMP9032 = 0;
                      i = 9;
return 0;
```

Memory mapping after build and:

run


Name	Value	Туре	Location
g_course	[]	const char[5]	0x0100 [SRAM]
[0x00]	67 'C'	const char	0x0100 [SRAM]
[0x01]	79 '0'	const char	0x0101 [SRAM]
[0x02]	77 'M'	const char	0x0102 [SRAM]
[0x03]	80 'P'	const char	0x0103 [SRAM]
[0x04]	0 ''	const char	0x0104 [SRAM]
g_inputCourse	0x0105	char*	0x010A [SRAM]
->	67 'C'	char	0x0105 [SRAM]
g_a	0 ''	char	0x0120 [SRAM]
g_b	0 ''	char	0x011F [SRAM]
─ course	[]	const char[9]	0x1100 [SRAM]
[0x00]	-1 'ÿ'	const char	0x1100 [SRAM]
[0x01]	-1 'ÿ'	const char	0x1101 [SRAM]
[0x02]	-1 'ÿ'	const char	0x1102 [SRAM]
[0x03]	-1 'ÿ'	const char	0x1103 [SRAM]
[0x04]	-1 'ÿ'	const char	0x1104 [SRAM]
[0x05]	-1 'ÿ'	const char	0x1105 [SRAM]
[0x06]	-1 'ÿ'	const char	0x1106 [SRAM]
[0x07]	-1 'ÿ'	const char	0x1107 [SRAM]
[80x0]	-1 'ÿ'	const char	0x1108 [SRAM]
─ inputCourse	OxFFFF	char*	0x1109 [SRAM]
->	-1 'ÿ'	char	0xFFFF [SRAM]
a	-1 'ÿ'	char	0x110B [SRAM]
b	0 ''	char	0x011E [SRAM]
i	-1 'ÿ'	char	0x110C [SRAM]

Memory mapping after execution

CACCU	CACOGLIOII		
Name	Value	Туре	Location
g_course	[]	const char[5]	0x0100 [SRAM]
[0x00]	67 'C'	const char	0x0100 [SRAM]
[0x01]	79 '0'	const char	0x0101 [SRAM]
[0x02]	77 'M'	const char	0x0102 [SRAM]
[0x03]	80 'P'	const char	0x0103 [SRAM]
[0x04]	0 ''	const char	0x0104 [SRAM]
g_inputCourse	0x0105	char*	0x010A [SRAM]
->	67 'C'	char	0x0105 [SRAM]
g_a	0 ''	char	0x0120 [SRAM]
g_b	0 ''	char	0x011F [SRAM]
course	[]	const char[9]	0x10F2 [SRAM]
[0x00]	67 'C'	const char	0x10F2 [SRAM]
[0x01]	79 '0'	const char	0x10F3 [SRAM]
[0x02]	77 'M'	const char	0x10F4 [SRAM]
[0x03]	80 'P'	const char	0x10F5 [SRAM]
[0x04]	57 '9'	const char	0x10F6 [SRAM]
[0x05]	48 '0'	const char	0x10F7 [SRAM]
[0x06]	51 '3'	const char	0x10F8 [SRAM]
[0x07]	50 '2'	const char	0x10F9 [SRAM]
[80x0]	0 ''	const char	0x10FA [SRAM]
inputCourse	0x0115	char*	0x10FB [SRAM]
->	67 'C'	char	0x0115 [SRAM]
a	-1 'ÿ'	char	0x10FD [SRAM]
b	0 ''	char	0x011E [SRAM]
i	10 '	char	0x10FE [SRAM]

Memory mapping diagram





Dynamic data





- Data have scope and duration in the program
- Data have types and structures
- Those features determine where and how to store data in memory.
- Constants are usually stored in the nonvolatile memory and variables are allocated in SRAM memory.
- In this lecture, we will only take a look at how to implement basic data type.
 - Advanced data/variable implementation will be covered later.

Example 1



 Translate the following C variables. Assume each integer takes four bytes.

```
int a;
unsigned int b;
char c;
char* d;
```



Example 1: solution

Translate the following variables. Assume

```
each .dseg
                             ; in data memory
          .org 0x100 ; start from address 0x100
          a: .byte 4 ; 4 byte integerb: .byte 4 ; 4 byte unsigned integerc: .byte 1 ; 1 character
          d: .byte 2 ; address pointing to the string
```

- All variables are allocated in SRAM
- Labels are given the same name as the variable for convenience.



Example 2

 Translate the following C constants and variables.

C code:

int a;
const char b[]="COMP9032";
const int c=9032;

Assembly code:

.dseg .org 0x100 a: .byte 4

.cseg

b: .DB 'C', 'O', 'M', 'P', '9', '0', '3', '2', 0

C: .DW 9032

All variables are in SRA\(\mathbf{N}\) and constants are in FLASH





- An insight of the memory mapping
 - In program memory, data are packed in words. If only a single byte left, that byte is stored in high byte and the low byte is filled with 0.

0x0000	'С'	'O'
0x0001	'M'	'P'
0x0002	'9'	'0'
0x0003	'3'	'2'
0x0004	0	0
0x0005	90	32
	We	ek5

Hex values

43	4F
4D	50
39	30
33	32
0	0
48	23

Example 3



Translate data structures

```
struct
{
     int student_ID;
     char name[20];
     char WAM;
} STUDENT_RECORD;

typedef struct STUDENT_RECORD *student;
student s1;
student s2;
```

Example 3: solution



Translate data structures

```
.set    student_ID=0
.set    name = student_ID+4
.set    WAM = name + 20
.set    STUDENT_RECORD_SIZE = WAM + 1

.dseg
s1:    .BYTE STUDENT_RECORD_SIZE
s2:    .BYTE STUDENT_RECORD_SIZE
```

Example 4



- Translate data structures
 - with initialization

```
struct
{
     int student_ID;
     char name[20];
     char WAM;
} STUDENT_RECORD;

typedef struct STUDENT_RECORD *student;
student s1 = {123456, "John Smith", 75};
student s2;
```





Translate data structures

```
student_ID=0
_set
      name = student_ID+4
.set
.set WAM = name + 20
      STUDENT_RECORD_SIZE = WAM + 1
.set
.cseg
s1_value:
                  HWRD(123456)
            .DW
            .DW
                   LWRD(123456)
                   "John Smith"
            .DB
            _DB
                   75
.dseg
      .BYTE STUDENT_RECORD_SIZE
s1:
s2:
      .BYTE STUDENT_RECORD_SIZE
```

Neek5

Remarks



- The constant values for initialization are stored in the program memory in order to keep the values when power is off.
- The variable will be populated with the initial values when the program is started.

Assembler expression



- In the assembly program, you can use expressions for values.
- When assembly, the assembler evaluates each expression and replaces the expression with the related value.

Assembler expression (cont.)



- The expression is of the form similar to normal math expressions
 - Consisting of operands, operators and functions.
 All expressions are internally 32 bits.

Example

```
Idi r26, low(label + 0xff0)

Function Operands Operator
```

Operands

- Operands can be
 - User defined labels
 - associated with memory addresses
 - User defined variables
 - defined by the SET directive
 - User defined constants
 - defined by the EQU directive
 - Integer constants
 - can be in several formats, including
 - Decimal (default): 10, 255
 - Hexadecimal (two notations): 0x0a, \$0a, 0xff, \$ff
 - Binary: 0b00001010, 0b111111111
 - Octal (leading zero): 010, 077
 - PC
 - Program counter value.

Operators

Same meanings as in C

Symbol	Description		
!	Logical Not		
~	Bitwise Not		
-	Unary Minus		
*	Multiplication		
/	Division		
+	Addition		
-	Subtraction		
<<	Shift left		
>>	Shift right		
<	Less than		
<< >>> < < >>> < < >>	Less than or equal		
>	Greater than		
>=	Greater than or equal		
==	Equal		
!=	Not equal		
&	Bitwise And		
^	Bitwise Xor		
	Bitwise Or		
&&	Logical And		
	Logical Or		



Functions

- LOW(expression)
 - Returns the low byte of an expression
- HIGH(expression)
 - Returns the second byte of an expression
- BYTE2(expression)
 - The same function as HIGH
- BYTE3(expression)
 - Returns the third byte of an expression
- BYTE4(expression)
 - Returns the fourth byte of an expression
- LWRD(expression)
 - Returns bits 0-15 of an expression
- HWRD(expression):
 - Returns bits 16-31 of an expression
- PAGE(expression):
 - Returns bits 16-21 of an expression
- EXP2(expression):
 - Returns 2 to the power of expression
- LOG2(expression):
 - Returns the integer part of log2(expression)



Example 1



```
;Example1:

ldi r17, 1<<5 ;load r17 with 1 ;shifted left 5 times
```

Example 2



```
;Example 2: compare r1:r0 with 3167

cpi r0, low(3167)
ldi r16, high(3167)
cpc r1, r16
brlt case1
...
case1: incr10
```

Micros



- A sequence of instructions in an assembly program often need to be repeated several times
- Micros help programmers to write code efficiently and nicely
 - Type/define a section code once and reuse it
 - Neat representation
 - like an inline function in C
 - When assembled, the micro definition is expanded at the place it was used.

Detectives for Micros



.MACRO

- Tells the assembler that this is the start of a Micro
- Takes the micro name and other parameters
 - Up to 10 parameters
 - Which are referenced by @0, ...@9 in the macro definition body

.ENDMACRO

Defines the end of a Macro definition.

Macros (cont.)



Macro definition structure:

.MACRO name ;macro body .ENDMACRO

Use of Macro

macro_name [para0, para1, ...,para9]





Swapping memory data p, q twice

With With	mag	<u>cro</u>
m	acro	SW

.macro swap1

lds r2, p ; load data

lds r3, q; from p, q

sts q, r2 ; store data

sts p, r3; to q, p

.endmacro

swap1

swap1

Without macro

lds r2, p

lds r3, q

sts q, r2

sts p, r3

lds r2, p

lds r3, q

sts q, r2

sts p, r3

Example 2



Swapping any two memory data

```
.macro swap2
```

lds r2, @0 ; load data from provided

lds r3, @1 ; two locations

sts @1, r2 ; interchange the data and

sts @0, r3 : store data back

.endmacro

swap2 a, b ;a is @0, b is @1

swap2 c, d ;c is @0, d is @1

Example 3



- Register bit copy
 - copy a bit from one register to a bit of another

register

```
.macro bitcopy
bst @0, @1
bld @2, @3
.endmacro
```

bitcopy r4, 2, r5, 3 bitcopy r5, 4, r7, 6

end: rjmp end

Memory access operations



- Access to data memory
 - Using instructions
 - Id, Ids, st, sts
- Access to program memory
 - Using instructions
 - lpm
 - spm
 - Not covered in this course
 - Most of time, we access program memory is to load data

Load Program Memory



• Syntax: *Ipm Rd, Z*

Operands: Rd∈{r0, r1, ..., r31}

• Operation: $Rd \leftarrow (Z)$

■ Z ← Z +1

• Words: 1

• Cycles: 3

Load from program memory



- The address label in the memory program is word address
 - Used by the PC register
- To access data, the byte address is used.
- Address register, Z, is used to point bytes in the program memory

Example



```
.include "m64def.inc" ; include definition for Z  
Idi ZH, high(Table_1<<1) ; Initialize Z-pointer  
Idi ZL, low(Table_1<<1)  
Ipm r16, Z ; Load constant from Program ; memory pointed to by Z (r31:r30)  
Table_1:  
.dw 0x5876 ; 0x76 is the value when Z_{LSB} = 0 ; 0x58 is the value when Z_{LSB} = 1
```

Complete example 1



 Copy data from Program memory to Data memory

Complete example 1 (cont.)



C description

```
struct
{
     int student_ID;
     char name[20];
     char WAM;
} STUDENT_RECORD;

typedef struct STUDENT_RECORD *student;
student s1 = {123456, "John Smith", 75};
```

Complete example 1 (cont.)



Assembly translation

```
student ID=0
.set
       name = student ID+4
set
.set WAM = name + 20
       STUDENT_RECORD_SIZE = WAM + 1
.set
.cseg
s1 value:
              .DW
                      HWRD(123456)
              .DW
                      LWRD(123456)
                      "John Smith"
              .DB
              .DB
                      75
       ldi r31, high(s1_value<<1)
start:
                                     pointer to student record
       ldi r30, low(s1 value<<1)
                                     ;value in the program memory
       ldi r29, high(s1)
                             ;pointer to student record holder
       ldi r28, low(s1)
                             ;in the data memory
       clr r16
```

Complete example 1 (cont.)



Assembly translation (cont.)

```
load:

cpi r16, STUDENT_RECORD_SIZE
brge end
lpm r10, z+
st y+, r10
inc r16
rjmp load
end:

rjmp end

.dseg
.ORG 0x100
s1: .BYTE STUDENT_RECORD_SIZE
```

Complete example 2



- Convert lower-case to upper-case for a string
 - The string is stored in the program memory
 - The resulting string after conversion is stored in data memory.
 - In ASCII, upper case letter + 32 = low case letter

Complete example 2 (cont.)



Assembly program

```
.include "m64def.inc"
.equ size =5
.def counter =r17
.dsea
                                   ; Set the starting address
.org 0x100
                                   ; of data segment to 0x100
Cap_string: .byte 5
.cseq
Low_string: .db "hello"
             Idi zl, low(Low_string<<1)</pre>
                                            ; Get the low byte of
                                               ; the address of "h"
             Idi zh, high(Low_string<<1)</pre>
                                            ; Get the high byte of
                                               ; the address of "h"
             Idi yh, high(Cap_string)
             Idi yl, low(Cap_string)
             clr counter
                                             : counter=0
```

Complete example 2 (cont.)



Assembly program (cont.)

```
main:

lpm r20, z+ ; Load a letter from flash memory subi r20, 32 ; Convert it to the capital letter st y+,r20 ; Store the capital letter in SRAM inc counter cpi counter, size brlt main


loop: nop rjmp loop
```

Assembly



- Assembly programs need to be converted to machine code before execution
 - This translation/conversion from assembly program to machine code is called assembly and is done by the assembler
- There are two steps in the assembly processes:
 - Pass one
 - Pass two

Two Passes in Assembly



- Pass one
 - Lexical and syntax analysis: checking for syntax errors
 - Record all the symbols (labels etc) in a symbol table
 - Expand macro calls
- Pass Two
 - Use the symbol table to substitute the values for the symbols and evaluate functions.
 - Assemble each instruction
 - i.e. generate machine code

Example

Assembly program



Symbol table

.equ bound=5

clr r10

loop:

cpi r16, bound

brlo end

inc r10

rjmp loop

end:

rjmp end

Symbol	Value	
bound	5	
loop	1	
end	5	

Example (cont.)

Code generation



Address	<u>Code</u>	Assembly statement	
0000000:	24AA	clr	r10
0000001:	3005	срі	r16,0x05
0000002:	F010	brlo	PC+0x03
0000003:	94A3	inc	r10
0000004:	CFFC	rjmp	PC-0x0003
0000005:	CFFF	rjmp	PC-0x0000






- A type of assembly process.
 - Can only be used for the source file that contains all the source code of the program
- Programmers use .org to tell the assembler the starting address of a segment (data segment or code segment)
- Whenever any change is made in the source program, all code must be assembled.
- A loader transfers an executable file (machine code) to the target system.

Absolute Assembly

-- workflow



Source file with location information (NAME.ASM)

Absolute assembler

Executable file (NAME.EXE)

Loader Program

Computer memory

Relocatable Assembly



- Another type of assembly process.
- Each source file can be assembled separately
- Each file is assembled into an object file where some addresses may not be resolved
- A linker program is needed to resolve all unresolved addresses and make all object files into a single executable file

Relocatable Assembly

-- workflow

Source file 1 (MODULE1.ASM

Source file 2 (MODULE1.ASM

VIODULET.ASI

Relocatable assembler

Relocatable assembler

Object file1 (MODULE1.OBJ

Object file2 (MODULE2.OBJ

Library of object files (FILE.LIB)

Code and data location information

Linker program

Executable file (NAME.EXE)



- 1. Refer to the AVR Instruction Set manual, study the following instructions:
 - Arithmetic and logic instructions
 - clr
 - inc, dec
 - Data transfer instructions
 - movw
 - sts, lds
 - Ipm
 - bst, bld
 - Program control
 - jmp
 - sbrs, sbrc

Week5




Design a checking strategy that can find the endianness of AVR machine.

3. Discuss the advantages of using Macros. Do Macros help programmer write an efficient code? Why?



4. Write an assembly program to find the length of a string. The string is stored in the program memory and the length will be stored in the data memory.



5. Write an assembly program to find the student average WAM in a class. The record for each student is defined as

```
struct
{
    int student_ID;
    char name[20];
    char WAM;
} STUDENT_RECORD;
typedef struct STUDENT_RECORD *student;
```

Assume there are 5 students and all records are stored in the program memory. The average WAM will be stored in the data of the mory.

Reading Material



- Chap. 5. Microcontrollers and Microcomputers
- User's guide to AVR assembler
 - This guide is a part of the on-line documentations accompanied with AVR Studio. Click help in AVR Studio.