## Data Conversion Chain — 20-02-2017




Figure 1: A typical signal chain

## 1 DSP

The equivalent outut voltage can be expressed with ??. It's maximum can be described with ??

$$V_{eq} = V_{ref} \left( \sum_{i=1}^{N} b_i 2^{-i} \right) \tag{1}$$


$$V_{eq} = V_{ref} \left( 1 - 2^{-N} \right) \tag{2}$$

This is a representation in UINT. In most realworld impelemntations INT using 2's complement is required. Sometimes if there is peak currents, Gray-Code is to be used to minimize peak currents!

The quantizer-error is defined with equation ??.

$$V_e = V_{in} - V_{eq} \tag{3}$$

It is assumed that the error behaves like white noise<sup>1</sup> because the digital signal is a sequence of pulses. If this is fourier transformed a constant spectral density is received.



Since the quantizer error has the probability density function of white noise, it can be depicted with the function seen in ??.




Figure 2: Probability density function of the quatizer error

With the knowledge of the fact that the variance equals the RMS<sup>2</sup> value, depicted in equation ?? and thus ??, we can now find the SNR<sup>3</sup> value with solving equation ??

$$(rms)^2 = \sigma$$
,  $\sigma$  is the standard deviation (4)

<sup>&</sup>lt;sup>1</sup>White noise means that the noise has the same amplitude for every frequency.

 $<sup>^2{\</sup>rm root}$  mean square

<sup>&</sup>lt;sup>3</sup>signal to noise ratio

$$(2)$$
 D/A

$$\sigma_e^2 = \int_{-\infty}^{+\infty} V_e^2 \rho(V_e) dV_e \tag{5}$$

$$= \int_{-\frac{LSB}{2}}^{+\frac{LSB}{2}} \frac{V_e^2}{LSB} dV_e \tag{6}$$

$$= \frac{1}{LSB} \frac{1}{3} V_e^3 \Big|_{-\frac{LSB}{2}}^{+\frac{LSB}{2}} \tag{7}$$

$$=\frac{LSB^2}{12} = \frac{1}{12}V_{ref}^2 2^{-2N} \tag{8}$$

$$SNR = \frac{V_{sig,rms}^2}{V_{n,rms}^2} \tag{9}$$

$$=\frac{\left(\frac{V_r e f}{2} \frac{1}{\sqrt{2}}\right)^2}{\frac{1}{12} V_{ref}^2 2^{-2N}} \tag{10}$$

$$= N \cdot 6.02dB + 1.76dB \tag{11}$$

Using this equation a statement about the ENOB<sup>4</sup> can be made, having a look at the SNR equation optained. This is given in ??.

$$N_{eff} = ENOB = \frac{SNDR - 1.76dB}{6.02dB}$$
 (12)




Figure 3: Output of a DAC and possible errors

 $\bigcirc$  A/D

(4) S&H

(5)(6) LP

Copyright © 2017 Noah Huesser

<sup>&</sup>lt;sup>4</sup>effective number of bits