## Data Conversion Chain — 20-02-2017




Figure 1: A typical signal chain

## (1) DSP

The equivalent outur voltage can be expressed with 1. It's maximum can be described with 2

$$V_{eq} = V_{ref} \left( \sum_{i=1}^{N} b_i 2^{-i} \right) \tag{1}$$

$$V_{eq} = V_{ref} \left( 1 - 2^{-N} \right) \tag{2}$$

This is a representation in UINT. In most realworld impelemntations INT using 2's complement is required. Sometimes if there is peak currents, Gray-Code is to be used to minimize peak currents!

The quantizer-error is defined with equation 3.

$$V_e = V_{in} - V_{eq} \tag{3}$$

Since the quantizer error has the probability density function of white noise<sup>1</sup>, it can be depicted with the function seen in 2.




Figure 2: Probability density function of the quatizer error

The white noise is assumed because the digital signal is a sequence of pulses. If this is fouriertransformed a constant spectral density is received.

- (2) D/A
- (3) A/D
- (4) S&H
- (5)(6) LP

Copyright © 2017 Noah Huesser

<sup>&</sup>lt;sup>1</sup>White noise means that the noise has the same amplitude for every frequency.