


WEBENCH ® Design Report

VinMin = 5.0V VinMax = 60.0V Vout = 3.3V Iout = 5.0A Device = LM76005QRNPRQ1 Topology = Buck Created = 2025-06-14 15:03:50.235 BOM Cost = \$4.13 BOM Count = 14 Total Pd = 1.09W

Design: 6 LM76005QRNPRQ1 LM76005QRNPRQ1 5V-60V to 3.30V @ 5A



Design Alerts


Component Selection Information


The LM76005-Q1 is qualified for Automotive applications. All passives and other components selected in this design may not be qualified for Automotive applications. The user is required to verify that all components in the design meet the qualification and safety requirements for their specific application.


Electrical BOM


Name	Manufacturer	Part Number	Properties	Qty	Price	Footprint
Cbias	Kemet	C0603C105K8PACTU Series= X5R	Cap= 1.0 uF ESR= 1.0 mOhm VDC= 10.0 V IRMS= 0.0 A	1	\$0.01	0603 5 mm ²
Cboot	MuRata	GRM155R61A474KE15D Series= X5R	Cap= 470.0 nF ESR= 1.0 mOhm VDC= 10.0 V IRMS= 0.0 A	1	\$0.02	0402 3 mm ²
Cin	TDK	C3225X7S2A475M200AB Series= X7S	Cap= 4.7 uF ESR= 5.89 mOhm VDC= 100.0 V IRMS= 6.7739 A	1	\$0.45	1210 15 mm ²
Cinx	TDK	C2012X7S2A474K125AB Series= X7S	Cap= 470.0 nF ESR= 17.152 mOhm VDC= 100.0 V IRMS= 1.58068 A	1	\$0.10	0805 7 mm ²
Cout	Chemi-Con	APXF6R3ARA471MH80G Series= PXF	Cap= 470.0 uF ESR= 9.0 mOhm VDC= 6.3 V IRMS= 4.5 A	1	\$0.44	CAPSMT 62 1100 406 mm ²
Coutx	TDK	C1608X7R1H474K080AC Series= X7R	Cap= 470.0 nF ESR= 10.974 mOhm VDC= 50.0 V IRMS= 1.57483 A	1	\$0.05	CAPSMT_62_H80 106 mm ² 0603 5 mm ²
Css	TDK	CGA3E3X7S2A333K080AB Series= X7S	Cap= 33.0 nF ESR= 139.637 mOhm VDC= 100.0 V IRMS= 462.26 mA	1	\$0.03	0603 5 mm ²
Cvcc	TDK	C1608X6S1C225K080AC Series= X6S	Cap= 2.2 uF ESR= 7.674 mOhm VDC= 16.0 V IRMS= 1.87823 A	1	\$0.03	0603 5 mm ²


Name	Manufacturer	Part Number	Properties	Qty	Price	Footprint
L1	Vishay-Dale	IHLP2525CZER8R2M01	L= 8.2 μH 68.0 mOhm	1	\$0.61	[] IHLP-2525CZ 75 mm ²
Rfbb	Vishay-Dale	CRCW040243K2FKED Series= CRCWe3	Res= 43.2 kOhm Power= 63.0 mW Tolerance= 1.0%	1	\$0.01	0402 3 mm ²
Rfbt	Vishay-Dale	CRCW0402100KFKED Series= CRCWe3	Res= 100.0 kOhm Power= 63.0 mW Tolerance= 1.0%	1	\$0.01	0402 3 mm ²
Rpgood	Vishay-Dale	CRCW0603100KFKEA Series= CRCWe3	Res= 100.0 kOhm Power= 100.0 mW Tolerance= 1.0%	1	\$0.01	0603 5 mm ²
Rt	Yageo	AC0402FR-07205KL Series=?	Res= 205.0 kOhm Power= 63.0 mW Tolerance= 1.0%	1	\$0.01	0402 3 mm ²
U1	Texas Instruments	LM76005QRNPRQ1	Switcher	1	\$2.35	RNP0030B 48 mm²











Operating Values

#	Name	Value	Category	Description
1.	BOM Count	14		Total Design BOM count
2.	Total BOM	\$4.134		Total BOM Cost
3.	Cin IRMS	521.344 mA	Capacitor	Input capacitor RMS ripple current
4.	Cin Pd	1.601 mW	Capacitor	Input capacitor power dissipation
5.	Cinx IRMS	154.822 mA	Capacitor	Bulk capacitor RMS ripple current
6.	Cinx Pd	411.13 µW	Capacitor	Bulk capacitor power dissipation
7.	Cout IRMS	574.444 mA	Capacitor	Output capacitor RMS ripple current
8.	Cout Pd	2.97 mW	Capacitor	Output capacitor power dissipation
9.	Coutx IRMS	3.132 mA	Capacitor	Output capacitor_x RMS ripple current
10.	Coutx Pd	107.63 nW	Capacitor	Output capacitor_x power loss
11.	IC lpk	3.5 A	IC	Peak switch current in IC
12.	IC Pd	636.06 mW	IC	IC power dissipation
13.	IC Tj	40.177 degC	IC	IC junction temperature
14.	IC Tolerance	20.0 mV	IC	IC Feedback Tolerance
15.	ICThetaJA Effective	16.0 degC/W	IC	Effective IC Junction-to-Ambient Thermal Resistance
16.	lin Avg	194.56 mA	IC	Average input current
17.	Ipp percentage	80.031 %	Inductor	Inductor ripple current percentage (with respect to average inducto current)
18.	L lpp	2.001 A	Inductor	Peak-to-peak inductor ripple current
	L Pd	447.68 mW	Inductor	Inductor power dissipation
	Cin Pd	1.601 mW	Power	Input capacitor power dissipation
	Cinx Pd	411.13 µW	Power	Bulk capacitor power dissipation
	Cout Pd	2.97 mW	Power	Output capacitor power dissipation
	Coutx Pd	107.63 nW	Power	Output capacitor_x power loss
	IC Pd	636.06 mW	Power	IC power dissipation
	L Pd	447.68 mW	Power	Inductor power dissipation
26.	Total Pd	1.089 W	Power	Total Power Dissipation
27.	Cross Freq	13.956 kHz	System	Bode plot crossover frequency
	0.00009	. 0.000	Information	2000 plot ologootol moquolity
28.	Duty Cycle	7.475 %	System	Duty cycle
_0.	Duty Oyolo	7.170 70	Information	Duty by blo
29.	Efficiency	88.341 %	System	Steady state efficiency
_0.	Lindondy	00.011 /0	Information	cloudy diale differency
30.	FootPrint	286.0 mm ²	System	Total Foot Print Area of BOM components
00.	1 Ooti Tiilt	200.0 111111	Information	rotain out i filit / lieu of Bow components
31.	Frequency	201.647 kHz	System	Switching frequency
J 1.	. roquonoy	EUTOTI MIZ	Information	Simoning inequation
32.	Gain Marg	-22.406 dB	System	Bode Plot Gain Margin
υ <u>ν</u> .	Jani Mary	22.700 GD	Information	Bodo Flot Gaill Margin
33.	lout	2.5 A	System	lout operating point
JJ.	iout	2.0 A	Information	iout operating point
34.	Low Freq Gain	69.913 dB	System	Gain at 1Hz
J4.	Low Fley Gaill	UJ.JIJ UD	Information	Jaili at 1112
35.	Mode	FCCM		Conduction Mode
აა.	IVIOUE	FOCIVI	System	Conduction Mode
26	Dhaca Mara	72.26 dog	Information	Pada Blat Bhasa Margin
36.	Phase Marg	72.26 deg	System	Bode Plot Phase Margin
27	Dout	0 0E W	Information	Total autout navar
37.	Pout	8.25 W	System	Total output power
20	V/:	40.0 \/	Information	Via an austing paint
38.	Vin	48.0 V	System	Vin operating point
			Information	

#	Name	Value	Category	Description
39.	Vin p-p	433.623 mV	System Information	Peak-to-peak input voltage
40.	Vout	3.3 V	System Information	Operational Output Voltage
41.	Vout Actual	3.315 V	System Information	Vout Actual calculated based on selected voltage divider resistors
42.	Vout Tolerance	3.439 %	System Information	Vout Tolerance based on IC Tolerance (no load) and voltage divider resistors if applicable
43.	Vout p-p	17.909 mV	System Information	Peak-to-peak output ripple voltage

Design Inputs

Name	Value	Description	
lout	5.0	Maximum Output Current	
SoftStart	15.0 ms	Soft Start Time (ms)	
VinMax	60.0	Maximum input voltage	
VinMin	5.0	Minimum input voltage	
Vout	3.3	Output Voltage	
base_pn	LM76005-Q1	Base Product Number	
source	DC	Input Source Type	
Та	30.0	Ambient temperature	
UserFsw	200.0 k	Customer Selected Frequency	

WEBENCH® Assembly

Component Testing

Some published data on components in datasheets such as Capacitor ESR and Inductor DC resistance is based on conservative values that will guarantee that the components always exceed the specification. For design purposes it is usually better to work with typical values. Since this data is not always available it is a good practice to measure the Capacitance and ESR values of Cin and Cout, and the inductance and DC resistance of L1 before assembly of the board. Any large discrepancies in values should be electrically simulated in WEBENCH to check for instabilities and thermally simulated in WebTHERM to make sure critical temperatures are not exceeded.

Soldering Component to Board

If board assembly is done in house it is best to tack down one terminal of a component on the board then solder the other terminal. For surface mount parts with large tabs, such as the DPAK, the tab on the back of the package should be pre-tinned with solder, then tacked into place by one of the pins. To solder the tab town to the board place the iron down on the board while resting against the tab, heating both surfaces simultaneously. Apply light pressure to the top of the plastic case until the solder flows around the part and the part is flush with the PCB. If the solder is not flowing around the board you may need a higher wattage iron (generally 25W to 30W is enough).

Initial Startup of Circuit

It is best to initially power up the board by setting the input supply voltage to the lowest operating input voltage 5.0V and set the input supply's current limit to zero. With the input supply off connect up the input supply to Vin and GND. Connect a digital volt meter and a load if needed to set the minimum lout of the design from Vout and GND. Turn on the input supply and slowly turn up the current limit on the input supply. If the voltage starts to rise on the input supply continue increasing the input supply current limit while watching the output voltage. If the current increases on the input supply, but the voltage remains near zero, then there may be a short or a component misplaced on the board. Power down the board and visually inspect for solder bridges and recheck the diode and capacitor polarities. Once the power supply circuit is operational then more extensive testing may include full load testing, transient load and line tests to compare with simulation results.

Load Testing

The setup is the same as the initial startup, except that an additional digital voltmeter is connected between Vin and GND, a load is connected between Vout and GND and a current meter is connected in series between Vout and the load. The load must be able to handle at least rated output power + 50% (7.5 watts for this design). Ideally the load is supplied in the form of a variable load test unit. It can also be done in the form of suitably large power resistors. When using an oscilloscope to measure waveforms on the prototype board, the ground leads of the oscilloscope probes should be as short as possible and the area of the loop formed by the ground lead should be kept to a minimum. This will help reduce ground lead inductance and eliminate EMI noise that is not actually present in the circuit.



Design Assistance

- 1. The LM76005-Q1 is qualified for Automotive applications. All passives and other components selected in this design may not be qualified for Automotive applications. The user is required to verify that all components in the design meet the qualification and safety requirements for their specific application
- 2. Master key: 3A09369785B968091A003B956300BD89[v1]
- 3. LM76005-Q1 Product Folder: http://www.ti.com/product/LM76005%2Dq1: contains the data sheet and other resources.

Important Notice and Disclaimer

TI provides technical and reliability data (including datasheets), design resources (including reference designs), application or other design advice, web tools, safety information, and other resources AS IS and with all faults, and disclaims all warranties. These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

Providing these resources does not expand or otherwise alter TI's applicable Terms of Sale or other applicable terms available either on ti.com or provided in conjunction with TI products.