Characteristics

- Location
- Capacity
- Unit of transfer
- Access method
- Performance
- Physical type
- Physical characteristics
- Organisation

Location

- CPU
- Internal
- External

Capacity

- Word size
  - The natural unit of organisation
- Number of words
  - or Bytes

Unit of Transfer

- Internal
  - Usually governed by data bus width
- External
  - Usually a block which is much larger than a word
- Addressable unit
  - Smallest location which can be uniquely addressed
  - Word internally
  - Cluster on M$ disks

Memory Hierarchy

- Registers
  - In CPU
- Internal or Main memory
  - May include one or more levels of cache
  - “RAM”
- External memory
  - Backing store

Memory Hierarchy - Diagram



Performance

- Access time
  - Time between presenting the address and getting the valid data
- Memory Cycle time
  - Time may be required for the memory to “recover” before next access
  - Cycle time is access + recovery
- Transfer Rate
  - Rate at which data can be moved

Physical Types

- Semiconductor
  - RAM
- Magnetic
  - Disk & Tape
- Optical
  - CD & DVD
- Others
  - Bubble
  - Hologram

Physical Characteristics

- Decay
- Volatility
- Erasable
- Power consumption

Organisation

- Physical arrangement of bits into words
- Not always obvious
- e.g. interleaved

The Bottom Line

- How much?
  - Capacity
- How fast?
  - Time is money
- How expensive?

Hierarchy List

- Registers
- L1 Cache
- L2 Cache
- Main memory
- Disk cache
- Disk
- Optical
- Tape

So you want fast?

- It is possible to build a computer which uses only static RAM (see later)
- This would be very fast
- This would need no cache
  - How can you cache cache?
- This would cost a very large amount

Locality of Reference

- During the course of the execution of a program, memory references tend to cluster
- e.g. loops

Cache

- Small amount of fast memory
- Sits between normal main memory and CPU
- May be located on CPU chip or module



Cache/Main Memory Structure



Cache operation – overview

- CPU requests contents of memory location
- Check cache for this data
- If present, get from cache (fast)
- If not present, read required block from main memory to cache
- Then deliver from cache to CPU
- Cache includes tags to identify which block of main memory is in each cache slot

Cache Read Operation - Flowchart



Cache Design

- Size
- Mapping Function
- Replacement Algorithm
- Write Policy
- Block Size
- Number of Caches

Size does matter

- Cost
  - More cache is expensive
- Speed
  - More cache is faster (up to a point)
  - Checking cache for data takes time

Typical Cache Organization



Mapping Function

- Cache of 64kByte
- Cache block of 4 bytes
  - i.e. cache is 16k (2^{14}) lines of 4 bytes
- 16MBytes main memory
- 24 bit address
  - (2^{24}=16M)

Direct Mapping

- Each block of main memory maps to only one cache line
  - i.e. if a block is in cache, it must be in one specific place
- Address is in two parts
- Least Significant w bits identify unique word
- Most Significant s bits specify one memory block
- The MSBs are split into a cache line field r and a tag of s-r (most significant)

Direct Mapping Address Structure

Tag s-r	Line or Slot r	Word w
8	14	2

- 24 bit address
- 2 bit word identifier (4 byte block)
- 22 bit block identifier
  - 8 bit tag (=22-14)
  - 14 bit slot or line
- No two blocks in the same line have the same Tag field
- Check contents of cache by finding line and checking Tag

Direct Mapping
Cache Line Table

Cache line	Main Memory blocks held
0	0, m, 2m, 3m…2s-m
1	1,m+1, 2m+1…2s-m+1
m-1	m-1, 2m-1,3m-1…2s-1

Direct Mapping Cache Organization



Direct Mapping Example



	Tag	Line	Word
Main memory address =	8	14	2

Direct Mapping Summary

- Address length = (s + w) bits
- Number of addressable units = 2s+w words or bytes
- Block size = line size = 2w words or bytes
- Number of blocks in main memory = 2s+ w/2w = 2s
- Number of lines in cache = m = 2r
- Size of tag = (s – r) bits

Direct Mapping pros & cons

- Simple
- Inexpensive
- Fixed location for given block
  - If a program accesses 2 blocks that map to the same line repeatedly, cache misses are very high

Associative Mapping

- A main memory block can load into any line of cache
- Memory address is interpreted as tag and word
- Tag uniquely identifies block of memory
- Every line's tag is examined for a match
- Cache searching gets expensive

Fully Associative Cache Organization



Associative Mapping Example





Associative Mapping
Address Structure

Tag 22 bit	Word 2 bit

- 22 bit tag stored with each 32 bit block of data
- Compare tag field with tag entry in cache to check for hit
- Least significant 2 bits of address identify which 16 bit word is required from 32 bit data block
- e.g.
  - Address Tag Data Cache line
  - FFFFFC FFFFFC24682468 3FFF

Associative Mapping Summary

- Address length = (s + w) bits
- Number of addressable units = 2s+w words or bytes
- Block size = line size = 2w words or bytes
- Number of blocks in main memory = 2s+ w/2w = 2s
- Number of lines in cache = undetermined
- Size of tag = s bits

Set Associative Mapping

- Cache is divided into a number of sets
- Each set contains a number of lines
- A given block maps to any line in a given set
  - e.g. Block B can be in any line of set i
- e.g. 2 lines per set
  - 2 way associative mapping
  - A given block can be in one of 2 lines in only one set

Set Associative Mapping Example

- 13 bit set number
- Block number in main memory is modulo 2^{13}
- 000000, 00A000, 00B000, 00C000 … map to same set

Two Way Set Associative Cache Organization



Set Associative Mapping Address Structure

Tag 9 bit	Set 13 bit	Word 2 bit

- Use set field to determine cache set to look in
- Compare tag field to see if we have a hit
- e.g
  - Address Tag Data Set number
  - 1FF 7FFC 1FF 12345678 1FFF
  - 001 7FFC 001 11223344 1FFF

Two Way Set Associative Mapping Example



Set Associative Mapping Summary

- Address length = (s + w) bits
- Number of addressable units = 2s+w words or bytes
- Block size = line size = 2w words or bytes
- Number of blocks in main memory = 2d
- Number of lines in set = k
- Number of sets = v = 2d
- Number of lines in cache = kv = k * 2d
- Size of tag = (s – d) bits

Replacement Algorithms (1)
Direct mapping

- No choice
- Each block only maps to one line
- Replace that line

Replacement Algorithms (2)
Associative & Set Associative

- Hardware implemented algorithm (speed)
- Least Recently used (LRU)
- e.g. in 2 way set associative
  - Which of the 2 block is lru?
- First in first out (FIFO)
  - replace block that has been in cache longest
- Least frequently used
  - replace block which has had fewest hits
- Random

Write Policy

- Must not overwrite a cache block unless main memory is up to date
- Multiple CPUs may have individual caches
- I/O may address main memory directly

Write through

- All writes go to main memory as well as cache
- Multiple CPUs can monitor main memory traffic to keep local (to CPU) cache up to date
- Lots of traffic
- Slows down writes

- Remember bogus write through caches!

Write back

- Updates initially made in cache only
- Update bit for cache slot is set when update occurs
- If block is to be replaced, write to main memory only if update bit is set
- Other caches get out of sync
- I/O must access main memory through cache
- N.B. 15% of memory references are writes

Pentium 4 Cache

- 80386 – no on chip cache
- 80486 – 8k using 16 byte lines and four way set associative organization
- Pentium (all versions) – two on chip L1 caches
  - Data & instructions
- Pentium III – L3 cache added off chip
- Pentium 4
  - L1 caches
    - 8k bytes
    - 64 byte lines
    - four way set associative
  - L2 cache
    - Feeding both L1 caches
    - 256k
    - 128 byte lines
    - 8 way set associative
  - L3 cache on chip

Intel Cache Evolution

Problem	**Solution**	**Processor on which feature first appears**
External memory slower than the system bus.	Add external cache using faster memory technology.	386
Increased processor speed results in external bus becoming a bottleneck for cache access.	Move external cache on-chip, operating at the same speed as the processor.	486
Internal cache is rather small, due to limited space on chip	Add external L2 cache using faster technology than main memory	486
Contention occurs when both the Instruction Prefetcher and the Execution Unit simultaneously require access to the cache. In that case, the Prefetcher is stalled while the Execution Unit's data access takes place.	Create separate data and instruction caches.	Pentium
Increased processor speed results in external bus becoming a bottleneck for L2 cache access.	Create separate back-side bus that runs at higher speed than the main (front-side) external bus. The BSB is dedicated to the L2 cache.	Pentium Pro
	Move L2 cache on to the processor chip.	Pentium II
Some applications deal with massive databases and must have rapid access to large amounts of data. The on-chip caches are too small.	Add external L3 cache.	Pentium III
	Move L3 cache on-chip.	Pentium 4

Pentium 4 Block Diagram



Pentium 4 Core Processor

- Fetch/Decode Unit
  - Fetches instructions from L2 cache
  - Decode into micro-ops
  - Store micro-ops in L1 cache
- Out of order execution logic
  - Schedules micro-ops
  - Based on data dependence and resources
  - May speculatively execute
- Execution units
  - Execute micro-ops
  - Data from L1 cache
  - Results in registers
- Memory subsystem
  - L2 cache and systems bus

Pentium 4 Design Reasoning

- Decodes instructions into RISC like micro-ops before L1 cache
- Micro-ops fixed length
  - Superscalar pipelining and scheduling
- Pentium instructions long & complex
- Performance improved by separating decoding from scheduling & pipelining
  - (More later – ch14)
- Data cache is write back
  - Can be configured to write through
- L1 cache controlled by 2 bits in register
  - CD = cache disable
  - NW = not write through
  - 2 instructions to invalidate (flush) cache and write back then invalidate
- L2 and L3 8-way set-associative
  - Line size 128 bytes