Section One: Introductio	on to AVR Development Tools
	SECTION ONE INTRODUCTION TO AVR DEVELOPMENT TOOLS

## **SECTION OVERVIEW**

### Complete the following objectives:

- Connect your AVR microcontroller board to a TekBot.
- Create a new AVRStudio4 project.
- Download and compile the sample AVR Assembly source code.
- Understand how to run and operate the Universal Programmer.
- Upload and run the sample program on the TekBots AVR microcontroller board.

# **PRELAB**

In labs to come you will be required to complete a prelab for each lab. The prelab will cover concepts and knowledge that is required for the lab. The prelabs are due at the beginning of your lab section each week. If you do not have your prelab done at the beginning of the lab period you will receive no credit for the prelab. Prelabs are to be submitted on paper, not by email. For this lab, no prelab is required.

## **PROCEDURE**

### Wiring Your TekBot

- 1. Take a look at the wiring diagrams available on the Lab webpage. To make the wires for connecting your TekBot boards together you will need to use the ribbon cable that came with your kit with male headers soldered to the ends and a bit of heat shrink tubing on the connections. There is a short tutorial on the TekBots webpage that explains this process in detail.
- 2. Because we are working with a modular programmable AVR microcontroller board, you can connect the whisker inputs and motor controller outputs to any pins on any port on the board. But for the demo lab to work properly, these cables need to be connected in a certain way. This configuration should be used throughout the course. It uses the pin's alternative functions rather than its primary functions. As the course progresses, you will learn what both of these functions are. Table 1 (next page) shows the proper pin connections.

Connection	Port	Pin	Alternative Function
Right Whisker	D	0	External Interrupt 0
Left Whisker	D	1	External Interrupt 1
Right Motor Enable	В	4	PWM Output for
			Timer/Counter0
Right Motor	В	5	PWM Output A for
Direction			Timer/Counter1
Left Motor Direction	В	6	PWM Output B for
			Timer/Counter1
Left Motor Enable	В	7	PWM Output for
			Timer/Counter2

Table 1: TekBots Connections to AVR Microcontroller Board

3. When you have completed the wiring, be sure to ask your TA to look it over before you turn the power on. If you have wired things incorrectly (especially if you have switched Vcc and ground), you WILL destroy parts of your TekBot. Please have the TA initial in the space below that you have shown your TekBot to them.

TA Initials:	

## **Looking at some AVR Source Code**

- 1. Download the sample code available on the webpage. This is a simple AVR source code that will run your TekBot in the simple BumpBot fashion. All code that you produce should be as well commented as this sample code. Save this code where you can find it in your UNIX file share network drive (commonly called drive Z:)
- 2. AVRStudio4 is the Integrated Development Environment (IDE) that you will be using to develop your AVR assembly code throughout the remainder of the course (with the exception of Lab 2). AVRStudio4 is a powerful IDE created by Atmel for their line of AVR microcontrollers. You will be using it to write assembly programs for your AVR microcontroller board that uses an ATmega128 microcontroller. Section 2 of the AVR Starter Guide, which can be found on the TekBots website, contains a good overview on how to use the program as well as some step-by-step tutorials. Briefly read through this section to gain a basic understanding of the IDE.

(Optional) If the IDE is not already installed on the computer, or if you are doing this lab from home, read through and follow the steps in Section 2.1.1 of the AVR Starters Guide to download and install AVRStudio4 on your computer.

#### Section One: Introduction to AVR Development tools

- 3. Follow the steps in Section 2.1.2 in the AVR Starters Guide to create a new project. In most IDE tools, a project is the base starting area to your program. It consists of all files you use and any settings for the program. When following this tutorial, you'll want to use the AVR assembly source code you downloaded from the web in step 1.
- 4. With the current project activated in step 4, follow the Project Simulation tutorial in Section 2.1.3 of the AVR Starters Guide to learn how to compile and simulate your program. By the end of this step, you should know how to successfully create an AVR project from scratch and be able to compile it into usable program hex code.
- 5. When assembly source code is compiled, it creates a binary program file (called a HEX file with a .hex extension). This HEX file contains the actual binary instructions that are used by the ATmega128 and is what needs to be uploaded onto the AVR Microcontroller Board.
- 6. To program the chip, a different piece of software will be used. You must run the Universal Programmer, which should be already available on the lab machines. This is an open source program that can upload the AVR HEX programs to the various AVR microcontrollers. You simply connect the AVR board to your PC using the TekBots Universal Programmer, USB cable and 10-pin IDC cable, which were all included in your lab kits. Follow the instructions on the Lab webpage.

#### **Section One: Introduction to AVR Development Tools**

With the program uploaded into the microcontroller, unplug the TekBot from the computer and turn it on. Observe the behavior; the TekBot should be operating in the similar BumpBot fashion. Demonstrate your TekBot to your TA.

TA Initials:	

Theory of Operation for Lab 1 AVR Assembly Code.

- Initializes key components of the ATmega128
- Starts the TekBot moving forward
- Polls the whiskers for input
- If right whisker is hit
  - o Backs up for a second
  - Turns left for a second
  - o Continues Forward
- If left whisker is hit
  - Backs up for a second
  - o Turns right for a second
  - Continues Forward

# STUDY QUESTIONS/ REPORT

For all labs you will be required to submit a short write-up that details what you did and why. You must use the template write-up available on the lab webpage. See the webpage and template for specific details on what should be included in the lab write-up. You must submit a hard copy of your write-up and code to your TA by the start of the following lab. NO LATE WORK IS ACCEPTED.

Regarding the formatting of your write-up, it should be typed. You are responsible for turning in a clean, organized and professional document free of misspelled words. The code you turn in must include sufficient comments for ANOTHER STUDENT to be able to understand your code. *Code that is not well documented will be penalized severely*. If you are interested in the style and detail expected of your comments, look at the code you just downloaded. Generally you should have a comment for every line of code.

There is no write-up required for this lab but you will turn in the answers to the study questions given below.

# **Study Questions:**

Most of the labs you do will have study questions that are to be answered within your lab write-up. This lab's study questions are given below and will be due at the start of lab next week. Although you will be exposed to some information that has not been covered in class, keep in mind that as a student accepted into pro school you will need to get into the habit of being pro-active. This involves reading ahead and preparing yourself before going to lab or class.

- 1. Go to the lab webpage and download the template write-up. Read it thoroughly and get familiar with the expected format. Specifically look at the included source code. What type of font is used? What size is the font? From here on when you include your source code in your lab write-up you must adhere to that font type and size.
- 2. Take a look at the code you downloaded for today's lab. Notice the lines that begin with .def and .equ followed by some type of expression. These are known as **pre-compiler directives**. Define pre-compiler directive. What is the difference between the .def and .equ directives (HINT: see section 5.1 of the AVR Starter Guide given on the lab webpage).
- 3. Take another look at the code you downloaded for today's lab. Read the comment that describes the macro definitions. From that explanation determine the 8-bit binary value of the following expressions. Note: the numbers below are decimal values.
  - a. (1 << 2)
  - b. (2 << 1)
  - c. (4>>1)
  - d. (1<<4)
  - e. (6>>1|1<<6)

# **CHALLENGE**

Challenge problems are additional tasks that can be preformed for the labs. By successfully completing a challenge problem you can get extra credit for your lab. To get credit for the challenge problem you must successfully demonstrate it to your TA as well as document it in your lab write up. Today's challenge question is given below:

1. You have learned to use a simple tool to download a program into your TekBot. Modify the program so the TekBot reverses twice as long before turning away and resuming forward motion. Demonstrate this to your TA and be turn in a copy of you modified assembler program