
# **Me Arm**

#### A robot with ROS and **Arduino**

**Alessia Ture** 








### **Introduction to MeArm**

- Compact and Open-Source: The MeArm is a compact, open-source robotic arm known for its simplicity and accessibility, making it an ideal platform for educational purposes and hobbyist projects.
- 4DOF Architecture: Featuring four degrees of freedom (DOF) powered by four micro servomotors
- Project Objective: control the MeArm using the Robot Operating System (ROS)



### **Arduino**

Arduino is an open-source **microcontroller** 

Arduino and ROS integration allows you to leverage the simplicity of Arduino for hardware control and the power of ROS for high-level communication and processing.



### rosserial: what is it?



Libraries for various microcontrollers that implement the rosserial communication protocol.



#### rosserial\_server:

A ROS node that communicates with the rosserial\_client and acts as a bridge between the microcontroller and the ROS ecosystem.

## How integrate ROS & Arduino?



#### **Arduino Node**

rosserial\_arduino
library in sketch,
allows the Arduino to
publish and subscribe
to ROS topics, call or
provide ROS services,
and use ROS time



#### **Ros Host**

run a node provided by rosserial, such as rosserial\_python. This node opens a serial port connection to the Arduino. It then serializes ROS messages into a byte stream



#### **Connection**

When the Arduino wants to publish data, rosserial\_client packages the data into packets and sends them over the serial link. The rosserial\_server receives these packets, unpacks them, and publishes

### **Arduino Node**

- Arduino sketch allows the MeArm to receive position commands for its joints from a ROS node, moving the servomotors to specified degrees.
- Sketch subscribes to the servo\_pose\_server topic, which should receive messages like mearm\_model::ServoAngles.
- A callback function, servoAnglesCallback, is defined which is automatically called every time a new message arrives on the topic. The function reads the angles from the messages and sets the servo motors corresponding to those angles

```
#include <Servo.h>
#include <ros.h>
#include <mearm model/ServoAngles.h>
Servo servo1:
Servo servo2:
Servo servo3:
Servo servo4:
ros::NodeHandle nh;
void servoAnglesCallback(const mearm_model::ServoAngles& angles_msg) {
  servo1.write(angles msg.servo1);
  servo2.write(angles_msg.servo2);
  servo3.write(angles_msg.servo3);
  servo4.write(angles_msg.servo4);
ros::Subscriber<mearm_model::ServoAngles> servoAnglesSub("servo_pose_server", &servoAnglesCallback);
void setup() {
  nh.getHardware()->setBaud(115200);
  nh.initNode();
  nh.subscribe(servoAnglesSub);
  servol.attach(9);
  servo2.attach(10):
  servo3.attach(11):
  servo4.attach(12):
void loop() {
  nh.spinOnce();
```

#### **Nodes**



#### robot\_joint\_mover

Defines a service that allows users to set the position of the robot's joints by sending the name of a predefined set of positions. When the service receives a request, it looks for the corresponding set of locations in the ROS Parameter Server.



#### mearm\_controller

Creates a publisher on a topic called **servo\_pose\_server** that publishes messages of type **ServoAngles**. These messages contain the angles for the servo motors that the MeArm will use to position its joints

## Messagges

Used for communication between nodes in a ROS system. This message is specifically designed to carry information about servomotor angles.


```
int16 servo1
int16 servo2
int16 servo3
int16 servo4
```

## **Topics**



Message Type: mearm\_model/ServoAngles

<u>Function</u>: Used to send precise positioning commands to the MeArm's servo motors. Nodes can post to this topic to change joint positions.



Message Type: sensor\_msgs/JointState

<u>Function</u>: Transmits the current state of the MeArm joints, including position, velocity and effort for each joint

### Services

ROS node (**robot\_joint\_mover**) calls this service and sends the name of a set of locations through the *set\_name* field.

The node, which manages the service, receives this request, executes the necessary logic to change the position of the and then would respond with success = true if the process is completed correctly, or success = false if there was an error or the set was not applicable.

string set\_name
--bool success

## Parameter Server

It is used to group the different positions that can be applied to the joints of the MeArm


These sets of positions can be used to quickly command the robot to assume specific positions.

```
position_sets:
```

set1: [0.0, 0.5, -0.5, 0.25] set2: [0.25, -0.5, 0.5, 0.0] set3: [-0.25, 0.0, 0.25, 0.5]


### **RViz**


RViz (ROS Visualization) is an interactive 3D visualization tool for the Robot Operating System (ROS) that allows users to visualize robot architecture, sensor data



## System Architecture

The schema present topics and node involed in RViz-arduino communication





### Thanks!

All the code show can be found at: https://github.com/ature/MeArm-Robot/