Robot Operating System

Lab 1: Packages, launch files, parameters and topic remapping

1 Goals

In this lab we will see the main tools to analyze nodes and topics.

1.1 Using the terminals

In ROS, a lot of commands have to be run from the terminal. Each terminal should be configured either to run ROS 1 things, or ROS 2 things. A simple shortcut allows changing this:

```
ros1ws # type this to configure the terminal for ROS 1 (default) ros2ws # type this to configure the terminal for ROS 2 (has to be done manually)
```

You can change the default behavior by updating the ros1ws line of your .bashrc file. Each time a package is compiled, the corresponding command (ros1ws / ros2ws) should be run in order to refresh the package list.

1.2 Bring up Baxter

Even if you have a real Baxter robot it can be a good idea to test the lab in simulation first. In both cases, we want to have a RViz display, which is mandatory in simulation and quite handy on the real robot. RViz is run automatically in both cases.

1.2.1 On the real robot

Baxter is a ROS1-based robot. To work with ROS 2 we thus have to run a bridge that transforms all or some topics between ROS 1 and ROS 2.

A launch file is available in the baxter_bridge package to run both the bridge and RViz. You have to connect to Baxter's ROSMASTER in the terminal where you run the bridge:

```
ros2ws
source ~/ros/baxter.sh # so that your ROSMASTER is Baxter
ros2 launch baxter_bridge baxter_bridge_launch.py
```

In you are in a lab on the real Baxter, remind the lab assistant to allow multiple publishers for this lab. It can be done from a ROS 1 terminal:

```
ros1ws
source ~/ros/baxter.sh # so that your ROSMASTER is Baxter
rosparam set allow_multiple true
```



1.2.2 In simulation (including virtual machine users)

The Baxter simulator behaves as the actual Baxter from the ROS 2 side, only with a very limited part of the same topics and services.

The baxter_bridge node should be run from a ROS 2 terminal:

```
ros2ws
ros2 launch baxter_simple_sim sim_launch.py
```

The launch file also runs RViz.

1.3 Initial state

Whether in simulation or on the robot, Baxter is not moving and is waiting for commands on any arm.

A few in/out topics exist and can be listed through:

```
rostopic list (ROS 1, if on the real robot) ros2 topic list (ROS 2)
```

1.4 Compiling the package

The folder should be put in your ROS 2 workspace (~/ros2/src). Compilation is done by calling colcon from the root of the workspace:

```
ros2ws
cd ~/ros2
colbuild --packages-select move_joint
```

2 Running the control nodes

A basic control GUI can be run with:

```
ros2 launch move_joint slider_launch.py
```

It runs a node that sends the slider value on a topic (here setpoint).

The Baxter robot has 2×7 joints as shown in Fig. 1, the names of which are listed in the table.

A special node called move_joint should be used to change the value published by the slider GUI, to the setpoint of a particular joint:

```
ros2 run move_joint move_joint
```

2.1 Initial state of the control nodes

Use ros2 node and ros2 topic to get the information on the nodes. There are currently two limitations:

• The move_joint node needs a parameter to tell which joint it should be controlling






Figure 1: Baxter joints

• The slider publishes on setpoint while the move_joint node listens to joint_setpoint Additionally, it would be nice to run the two nodes in the same lauch file.

2.2 Regroup all nodes in the same launch file

Open the slider_launch.py and add a line equivalent to calling ros2 run move_joint move_joint

Then, add a parameter to tell which joint should be controlled: parameters = {'joint_name': 'right_e0'}

To run this launch file, you can go to its folder and type ros2 launch ./slider_launch.py. Display the graph (rqt_graph) to detect that the slider node and move_joint do not communicate, because they do not use the same topics.

2.3 Remapping

In this section we will remap the topic name of move_joint such that is uses setpoint instead of joint_setpoint.

Modify the launch file by adding this argument to the move_joint node:

```
remappings = {'joint_setpoint': 'setpoint'}.items()
```

Run the launch file again and you should be able to control the chosen joint.

3 Playing with launch files

3.1 Argument for joint name

Now that a launch file exists to control 1 joint from a slider, we will change the hard-coded joint name to an argument:



```
sl.declare_arg('name', 'right_e0')
```

This syntax tells the launch file that is now has a name argument, with default value 'right_e0'.

Change the hard-coded value to the argument one sl.arg('right_e0') and check that the behavior is the same

Also, you can rename the slider GUI by giving an additional argument:

```
sl.node('slider_publisher', 'slider_publisher', name=sl.arg('name'), ...)
```

Then, run the launch file with another name, for instance:

ros2 launch ./slider_launch.py name:=left_e0

On another terminal, try to run the same launch file for another joint. What happens?

3.2 Including launch files in other launch files

In this last section we will write a new launch file that will include the previous one, for various joint names. In order to avoid node / topic duplicates, each nodes relative to a specific joint will be in their own namespace.

The syntax to include a launch file in another one is as follow:

```
sl.include('move_joint', 'slider_launch.py', launch_arguments = {'name': 'right_e0'})
```

It should be called from a namespace block, with this syntax:

```
with sl.group(ns = 'right_e0'):
    sl.include('move_joint', 'slider_launch.py', launch_arguments = {'name': 'right_e0'})
```

Check that the behavior is similar to the previous one. Then, write a for loop to run this code for many joint names:

```
for joint in ('right_e0', 'right_e1', ...):
    with sl.group(ns = joint):
        sl.include(...)
```

