```
TITLE "PS/2 INPUT";
%_____
   PS/2 input module : Communication between PS/2 bus and System
                      bus.
INCLUDE "SC_TO_U2.inc";
CONSTANT ps2_addr = H"50";
                                       -- Keyboard address in I/O
SUBDESIGN PS2_IN
                           : input; -- 20MHz clock
: input; -- Reset signal from uC
    GEN
   RESET
    -- Bus
    ADDR[7..0]
                        : input; -- Address bus
: output; -- Data bus
   DATA[7..0]
                           : output; -- Wait signal
    WAIT
                           : input; -- I/O request signal
    IORQ
                           : input;
                                       -- Read signal
   RD
    -- PS/2 debug
    PS2_DEBUG_PORT[7..0] : output; -- Output port for debugging
    -- PS/2 connection port
   PDATA_IN[7..0] : input; -- PS/2 bus input port
VARIABLE
   -- Bus
                           : SC_TO_U2; -- Scancode to U2 decoder
    -- Secure input dff's
   DFF_1_PS2_CLK : DFF; -- Input dff #1 for clock
DFF_2_PS2_CLK : DFF; -- Input dff #2 for clock
DFF_1_PS2_DATA : DFF; -- Input dff #1 for data
DFF_2_PS2_DATA : DFF; -- Input dff #2 for data
   DFF_2_PS2_DATA
-- Data recieving
PS2_FRAME[10..0] : DFF;
PS2_CNT_FRAME[3..0] : DFF;
PS2_CNT_BYTE[1..0] : DFF;
DFF;
                                      -- Recieved frame
                                   -- Frame bit's counter
                                       -- Frame bit's counter
                                       -- Data from PS/2 frame -
hardwired
   PS2_BYTE_READY : DFF;
                                       -- Data byte is ready flag
    -- Debug
    -- Machines
```

Revision: PS2_LPT_TRANSMITTER

```
-- Machine for PS/2 bus communication
      AUT PS2 : machine of bits (Q[1..0])
                                  with states (S0=B"00", S1=B"01",
                                                              S2=B"10", S3=B"11");
       -- Machine for system bus communication
      AUT_PS2_BUS : machine of bits (QB[2..0])
                                  with states (SPB0=B"000", SPB1=B"001", SPB2=B"010",
                                                             SPB3=B"011", SPB4=B"100", SPB5=B"101",
                                                              SPB6=B"110", SPB7=B"111");
BEGIN
       % assign global clock %
      DFF_1_PS2_CLK.CLK = GEN;
DFF_2_PS2_CLK.CLK = GEN;
      DFF_2_PS2_CLK.CLK
      DFF_1_PS2_DATA.CLK = GEN;
DFF_2_PS2_DATA.CLK = GEN;
PS2_FRAME[].CLK = GEN;
      PS2_CNT_FRAME[].CLK = GEN;
PS2_CNT_BYTE[].CLK = GEN;
      D_PS2_DEBUG_PORT[].CLK = GEN;
      PS2_BYTE[].CLK = GEN;
      PS2_BYTE_READY.CLK = GEN;
CMD_READ.CLK = GEN;
KEY_Z[].CLK = GEN;
                                             = GEN;
      KEY_Z[].CLK
                                       = GEN;
      KEY_D0[].CLK
KEY_D1[].CLK
KEY_D2[].CLK
      KEY_D2[].CLK
      DFF_DATA[].CLK
      SIG_WAIT.CLK
      CNT_DATA[].CLK
      S2U.GEN
      AUT PS2.CLK
      AUT_PS2_BUS.CLK = GEN;
       % assign global reset %
      S2U.RESET = RESET;
DFF_1_PS2_CLK.CLRN = RESET;
DFF_2_PS2_CLK.CLRN = RESET;
DFF_1_PS2_DATA.CLRN = RESET;
DFF_2_PS2_DATA.CLRN = RESET;
PS2_FRAME[].CLRN = RESET;
      PS2_CNT_FRAME[].CLRN = RESET;
PS2_CNT_BYTE[].CLRN = RESET;
      D_PS2_DEBUG_PORT[].CLRN = RESET;
      PS2_BYTE[].CLRN = RESET;

      PS2_BYTE[].CLRN
      = RESET;

      PS2_BYTE_READY.CLRN
      = RESET;

      CMD_READ.CLRN
      = RESET;

      KEY_Z[].CLRN
      = RESET;

      KEY_D0[].CLRN
      = RESET;

      KEY_D1[].CLRN
      = RESET;

      KEY_D2[].CLRN
      = RESET;

      DFF_DATA[].CLRN
      = RESET;

      SIG_WAIT.CLRN
      = RESET;
```

```
= RESET;
    CNT_DATA[].CLRN
    AUT PS2.RESET
                          = !RESET;
    AUT_PS2_BUS.RESET
                          = !RESET;
    % connect variables %
    TIAW
                           = SIG_WAIT.Q;
    S2U.SC_Z[]
                          = KEY_Z[];
   S2U.SC_D0[]
                         = KEY_D0[];
    S2U.SC_D1[]
                          = KEY_D1[];
    S2U.SC_D2[]
                           = KEY_D2[];
    case PS2_CNT_BYTE[] is
        when B"00" => PS2_DEBUG_PORT[] = 0;
        when B"01" => PS2_DEBUG_PORT[] = 1;
        when B"10" => PS2_DEBUG_PORT[] = 3;
        when B"11" => PS2_DEBUG_PORT[] = 7;
    end case;
    DATA[] = DFF_DATA[];
    % Hardwired byte from frame %
    PS2 BYTE[] = (PS2_FRAME8, PS2_FRAME7, PS2_FRAME6, PS2_FRAME5, PS2_FRAME4,
PS2_FRAME3, PS2_FRAME2, PS2_FRAME1);
    % Secure input of ps2 clock %
    DFF_1_PS2_CLK.D = PDATA_IN1;
    DFF_2_PS2_CLK.D = DFF_1_PS2_CLK.Q;
    % Secure input of ps2 data %
    DFF_1_PS2_DATA.D = PDATA_IN0;
    DFF_2_PS2_DATA.D = DFF_1_PS2_DATA.Q;
    % Bus %
    if(ADDR[] == ps2_addr & IORQ == GND & RD == GND) then
           % Command read %
           CMD_READ.D = VCC;
    else
           CMD READ.D = GND;
    end if;
    case AUT_PS2_BUS is
        % Wait for command from uC %
        when SPB0 => CMD_READ.D = CMD_READ.Q;
                     KEY Z[] = B"00000000";
                     KEY_D0[] = B"00000000";
                     KEY_D1[] = B"00000000";
                     KEY_D2[] = B"00000000";
                     PS2\_CNT\_BYTE[] = B"00";
                     CNT_DATA[] = B"00000000";
                     DFF DATA[] = 0;
                     if(CMD_READ.Q == 1) then
                        SIG WAIT.D = GND;
                        -- activate reciever
                        AUT_PS2_BUS = SPB1;
```

```
else
                -- unblock after reset
                SIG_WAIT.D = VCC;
                AUT_PS2_BUS = SPB0;
             end if;
% Wait for frame %
when SPB1 => CMD_READ.D = CMD_READ.Q;
             KEY_Z[] = KEY_Z[];
             KEY_D0[] = KEY_D0[];
             KEY_D1[] = KEY_D1[];
             KEY_D2[] = KEY_D2[];
             CNT DATA[] = CNT DATA[];
             DFF_DATA[] = DFF_DATA[];
             PS2_CNT_BYTE[] = PS2_CNT_BYTE[];
             if(PS2_BYTE_READY.Q == 1) then
                AUT_PS2_BUS = SPB2;
             else
                AUT_PS2_BUS = SPB1;
             end if;
% Check if frame data is "F0" %
when SPB2 => CMD_READ.D = CMD_READ.Q;
             KEY_Z[] = KEY_Z[];
             KEY_D0[] = KEY_D0[];
             KEY_D1[] = KEY_D1[];
             KEY_D2[] = KEY_D2[];
             CNT_DATA[] = CNT_DATA[];
             DFF_DATA[] = DFF_DATA[];
             PS2_CNT_BYTE[] = PS2_CNT_BYTE[];
             if(PS2_BYTE[] == B"11110000") then
                AUT_PS2_BUS = SPB3;
             else
                AUT_PS2_BUS = SPB1;
             end if;
% Wait for data frame ( after "FO" comes scancode of key ) %
when SPB3 => CMD READ.D = CMD READ.Q;
             KEY Z[] = KEY Z[];
             KEY_D0[] = KEY_D0[];
             KEY_D1[] = KEY_D1[];
             KEY_D2[] = KEY_D2[];
             CNT_DATA[] = CNT_DATA[];
             DFF_DATA[] = DFF_DATA[];
             PS2_CNT_BYTE[] = PS2_CNT_BYTE[];
             if(PS2_BYTE_READY.Q == 1) then
                AUT_PS2_BUS = SPB4;
             else
                AUT_PS2_BUS = SPB3;
             end if;
% Write key scancode into correct buffer %
when SPB4 => CMD_READ.D = CMD_READ.Q;
             KEY_Z[] = KEY_Z[];
             KEY D0[] = KEY D0[];
             KEY_D1[] = KEY_D1[];
```

PS2 IN.tdf

```
KEY_D2[] = KEY_D2[];
             CNT DATA[] = CNT DATA[];
             DFF_DATA[] = DFF_DATA[];
             PS2_CNT_BYTE[] = PS2_CNT_BYTE[]+1;
             case PS2_CNT_BYTE[] is
                when 0 => KEY_Z[] = PS2_BYTE[];
                          AUT_PS2_BUS = SPB1;
                when 1 \Rightarrow KEY_D2[] = PS2_BYTE[];
                          AUT_PS2_BUS = SPB1;
                when 2 => KEY_D1[] = PS2_BYTE[];
                          AUT PS2 BUS = SPB1;
                when 3 => KEY_D0[] = PS2_BYTE[];
                          AUT_PS2_BUS = SPB5;
             end case;
% Convert ZDDD to U2 and put it on data bus %
when SPB5 => CMD_READ.D = CMD_READ.Q;
             KEY_Z[] = KEY_Z[];
             KEY_D0[] = KEY_D0[];
             KEY_D1[] = KEY_D1[];
             KEY_D2[] = KEY_D2[];
             CNT_DATA[] = CNT_DATA[];
             PS2_CNT_BYTE[] = PS2_CNT_BYTE[];
             DFF_DATA[] = S2U.U2_LS[];
             if( CNT_DATA[] < 20 ) then</pre>
                AUT_PS2_BUS = SPB6;
             else
                AUT_PS2_BUS = SPB7;
             end if;
% Extend wait signal %
when SPB6 => CMD_READ.D = CMD_READ.Q;
             KEY_Z[] = KEY_Z[];
             KEY_D0[] = KEY_D0[];
             KEY_D1[] = KEY_D1[];
             KEY D2[] = KEY D2[];
             CNT_DATA[] = CNT_DATA[]+1;
             PS2_CNT_BYTE[] = PS2_CNT_BYTE[];
             DFF_DATA[] = DFF_DATA[];
             AUT_PS2_BUS = SPB5;
% Remove Wait, and wait for processor read %
when SPB7 => SIG_WAIT.D = VCC;
             CMD_READ.D = CMD_READ.Q;
             KEY_Z[] = KEY_Z[];
             KEY_D0[] = KEY_D0[];
             KEY_D1[] = KEY_D1[];
             KEY_D2[] = KEY_D2[];
             CNT_DATA[] = CNT_DATA[];
             PS2_CNT_BYTE[] = PS2_CNT_BYTE[];
             DFF DATA[] = DFF DATA[];
```

```
if(IORQ == VCC & RD == VCC)then
                        AUT_PS2_BUS = SPB0;
                     else
                        AUT_PS2_BUS = SPB7;
                     end if;
    end case;
    case AUT_PS2 is
        % PS2 clock down - start bit %
        when S0 => PS2_CNT_FRAME[] = B"0000";
                    PS2 FRAME[] = B"00000000000";
                    PS2_BYTE_READY.D = GND;
                    if(DFF_1_PS2_CLK.Q == 0 & DFF_2_PS2_CLK.Q == 1) then
                        AUT_PS2 = S2;
                        AUT PS2 = S0;
                    end if;
        % Wait for clock falling edge %
        when S1 => PS2_CNT_FRAME[] = PS2_CNT_FRAME[];
                    PS2_FRAME[] = PS2_FRAME[];
                    PS2_BYTE_READY.D = GND;
                    if(DFF_1_PS2_CLK.Q == 0 & DFF_2_PS2_CLK.Q == 1) then
                        AUT_PS2 = S2;
                    else
                        AUT PS2 = S1;
                    end if;
        % Read bit into frame buffer %
        when S2 => PS2_CNT_FRAME[] = PS2_CNT_FRAME[]+1;
                    PS2\_FRAME[] = (DFF\_2\_PS2\_DATA.Q, PS2\_FRAME[10..1]);
                    PS2_BYTE_READY.D = GND;
                    if(PS2_CNT_FRAME[] < 10) then</pre>
                        AUT_PS2 = S1;
                    else
                        AUT PS2 = S3;
                    end if;
        % 11 bit frame is ready %
        when S3 => PS2_FRAME[] = PS2_FRAME[];
                    PS2_CNT_FRAME[] = PS2_CNT_FRAME[];
                    PS2 BYTE READY.D = VCC;
                    -- reciever off
                    AUT_PS2 = S0;
    end case;
END;
```