AVR Interfacing


IO Ports


Agenda

- I/O Ports.
- I/O Ports Programming.
- Interfacing with Switches and Leds.
- Interfacing with 7-Segment.
- Interfacing with DC-Motor.
- Interfacing with LCD.
- Interfacing with Keypad.

- ATmega328p has programmable I/O lines divided into:
 - ➤ PORTB(PB7.....PB0)
 - > PORTC(PCo.....PC0)
 - ➤ PORTD(PD7.....PD0)
- Each PORT is controlled by 3 registers:
 - > DDRx:
 Data Direction Register to set the pin either output or input pin.
 - PORTx
 Output Register to assign a value to the port (from μC to interface).
 - PINx:
 Input Register where it holds the input value from interface.

Note: Most pins in µC make more than one function (multiplexed functions)







Port A Data Register – PORTA

Bit	7	6	5	4	3	2	1	0	
	PORTA7	PORTA6	PORTA5	PORTA4	PORTA3	PORTA2	PORTA1	PORTA0	PORTA
Read/Write	R/W	RW	R/W	R/W	R/W	R/W	R/W	R/W	
Initial Value	0	0	0	0	0	0	0	0	

Port A Data Direction Register – DDRA

Bit	7	6	5	4	3	2	1	0	
	DDA7	DDA6	DDA5	DDA4	DDA3	DDA2	DDA1	DDA0	DDRA
Read/Write	R/W								
Initial Value	0	0	0	0	0	0	0	0	

Port A Input Pins Address - PINA


Bit	7	6	5	4	3	2	1	0	
	PINA7	PINA6	PINA5	PINA4	PINA3	PINA2	PINA1	PINA0	PINA
Read/Write	R	R	R	R	R	R	R	R	
Initial Value	N/A								

PiN -> mc





- To decided which Port is input and which is output:
 - Configure the port direction use register DDRX
 - $\underline{1} \rightarrow$ for Output.
 - $0 \rightarrow$ for Input.
- To Read(input case):
 - Use register PINx
- To Write(output case) :
 - Use register PORTx.





Note:

In case you set any PIN as **input** you can activate the **internal pull up** resistor by setting the corresponding bit in **PORTX** register.

F10151

I/O Ports Programming

How to set values in registers



- > DDRA=5; /*(decimal)mean I activate pin 0 and pin 2 as output and the rest as input pins */
- ➤ DDRB=0x14; /*(hexadecimal)mean I activate pin 2 and pin 4 as output and the rest as input pins */
- ➤ DDRC=0b0000011; /*(binary)mean I activate pin 0 and pin 1 as output pins and the rest as input pins */

How to deal with a specific pin with conserving other pins

- To set specified bit in register
 Make OR operation on the register with The pin number.
 - ☐ For example if we want to set pin number 5 in PORTA


$$PORTA = PORTA \mid (1 << PA5);$$

> To clear specified bit in register

Make AND operation on the register with (NOT) The pin number.

☐ For example if we want to set pin number 3 in PORTB

$$PORTB = PORTB \& (\sim (1 << PB3));$$



11011111





Make XOR operation on the register with The pin number

☐ For example if we want to toggle pin number 2 in PORTC

$$PORTC = PORTC \land (1 << PC2);$$




To set the pin 2 in PORTB as input pin and use the internal pull up resistor of this pin.

$$DDRB = DDRB & (\sim (1 \ll PB2))$$

$$PORTB = PORTB \mid (1 \ll PB2)$$



1001







```
DDRA = 0xFF; //initialize portA as output
DDRB = 0x00; //initialize portB as input
if ((PINB & 0b00000001) == 1) //read a switch on PB0
                         //All LEDs on
      PORTA = 0xFF;
else
      PORTA = 0x00; //All LEDs off
```

I/O Port applications


- As Output
 - LED and 7-Segemnt
 - LCD display
 - Motors.
 - Buzzer.
 - Signal to another μC.
 - Output to PC through PC Serial Port.
- As Input
 - Switches(push button, keypad etc.)
 - Analog/Digital sensors.
 - Signal from another μC.
 - Input from PC through PC Serial Port.

Interfacing with Switches and Leds

LED Configuration

el logic bta3ak by-act as gnd


Negative Logic



el logic bta3k by-act as vcc

Positive Logic

34an el led teshtghl lazm a7ot 1





34an el led teshtghl lazm a7ot 0


Interfacing with Switches and Leds

Switch Configuration







Pull Down Resistor




Pull UP Resistor






Interfacing with Switches and Leds

Switch de-bounce problem








Could be handled using software or hardware.


- 00
- It relies on the fact that bouncing takes a maximum period of 20-30 ms.
- The basic idea is to implement a delay after the first detected edge, during which no scanning for the switch is done. after the delay period is finished, scanning can proceed (Exercise 3).

Interfacing with 7-Segment










Common Cathode

0

Interfacing with 7-Segment

In order to reduce the number of pins can be used to interface the 7 segment, we use decoder connected and follows;



Digit	Decoder inputs							
Digit	C3	C2	C1	CO				
0	0	0	0	0				
1	0	0	0	1				
2	0	0	1	0				
3	0	0	1	1				
4	0	1	0	0				
5	0	1	0	1				
6	0	1	1	0				
7	0	1	1	1				
8	1	0	0	0				
9	1	0	0	1				