

Modulation

- Modulation
 - is to convert data (digital or analog) into an EM wave
 - alters certain properties of a radio wave, called carrier wave, whose frequency is the same as the center frequency of the wireless channel used for transmission.

Allocated radio spectrum is a precious resource so it has to be used efficiently.

- Types:
 - Analog modulation (for analog signals)
 - Digital modulation (for digital signals)

Modulation Techniques

Analog Modulation:


- >>transmits continuous signals
- Amplitude Modulation (AM)
- Frequency Modulation (FM)
- Phase Modulation (PM)

Digital Modulation:

- >>transmits digital signals that consist of a sequence of 0 and 1 bits
- Amplitude Shift Keying (ASK)
- Frequency Shift Keying (FSK)
- Phase Shift Keying (PSK)

Amplitude Shift Keying (ASK)


- Also known as "OOK" On-Off Keying
- A binary 1 is represented by the presence of the signal.
- A binary 0 is represented by the absence of the signal.



Issue: No signal or zero bit.


Frequency Shift Keying (FSK)

BFSK → Binary FSK (only two frequencies used to represent single bits)




Phase Shift Keying (PSK)


- BPSK → Binary PSK
 - Binary 1 is represented by the presence of a carrier signal with a phase difference Piradians from Binary 0's signal.



Quadrature Phase Shift Keying (QPSK)

Uses four phases each separated by Pi/2 radians (90 degrees)






Symbol duration in this modulation is twice the bit duration.


Quadrature Amplitude Modulation (QAM)


Amplitude and phase modulation of 2 orthogonal carriers (phase difference Pi/2)



2 Amplitudes (distance from center), 4 Phases


- 8 symbols → 8-QAM
- 1 symbol=3 bits





Baud rate=symbol rate > how many symbols/second

Quadrature Amplitude Modulation (QAM)



• <u>Drawback:</u> as the number of symbols increases, system becomes more complex and susceptible to errors.

Multiple Access Techniques

 Transmission Medium in wireless networks is broadcast in nature → thus a node can't just transmit whenever it wants to.

Multiple access techniques are used to control access to the Shared Medium

• Examples:

- ☐ Frequency Division Multiple Access (FDMA)
- ☐ Time Division Multiple Access (TDMA)
- □ Code Division Multiple Access (CDMA)
- ☐ Space Division Multiple Access (SDMA)


Frequency Division Multiple Access (FDMA)

 BW is divided into multiple frequency channels/bands separated by guard bands (to eliminated interchannel interference)

- Tradeoff: efficiency versus interference.
- A Tx/Rx uses a single dedicated frequency channel.

• Example:


- Cellular networks: the base station (BS) dynamically allocates a different carrier frequency to each mobile station (MS)
- Each node is allocated two frequencies:
 - UL: uplink → BS receive, node transmit
 - DL: downlink → BS transmit, node receive
 - called FDD (Frequency Division Duplex)



Time Division Multiple Access (TDMA)

• Each frequency band is divided into several time slots (channels) that repeat over time.

- The set of periodically repeating time slots is called a TDMA frame.
- A Tx/Rx is assigned one or more time slots in each frame.
- → The node transmits only on those slots.



- For two-way communication:
 - UL and DL time slots are allocated
 - Can be on the same band (TDD-TDMA: Time Division Duplex-TDMA)
 - Can be on different bands (FDD-TDMA: Frequency Division Duplex-TDMA)

Code Division Multiple Access (CDMA)


Every channel uses the entire spectrum.

Each channel transmission is encoded with pseudo-random digital sequence.

A unique code is assigned to each user.


Codes are orthogonal.

- Types:
 - Frequency Hopping Spread Spectrum (FHSS)
 - Direct Sequence Spread Spectrum (DSSS)



Frequency Hopping Spread Spectrum (FHSS)

- A simple technique in which the transmission switches across multiple narrow-band frequencies in a pseudo-random manner.
- The sequence of transmission frequencies is known to Tx-Rx pair and appears random to other nodes.



- Frequency Hopping: is the process of switching from one channel to the other.
 - For example, a frequency was allotted to sender 1 for a particular period of time. Now, after a
 while, sender 1 hops to the other frequency and sender 2 uses the first frequency, which was
 previously used by sender 1. This is called frequency reuse.
- Dwell time: the amount of time spent on each frequency hop.
- FHSS is used to avoid interference (because the signal hops to a different frequency band) and to prevent eavesdropping (frequency-hopping pattern is not known to others).

Direct Sequence Spread Spectrum (DSSS)

- Each node assigned an n-bit code, called chipping-code.
- n is the chipping-rate.
- All codes are orthogonal to each other, i.e. the dot product of the vector representations of any two codes is zero.
- For a binary 1, the sender transmits its code.
- For a binary 0, the sender transmits the complement of the code.
- Example: codes v1=(1,-1) and $v2=(1,1) \rightarrow dot product=0$
 - For a binary 1, the sender transmits its code
 - If the user is using v1, then it would transmit the code v1=(1,-1)
 - For a binary 0, the sender transmits the complement of the code.
 - If the user is using v1, then it would transmit the code -v1=(-1,1)

DSSS Example

- Assume we have two users that use orthogonal codes v1=(1,-1) and v2=(1,1)
- what is the chipping rate in this case? →2
- User 1 wants to transmit (1,0,1,1)
- User 2 wants to transmit (0,0,1,1)
- Encoding of user1 = [(1,-1),(-1,1),(1,-1),(1,-1)]
 - Resulting signal is [1,-1,-1,1,1,-1,1,-1]
- Encoding of user2 = [(-1,-1),(-1,-1),(1,1),(1,1)]
 - Resulting signal is [-1,-1,-1,-1,1,1,1]
- Composite transmitted signal is

$$(1,-1,-1,1,1,-1,1,-1) + (-1,-1,-1,-1,1,1,1,1) = (0,-2,-2,0,2,0,2,0)$$

DSSS Example

- Received Composite signal: C = (0,-2,-2,0,2,0,2,0)
- We know that the chipping rate is 2, hence C = [(0,-2),(-2,0),(2,0),(2,0)]
- To decode:
 - User1 = C.v1
 - User2 = C.v2
 - User 1 = [(0,-2),(-2,0),(2,0),(2,0)].(1,-1) = ((0+2),(-2+0),(2+0),(2+0)) = (2,-2,2,2)
 - User 2 = [(0,-2),(-2,0),(2,0),(2,0)].(1,1) = ((0-2),(-2+0),(2+0),(2+0)) = (-2,-2,2,2)
- Above zero →1
- Below Zero →0

Why this works??

- Hence the received bits are:
 - User 1 = (1,0,1,1)
 - User 2 = (0,0,1,1)

Space Division Multiple Access (SDMA)

Space dimension.

Uses directional tx antennas to cover angular regions.

Same frequency is used for each space.

