The Memory System

Virtual Memory

Virtual Memory

- Recall that an important challenge in the design of a computer system is to provide a large, fast memory system at an affordable cost.
- Architectural solutions to increase the effective speed and size of the memory system.
- Cache memories were developed to increase the effective speed of the memory system.
- <u>Virtual memory</u> is an architectural solution to increase the effective size of the memory system.

Virtual Memory (contd..)

- Recall that the addressable memory space depends on the number of address bits in a computer.
 - For example, if a computer issues 32-bit addresses, the addressable memory space is 4G bytes.
- Physical main memory in a computer is generally not as large as the entire possible addressable space.
 - Physical memory typically ranges from a few hundred megabytes to 1G bytes.
- Large programs that cannot fit completely into the main memory have their parts stored on secondary storage devices such as magnetic disks.
 - Pieces of programs must be transferred to the main memory from secondary storage before they can be executed.


Virtual Memory (contd..)

- When a new piece of a program is to be transferred to the main memory, and the main memory is full, then some other piece in the main memory must be replaced.
 - Recall this is very similar to what we studied in case of cache memories.
- Operating system automatically transfers data between the main memory and secondary storage.
 - Application programmer need not be concerned with this transfer.
 - Also, application programmer does not need to be aware of the limitations imposed by the available physical memory.

Virtual Memory (contd..)

- Techniques that automatically move program and data between main memory and secondary storage when they are required for execution are called <u>virtual-memory</u> techniques.
- Programs and processors reference an instruction or data independent of the size of the main memory.
- Processor issues binary addresses for instructions and data called logical or virtual addresses.
- Virtual addresses are translated into physical addresses by a combination of hardware and software subsystems.
 - If virtual address refers to a part of the program that is currently in the main memory, it is accessed immediately.
 - If the address refers to a part of the program that is not currently in the main memory, it is first transferred to the main memory before it can be used.

Virtual Memory Organization



- •Memory management unit (MMU) translates virtual addresses into physical addresses.
- •If the desired data or instructions are in the main memory they are fetched as described previously.
- •If the desired data or instructions are not in the main memory, they must be transferred from secondary storage to the main memory.
- •MMU causes the operating system to bring the data from the secondary storage into the main memory.


Address Translation

- Assume that program and data are composed of fixed-length units called pages.
- A page consists of a block of words that occupy contiguous locations in the main memory.
- Page is a basic unit of information that is transferred between secondary storage and main memory.
- Size of a page commonly ranges from 2K to 16K bytes.
 - Pages should not be too small, because the access time of a secondary storage device is much larger than the main memory.
 - Pages should not be too large, else a large portion of the page may not be used, and it will occupy valuable space in the main memory.

- Concepts of virtual memory are similar to the concepts of cache memory.
- Cache memory:
 - Introduced to bridge the speed gap between the processor and the main memory.
 - Implemented in hardware.
- Virtual memory:
 - Introduced to bridge the speed gap between the main memory and secondary storage.
 - Implemented in part by software.

- Each virtual or logical address generated by a processor is interpreted as
 a virtual page number (high-order bits) plus an offset (low-order bits) that
 specifies the location of a particular byte within that page.
- Information about the main memory location of each page is kept in the page table.
 - Main memory address where the page is stored.
 - Current status of the page.
- Area of the main memory that can hold a page is called as page frame.
- Starting address of the page table is kept in a page table base register.

- Virtual page number generated by the processor is added to the contents of the page table base register.
 - This provides the address of the corresponding entry in the page table.
- The contents of this location in the page table give the starting address of the page if the page is currently in the main memory.




- Page table entry for a page also includes some control bits which describe the status of the page while it is in the main memory.
- One bit indicates the validity of the page.
 - Indicates whether the page is actually loaded into the main memory.
 - Allows the operating system to invalidate the page without actually removing it.
- One bit indicates whether the page has been modified during its residency in the main memory.
 - This bit determines whether the page should be written back to the disk when it is removed from the main memory.
 - Similar to the dirty or modified bit in case of cache memory.

- Other control bits for various other types of restrictions that may be imposed.
 - For example, a program may only have read permission for a page, but not write or modify permissions.

- Where should the page table be located?
- Recall that the page table is used by the MMU for every read and write access to the memory.
 - Ideal location for the page table is within the MMU.
- Page table is quite large.
- MMU is implemented as part of the processor chip.
- Impossible to include a complete page table on the chip.
- Page table is kept in the main memory.
- A copy of a small portion of the page table can be accommodated within the MMU.
 - Portion consists of page table entries that correspond to the most recently

accessed pages.

- A small cache called as Translation Lookaside Buffer (TLB) is included in the MMU.
 - TLB holds page table entries of the most recently accessed pages.
- Recall that cache memory holds most recently accessed blocks from the main memory.
 - Operation of the TLB and page table in the main memory is similar to the operation of the cache and main memory.
- Page table entry for a page includes:
 - Address of the page frame where the page resides in the main memory.
 - Some control bits.
- In addition to the above for each page, TLB must hold the virtual page number for each page.



<u>Associative-mapped TLB</u>

High-order bits of the virtual address generated by the processor select the virtual page.

These bits are compared to the virtual page numbers in the TLB.

If there is a match, a hit occurs and the corresponding address of the page frame is read.

If there is no match, a miss occurs and the page table within the main memory must be consulted.

Set-associative mapped TLBs are found in commercial processors.

- How to keep the entries of the TLB coherent with the contents of the page table in the main memory?
- Operating system may change the contents of the page table in the main memory.
 - Simultaneously it must also invalidate the corresponding entries in the TLB.
- A control bit is provided in the TLB to invalidate an entry.
- If an entry is invalidated, then the TLB gets the information for that entry from the page table.
 - Follows the same process that it would follow if the entry is not found in the TLB or if a "miss" occurs.

- What happens if a program generates an access to a page that is not in the main memory?
- In this case, a page fault is said to occur.
 - Whole page must be brought into the main memory from the disk, before the execution can proceed.
- Upon detecting a page fault by the MMU, following actions occur
 - MMU asks the operating system to intervene by raising an exception.
 - Processing of the active task which caused the page fault is interrupted.
 - Control is transferred to the operating system.
 - Operating system copies the requested page from secondary storage to the main memory.
 - Once the page is copied, control is returned to the task which was interrupted.

- Servicing of a page fault requires transferring the requested page from secondary storage to the main memory.
- This transfer may incur a long delay.
- While the page is being transferred the operating system may:
 - Suspend the execution of the task that caused the page fault.
 - ▶ Begin execution of another task whose pages are in the main memory.
- Enables efficient use of the processor.

- ► How to ensure that the interrupted task can continue correctly when it resumes execution?
- There are two possibilities:
 - ► Execution of the interrupted task must continue from the point where it was interrupted.
 - ▶ The instruction must be restarted.
- Which specific option is followed depends on the design of the processor.

- When a new page is to be brought into the main memory from secondary storage, the main memory may be full.
 - Some page from the main memory must be replaced with this new page.
- How to choose which page to replace?
 - This is similar to the replacement that occurs when the cache is full.
 - The principle of locality of reference (?) can also be applied here.
 - A replacement strategy similar to LRU can be applied.
- Since the size of the main memory is relatively larger compared to cache, a relatively large amount of programs and data can be held in the main memory.
 - Minimizes the frequency of transfers between secondary storage and main memory.

- A page may be modified during its residency in the main memory.
- When should the page be written back to the secondary storage?
- Recall that we encountered a similar problem in the context of cache and main memory:
 - Write-through protocol(?)
 - Write-back protocol(?)
- Write-through protocol cannot be used, since it will incur a long delay each time a small amount of data is written to the disk.

Thank You