microplay





- cen	7-2-2-2		A second second	1 / 1 / 1
Controller	Anbindung	Benötigt	Information	Einschränkungen
8Bitdo N30 Pro / N30 Pro2	Kabel	USB-Kabel		
8Bitdo N30 Pro / N30 Pro2	Kabellos	Bluetooth-Adapter*		
8Bitdo SN30	Kabel	USB-Kabel	Thumbstick, L2/R2	DC-NDS-N64-PSP N/A
8Bitdo SN30	Kabellos	Bluetooth-Adapter*	Thumbstick, L2/R2	DC-NDS-N64-PSP N/A
8Bitdo SN30 Pro / Pro+	Kabel	USB-Kabel		
8Bitdo SN30 Pro / Pro+	Kabellos	Bluetooth-Adapter*		
8Bitdo Zero/Zero2	Kabel	USB-Kabel	Thumbstick, L2/R2	DC-NDS-N64-PSP N/A
8Bitdo Zero/Zero2	Kabellos	Bluetooth-Adapter*	Thumbstick, L2/R2	DC-NDS-N64-PSP N/A
8Bitdo M30	Kabellos	Bluetooth-Adapter*	Thumbstick	DC-NDS-N64-PSP N/A
Playstation 3	Kabel	USB-Kabel		
Playstation 3	Kabellos	Bluetooth-Adapter*		
Playstation 4	Kabel	USB-Kabel		
Playstation 4	Kabellos	Bluetooth-Adapter*		
Xbox 360	Kabel	USB-Kabel		
Xbox 360	Kabellos	Xbox360-Receiver	4 Controller auf 1 Reciever	
Xbox-One	Kabel	USB-Kabel		
Xbox-One	Kabellos	Xbox-Receiver		
Xbox-One S/X	Kabellos	Bluetooth-Adapter*		
Steam Controller	Kabellos	Steam-Adapter	D-Pad Motorgesteuert	D-Pad sensibel
Switch Pro Controller	Kabellos	Bluetooth-Adapter*		
Wiimote	Kabellos	Bluetooth-Adapter*		
Wii U Pro Controller	Kabellos	Bluetooth-Adapter*		
Retroflag USB Controller-U	Kabel	USB-Kabel	L2/R2	DC-NDS-N64-PSP N/A
Retroflag USB Controller-J	Kabel	USB-Kabel	L2/R2	DC-NDS-N64-PSP N/A
Retroflag USB Controller-M	Kabel	USB-Kabel	L2/R2	DC-NDS-N64-PSP N/A
SEGA USB	Kabel	USB-Kabel	Thumbstick, L2/R2	DC-NDS-N64-PSP N/A
NINTENDO USB	Kabel	USB-Kabel	Thumbstick, L2/R2	DC-NDS-N64-PSP N/A
PC Controller USB	Kabel	USB-Kabel	Thumbstick, L2/R2!	
Universal Controller USB	Kabel	USB-Kabel	Thumbstick, L2/R2!	
PC Tastatur	Kabel	USB-Kabel	Thumbstick	N64 N/A
PC Tastatur	Kabellos	Hersteller-Adapter	Thumbstick	N64 N/A

* Kompatible Bluetooth-Adapter

◆8Bitdo Wireless USB Adapter ◆CSR 4.0 USB Adapter ◆Bluetooth 4.0 USB Adapter Univ.

MPCORE NXT (c)opyright by microplay

N/A = nicht verfügbar | L2/R2 = Tasten nicht verfügbar | L2/R2! = Tasten vII. nicht verfügbar | Thumbstick = Stick nicht verfügbar

- 1 - von 1 v1.3