microplay





Controller	Anbindung	Benötigt	Information
OBY I MOS (MOS		1100 14 1 1	TI 1 11 1 10/D0
8Bitdo N30 / M30	Kabel	USB-Kabel	Thumbstick, L2/R2
8Bitdo N30 / M30	Kabellos	Bluetooth-Adapter*	Thumbstick, L2/R2
8Bitdo N30 Pro / N30 Pro2	Kabel	USB-Kabel	
8Bitdo N30 Pro / N30 Pro2	Kabellos	Bluetooth-Adapter*	
8Bitdo SN30	Kabel	USB-Kabel	Thumbstick, L2/R2
8Bitdo SN30	Kabellos	Bluetooth-Adapter*	Thumbstick, L2/R2
8Bitdo SN30 Pro / Pro+	Kabel	USB-Kabel	
8Bitdo SN30 Pro / Pro+	Kabellos	Bluetooth-Adapter*	
8Bitdo Zero/Zero2	Kabel	USB-Kabel	Thumbstick, L2/R2
8Bitdo Zero/Zero2	Kabellos	Bluetooth-Adapter*	Thumbstick, L2/R2
8Bitdo N30 Arcade Stick	Kabellos	Bluetooth-Adapter*	
Playstation 3	Kabel	USB-Kabel	
Playstation 3	Kabellos	Bluetooth-Adapter*	
Playstation 4	Kabel	USB-Kabel	
Playstation 4	Kabellos	Bluetooth-Adapter*	
Xbox 360	Kabel	USB-Kabel	
Xbox 360	Kabellos	Xbox360-Receiver	4 Controller auf 1 Reciever
Xbox-One	Kabel	USB-Kabel	1 Controller dur 1 Madie von
Xbox-One	Kabellos	Xbox-Receiver	
Xbox-One S/X	Kabellos	Bluetooth-Adapter*	
ABOX GIIG GIX	rabonos	Bidotootii 7 idaptoi	
Steam Controller	Kabellos	Steam-Adapter	D-Pad Motorgesteuert
Switch Pro Controller	Kabellos	Bluetooth-Adapter*	
Wiimote	Kabellos	Bluetooth-Adapter*	
Wii U Pro Controller	Kabellos	Bluetooth-Adapter*	
Retroflag USB Controller-U	Kabel	USB-Kabel	Thumbstick, L2/R2
Retroflag USB Controller-J	Kabel	USB-Kabel	Thumbstick, L2/R2
Retroflag USB Controller-M	Kabel	USB-Kabel	Thumbstick, L2/R2
SEGA USB	Kabel	USB-Kabel	Thumbstick, L2/R2
NINTENDO USB	Kabel	USB-Kabel	Thumbstick, L2/R2
PC Controller USB	Kabel	USB-Kabel	Thumbstick, L2/R2
Universal Controller USB	Kabel	USB-Kabel	Thumbstick, L2/R2
PC Tastatur	Kabel	USB-Kabel	Thumbstick
PC Tastatur	Kabellos	Hersteller-Adapter	Thumbstick

* Kompatible Bluetooth-Adapter

MPCORE NXT (c)opyright by microplay

N/A = nicht verfügbar L2/R2 = tasten nicht verfügbar für diverese Emulatoren Thumbstick = DC,NDS,N64,PSP nicht spielbar, Thumbsticks fehlen

٧l

11.08.2019 - 1 - von 1