ARCOS Group

uc3m Universidad Carlos III de Madrid

Lesson 3 (III)

Fundamentals of assembler programming

Computer Structure


Bachelor in Computer Science and Engineering



Contents

- Basic concepts on assembly programming
- MIPS32 assembly language, memory model and data representation
- Instruction formats and addressing modes
- Procedure calls and stack convention

Review



lw SW 1b sb lbu

memory address Register,

- Number representing an address
- Symbolic label representing an address
- (register): represents the address stored in the register
- num(register): represents the address obtained by summing num with the address stored in the register
- label + num: represents the address obtained by adding label with num

Information of an instruction

▶ The instructions:

- Its size is adjusted to one or multiples word
- ▶ They are divided in fields:
 - Operation to do
 - Operands
 - □ There can be implicit operands

op.ALU	reg.	reg.	req.
0101	0011	1000	1010
add	r1	r2	r3

▶ The instruction format:

- Form of representation of an instruction composed of fields of binary numbers:
 - The field size limits the number of values to encode

Information of an instruction

- Very few formats:
 - ▶ Each instruction belongs to a format
- Example: instruction formats in MIPS

Type R arithmetic	op.	rs	rt	rd	shamt	func.
	6 bits	5 bits	5 bits	5 bits	5 bits	6 bits
Type I Immediate	op.	rs	rt	offset		
transfer	6 bits	5 bits	5 bits		16 bits	
Type J branches	op.			offset		
	6 bits				26 bits	

Instruction and pseudoinstruction in MIPS32

- ▶ An assembly instruction corresponds to a machine instruction
 - A machine instruction occupies 32 bits
 - Example: addi \$t1,\$t1,2
- A pseudo-assembler instruction corresponds to one or several machine instructions.
 - Example I:
 - ▶ The instruction: move reg2, reg1
 - It is equivalent to: add reg2, \$zero, reg1
 - Example 2:
 - ▶ The instruction: li \$t1, 0x00800010
 - It does not fit in 32 bits, but it can be used as a pseudoinstruction.
 - It is equivalent to:
 - □ lui \$t1, 0x0080
 - □ ori \$t1, \$t1, 0x0010

Instruction fields

Each field encodes:

- Operation (Operation code)
 - Instruction and format used


op.ALU	reg.	reg.	roe
0101	0011	1000	reg.
add	r1	r2	r3

Operands

- Location of operands
- Location for results
- Location of next instruction (in branches)
 - □ Implicit: PC ← PC + '4' (next instruction)
 - \square Explicit: j 0x01004 (PC modified)

Locations of operands

- I. In the instruction
- 2. In registers (processor)
- 3. Main memory
- 4. Input/output modules



Addressing modes

- Procedure that allows to localize the operands
- Types:
 - **Implicit**
 - **Immediate**
 - DirectTo memory
 - IndirectTo registerTo memory
 - Relative
 To index register
 Base register
 To PC
 To stack

Implicit addressing

- ▶ The operand is not encoded in the instruction.
- ▶ Example : beqz \$a0 label l
 - If \$a0 is zero, branch to label
 - ▶ \$a0 is an operand, \$zero is the other one

op	rs	16 bits

- ▶ G/B
 - Good: It is fast because no extra memory access is required.
 - Good: Instructions shorter
 - Bad: limited options

Immediate addressing


- Operand is in the instruction.
- Example (MIPS):
 - ▶ li \$a0 25
 - addi \$t | \$t2 50

			\rightarrow
op	rs	16 bits	

- ▶ G/B
 - Good: It is fast because no extra memory access is required
 - Bad: not always fits in a word
 - ▶ li \$t1, 0x00800010
 - Need more than 32 bits, but equivalent to:
 - □ lui \$t1, 0x0080
 - □ ori \$t1, \$t1, 0x0010

Register addressing


- Operand is in a register.
- Example (MIPS): move \$a0 \$a1
 - \$a0 and \$a1 are encoded in the instruction



- G/B:
 - Bad: limited number of registers
 - Good: Small address field
 - Good: Faster access (no extra memory access required)

Direct addressing


- Operand in memory. The instruction encodes the address
- Example (MIPS): |w \$t|, 0xFFF0
 - Load in \$t1 the word stored in address 0xFFF0



- G/B:
 - Bad: memory access time is larger than register access time
 - Bad: large fields=> large instructions
 - Good: capacity is bigger than register file

Register indirect addressing

The instruction has the register where the address is stored



▶ G/B:

- Good: Small fields
- Good: MIPS can allow in a register an address for addressing the entire memory (registers have 32 bits)
- Bad: extra memory access (slow execution)

Indirect addressing

 The instruction has the address where the operand address is stored (not available in MIPS)



Load in RI the item stored in the address stored in ADDR



- G/B:
 - Bad: several memory accesses are required
 - Bad: slower instructions
 - ▶ Good: large address space, addressing can be multilevel (e.g.: [[[.RI]]])

Memory


operand

Address 2

Base-register addressing

Example: 1w \$a0 12(\$t1)


- □ Load in \$a0 the word stored in address: \$t1 + 12
- □ \$t1 represents the base address



Index-register addressing

Example: 1w \$a0 address(\$t1)

- ☐ Load in \$a0 the word stored in address: \$tI + address
- □ \$t1 represents an index (offset from address)



Used in arrays

```
int vec[5];
main ()
    v[4] = 8;
```

```
.data
.align 2 # next item align to 4
vec: .space 20 # 5 elem. *4 bytes
.text
.globl main
main: la $t1 vec
        li $t2 8
        sw $t2 16($t1)
```

Used in arrays


```
int vec[5];
main ()
 v[3] = 8;
 v[4] = 8;
```

```
.data
.align 2  # next item align to 4
vec: .space 20 # 5 elem. *4 bytes
.text
.globl main
main: li $t1 12
        li $t2 8
        sw $t2 vec($t1)
        addi $t1 $t1 4
        sw $t2 vec($t1)
```

PC-relative addressing

Example: beqz \$t1 label

- \square If t = 0, then PC = PC + "label"
- ☐ Label represents a displacement



Program counter in MIPS 32

- Registers of 32 bits
- Program counter of 32 bits
- Instructions of 32 bits (one word)
- Program counter stores instruction address
- Next instruction is 4 bytes beyond
- Program counter is updated:
 - ▶ PC = PC + 4

address:	Instructi	on:
0x00400000	or	\$2,\$0,\$0
0x00400004	slt	\$8,\$0,\$5
0x00400008	beq	\$8,\$0,3
0x0040000c	add	\$2,\$2,\$4
0x00400010	addi	\$5,\$5,-1
0x00400014	j	0x100001

PC-relative addressing in MIPS

▶ Instruction beq \$9, \$0, label is encoded as:



When \$t0 == \$1, what is the value for end label?

```
loop: beq $t0,$1, end
add $t8,$t4,$t4
addi $t0,$0,-1
j loop
end: ...
```

Label must be encoded in an "immediate" field

PC-relative addressing in MIPS

▶ Instruction beq \$9, \$0, label is encoded as:

6 5 5 16
CO rs rt immediate

▶ When \$t0 == \$I, end is 3 ("number of instructions to skip")

```
loop: beq $t0,$1, end
...
end:
```

- Reasons:
 - When an instruction is going to be executed, PC has the addresss of next instruction in memory
 - When the condition in satisfied: PC = PC + (label* 4)

end represents the address where the instruction move is stored

```
li
             $t0 8
        li
             $t1 4
        li
             $t2 1
        li $t4 0
while:
        bge $t4 $t1 end
        mul $t2 $t2 $t0
        addi $t4 $t4 1
        b while
        move $t2 $t4
end:
```

	li	\$t0	8	
	li	\$t1	4	
	li	\$t2	1	
	li	\$t4	0	
while:	bge	\$t4	\$t1	end
	mul	\$t2	\$t2	\$t0
	addi	\$t4	\$t4	1
	b	whi	le	
end:	move	\$t2	\$t4	4

Address	Content					
0x0000100	li	\$t0	8			
0x0000104	li	\$t1	4			
0x0000108	li	\$t2	1			
0x000010C	li	\$t4	0			
0x0000110	bge	\$t4	\$t1	end		
0x0000114	mul	\$t2	\$t2	\$t0		
0x0000118	addi	\$t4	\$t4	1		
0x000011C	b	whil	Le			
0x0000120	move	\$t2	\$t4	1		

	li	\$t0	8	
	li	\$t1	4	
	li	\$t2	1	
	li	\$t4	0	
while:	bge	\$t4	\$t1	end
	mul	\$t2	\$t2	\$t0
	addi	\$t4	\$t4	1
	b	whi	le	
end:	move	\$t2	\$t4	4

• end represents a displacement relative to current PC => 3

$$PC = PC + 3 * 4$$

• while represents a displacement relative to current PC => -4

$$PC = PC + (-4)*4$$

Address	Content					
0x0000100	li	\$t0	8			
0x0000104	li	\$t1	4			
0x0000108	li	\$t2	1			
0x000010C	li	\$t4	0			
0x0000110	bge	\$t4	\$t1	end		
0x0000114	mul	\$t2	\$t2	\$t0		
0x0000118	addi	\$t4	\$t4	1		
0x000011C	b	whil	Le			
0x0000120	move	\$t2	\$t4	4		

	li	\$t0	8	
	li	\$t1	4	
	li	\$t2	1	
	li	\$t4	0	
while:	bge	\$t4	\$t1	end
	mul	\$t2	\$t2	\$t0
	addi	\$t4	\$t4	1
	b	whi	le	
end:	move	\$t2	\$t4	4

• end represents a displacement relative to current $PC \Rightarrow 3$

$$PC = PC + 3 * 4$$

• while represents a displacement relative to current PC = > -4

$$PC = PC + (-4)*4$$

Address	Content					
0x0000100	li	\$t0	8			
0x0000104	li	\$t1	4			
0x0000108	li	\$t2	1			
0x000010C	li	\$t4	0			
0x0000110	bge	\$t4	\$t1	3		
0x0000114	mul	\$t2	\$t2	\$t0		
0x0000118	addi	\$t4	\$t4	1		
0x000011C	b	-4				
0x0000120	move	\$t2	\$t4	4		

Differences between b and j instructions

Instruction j address



Branch address => PC = address


Instruction b displacement

op.			displacement
6 bits	5 bits	5 bits	I 6 bits

Branch address => PC = PC + displacement


Stack addressing

PUSH Reg Push the content of a register (item)



Stack grows to lower memory addresses

Stack addressing



Stack grows to lower memory addresses

Stack addressing

- MIPS does not have PUSH or POP instructions
- ▶ The stack pointer (\$sp) is visible
 - We assume that stack pointer points to the last element in the stack

PUSH \$t0

POP \$t0

Examples of addressing types

- ▶ la \$t0 label immediate
 - The second operand is an address
 - But this address is not accessed, the address is the operand
- Iw \$t0 label
 - The second operand is an address
 - A memory access is required to obtain the final operand
- bne \$t0 \$t1 label
 PC-relative
 - Last operand represents a displacement
 - Label is encoded as a number that represents a displacement relative to PC

Addressing modes in MIPS

Immediate value

Register \$r

Direct dir

Register indirect (\$r)

Register relative displacement(\$r)

PC-relative label beq

Stack-relative displacement(\$sp)

Contents

- Basic concepts on assembly programming
- MIPS32 assembly language, memory model and data representation
- Instruction formats and addressing modes
- Procedure calls and stack convention

Instruction format

- A machine instruction is divided in fields
- A machine instruction includes:
 - Operation code
 - Operand addresses
 - Result address
 - Address of the next instruction
 - How the operands are represented
- Example in MIPS:



Instruction format

- ▶ The format specifies, for each field in the instruction:
 - The meaning of each field
 - The number of bits of each field
 - How is encoded each field
 - binary, I's complement, displacement w.r.t. ...

Usually:

- Very few formats in order to simplify the control unit design.
- Fields of the same type have the same length.
- Operation code is the first field (of first word)

Format length

▶ The format length is number of bits used to encode the instruction

Two types:


- Unique length:
 - All instructions with the same size
 - Examples:
 - ☐ MIPS32 (32 bits), PowerPC (32 bits), ...
- Variable length:
 - Different instructions can have different sizes
 - How to know the length of an instruction? \rightarrow Op. code
 - Examples:
 - □ IA32 (Intel processors): variable number of bytes

Instruction format

- The size of an instruction is usually one word, but there can be instructions of several words
 - In MIPS the size of all instructions is one word (32 bits)
- Operation code:
 - With n bits we can encode 2ⁿ instructions
 - We can use extensions fields to encode more instructions
 - Example: in MIPS, arithmetic instructions have the operation code 0. The operation is encoded in func. field


Type R arithmetic	op.	rs	rt	rd	shamt	func.	
-------------------	-----	----	----	----	-------	-------	--

Example: MIPS instruction formats



Example of MIPS formats


- MIPS Instruction:
 - □ add \$8,\$9,\$10
 - ☐ Format:



Decimal representation:



Binary representation



Example of MIPS formats

- MIPS Instruction:
 - □ addi \$21,\$22,-50
 - ☐ Format:



Decimal representation:



Binary representation

001000 10110 10101 1111111111001110

How to use the addi instruction with 32 bits values?

- What happens when this instruction is used in a program?
 - addi \$t0,\$t0, 0xABABCDCD
 - The immediate value has 32 bits. This instruction cannot be encoded in one word (32 bits)

How to use the addi instruction with 32 bits values?

- What happens when this instruction is used in a program?
 - ▶ addi \$t0,\$t0, 0xABABCDCD
 - The immediate value has 32 bits. This instruction cannot be encoded in one word (32 bits)

Solution:

▶ This instruction is translated to:

```
lui     $at, 0xABAB

ori     $at, $at, 0xCDCD

add     $t0, $t0, $at
```

▶ The \$at is reserved to the assembler

Questions

How does the unit control know the format of an instruction?

- How does the unit control know the number of operands of an instruction?
- How does the unit control know the format of each operand?

Operation code

Fixed size:

- \rightarrow n bits \rightarrow 2ⁿ operation codes
- ▶ m operation codes \rightarrow log₂m bits.

Extension fields

- MIPS (arithmetic-logic instructions)
- ▶ Op = 0;The instruction is encoded in func



Variable sizes:

More frequent instructions= shorter sizes

Example

- A 16-bit computer has an instruction set of 60 instructions and a register bank with 8 registers.
- ▶ Define the format of this instruction: ADDx RI R2 R3, where RI, R2 and R3 are registers.

word-> 16 bits
60 instructions
8 registers (in RB)
ADDx RI(reg.), R2(reg.), R3(reg.)

Word of 16 bits

I6 bits


word-> 16 bits
60 instructions
8 registers (in RB)
ADDx R1(reg.), R2(reg.), R3(reg.)

▶ To encode 60 instructions, 6 bits are required for the operation code




word-> 16 bits 60 instructions 8 registers (in RB) ADDx RI(reg.), R2(reg.), R3(reg.)

▶ To encode 8 registers, 3 bits are required



word-> 16 bits 60 instructions 8 registers (in RB) ADDx RI(reg.), R2(reg.), R3(reg.)

Spare one bit (16-6-3-3-3 = 1)



Instruction sets

▶ There are different ways for the classification of the instructions sets.

- For example:
 - By complexity of the instruction set
 - CISC vs RISC
 - By available execution modes

CISC-RISC

- CISC: Complex Instruction Set Architecture (http://es.wikipedia.org/wiki/RISC)
 - Many instructions
 - Complex instructions
 - Irregular design
- ▶ RISC: Reduced Instruction Set Code (http://es.wikipedia.org/wiki/CISC)
 - Simple instructions
 - Very few instructions
 - Instructions with fixed size
 - Many registers
 - Most of instructions use registers
 - Parameters are passed using registers
 - Pipelined architectures

Execution modes

- The execution modes indicates the number of operands and the type of operands that can be specified in an instruction.
 - ▶ 0 addresses → Stack.
 - □ PUSH 5; PUSH 7; ADD
 - ▶ I address → Accumulator register.
 - □ ADD RI -> AC <- AC + RI
 - ▶ 2 addresses → Registers, Register-memory, Memory-memory.
 - \square ADD .R0, .RI (R0 <- R0 + RI)
 - ▶ 3 addresses → Registers, Register-memory, memory-memory.
 - □ ADD .R0, .R1, .R2

Exercise

A 16-bit computer, with byte memory addressing has 60 machine instructions and a register bank with 8 registers. What is the format for the instruction ADDV R1, R2, M, where R1 y R2 are registers and M represents a memory address?

Exercise

- A 32-bit computer with byte memory addressing has 64 machine instructions and 128 registers. Consider the instruction SWAPM addr1, addr2, that swaps the content of two memory addresses addr1 and addr2.
 - What is the memory address space of this computer?
 - Define the format for this instruction.
 - Write a program fragment in MIPS32 equivalent to the above instruction
 - If the instruction has to be encoded in one word, what is the addresses range assuming that memory addresses are represented in binary?