
DATA HAZARDS 1/17 Ejemplo de Código con Dependencias

```
sub $2. $1.$3  # Register $2 written by sub
and $12.$2.$5  # 1st operand($2) depends on sub
or $13.$6.$2  # 2nd operand($2) depends on sub
add $14.$2.$2  # 1st($2) & 2nd($2) depend on sub
sw $15.100($2)  # Base ($2) depends on sub
```

DATA HAZARDS 2/17 Representación Multiclock de Dependencias



DATA HAZARDS 3/17 Notaciones y Tipos de Data Hazards

- 1a. EX/MEM.RegisterRd = ID/EX.RegisterRs
- 1b. EX/MEM.RegisterRd = ID/EX.RegisterRt
- MEM/WB.RegisterRd = ID/EX.RegisterRs
- 2b. MEM/WB.RegisterRd = ID/EX.RegisterRt

```
sub $2, $1, $3 # Register $2 set by sub
and $12, $2, $5 # 1st operand($2) set by sub
or $13, $6, $2 # 2nd operand($2) set by sub
add $14, $2, $2 # 1st($2) & 2nd($2) set by sub
sw $15, 100($2) # Index($2) set by sub
```


DATA HAZARDS 4/17 Campos de Instrucciones

Field	0	rs	rt	rd	shamt	funct			
Bit positions 31:26		25:21	20:16	15:11 10:6		5:0			
a. R-type i	nstruction								
Field	35 or 43	rs	rt	address					
	positions 31:26 25:21 20:16					15:0			
Bit positions	31:26	25:21	20:16		15:0				
. N. 1951 N. 1952 N. 1957 N	31:26 store instr		20:16		15:0				
. N. 1951 N. 1952 N. 1957 N			20:16		15:0				
. N. 1951 N. 1952 N. 1957 N			20:16 rt		15:0 address				


c. Branch instruction

add rd,rs,rt and rd,rs,rt or rd,rs,rt sw rt,base(rs) lw rt base(rs)


DATA HAZARDS 5/17 Campos de Instrucciones




DATA HAZARDS 6/17 Forwarding



DATA HAZARDS 7/17 Forwarding



a. No forwarding



b. With forwarding

DATA HAZARDS 8/17 Forwarding

Mux control Source		Explanation			
ForwardA = 00	ID/EX	The first ALU operand comes from the register file.			
ForwardA = 10	EX/MEM	The first ALU operand is forwarded from the prior ALU result.			
ForwardA = 01	MEM/WB	The first ALU operand is forwarded from data memory or an earlier ALU result.			
ForwardB = 00	ID/EX	The second ALU operand comes from the register file.			
ForwardB = 10	EX/MEM	The second ALU operand is forwarded from the prior ALU result.			
ForwardB = 01	MEM/WB	The second ALU operand is forwarded from data memory or an earlier ALU result.			

DATA HAZARDS 9/17 Condiciones para Forward


EX hazard:

```
if (EX/MEM.RegWrite
and (EX/MEM.RegisterRd ≠ 0)
and (EX/MEM.RegisterRd = ID/EX.RegisterRs)) ForwardA = 10
if (EX/MEM.RegWrite
and (EX/MEM.RegisterRd ≠ 0)
and (EX/MEM.RegisterRd - ID/EX.RegisterRt)) ForwardB = 10
MEM hazard:
if (MEM/WB.RegWrite
 and (MEM/WB.RegisterRd ≠ 0)
and (MEM/WB.RegisterRd = ID/EX.RegisterRs)) ForwardA = 01
if (MEM/WB.RegWrite
and (MEM/WB.RegisterRd ≠ 0)
and (MEM/WB.RegisterRd = ID/EX.RegisterRt)) ForwardB = 01
```


DATA HAZARDS 10/17 Condiciones para Forward

```
add $1,$1,$2
 add $1,$1,$3
 add $1,$1,$4
if (MEM/WB.RegWrite
and (MEM/WB.RegisterRd ≠ 0)
and not(EX/MEM.RegWrite and (EX/MEM.RegisterRd ≠ 0)
       and (EX/MEM.RegisterRd ≠ ID/EX.RegisterRs)
and (MEM/WB.RegisterRd = ID/EX.RegisterRs)) ForwardA = 01
if (MEM/WB.RegWrite
and (MEM/WB.RegisterRd ≠ 0)
and not(EX/MEM.RegWrite and (EX/MEM.RegisterRd ≠ 0)
       and (EX/MEM.RegisterRd ≠ ID/EX.RegisterRt)
and (MEM/WB.RegisterRd = ID/EX.RegisterRt)) ForwardB = 01
```

DATA HAZARDS 11/17 Condiciones para Forward




DATA HAZARDS 12/17 Condiciones para Forward



DATA HAZARDS 13/17 Stalls





DATA HAZARDS 14/17 Stalls


```
if (ID/EX.MemRead and
  ((ID/EX.RegisterRt - IF/ID.RegisterRs) or
  (ID/EX.RegisterRt = IF/ID.RegisterRt)))
  stall the pipeline
```

DATA HAZARDS 15/17 Stalls

Instruction	Execution/address calculation stage control lines				Memory access stage control lines			Write-back stage control lines	
	RegDst	ALUOp1	ALUOp0	ALUSTO	Branch	Mem- Read	Mem- Write	Reg- Write	Memto- Reg
R-format	1	1	0	0	0	D	0	1	0
19	0	0	0	1	0	1	0	1	1
\$W	Х	0	0	1	0	0	1	0	Х
beq	Х	0	1	0	1	0	0	0	Х

DATA HAZARDS 16/17 Stalls





DATA HAZARDS 17/17 Stalls

