

Configuring RTP-Based VolP Operations

First Published: August 14, 2006 Last Updated: July 31, 2008

This module describes how to configure an IP Service Level Agreements (SLAs) Real-Time Transport Protocol (RTP)-based Voice over IP (VoIP) Operation feature to set up and schedule a test call for using Voice gateway digital signal processors (DSPs) to gather network performance-related statistics for the call. Available statistical measurements for VoIP networks include jitter, frame loss, Mean Opinion Score for Conversational Quality (MOS-CQ), and Mean Opinion Score for Listening Quality (MOS-LQ).

Finding Feature Information in This Module

Your software release may not support all the features documented in this module. For the latest feature information and caveats, see the release notes for your platform and software release. To find information about the features documented in this module, and to see a list of the releases in which each feature is supported, see the "Feature Information for IP SLAs RTP-Based VoIP Operations" section on page 10.

Use Cisco Feature Navigator to find information about platform support and Cisco software image support. To access Cisco Feature Navigator, go to http://www.cisco.com/go/cfn. An account on Cisco.com is not required.

Contents

- Prerequisites for IP SLAs RTP-Based VoIP Operations, page 2
- Restrictions for IP SLAs RTP-Based VoIP Operations, page 2
- Information About IP SLAs RTP-Based VoIP Operations, page 2
- How to Configure IP SLAs RTP-Based VoIP Operations, page 4
- Configuration Examples for IP SLAs RTP-Based VoIP Operations, page 7
- Additional References, page 8
- Feature Information for IP SLAs RTP-Based VoIP Operations, page 10



Prerequisites for IP SLAs RTP-Based VoIP Operations

- Both the source and destination routers must be running Cisco IOS Release 12.4(4)T or later releases.
- Both the source and destination routers must be running a Cisco IOS image with the Cisco IOS IP Voice or higher grade feature package.
- The source router must have a network module with a c5510 or c549 DSP. The destination router need not have a network module with a DSP.
- The IP SLAs Responder must be enabled on the destination gateway.

Restrictions for IP SLAs RTP-Based VoIP Operations

- The IP SLAs RTP-based VoIP operation gathers statistical information only from the DSP of the source router.
- For source-to-destination measurements, the RTP-based VoIP operation does not obtain statistical information from DSPs.
- Depending on the type of DSP, the statistics measured by the IP SLAs RTP-based VoIP operation will vary. For more information, see the "Statistics Measured by the IP SLAs RTP-Based VoIP Operation" section on page 2.
- The voice port used by the IP SLAs RTP-based VoIP operation will not be available for other calls.

Information About IP SLAs RTP-Based VoIP Operations

- Benefits of the IP SLAs RTP-Based VoIP Operation, page 2
- Statistics Measured by the IP SLAs RTP-Based VoIP Operation, page 2

Benefits of the IP SLAs RTP-Based VolP Operation

The IP SLAs RTP-Based VoIP Operation feature provides the following key benefits:

- End-to-end performance measurements using DSPs for determining voice quality in VoIP networks.
- Proactive threshold violation monitoring through Simple Network Management Protocol (SNMP) trap notifications and syslog messages.

Statistics Measured by the IP SLAs RTP-Based VoIP Operation

The IP SLAs RTP-based VoIP operation provides an enhanced capability to measure voice quality using DSP-based calculations to determine MOS scores. For customer scenarios where the destination gateway does not have DSP hardware, statistical information is gathered only from the DSP of the source gateway. In this case, the RTP data stream is looped back from the destination to the source gateway.

The statistics gathered by the IP SLAs RTP-based VoIP operation will vary depending on the type of DSP module (see Table 1 and Table 2).

Table 1 Statistics Gathered by the RTP-Based VoIP Operation for c549 DSPs

| Statistics | Description |
|---|--|
| Interarrival jitter (destination-to-source | Interarrival jitter is the mean deviation (smoothed absolute value) of the difference in packet spacing for a pair of packets. |
| and source-to-destination) | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| | For more information about interarrival jitter, see RFC 3550 (RTP: A Transport Protocol for Real-Time Applications). |
| Estimated R factor | Estimated transmission rating factor R. |
| (destination-to-source and source-to-destination) | This value is based on one-way transmission delay and standard default values. No values are obtained from the DSP to calculate the estimated transmission rating factor R. |
| | For more information about the estimated R factor, see International Telecommunication Union Telecommunication Standardization Sector (ITU-T) Recommendation G.107 (<i>The E-model, a computational model for use in transmission planning</i>). |
| MOS-CQ | Mean Opinion Score for Conversational Quality. |
| (destination-to-source and source-to-destination) | This value is obtained by conversion of the estimated R factor to Mean Opinion Score (MOS) using ITU-T Recommendation G.107 conversion tables. |
| | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| Round-trip time (RTT) latency | Round-trip time latency for an RTP packet to travel from the source to the destination and back to the source. |
| Packet loss | Number of packets lost. |
| (destination-to-source and source-to-destination) | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| Packets missing in | Number of missing packets. |
| action (source-to-destination) | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| One-way latency | Average, minimum, and maximum latency values. |
| (destination-to-source and source-to-destination) | These values are measured by sending RTP packets to IP SLAs Responder. The RTP data stream is then looped back from the destination to the source gateway. |

Table 2 Statistics Gathered by the RTP-Based VoIP Operation for c5510 DSPs

| Statistics | Description |
|--|---|
| Interarrival jitter (destination-to-source and source-to-destination) | Interarrival jitter is the mean deviation (smoothed absolute value) of the difference in packet spacing for a pair of packets. |
| | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| | For more information on how this value is calculated, see RFC 1889 (RTP: A Transport Protocol for Real-Time Applications). |
| Estimated R factor | Estimated transmission rating factor R. |
| (destination-to-source and source-to-destination) | This value is based on one-way transmission delay and standard default values, as well as values obtained from the DSP. |
| source to destination, | For more information about how to calculate the estimated R factor, see International Telecommunication Union Telecommunication Standardization Sector (ITU-T) Recommendation G.107 (<i>The E-model, a computational model for use in transmission planning</i>). |
| MOS-CQ | Mean Opinion Score for Conversational Quality. |
| (destination-to-source and source-to-destination) | This value is obtained by conversion of the estimated R factor to Mean Opinion Score (MOS) using ITU-T Recommendation G.107 conversion tables. |
| | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| Round-trip time (RTT) latency | Round-trip time latency for an RTP packet to travel from the source to the destination and back to the source. |
| Packet loss | Number of packets lost. |
| (destination-to-source and source-to-destination) | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| Packets missing in | Number of missing packets. |
| action (source-to-destination) | The source-to-destination value is measured by sending RTP packets to the IP SLAs Responder. No values are obtained from the DSP for this measurement. |
| One-way latency | Average, minimum, and maximum latency values. |
| (destination-to-source and source-to-destination) | These values are measured by sending RTP packets to IP SLAs Responder. The RTP data stream is then looped back from the destination to the source gateway. |
| Frame loss | Number of DSP frame loss events. |
| (destination-to-source) | A frame loss can occur due to such events as packet loss, late packets, or a jitter buffer error. |
| MOS-LQ (destination-to-source) | Mean Opinion Score for Listening Quality. |

How to Configure IP SLAs RTP-Based VoIP Operations

• Configuring and Sceduling an IP SLAs RTP-Based VoIP Operation, page 5

Configuring and Sceduling an IP SLAs RTP-Based VolP Operation

Perform this task to configure and schedule an IP SLAs RTP-based VoIP operation.

SUMMARY STEPS

- 1. enable
- 2. configure terminal
- 3. ip sla operation-number
- 4. **voip rtp** {destination-ip-address | destination-hostname} **source-ip** {ip-address | hostname} **source-voice-port** {slot [/subunit/port:ds0-group-number]} [**codec** codec-type] [**duration** seconds] [**advantage-factor** value]
- 5. frequency seconds
- **6. history** *history-parameter*
- 7. owner text
- 8. tag text
- 9. threshold milliseconds
- **10. timeout** *milliseconds*
- 11. exit
- 12. ip sla reaction-configuration operation-number react monitored-element [action-type option] [threshold-type {average [number-of-measurements] | consecutive [occurrences] | immediate | never | xofy [x-value y-value]}] [threshold-value upper-threshold lower-threshold]
- 13. ip sla schedule operation-number [life {forever | seconds}] [start-time {hh:mm[:ss] [month day | day month] | pending | now | after hh:mm:ss}] [ageout seconds] [recurring]
- 14. exit
- **15**. **show ip sla monitor configuration** [operation-number]

DETAILED STEPS

| | Command or Action | Purpose |
|--------|--|---|
| Step 1 | enable | Enables privileged EXEC mode. |
| | | • Enter your password if prompted. |
| | <pre>Example: Router> enable</pre> | |
| Step 2 | configure terminal | Enters global configuration mode. |
| | Example: Router# configure terminal | |
| Step 3 | ip sla operation-number | Begins configuration for an IP SLAs operation and enters IP SLA configuration mode. |
| | <pre>Example: Router(config)# ip sla 1</pre> | |

| | Command or Action | Purpose |
|---------|--|---|
| Step 4 | <pre>voip rtp {destination-ip-address destination-hostname} source-ip {ip-address hostname} source-voice-port {slot [/subunit/port:ds0-group-number]} [codec codec-type] [duration seconds] [advantage-factor value]</pre> | Enters IP SLAs VoIP RTP configuration mode and configures the IP SLAs operation as an RTP-based VoIP operation. |
| | Example: Router(config-ip-sla) # voip rtp 10.2.3.4 source-ip 10.5.6.7 source-voice-port 1/0:1 codec g711alaw duration 30 advantage-factor 5 | |
| Step 5 | frequency seconds | (Optional) Sets the rate at which a specified IP SLAs operation repeats. The default frequency value is 60 seconds. |
| | <pre>Example: Router(config-ip-sla-voip-rtp)# frequency 90</pre> | seconds. |
| Step 6 | history history-parameter | (Optional) Specifies the parameters used for gathering statistical history information for an IP SLAs operation. |
| | <pre>Example: Router(config-ip-sla-voip-rtp)# history buckets-kept 25</pre> | |
| Step 7 | owner text | (Optional) Configures the SNMP owner of an IP SLAs operation. |
| | <pre>Example: Router(config-ip-sla-voip-rtp)# owner 10.16.1.1 cwb.cisco.com John Doe RTP 555-1212</pre> | |
| Step 8 | tag text | (Optional) Creates a user-specified identifier for an IP SLAs operation. |
| | <pre>Example: Router(config-ip-sla-voip-rtp)# tag testoperation</pre> | |
| Step 9 | threshold milliseconds | (Optional) Sets the upper threshold value for calculating network monitoring statistics created by an IP SLAs |
| | <pre>Example: Router(config-ip-sla-voip-rtp)# threshold 10000</pre> | operation. |
| Step 10 | timeout milliseconds | (Optional) Sets the amount of time an IP SLAs operation waits for a response from its request packet. |
| | <pre>Example: Router(config-ip-sla-voip-rtp)# timeout 10000</pre> | |
| Step 11 | exit | Exits IP SLAs VoIP RTP configuration submode and returns to global configuration mode. |
| | <pre>Example: Router(config-ip-sla-voip-rtp)# exit</pre> | |

| | Command or Action | Purpose |
|---------|---|--|
| Step 12 | <pre>ip sla reaction-configuration operation-number react monitored-element [action-type option] [threshold-type {average [number-of-measurements] consecutive [occurrences] immediate never xofy [x-value y-value]}] [threshold-value upper-threshold lower-threshold]</pre> | (Optional) Configures certain actions to occur based on events under the control of Cisco IOS IP SLAs. |
| | Example: Router(config) # ip sla reaction-configuration 1 react frameLossDS action-type traponly threshold-type consecutive 3 | |
| Step 13 | <pre>ip sla schedule operation-number [life {forever seconds}] [start-time {hh:mm[:ss] [month day day month] pending now after hh:mm:ss}] [ageout seconds] [recurring]</pre> | Specifies the scheduling parameters for an IP SLAs operation. |
| | <pre>Example: Router(config)# ip sla schedule 1 start-time now life forever</pre> | |
| Step 14 | exit | (Optional) Exits global configuration mode and returns to privileged EXEC mode. |
| | <pre>Example: Router(config)# exit</pre> | |
| Step 15 | show ip sla configuration [operation-number] | (Optional) Displays configuration values including all defaults for all IP SLAs operations or a specified operation. |
| | Example: Router# show ip sla configuration 10 | |

Troubleshooting Tips

Use the **debug ip sla trace** and **debug ip sla error** commands to help troubleshoot issues with an IP SLAs operation.

What to Do Next

To view and interpret the results of an IP SLAs operation use the **show ip sla statistics** and **show ip sla statistics** aggregated commands. Checking the output for fields that correspond to criteria in your service level agreement will help you determine whether the service metrics are acceptable.

Configuration Examples for IP SLAs RTP-Based VoIP Operations

• Example: Configuring an IP SLAs RTP-Based VoIP Operation, page 8

Example: Configuring an IP SLAs RTP-Based VolP Operation

The following example shows how to configure an IP SLAs RTP-based VoIP operation:

```
ip sla 1
  voip rtp 10.2.3.4 source-ip 10.5.6.7 source-voice-port 1/0:1 codec g711alaw duration 30
advantage-factor 5
!
ip sla reaction-configuration 1 react FrameLossDS action-type traponly threshold-type
consecutive 3
!
ip sla schedule 1 start-time now life forever
```

Use the **show ip sla statistics** command in privileged EXEC mode to display the current operational status and statistics for an IP SLAs operation. Use the **show ip sla statistics aggregated** command in privileged EXEC mode to display the aggregated hourly status and statistics for an IP SLAs operation.

Additional References

The following sections provide references related to the IP SLAs RTP-Based VoIP Operation feature.

Related Documents

| Related Topic | Document Title |
|---|--|
| Cisco IOS IP SLAs UDP-based VoIP operations for VoIP networks | "IP SLAs—Analyzing VoIP Service Levels Using the UDP Jitter Operation" chapter of the Cisco IOS IP SLAs Configuration Guide |
| Cisco IOS commands | Cisco IOS Master Commands List, All Releases |
| Cisco IOS IP SLAs commands | Cisco IOS IP SLAs Command Reference |

Standards

| Standard | Title |
|---|-------|
| No new or modified standards are supported by this feature, and support for existing standards has not been modified by this feature. | |

MIBs

| MIB | MIBs Link |
|-----|---|
| | To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: |
| | http://www.cisco.com/go/mibs |

RFCs

| RFC | Title |
|---|-------|
| No new or modified RFCs are supported by this feature, and support for existing RFCs has not been modified by this feature. | |

Technical Assistance

| Description | Link |
|---|----------------------------------|
| The Cisco Technical Support & Documentation | http://www.cisco.com/techsupport |
| website contains thousands of pages of searchable | |
| technical content, including links to products, | |
| technologies, solutions, technical tips, and tools. | |
| Registered Cisco.com users can log in from this page to | |
| access even more content. | |

Feature Information for IP SLAs RTP-Based VoIP Operations

Table 3 lists the features in this module and provides links to specific configuration information.

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator enables you to determine which software images support a specific software release, feature set, or platform. To access Cisco Feature Navigator, go to http://www.cisco.com/go/cfn. An account on Cisco.com is not required.



Table 3 lists only the software release that introduced support for a given feature in a given software release train. Unless noted otherwise, subsequent releases of that software release train also support that feature.

Table 3 Feature Information for IP SLAs RTP-Based VoIP Operations

| Feature Name | Releases | Feature Information |
|--|----------|--|
| IP SLAs RTP-Based VoIP Operation | 12.4(4)T | The Cisco IOS IP Service Level Agreements (SLAs) Internet Control Message Protocol (ICMP) jitter operation provides the capability to generate a stream of ICMP packets to gather network performance-related statistics. Available statistical measurements for the IP SLAs ICMP jitter operation include latency, round-trip time, jitter (interpacket delay variance), and packet loss between a Cisco device (source) and any other IP device (destination). |
| IP SLAs RTP-Based VoIP Operation Enhancements | 12.4(6)T | New statistical measurement options for the source-to-destination data path were added. |

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2007-2008 Cisco Systems, Inc. All rights reserved.