

Securely purge data on an encrypted volume

ONTAP 9

NetApp November 04, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap/encryption-at-rest/secure-purge-data-encrypted-volume-concept.html on November 04, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Securely purge data on an encrypted volume	1
Securely purge data on an encrypted volume overview	1
Securely purge data on an encrypted volume without a SnapMirror relationship	2
Securely purge data on an encrypted volume with an Asynchronous SnapMirror relationship	3
Scrub data on an encrypted volume with a Synchronous SnapMirror relationship	4

Securely purge data on an encrypted volume

Securely purge data on an encrypted volume overview

Beginning in ONTAP 9.4, you can use secure purge to non-disruptively scrub data on NVE-enabled volumes. Scrubbing data on an encrypted volume ensures that it cannot be recovered from the physical media, for example, in cases of "spillage," where data traces may have been left behind when blocks were overwritten, or for securely deleting a vacating tenant's data.

Secure purge works only for previously deleted files on NVE-enabled volumes. You cannot scrub an unencrypted volume. You must use KMIP servers to serve keys, not the onboard key manager.

Secure purge functions differently depending upon your version of ONTAP.

- In ONTAP 9.8 and later:
 - Secure purge is supported by MetroCluster and FlexGroup.
 - If the volume being purged is the source of a SnapMirror relationship, you do not have to break the SnapMirror relationship to perform a secure purge.
 - The re-encryption method is different for volumes using SnapMirror data protection versus volumes not using SnapMirror data protection (DP) or those using SnapMirror extended data protection..
 - By default, volumes using SnapMirror data protection (DP) mode re-encrypt data using the volume move re-encryption method.
 - By default, volumes not using SnapMirror data protection or volumes using SnapMirror extended data protection (XDP) mode use the in-place re-encryption method.
 - These defaults can be changed using the secure purge re-encryption-method [volume-move|in-place-rekey] command.
 - By default, all Snapshot copies in FlexVol volumes are automatically deleted during the secure purge
 operation. By default, Snapshots in FlexGroup volumes and volumes using SnapMirror data protection
 are not automatically deleted during the secure purge operation. These defaults can be changed using
 the secure purge delete-all-snapshots [true|false]. command.
- In ONTAP 9.8 and earlier:
 - Secure purge does not support the following:
 - FlexClone
 - SnapVault
 - FabricPool
 - If the volume being purged is the source of a SnapMirror relationship, you must break the SnapMirror relationship before you can purge the volume.

If there are busy Snapshot copies in the volume, you must release the Snapshot copies before you can purge the volume. For example, you may need to split a FlexClone volume from its parent.

• Successfully invoking the secure-purge feature triggers a volume move that re-encrypts the remaining, unpurged data with a new key.

The moved volume remains on the current aggregate. The old key is automatically destroyed, ensuring

Securely purge data on an encrypted volume without a SnapMirror relationship

Beginning in ONTAP 9.4, you can use secure-purge to non-disruptively "scrub" data on NVE-enabled volumes.

What you'll need

- You must be a cluster administrator to perform this task.
- · Advanced privileges are required for this task.

About this task

Secure-purge may take from several minutes to many hours to complete, depending on the amount of data in the deleted files. You can use the volume encryption secure-purge show command to view the status of the operation. You can use the volume encryption secure-purge abort command to terminate the operation.



In order to do a secure purge on a SAN host, you must delete the entire LUN containing the files you want to purge, or you must be able to punch holes in the LUN for the blocks that belong to the files you want purge. If you cannot delete the LUN or your host operating system does not support punching holes in the LUN, you cannot perform a secure purge.

Steps

- 1. Delete the files or the LUN you want to securely purge.
 - On a NAS client, delete the files you want to securely purge.
 - On a SAN host, delete the LUN you want to securely purge or punch holes in the LUN for the blocks that belong to the files you want to purge.
- 2. On the storage system, change to advanced privilege level:

```
set -privilege advanced
```

3. If the files you want to securely purge are in snapshots, delete the snapshots:

```
snapshot delete -vserver SVM name -volume vol name -snapshot
```

4. Securely purge the deleted files:

```
volume encryption secure-purge start -vserver SVM_name -volume_name
```

The following command securely purges the deleted files on vol1 on SVMvs1:

```
cluster1::> volume encryption secure-purge start -vserver vs1 -volume
vol1
```

5. Verify the status of the secure-purge operation:

Securely purge data on an encrypted volume with an Asynchronous SnapMirror relationship

Beginning in ONTAP 9.8, you can use secure-purge to non-disruptively "scrub" data on NVE-enabled volumes with an Asynchronous SnapMirror relationship.

What you'll need

- You must be a cluster administrator to perform this task.
- · Advanced privileges are required for this task.

About this task

Secure-purge may take from several minutes to many hours to complete, depending on the amount of data in the deleted files. You can use the volume encryption secure-purge show command to view the status of the operation. You can use the volume encryption secure-purge abort command to terminate the operation.



In order to do a secure purge on a SAN host, you must delete the entire LUN containing the files you want to purge, or you must be able to punch holes in the LUN for the blocks that belong to the files you want purge. If you cannot delete the LUN or your host operating system does not support punching holes in the LUN, you cannot perform a secure purge.

Steps

1. On the storage system, change to advanced privilege level:

```
set -privilege advanced
```

- 2. Delete the files or the LUN you want to securely purge.
 - On a NAS client, delete the files you want to securely purge.
 - On a SAN host, delete the LUN you want to securely purge or punch holes in the LUN for the blocks that belong to the files you want to purge.
- 3. Prepare vol A in the Asynchronous relationship be securely purged:

```
volume encryption secure-purge start -vserver SVM_name -volume volume_name
-prepare true
```

Repeat this step on each volume in your Asynchronous SnapMirror relationship.

4. If the files you want to securely purge are in snapshots, delete the snapshots:

```
snapshot delete -vserver SVM_name -volume vol_name -snapshot
```

- 5. If the files you want to securely purge are in the base snapshots, do the following:
 - a. Create a snapshot on vol_A in the Asynchronous SnapMirror relationship: volume snapshot create -snapshot snapshot_name -vserver SVM_name -volume vol name
 - b. Update the SnapMirror to move the base snapshot forward:

snapmirror update -source-snapshot snapshot_name -destination-path
destination path

Repeat this step for each volume in the Asynchronous SnapMirror relationship.

c. Repeat steps (a) and (b) equal to the number of base snapshots plus one.

For example, if you have two base snapshots, you should repeat steps (a) and (b) three times.

d. Verify that the base snapshot is present: snapshot show -vserver SVM name -volume vol name`

e. Delete the base snapshot: snapshot delete -vserver SVM name -volume vol name -snapshot snapshot

6. Securely purge the deleted files:

volume encryption secure-purge start -vserver SVM_name -volume_name

Repeat this step on each volume in the Asynchronous SnapMirror relationship.

The following command securely purges the deleted files on vol1 on SVMvs1:

cluster1::> volume encryption secure-purge start -vserver vs1 -volume
vol1

7. Verify the status of the secure-purge operation:

volume encryption secure-purge show

Scrub data on an encrypted volume with a Synchronous SnapMirror relationship

Beginning in ONTAP 9.8, you can use secure-purge to non-disruptively "scrub" data on NVE-enabled volumes with a Synchronous SnapMirror relationship.

What you'll need

- You must be a cluster administrator to perform this task.
- Advanced privileges are required for this task.

About this task

Secure-purge may take from several minutes to many hours to complete, depending on the amount of data in the deleted files. You can use the volume encryption secure-purge show command to view the status of the operation. You can use the volume encryption secure-purge abort command to terminate the operation.



In order to do a secure purge on a SAN host, you must delete the entire LUN containing the files you want to purge, or you must be able to punch holes in the LUN for the blocks that belong to the files you want purge. If you cannot delete the LUN or your host operating system does not support punching holes in the LUN, you cannot perform a secure purge.

Steps

1. On the storage system, change to advanced privilege level:

```
set -privilege advanced
```

- 2. Delete the files or the LUN you want to securely purge.
 - On a NAS client, delete the files you want to securely purge.
 - On a SAN host, delete the LUN you want to securely purge or punch holes in the LUN for the blocks that belong to the files you want to purge.
- 3. Prepare vol_A in the Asynchronous relationship be securely purged:

```
volume encryption secure-purge start -vserver SVM_name -volume volume_name
-prepare true
```

Repeat this step for the other volume in your Synchronous SnapMirror relationship.

4. If the files you want to securely purge are in snapshots, delete the snapshots:

```
snapshot delete -vserver SVM name -volume vol A -snapshot snapshot
```

5. If the secure purge file is in the base or common snapshots, update the SnapMirror to move the common snapshot forward:

```
snapmirror update -source-snapshot snapshot_name -destination-path
destination path
```

There are two common snapshots, so this command must be issued twice.

6. If the secure purge file is in the application consistent snapshot, delete the snapshot on both volumes in the Synchronous SnapMirror relationship:

```
snapshot delete -vserver SVM name -volume vol name -snapshot snapshot
```

Perform this step on both volumes.

7. Securely purge the deleted files:

```
volume encryption secure-purge start -vserver SVM name -volume volume name
```

Repeat this step on each volume in the synchronous SnapMirror relationship.

The following command securely purges the deleted files on vol1 on SMV vs1.

```
cluster1::> volume encryption secure-purge start -vserver vs1 -volume
vol1
```

8. Verify the status of the secure-purge operation:

volume encryption secure-purge show

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.