Black Rail SongMeter 2+ (ARU) programming

Adam Smith, USFWS Southeast Inventory and Monitoring (adam_d_smith@fws.gov)
20 March, 2019

1. Remove front panel from SongMeter (ARU)

2. Check/install batteries

a. The main power supply is 4 "D"-sized high-capacity rechargeable NiMH batteries. Make sure these are fully charged. The internal clock runs on 2 "AA" alkaline batteries. Replace (or at least check the voltage levels of) these prior to first deployment each year.

3. Install flash cards

a. Insert 1 - 4 SDHC cards (16, 32, 64, or 128 GB; Class 10), filling from Slot A - D as needed.



4. Check bias and gain jumper settings

a. Ensure bias and gain jumpers (left side of the control panel) match the following figure on both left and right channels.



5. Power on ARU

a. Flip Power Source switch to Internal (right side of control panel).

6. Ensure up-to-date firmware version

a. As of 20 March, 2019, this is R3.3.9 for the Song Meter SM2+. It will display on the second line of the LCD screen. For example:

```
2019-Jan-29 13:54:00
Song Meter II R3.3.9
```

- b. If the firmware is current, proceed to the next step. If the firmware is out of date, download the current version.
- c. Power down the ARU by flipping the Power Source switch to Off.
- d. Copy the CURRENT_FIRMWARE.SM2 file to the top level directory of any capacity SD card.
- e. Safely eject this SD card, then insert into Slot A of the SM2+.
- f. While pressing and holding the UP button, power on the ARU by moving the Power Source switch to Internal.
- g. Continue holding the UP button until you see the message "Song Meter II Boot".
- h. Using the UP/DOWN buttons if necessary, navigate to the CURRENT_FIRMWARE desired firmware file and pressSELECT. You should see the following messages on the LCD screen:

```
Upgrading......
Upgrading Complete! Press Reset to Boot
```

- i. There is no Reset button on the SM2+, so flip the Power Source switch to Off and then Internal to reboot with the new firmware.
- j. Success will be indicated as in Step a.

7. Set date/time, if necessary

- a. Use time.gov to get official US time.
- b. Press SELECT button and navigate to Settings with the DOWN button. With Settings highlighted, press SELECT again.
- c. Highlight Time and date and press SELECT
- d. Highligh the current date and time and press SELECT
- e. Work through the year, month, day, hour, minutes, and seconds settings sequentially, pressing SELECT after each component is set.
- f. The date/time will be set when you press SELECT after setting the seconds component.

8. Set sunrise/sunset reference

- a. Navigate (using UP/DOWN buttons) to Solar, press SELECT, and press UP button until Sunrise/set is indicated. Press SELECT.
- b. Press BACK button to return to Settings menu.

9. Set location of ARU

a. Navigate to Location and press SELECT

- b. Press SELECT and modify the location prefix. Use an established point identification, if available (e.g., CDI4H). If not, use something logical and unique. Press SELECT after a trailing blank space to finish the prefix.
- c. Navigate to Latitude and press SELECT. Set the latitude of the location of ARU deployment.
- d. Navigate to Longitude and press SELECT. Set the longtitude of the location of ARU deployment.

10. Confirm audio settings

- a. Navigate to Audio and press SELECT.
- b. Set Sample rate to 22050.
- c. Set Channels to Stereo.
- d. Set File Format to WAV.
- e. Set both Gain Left and Gain Right to + 0.0 dB.
- f. Navigate to Advanced Settings and press SELECT.
- g. Set both Dig HPF Left and Dig HPF Right to 459. They will display fs/48 after setting.
- h. Ensure the following settings are Off: Dig LPF Left, Dig LPF Right, Trg Lvl Left, and Trg Lvl Right.
- i. Ensure Bits setting is 16. The other Trg setting options are irrelevant provided other settings are as specified above.
- j. Press BACK 3X to return to the ARU Main Menu.

11. Set ARU recording program

- a. Navigate to Schedule and press SELECT. This will move the cursor to the right to choose between advanced and daily schedules.
- b. Navigate to advanced schedule and press SELECT.
- c. Confirm the following program and, if necessary, change it by SELECTing each line and navigating through the options:
 - 01 AT TIME 22:00:00
 - 02 DO
 - 03 RECORD 02:00:00
 - 04 GOTO LINE 02 OOX
- d. Press BACK until you arrive at the ARU Main Menu.

12. Power down the ARU

a. Flip Power Source switch to Off.

13. Replace front panel on SongMeter (ARU)

a. The SongMeter (ARU) is now ready for deployment.