```
#include " threadsCore.h"
     #include "osDefs.h"
 3
 4
    //global variables
 5
    uint32 t* endOfStack_ptr = NULL;
6
    int numThreads = 0;
7
    int idleIndex = 0;
8
    threadStruct threadCollection[MAX THREADS];
10
    //obtain the initial location of MSP by looking it up in the vector table
11
     uint32 t* getMSPInitialLocation (void) {
12
       uint32 t* MSP ptr = (uint32 t*) 0x0; //define a pointer to a pointer that points to initial MSP
       printf("MSP: %08x\n", *MSP_ptr);
13
       if (endOfStack ptr == NULL) { //only allow endOfStack ptr to be set to initial MSP location once
14
15
         endOfStack ptr = (uint32 t*) *MSP ptr;
16
17
18
       return (uint32 t*) *MSP ptr; //dereference so that it returns just the pointer to initial MSP
19
    }
20
     //return address of new a PSP with offset of "offset" bytes from MSP
21
22
    uint32 t* getNewThreadStack (uint32 t offset) {
23
       //check if we are exceeding the max stack size
24
       if (MAX STACK < offset) {</pre>
25
         printf("ERROR: Offset too large");
26
         return NULL;
27
           //make sure to look for a NULL return in future functions to check if getNewThreadStack failed or
     not
28
      }
29
30
       //calculate address of PSP from MSP
31
       uint32 t* MSP ptr = getMSPInitialLocation();
32
       uint32 t PSP adr = (uint32 t) MSP ptr - offset;
33
34
       //check if PSP address is a number divisible by 8
35
       if (PSP adr%8 != 0) {
36
         PSP adr = PSP adr+sizeof(uint32 t); //add 4 to address to ensure valid address for the stack
37
38
39
       //check if overwriting a previous stack
40
       if(PSP adr > (uint32 t) endOfStack ptr-(STACK SIZE)){
         printf("ERROR: Overwriting old data");
41
42
         return NULL;
43
       }
44
45
       //assign PSP ptr to point to PSP adr
       uint32 t* PSP ptr = (uint32 t*) PSP adr;
47
       printf("PSP: %08x\n", (uint32 t) PSP ptr);
48
       endOfStack ptr = PSP ptr;
49
50
      return PSP_ptr;
51
     }
52
53
54
     //LAB 1: set the value of PSP to threadStack and ensure that the microcontroller is using that value by
     changing the CONTROL register
55
     /*void setThreadingWithPSP (uint32 t* threadStack) {
56
        _set_PSP((uint32_t) threadStack);
         set_CONTROL(1 << \overline{1});
57
58
59
60
61
     //Initializes the thread stack and its initial context in memory
     int osThreadNew(void (*fun_ptr) (void), int timeslice, int sleepTime) {
62
63
       ++numThreads;
64
       int stackID = numThreads-1;
65
       //generate and store TSP
       if (threadCollection[stackID].fun ptr == idleThread) {
67
         threadCollection[stackID].TSP = getNewThreadStack(STACK SIZE + numThreads*STACK SIZE); //in the
     future, use a smaller stack size for idle & modify getNewThreadStack to allow for this
69
```

\\ecfile1.uwaterloo.ca\e2adam\My Documents\GitHub\MTE241 RTOS\src\ threadsCore.c

```
threadCollection[stackID].TSP = getNewThreadStack(STACK SIZE + numThreads*STACK SIZE); //MSP stack
 71
      + n*thread stacks
 72
 73
 74
        //if getnewThreadStack encounters an error creating the thread pointer, TSP generated will be a NULL
     pointer
 75
       if(threadCollection[stackID].TSP == NULL) {
 76
          --numThreads;
 77
          return -1; //osThreadNew failed
 78
 79
 80
        //set threadStruct params
       threadCollection[stackID].fun_ptr = fun_ptr;
 81
        threadCollection[stackID].timer = timeslice;
 83
        threadCollection[stackID].timeslice = timeslice;
        threadCollection[stackID].sleepTime = sleepTime;
 85
 86
       //set the values for what the "running" thread will populate the registers with
 87
        *(--threadCollection[stackID].TSP) = 1<<24; //xPSR
        *(--threadCollection[stackID].TSP) = (uint32_t) fun_ptr; //PC (program counter)
 88
 89
 90
          //dummy values (need to be nonzero)
 91
          *(--threadCollection[stackID].TSP) = 0xE; //LR
 92
          *(--threadCollection[stackID].TSP) = 0xC; //R12
 93
          *(--threadCollection[stackID].TSP) = 0x3; //R3
          *(--threadCollection[stackID].TSP) = 0x2; //R2
 94
 9.5
          *(--threadCollection[stackID].TSP) = 0x1; //R1
          *(--threadCollection[stackID].TSP) = 0x0; //R0
 96
 97
          //dummy values (for testing purposes)
99
          *(--threadCollection[stackID].TSP) = 0xB; //R11
100
          *(--threadCollection[stackID].TSP) = 0xA; //R10
          *(--threadCollection[stackID].TSP) = 0x9; //R9
101
          *(--threadCollection[stackID].TSP) = 0x8; //R8
102
          *(--threadCollection[stackID].TSP) = 0x7; //R7
103
104
          *(--threadCollection[stackID].TSP) = 0x6; //R6
105
          *(--threadCollection[stackID].TSP) = 0x5; //R5
106
          *(--threadCollection[stackID].TSP) = 0x4; //R4
107
108
        threadCollection[stackID].status = WAITING;
109
110
        //if the idle thread is being initialized
111
        if(threadCollection[stackID].fun ptr == idleThread) {
112
          --numThreads;
          idleIndex = numThreads;
113
114
115
116
       return 0;
117
     }
118
119
     //idle function
120
     void idleThread(void) {
121
       while (1);
122
```