Change the storage cluster administrator password

HCI

Dave Bagwell June 25, 2020

This PDF was generated from https://docs.netapp.com/us-en/hci/docs/task_mnode_change_storage_cluster_admin_password.html on July 15, 2020. Always check docs.netapp.com for the latest.



Table of Contents

Change the storage cluster administrator	password	1
--	----------	---

Change the storage cluster administrator password

You can update the storage cluster administrator password by using the REST API UI.

Before you begin

Ensure that you have changed the storage cluster administrator password by using the NetApp Element software UI.

Steps

- 1. From a browser, log into the management node REST API UI:
 - a. Go to the storage MVIP and log in.

Doing this causes the certificate to be accepted for the next step.

b. Access the REST API UI on the management node by entering the management node IP address followed by /mnode:

https://[IP address]/mnode

- 2. Click **Authorize** or any lock icon and complete the following:
 - a. Enter the cluster user name and password.
 - b. Enter the client ID as mnode-client.
 - c. Click **Authorize** to begin a session.
 - d. Close the window.
- 3. Run GET /assets to find the base asset ID that you will need for the next steps:
 - a. Click GET /assets
 - b. Click **Try it out**.
 - c. Click Execute.
- 4. Copy the value for id for the base asset to your clipboard.



A base asset and sub-assets were created when you ran the upgrade or setup scripts during management node installation or upgrade or deployed your NetApp HCI using the NetApp Deployment Engine.

- 5. Retrieve the storage asset:
 - a. Click GET /assets/{ASSET_ID}/storage-clusters.

- b. Click Try it out.
- c. Enter the ID from the base asset step in asset_ID.
- d. Click Execute.
- 6. Update the storage asset:
 - a. Click PUT /assets/{ASSET_ID}/storage-clusters/{STORAGE_ID}.
 - b. Click **Try it out**.
- 7. Update the required payload values for the storage asset as defined in the **Model** tab:
 - a. Remove the hostname and SSL certificate lines.
 - b. Enter the new password on the password line.

```
{
"username": "admin",
"password": "admin",
"ip": "10.10.1.124",
"config": {}
}
```

- c. Enter the parent base asset ID in the **asset_id** field.
- d. Click Execute.

Find more information

- NetApp HCI Documentation Center
- NetApp HCI Resources Page

Copyright Information

Copyright © 2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval systemwithout prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.