
There can be a time delay before an error and a failure, or a failure may never even occur from an error. Same with going from faults to errors.

On example of liveware faults was pilots who required training after controls became digital.

- Permanent errors must be repaired
- Intermittent errors depend on the error: Do we fix the error or just modify the cases which cause the error?
- Transient errors cannot be easily fixed. They need to be tolerated.

Consider the circuit $f = \overline{A + B}$



To test a fault, we need to set the faulty inpit to the complement and the other inputs to be non-dominating. So to test A-sa0, we need A=1, B=0 and will get 1 if the fault isn't there, or 1 if the fault is. Likewise, to test A-sa1, we need A=0, B=0 and will get 0 if the fault isn't there, and 1 if the fault is.

Note that:

- < 0, 0 > will detect A-sa1, B-sa1 and f-sa0.
- < 0, 1 > will detect B-sa0 and f-sa1.
- \bullet < 1,0 > will detect A-sa0 and f-sa1.

So our test set is $\{00,01,10\}$ Boolean difference example (circuit in slides): To detect y-sa0, find values such that $y\frac{df}{dy}=1$: $y(f(y=0)\oplus f(y=1))=1 \implies y(z\oplus x)=1 \implies \overline{x}yz+xy\overline{z}=1$ Therefore, 011 and 110 can detect the fault.