

Pulse Assistant

For HOBOware® Pro Software

License Agreement

This software is furnished in accordance with a separate license agreement included with the software, and subject to any restrictions set forth therein. For more information about Onset's licensing terms and policies, contact Onset Customer Service at 1-800-LOGGERS, or visit http://www.onsetcomp.com/legal.

About Data Assistants

Data assistants are plug-in utilities for HOBOware Pro. They let you create new data series by combining data recorded by the logger with additional data that you enter before you display the plot. If your logger or datafile contains data that supports a data assistant, you will see a Data Assistants section at the bottom of the Plot Setup dialog. Select an assistant and click **Process** to continue. For information about installing and managing data assistants, refer to the following page at the Onset web site:

http://www.onsetcomp.com/dataAssistants

© 2008 Onset Computer Corporation. All rights reserved.

Doc #: 10570-E

Onset and HOBOware Pro are registered trademarks of Onset Computer Corporation. WattNode is a registered trademark of Continental Control Systems, LLC. All other trademarks are the property of their respective companies.

Introduction

The Pulse Scaling Assistant converts a data series from a compatible sensor to some other measurement when you enter a raw value and its corresponding measurement value. The conversion must be based on a linear relationship. Nonlinear scaling is not supported. After the data is displayed in a plot, you may apply filters to the new series.

This assistant can be run from the **Launch** window (Pre-set Parameters) or from the **Plot Setup** dialog. If you run the assistant from the **Plot Setup** dialog, you must run the assistant each time you readout the logger or open a datafile.

Pre-set Parameters

If you run the assistant from the **Launch** window, parameters are applied automatically each time you readout the logger. Once you have pre-defined a parameter set, the parameters are also used when current readings are viewed in the **Status** window. Parameter sets are stored on the logger and apply to that logger and channel configuration only.

The parameters last entered into any given Data Assistant will be the default used the next time the Data Assistant is run, unless it is being used to edit an existing parameter set. If you run a Data Assistant at Plot Setup time, and the next time you run it from the **Launch** window, the default values are the value you entered at Plot Setup time.

The Pre-set Parameters feature is available for the HOBO U30, the HOBO H21 (Weather Station and Micro Station) and the HOBO H22 (Energy Logger Pro) loggers.

Pre-set Parameters

If you run the assistant from the **Launch** window, parameters are applied automatically each time you readout the logger. Once you have pre-defined a parameter set, the parameters are also used when current readings are viewed in the **Status** window. The Pre-set Parameters feature is available for the HOBO U30, the HOBO H21 (Weather Station and Micro Station) and the HOBO H22 (Energy Logger Pro) loggers. Parameter sets are stored on the logger, and apply to that logger and channel configuration only.

The parameters last entered into any given Data Assistant will be the default used the next time the Data Assistant is run, unless it is being used to edit an existing parameter set. If you run a Data Assistant at Plot Setup time, and the next time you run it from the Launch window, the default values are the value you entered at Plot Setup time.

Sensors

This assistant is available for the following sensors:

- S-UCA-xxxx and S-UCC-xxxx Electronic Switch Pulse Input Adapter
- S-UCB-xxxx and S-UCD-xxxx Contact Closure Pulse Input Adapter

The Pulse Scaling Assistant can be applied only to logged data from these sensors. To avoid confusion, keep in mind the other types of scaling that are available within HOBOware Pro:

- FlexSmart[™] modules are set up for scaling prior to launch, as part of the module configuration process. (Consult the HOBOware User's Guide for details.)
- You may use HOBOware Pro to set up linear scaling for the CABLE-4-20-mA and CABLE-2.5-STEREO sensors on a U12 logger prior to launch. (Consult the HOBOware User's Guide for details.)
- The Linear Scaling Assistant is similar to the Pulse Scaling Assistant, but has slightly different input options and is compatible with a different group of sensors. (Consult the *Linear Scaling Assistant User's Guide* for details.)

After you use the assistant and display the plot, you may apply filters to the new series.

Using the Pulse Scaling Assistant

From the **Launch** window:


- 1. Launch a logger that has a supported Electronic Switch Pulse Input Adapter connected.
- 2. Click the **Data Assistant** button.
- 3. Double-click the assistant name or,

select the kWh assistant name and click the **Create** button.

From the **Plot Setup** dialog:

- Read out a logger or open a datafile that contains a Counts series from a supported Electronic Switch Pulse Input Adapter.
- Select kWh Assistant.
- 3. Click the **Process** button.

The Pulse Scaling Assistant dialog will appear.



1. Select Data Series

If your data file includes multiple scalable series, choose the one you want to scale from the **Raw Series** drop-down list. (If your logger supports sensor locations, the location you entered will be displayed here.)

2. Parameters

In the **Scaled** column of the Parameters panel, enter the units name for the scaled series, and enter a scaled value in the **Scaled** box to correspond with the number in the **Raw** box. These numbers establish the relationship between the raw and scaled values.

3. Keep the default **Resultant Series Name**, or enter a new one. You may also enter **User Notes** concerning the series you are creating. If you are running the Data Assistant from the **Launch** window, the **Resultant Series Name** field cannot be blank.

NOTE: .All of these settings will be retained as default values the next time you access the Pulse Scaling Assistant.

4. User Notes

Enter any **User Notes** concerning the series you are creating (optional).

5. Save Parameter Set or Create New Series

If you are in the **Launch** window, click **Save Parameter Set**.

If you are in the **Plot Setup** dialog, click **Create New Series**.

NOTE: All of these settings will be retained as default values the next time you access the assistant.


To create additional series using a different raw series or different parameters, click the **Create** button (if in the **Launch** window) or the **Process** button (if in the **Plot Setup** dialog).

Generating New Series

If you are running the assistant from the **Launch** window, the parameters will be applied each time you readout the logger. If you are running the assistant from the **Plot Setup** dialog, the new series will be generated when you click the **Plot** button.

Display

The scaled series will appear in the graph, and data will be displayed in the legend and in the **Details** pane (shown below).



Available Filters

After the plot is displayed, you may apply filters to the scaled series as you would for any other series in HOBOware Pro. In addition to the minimum, maximum, and average filters that are available for most series, the scaled pulse series allows you to create a new series showing totals over a period of time.

Software Updates

If you have an Internet connection, HOBOware Pro can periodically ask if you would like it to check the Onset website for software updates. This includes updates to your data assistants.

The default is to check once per week, but you can configure HOBOware Pro to check daily or monthly. In Preferences, go to the General pane. **Check for HOBOware updates** is located under the Startup heading.

You may check for updates manually at any time. Choose **Check for Updates** from the Help menu.

License Agreement

This software is furnished in accordance with a separate license agreement included with the software, and subject to any restrictions set forth therein. For more information about Onset's licensing terms and policies, contact Onset Customer Service at 1-800-LOGGERS, or visit http://www.onsetcomp.com/legal.