Cortex - A Series

Version: 1.0

Programmer's Guide

Non-Confidential - Draft - Beta



Cortex-A Series Programmer's Guide

Copyright © 2010 ARM. All rights reserved.

Release Information

The following changes have been made to this book.

Change history

Date	Issue	Confidentiality	Change
17 December 2010	A-2	Non-Confidential	First release

Proprietary Notice

Words and logos marked with or are registered trademarks or trademarks of ARM in the EU and other countries, except as otherwise stated below in this proprietary notice. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Where the term ARM is used it means "ARM or any of its subsidiaries as appropriate".

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Product Status

The information in this document is for a Beta product, that is a product under development.

Web Address

http://www.arm.com

Contents

Cortex-A Series Programmer's Guide

	Prefa	ace	
		References	x
		Typographical conventions	xi
		Feedback	
		Terms and Abbreviations	
Chapter 1	Intro	oduction	
-	1.1	History	1-3
	1.2	System-on-Chip (SoC)	
	1.3	Embedded systems	
Chapter 2	The	ARM Architecture	
-	2.1	Architecture versions	2-3
	2.2	Architecture history and extensions	
	2.3	Highlights of the ARM Cortex-A architecture	
	2.4	Processors and pipelines	2-9
Chapter 3	Gett	ing Started	
-	3.1	Linux distributions	3-2
	3.2	Useful tools	3-5
	3.3	GNU toolchain	3-6
	3.4	Example platforms	3-7
	3.5	Linaro	
Chapter 4	ARM	Registers, Modes and Instruction Sets	
•	4.1	Instruction sets	4-2
	4.2	Modes	
	4.3	Registers	

	4.4	Instruction pipelines	4-7
	4.5	Branch prediction	
Chantar F	Intro	duction to Accombly Language	
Chapter 5	5.1	duction to Assembly Language	F. (
	5.1 5.2	Comparison with other assembly languages	
	_	Instruction sets	
	5.3	ARM tools assembly language	
	5.4	Introduction to the GNU Assembler	
	5.5	Interworking	
	5.6	Identifying assembly code	5-11
Chapter 6	ARM	/Thumb Unified Assembly Language Instructions	
	6.1	Instruction set basics	6-2
	6.2	Data processing operations	6-6
	6.3	Multiplication operations	6-8
	6.4	Memory instructions	6-9
	6.5	Branches	6-12
	6.6	Integer SIMD instructions	6-13
	6.7	Saturating arithmetic	
	6.8	Miscellaneous instructions	
Chapter 7	Cach	nes	
Chaptor i	7.1	Why do caches help?	7_3
	7.1	Cache drawbacks	
	7.3	Memory hierarchy	
	7.3 7.4		
	7. 4 7.5	Cache terminology Cache architecture	
	7.5 7.6		
	7.0 7.7	Cache controller	
		Direct mapped caches	
	7.8	Set associative caches	
	7.9	A real-life example	
	7.10	Virtual and physical tags and indexes	
	7.11	Cache policies	
	7.12	Allocation policy	
	7.13	Replacement policy	
	7.14	Write policy	
	7.15	Write buffers	
	7.16	Fetch buffers	7-19
	7.17	Cache performance and hit rate	
	7.18	Invalidating and cleaning cache memory	
	7.19	Cache lockdown	7-22
	7.20	Level 2 cache controller	7-23
	7.21	Point of coherency and unification	7-24
	7.22	Parity and ECC in caches	7-25
	7.23	Tightly coupled memory	7-26
Chapter 8	Mem	ory Management Unit	
•	8.1	Virtual memory	8-3
	8.2	Level 1 page tables	
	8.3	Level 2 page tables	
	8.4	The Translation Lookaside Buffer	
	8.5	TLB coherency	
	8.6	Choice of page sizes	
	8.7	Memory attributes	
	8.8	Multi-tasking and OS usage of page tables	
	8.9	ARM Linux use of page tables	
	0.9	ALVIN FILLING 036 OI have rapids	o-10
Chapter 9		ory Ordering	
	9.1	ARM memory ordering model	9-4

	9.2	Memory barriers	9-7
	9.3	Cache coherency implications	
	9.4	Linux use of barriers	
Chapter 10	Exce	eption Handling	
-	10.1	Types of exception	10-2
	10.2	Entering an exception handler	10-4
	10.3	Exit from an exception handler	10-5
	10.4	Exception mode summary	10-6
	10.5	Vector table	
	10.6	Distinction between FIQ and IRQ	10-9
	10.7	Return instruction	10-10
Chapter 11	Inter	rupt Handling	
	11.1	External interrupt requests	11-2
	11.2	Interrupt controllers	11-5
Chapter 12	Othe	r Exception Handlers	
	12.1	Abort handler	12-2
	12.2	Undefined instruction handling	12-4
	12.3	SVC exception handling	
	12.4	ARM Linux exception program flow	12-6
Chapter 13	Boot	Code	
	13.1	Booting a bare-metal system	13-2
	13.2	Configuration	
	13.3	Booting Linux	13-7
Chapter 14	Porti		
	14.1	Endianness	
	14.2	Alignment	
	14.3	Miscellaneous C porting issues	
	14.4 14.5	Porting ARM assembly code to ARMv7 Porting ARM code to Thumb-2	
Chantar 15	Anni	ication Binary Interfaces	
Chapter 15	15.1	ication Binary Interfaces Procedure call standard	15-2
	15.2	Mixing C and assembly code	
Chapter 16	Profi	iling	
•	16.1	Profiler output	16-3
Chapter 17	Optii	mizing Code to Run on the ARM Processor	
	17.1	Compiler optimizations	17-3
	17.2	ARM Memory system optimization	17-6
	17.3	Source code modifications	17-12
	17.4	Microarchitecture optimizations	17-16
Chapter 18	Float	ting Point	
	18.1	Floating-Point Basics and the IEEE-754 Standard	
	18.2	VFP Support in GCC	
	18.3	VFP Support in Linux	
	18.4	Floating point optimization	18-11
Chapter 19	Intro	ducing NEON	
	19.1	SIMD	
	19.2	NEON architecture overview	
	19.3	NEON comparisons with other SIMD solutions	19-7

Chapter 20	Writi	ng NEON Code	
	20.1	NEON C compiler and assembler	20-2
	20.2	Optimizing NEON assembler code	
	20.3	NEON power saving	
Chapter 21	Powe	er Management	
	21.1	Power and clocking	21-2
Chapter 22	Intro	duction to Multi-processing	
	22.1	Multi-processing ARM systems	22-3
	22.2	Symmetric multi-processing	22-5
	22.3	Asymmetric multi-processing	22-7
Chapter 23	SMP	Architectural Considerations	
	23.1	Cache coherency	23-2
	23.2	Handling interrupts in an SMP system	
	23.3	Exclusive accesses	
	23.4	Booting SMP systems	
	23.5	Accelerator Coherency Port (ACP)	
	23.6	Private memory region	23-13
Chapter 24	Paral	llelizing Software	
	24.1	Decomposition methods	
	24.2	Threading models	
	24.3	Synchronization mechanisms	
	24.4	Threading libraries	24-6
Chapter 25	Issue	es with Parallelizing Software	
	25.1	Thread safety and reentrancy	25-2
	25.2	Performance issues	25-3
	25.3	Profiling in SMP systems	25-5
	25.4	SMP Barriers	25-6
Chapter 26	Secu	ırity	
	26.1	TrustZone hardware architecture	26-2
Chapter 27	Debu	ıg	
	27.1	ARM debug hardware	27-2
	27.2	ARM trace hardware	27-3
	27.3	Debug monitor	
	27.4	Linux debug	27-6
Appendix A	Instr	uction Summary	
	A.1	Instruction Summary	A-2
Appendix B	NEO	N and VFP Instruction Summary	
	B.1	NEON general data processing instructions	B-6
	B.2	NEON shift instructions	B-12
	B.3	NEON logical and compare operations	B-16
	B.4	NEON arithmetic instructions	B-22
	B.5	NEON multiply instructions	
	B.6	NEON load and store element and structure instructions	
	B.7	VFP instructions	
	B.8	NEON and VFP pseudo-instructions	B-46
Appendix C		ling ARM Linux	
	C.1	Building the Linux kernel	C-2

C.2	Creating the Linux filesystem	C-7
C.3	Putting It together	C-9
C.4	Troubleshooting C	-11

Preface

This book is intended to provide an introduction to programmers using processors which conform to the ARM ARMv7–A architecture. (The v7 refers to version 7 of the architecture, while A indicates the architecture profile which describes Application Processors.) This includes the Cortex-A8, Cortex-A9 and Cortex-A5 processors. It is intended to complement the official documentation, such as the ARM *Technical Reference Manuals* (TRMs) for the processors themselves, documentation for individual devices or boards and of course, most importantly. for all ARM programmers, the ARM *Architecture Reference Manual* (or the "ARM ARM"). This book does not seek to replace any of these sources of information. Although much of the text is also applicable to other ARM processors, we do not explicitly cover processors which implement older versions of the Architecture, or those which fall into the M class of the architecture.

Our goal is to provide a readable introduction to the architecture, covering the feature set in detail and providing practical advice on writing both C and Assembly Language which runs efficiently on the processor. We assume familiarity with C coding and some knowledge of microprocessor architectures, although no ARM-specific background is needed. We hope that the text will be well suited to programmers with a desktop PC or x86 background taking their first steps into the ARM based world.

The book introduces the fundamentals of the ARM architecture and provides some background on individual processors (Chapter 2). We then move on to briefly consider some of the tools and platforms available to those getting started with ARM programming (Chapter 3). Chapters 4, 5 and 6 provide a brisk introduction to ARM Assembly Language programming, covering the various registers, modes and assembly language instructions. We then switch our focus to the memory system and look at Caches, Memory Management and Memory Ordering in Chapters 7, 8 and 9. Dealing with interrupts and other exceptions is discussed in Chapters 10 to 12 which completes the coverage of the basic features of ARM processors.

We then move to more software focussed topics and take a look at boot code (Chapter 13) before going on to look at issues with porting C and assembly code to ARMv7, both from other architectures and from older versions of the ARM architecture (Chapter 14). Chapter 15 covers the

Application Binary Interface, knowledge which is useful to both C and Assembly Language programmers. Profiling and optimizing of code is covered in Chapters 16 and 17. Many of the techniques presented are not specific to the ARM architecture, but we also provide some processor-specific hints. We look at floating point and ARM's Advanced SIMD extensions (NEON) in Chapters 18-20. These chapters are only an introduction to the relevant topics. It would require a significantly longer piece of text to cover all of the powerful capabilities of NEON and how to apply these to common signal processing algorithms. Power management is an important part of ARM programming and is covered in Chapter 21.

Chapters 22-25 cover the area of multi-processing. We take a detailed look at how this is implemented by ARM and how programmers may write code to take advantage of it. The main part of the book is then completed with brief coverage of ARM's security extensions (TrustZone®) and the powerful hardware debug features available to programmers (Chapter 27). Appendices A and B give a summary of the available ARM, NEON and VFP instructions and Appendix C gives step by step instructions for configuring and building ARM Linux.

References

Cohen, D. "On Holy Wars and a Plea for Peace" USC/ISI IEN April, 1980, http://www.ietf.org/rfc/ien/ien137.txt

Furber, Steve, "ARM System-on-chip Architecture", 2nd Edition, Addison, Wesley, 2000, ISBN: 9780201675191

Hohl. William "ARM Assembly Language: Fundamentals and Techniques" CRC Press, 2009. ISBN: 9781439806104

Sloss, Andrew N.; Symes, Dominic; Wright, Chris "ARM System Developer's Guide: Designing and Optimizing System Software" Morgan Kaufmann, 2004, ISBN: 9781558608740

Yiu, Joseph "The Definitive Guide to the ARM Cortex-M3", 2nd Edition, Newnes, 2009, ISBN: 9780750685344.

ANSI/IEEE Std 754-1985 "IEEE Standard for Binary Floating-Point Arithmetic".

ANSI/IEEE Std 1003.1-1990 "Standard for Information Technology - Portable Operating System Interface (POSIX) Base Specifications, Issue 7".

ANSI/IEEE Std 1149.1-2001 "IEEE Standard Test Access Port and Boundary-Scan Architecture".

ARM Architecture Reference Manual - ARMv7-A and ARMv7-R edition (Errata markup).

The ARM Architecture Reference Manual (Known as the ARM ARM) is a must-read for any serious ARM programmer. It is available (after registration) from the ARM website. It fully describes the ARMv7 instruction set architecture, programmer's model, system registers, debug features and memory model. It forms a detailed specification to which all implementations of ARM processors must adhere.

ARM Generic Interrupt Controller Architecture Specification.

ARM Compiler Toolchain Assembler Reference.

The individual processor Technical Reference Manuals provide a detailed description of the processor behavior. They may be obtained from the ARM website documentation area, http://infocenter.arm.com/help/index.jsp (registration may be required).

Typographical conventions

This book uses the following typographical conventions:

italic Highlights important notes, introduces special terminology, denotes

internal cross-references, and citations.

bold Highlights interface elements, such as menu names. Denotes signal

names. Also used for terms in descriptive lists, where appropriate.

monospace Denotes text that you can enter at the keyboard, such as commands, file

and program names, and source code.

monospace italic Denotes arguments to monospace text where the argument is to be

replaced by a specific value.

< and > Enclose replaceable terms for assembler syntax where they appear in code

or code fragments. For example:

MRC p15, 0 <Rd>, <CRn>, <CRm>, <Opcode_2>

Feedback

ARM welcomes feedback on this product and its documentation.

Feedback on this product

If you have any comments or suggestions about this product, contact your supplier and give:

- The product name.
- The product revision or version.
- An explanation with as much information as you can provide. Include symptoms if appropriate.

Feedback on this book

If you have any comments on this book, send an e-mail to errata@arm.com. Give:

- the title
- the number, ARM DEN0013A-2
- the relevant page number(s) to which your comments apply
- a concise explanation of your comments.

ARM also welcomes general suggestions for additions and improvements.

Terms and Abbreviations

Terms used in this document are defined here.

AAPCS ARM Architecture Procedure Call Standard.

ABI Application Binary Interface.

ACP Accelerator Coherency Port.

AHB Advanced High-Performance Bus.

AMBA[®] Advanced Microcontroller Bus Architecture.

AMP Asynchronous Multi-Processing.

AOS Advanced Operating Systems.

APB Advanced Peripheral Bus.

ARM ARM The ARM Architecture Reference Manual.

ASIC Application Specific Integrated Circuit.

APSR Application Program Status Register.

ASID Address Space ID.

ATPCS ARM Thumb® Procedure Call Standard.

AXI Advanced eXtensible Interface.

BE8 Byte Invariant Big-Endian Mode.

BSP Board Support Package.

BTAC Branch Target Address Cache.

BTB Branch Target Buffer.

CISC Complex Instruction Set Computer.

CP15 Coprocessor 15 - System Control Coprocessor.

CPSR Current Program Status Register.

DAP Debug Access Port.

DBX Direct Bytecode Execution.

DDR Double Data Tate (SDRAM).

DMA Direct Memory Access.

DMB Data Memory Barrier.

DSB Data Synchronization Barrier.

DVFS Dynamic Voltage/Frequency Scaling.

EABI Embedded ABI.

ECC Error Correcting Code.

ECT Embedded Cross Trigger.

ETB Embedded Trace Buffer™.

ETM Embedded Trace Macrocell™.

FIQ An interrupt type (formerly fast interrupt).

FPSCR Floating Point Status and Control Register.

GCC GNU Compiler Collection.

GIC Generic Interrupt Controller.GIF Graphics Interchange Format.

Gprof GNU profiler.

Harvard cache Architecture with physically separate storage and signal pathways for

instructions and data.

IRQ Interrupt Request (normally external interrupts).

ISA Instruction Set Architecture.

ISB Instruction Synchronization Barrier.

ISR Interrupt Service Routine.

Jazelle ARM's bytecode acceleration solution.

L1/L2 Level 1/Level 2.

LSB Least Significant Bit.

MESI A cache coherency protocol with four states, Modified, Exclusive, Shared

and Invalid.

MMU Memory Management Unit.

MPU Memory Protection Unit.

NEONTM The ARM SIMD Extensions.

NMI Non-Maskable Interrupt.

Oprofile A Linux system profiler.

QEMU A processor emulator.

PCI A computer bus.

PIPT Physically Indexed, Physically Tagged.

PLE Preload Engine.

PMU Performance Monitor Unit.

PoC Point of Coherency.

PoU Point of Unification.

PPI Private Peripheral Input.

PSR Program Status Register.

PTE Page Table Entry.

RCT Runtime Compiler Target.

RISC Reduced Instruction Set Computer.

RVCT RealView Compilation Tools.

SCU Snoop Control Unit.

SGI Software Generated Interrupt.

SIMD Single Instruction, Multiple Data.

SiP System in Package.

SMP Sychronous Multi-Processing.

SoC System on Chip. Stack Pointer.

SP

SPI Shared Peripheral Interrupt.

SPSR Saved Program Status Register.

SVC Supervisor Call.

SWI Software Interrupt.

SYS System Mode.

TAP Test Access Port (JTAG Interface).

TCM Tightly Coupled Memory.

 $TDMI^{\tiny{\circledR}}$ Thumb, Debug, Multiplier, ICE.

TEX Type Extension.

Thumb® An instruction set extension to ARM.

Thumb®-2 An instruction set extension to ARM, with both 16-bit and 32-bit

instructions.

TLB Translation Lookaside Buffer.

TLS Thread Local Storage.

TrustZone® ARM's security extension.

TTB Translation Table Base.

UAL Unified Assembly Language.

UART Universal Asynchronous Receiver/Transmitter.

Uboot A Linux Bootloader.

USR User mode, an n privileged processor mode.

VFP ARM's floating point instruction set.

VIC Vectored Interrupt Controller.

VIPT Virtually Indexed, Physcially Tagged.

Execute Never. XN

Chapter 1 Introduction

ARM processors are everywhere. More than 10 billion ARM based devices had been manufactured by the end of 2008 and at the time of writing (early 2010), it is estimated that around one quarter of electronic products contain one or more ARM processors. The figure of 20 billion ARM processors shipped looks likely to be reached later in 2010. It is likely that readers of this book own products containing ARM-based devices – a mobile phone, personal computer, television or car. It may come as a surprise to programmers more used to the personal computer to learn that the x86 architecture occupies a much smaller (but still highly lucrative) position in terms of total microprocessor shipments, with around three billion devices.

The ARM architecture has advanced significantly since the first ARM1 silicon in 1985. The ARM core is not a single processor, but a whole family of processors, which share common instruction sets and programmer's models and have some degree of backward compatibility.

The purpose of this book is to bring together information from a wide variety of sources to provide a single guide for programmers wishing to develop applications for the latest Cortex-A series of processors. We will cover hardware concepts such as caches and Memory Management Units, but only where this is valuable to the application writer. The book is intended to provide information which will be useful to both assembly language and C programmers. We will look at how complex operating systems, such as Linux, make use of ARM features and how to take full advantage of the many advanced capabilities of the ARM processor, in particular writing software for multi-processing and using the SIMD capabilities of the device

This is not an introductory level book. We assume knowledge of the C programming language and microprocessors, but not any ARM-specific background. In the allotted space, we cannot hope to cover every topic in detail. In some chapters, we suggest further reading (referring either to books or websites) which can give a deeper level of background to the topic in hand, but in this book we will focus on the ARM-specific detail. We do not assume the use of any particular tool chain. We will mention both GNU tools and those from ARM during the course of the book.

Let us begin, however, with a brief look at the history of ARM.

1.1 History

The first ARM processor was designed within Acorn Computers Ltd by a team led by Sophie Wilson and Steve Furber, with the first silicon (which worked first time!) produced in April 1985. This ARM1 was quickly replaced by the ARM2 (which added multiplier hardware) which was used in real systems, including Acorn's Archimedes personal computer.

ARM Ltd. was formed in Cambridge, England in November 1990, as Advanced RISC Machines Ltd. It was a joint venture between Apple Computers, Acorn Computers and VLSI Technology and has out-lived two of its parents. The original 12 employees came mainly from the team within Acorn Computers. One reason for spinning ARM off as a separate company was that the processor had been selected by Apple Computers for use in its Newton product.

The new company quickly decided that the best way forward for their technology was to license their intellectual property (IP). Instead of designing, manufacturing and selling the chips themselves, they would sell rights to their designs to semiconductor companies. These companies would design the ARM processor into their own products, in a partnership model. This IP Licensing business is how ARM continues to operate today. ARM was quickly able to sign up licensees with Sharp, Texas Instruments and Samsung among prominent early customers. In 1998, ARM Holdings floated on the London Stock Exchange and Nasdaq. At the time of writing, ARM has nearly 2000 employees and has expanded somewhat from its original remit of processor design. ARM also licenses "Physical IP" – libraries of cells (NAND gates, RAM and so forth), graphics and video accelerators and software development products such as compilers, debuggers, boards and application software.

1.2 System-on-Chip (SoC)

Chip designers today can produce chips with many millions of transistors. Designing and verifying such complex circuits has become an extremely difficult task. It is increasingly rare for all of the parts of such systems to be designed by a single company. In response to this, ARM Ltd. and other semiconductor IP companies design and verify components (so-called IP blocks or cores). These are licensed by semiconductor companies who use these blocks in their own designs and include microprocessors, DSPs, 3D graphics and video controllers, along with many other functions.

The semiconductor companies take these blocks and integrate many other parts of a particular system onto the chip, to form a "System-on-Chip" or SoC. The architects of such devices must select the appropriate processor(s), memory controllers, on-chip memory, peripherals, bus interconnect and other logic (including perhaps analog or radio frequency components), in order to produce a system.

The term *Application Specific Integrated Circuit* (ASIC) is one that we will also use in the book. This is simply an IC design which is specific to a particular application. An individual ASIC may well contain an ARM processor, memory and so forth and clearly there is a large overlap with devices which can be termed SoCs. (The term SoC usually refers to a device with a higher degree of integration, including many of the parts of the system in a single device, possibly including analog, mixed-signal and/or radio frequency circuits.)

The large semiconductor companies which invest tens of millions of dollars to create these devices will typically also make a large investment in software to run on their platform. It would be uncommon to produce a complex system with a powerful processor without at least having ported one or more operating systems to it and written device drivers for peripherals.

Of course, powerful operating systems like Linux require significant amounts of memory to run, more than is usually able to be fitted into a single silicon device. The term System-on-Chip is therefore not always named entirely accurately, as the device does not always contain the whole system. Apart from the issue of silicon area, it is also often the case that many useful parts of a system require specialist silicon manufacturing processes which preclude them from being placed on the same die. An extension of the SoC which addresses this to some extent is the concept of System-in-Package (SiP) which combines a number of individual chips within a single physical package. Also widely seen is package-on-package stacking. The package used for the SoC chip contains connections on both the bottom (for connection to a PCB) and top (for connection to a separate package which might contain a flash memory or a large SDRAM device.

This book is not targeted at any particular SoC device and does not replace the documentation for the individual product you are targeting for your application. It is important to be aware of and be able to distinguish between specifications of the processor and behavior (for example, physical memory maps, peripherals and other features) which is specific to the device you are using.

1.3 Embedded systems

An embedded system is conventionally defined as piece of computer hardware which runs software designed to perform a specific task. Examples of such systems might be TV set-top boxes, smartcards, routers, disk drives, printers, automobile engine management systems, MP3 players or photocopiers. These contrast with what is generally considered as a computer system, that is, one which can run a wide range of general purpose software and possesses input and output devices like a keyboard and a graphical display of some kind.

Of course, this distinction is becoming increasingly blurred. Consider the cellular or mobile phone. A basic model may simply perform the task of making phone calls, but a smartphone may run a complex operating system to which many thousands of applications are available for download.

Embedded systems may contain very simple 8-bit microprocessors, such as an Intel 8051 or PIC micro-controllers, or some of the more complex 32- or 64-bit processors, such as the ARM family which form the subject matter for this book. They need some RAM (Random Access memory) and some form of ROM (Read Only Memory) or other non-volatile storage to hold the program(s) to be executed by the system. Systems will almost always have additional peripherals, relating to the actual function of the device – typically including UARTs, interrupt controllers, timers, GPIO (General Purpose I/O) signals, but also potentially quite complex blocks such as Digital Signal Processors (DSP) or Direct Memory Access (DMA) controllers.

Software running on such systems is typically grouped into two separate parts, the operating system (OS) and applications which run on top of the OS. A wide range of operating systems are in use, ranging from simple kernels, to complex Real-Time Operating Systems (RTOS), to full-featured complex operating systems, of the kind which might be found on a desktop computer. Microsoft Windows or Linux are familiar examples of the latter. In this book, we will concentrate mainly on examples from Linux. The source code for Linux is readily available for inspection by the reader and is likely to be familiar to many programmers. Nevertheless, lessons learned from Linux are equally applicable to other operating systems.

Applications running in an embedded system take advantage of the services which the OS provides, but also need to be aware of low level details of the hardware implementation, or worry about interactions with other applications that are running on the system at the same time.

There are many constraints on embedded systems, which can make programming them rather more difficult than writing an application for a general purpose processor.

- *Memory footprint*: In many systems, to minimize cost (and power), memory size may be limited. The programmer may be forced to consider the size of the program and how to reduce memory usage while it runs.
- Real-time behavior: A feature of many systems is that there are deadlines to respond to external events. This may be a "hard" requirement (a car braking system MUST respond within a certain time) or "soft" requirement (audio processing must complete within a certain time-frame to avoid a poor user experience but failure to do so under rare circumstances may not render the system worthless).
- Power: In many embedded systems, the power source is a battery and programmers and hardware designers must take great care to minimize the total energy usage of the system.
 For example, by slowing the clock, reducing supply voltage and/or switching off the processor when there is no work to be done.
- *Cost*: Reducing the bill of materials may be a significant constraint on system design.
- *Time to market*: In competitive markets, the time to develop a working product may significantly impact the success of that product.

Chapter 2 The ARM Architecture

As discussed in the opening chapter of this book, ARM does not manufacture silicon devices. Instead, ARM creates microprocessor designs, which are licensed to semiconductor companies and OEMs, who integrate them into System-on-Chip devices.

To ensure compatibility between implementations, ARM defines architecture specifications which define how compliant products must behave. Processors implementing the ARM architecture conform to a particular version of the architecture. There may be multiple processors with different internal implementations and micro-architectures, different cycle timings and clock speeds which conform to the same version of the architecture.

The programmer must distinguish between behaviors which are specific to the following:

Architecture

This defines behavior common to a set, or family, of processor designs and is defined in the appropriate ARM Architecture Reference Manual (ARM ARM). It covers instruction sets, registers, exception handling and other programmers' model features. The architecture defines behavior that is visible to the programmer, for example, what registers are available, and what individual assembly language instructions actually do.

Micro-architecture This defines how the visible behavior specified by the architecture is implemented. This could include the number of pipeline stages, for example. It may still have some programmer visible effects, such as, how long a particular instruction take to execute. Or, after how many cycles is the result available?

Processor

A processor is an individual implementation of a micro-architecture. In theory, there could be multiple processors which implement the same micro-architecture, but in practice, each processor has unique micro-architectural characteristics. A processor might be licensed and

manufactured by many companies. It might therefore, have been integrated into a wide range of different devices and systems, with a correspondingly wide range of memory maps, peripherals, and other implementation specific features Processors are documented in Technical Reference Manuals, available on the ARM website.

Core

We use this term to refer to a separate logical execution unit inside a multi-core processor.

Individual systems A System-on-Chip (SoC) contains one or more processors and typically also memory and peripherals. The device may be part of a system which contains one or more of additional processors, memory, and peripherals. Documentation is available not from ARM, but from the supplier of the individual SoC or board.

2.1 Architecture versions

Periodically, new versions of the architecture are announced by ARM. These add new features or make changes to existing behaviors. Such changes are typically backwards compatible, meaning that user code which ran on older versions of the architecture will continue to run correctly on new versions. Of course, code written to take advantage of new features will not run on older processors that lack these features.

In all versions of the architecture, some system features and behaviors are left as implementation-defined. For example, the architecture does not define cycle timings for individual instructions or cache sizes. These are determined by the individual micro-architecture.

Each architecture version may also define one or more optional extensions. These may or may not be implemented in a particular implementation of a processor. For example, in the ARMv7 architecture, the Advanced SIMD instruction set is available as an optional extension, and we discuss this at length in Chapter 19 *Introducing NEON*.

The ARMv7 architecture also has the concept of "Profiles". These are variants of the architecture describing processors targeting different markets and usages.

The profiles are as follows

- A. The Application profile defines an architecture aimed at high performance processors, supporting a virtual memory system using a Memory Management Unit (MMU) and therefore capable of running complex operating systems. Support for the ARM and Thumb instruction sets is provided.
- R. The *Real-time* profile defines an architecture aimed at systems that need deterministic timing and low interrupt latency and which do not need support for a virtual memory system and MMU, but instead use a simpler memory protection unit (MPU).
- M. The Microcontroller profile defines an architecture aimed at lower cost/performance systems, where low-latency interrupt processing is vital. It uses a different exception handling model to the other profiles and supports only a variant of the Thumb instruction set

Throughout this book, our focus will be on version 7 of the architecture (ARMv7), particularly ARMv7-A, the Application profile. This is the newest version of the architecture at the time of writing (2010). It is implemented by the latest high performance processors, such as the Cortex-A5, Cortex-A8 and Cortex-A9 processors, and also by processors from Marvell and Qualcomm, among others. We will, where appropriate, point out differences between ARMv7 and older versions of the architecture.

2.2 Architecture history and extensions

In this section, we look briefly at the development of the architecture through previous versions. Readers unfamiliar with the ARM architecture should not worry if parts of this description use terms they don't know, as we will discuss all of these topics later in the text.

The ARM architecture changed relatively little between the first test silicon in the mid 1980s through to the first ARM6 and ARM7 devices of the early 1990s. The first version of the architecture was implemented only by the ARM1. Version 2 added multiply and multiply-accumulate instructions and support for coprocessors, plus some further innovations. These early processors had a 24-bit program counter. Version 3 of the architecture separated the program counter and program status registers and added several new modes. Version 4 adds support for halfword load and store operations and an additional kernel-level privilege mode.

The ARMv4T architecture, which introduced the Thumb (16-bit) instruction set, was implemented by the ARM7TDMI and ARM9TDMI processors, products which have shipped in their billions. The ARMv5TE architecture added improvements for DSP-type operations and saturated arithmetic and to ARM/Thumb interworking. ARMv6 made a number of enhancements, including support for unaligned memory access, significant changes to the memory architecture and for multi-processor support, plus some support for SIMD operations operating on bytes/halfwords within the 32-bit general purpose registers. It also provided a number of optional extensions, notably Thumb-2 and Security Extensions (TrustZone). Thumb-2 extends Thumb to be a variable length (16-bit and 32-bit) instruction set. The ARMv7-A architecture makes the Thumb2 extensions mandatory and adds the Advanced SIMD extensions (NEON), discussed in Chapter 19 and Chapter 20.

A brief note on the naming of processors may be useful for readers. For a number of years, ARM adopted a sequential numbering system for processors with ARM9 following ARM8, which came after ARM7. Various numbers and letters were appended to the base family to denote different variants. For example, the ARM7TDMI processor has T for Thumb, D for Debug, M for a fast multiplier and I for embedded Ice. For the ARMv7 architecture, ARM adopted the brand name *Cortex* for many of the processors, with a supplementary letter indicating which of the three profiles (A, R or M) the processor supports. Figure 2-1 on page 2-5 shows how different versions of the architecture correspond to different processor implementations. The figure is not comprehensive and does not include all architecture versions or processor implementations.




Figure 2-1 Architecture and processors

In Figure 2-2, we show the development of the architecture over time, illustrating additions to the architecture at each new version. Almost all architecture changes are backward-compatible, meaning unprivileged software written for the ARMv4T architecture can still be used on ARMv7 processors.




Figure 2-2 Architecture history

Individual chapters of this book will cover these architecture topics in greater detail, but here we will briefly introduce a number of architecture elements.

2.2.1 DSP multiply-accumulate and saturated arithmetic Instructions

These instructions, added in the ARMv5TE architecture, improve the capability for digital signal processing and multimedia software and are denoted by the letter E. The new instructions provide many variations of signed multiply-accumulate, saturated add and subtract, and count leading zeros and are present in all later versions of the architecture. In many cases, this made it possible to remove a simple separate DSP from the system.

2.2.2 Jazelle

Jazelle-DBX (Direct Bytecode eXecution) allows a subset of Java Bytecodes to be executed directly within hardware as a third execution state (and instruction set). Support for this is denoted by the J in the ARMv5TEJ architecture. Support for this state is mandatory from ARMv6, although a specific ARM core can optionally implement actual Jazelle hardware acceleration, or handle the bytecodes through software emulation. The Cortex-A9 and Cortex-A5 processors offer configurable support for Jazelle.

Jazelle-DBX is best suited to providing high performance Java in very memory limited systems (for example, feature phone or low-cost embedded use). In today's systems, it is mainly used for backwards compatibility.

2.2.3 Thumb Execution Environment (ThumbEE)

This is also described as Jazelle-RCT (Runtime Compilation Target). It involves small changes to the Thumb-2 instruction set that make it a better target for code generated at runtime in controlled environments (for example, by managed languages like Java, Dalvik, C#, Python or Perl). The feature set includes automatic null pointer checks on loads and stores and instructions to check array bounds, plus special instructions to call a handler. These are small sections of critical code, used to implement a specific feature of a high level language. These changes come from re-purposing a handful of opcodes.

ThumbEE is designed to be used by high-performance just-in-time or ahead-of-time compilers, where it can reduce the code size of recompiled code. Compilation of managed code is outside the scope of this document.

2.2.4 Thumb-2

Thumb-2 extends the original 16-bit Thumb instruction set with additional 16-bit and 32-bit instructions. Thumb-2 achieves similar code density to Thumb but with performance similar to the 32-bit ARM instruction set. Thumb-2 provides virtually all the features of the ARM instruction set, plus some additional capabilities.

2.2.5 Security extensions (TrustZone)

The TrustZone extensions were added in ARMv6Z and are present in the ARMv7-A profile covered in this book. TrustZone provides two virtual processors with rigorously enforced hardware access control between the two. This means that the processor provides two "worlds", Secure and Normal, with each world operating independently of the other in a way which prevents information leakage from the secure world to the non-secure and which stops non-trusted code running in the secure world. This is discussed in more detail, later in this book

2.2.6 VFP

VFP is an extension which implements single-precision and optionally, double-precision floating-point arithmetic, compliant with the ANSI/IEEE Std. 754-1985 standard.

2.2.7 Advanced SIMD (NEON)

The NEON extension provides a Single Instruction Multiple Data (SIMD) instruction set, with separate register files (shared with VFP) and a separate NEON pipeline back-end. It supports 8-, 16-, 32- and 64-bit integer and single-precision (32-bit) floating-point data, which can be operated on in parallel in 64-bit and 128-bit registers.

2.3 Highlights of the ARM Cortex-A architecture

Here, we summarize a number of key points common to all of the Cortex-A family of devices.

- 32-bit RISC processor, with 16 × 32-bit register file with mode-based register banking.
- Harvard Architecture (separate, concurrent access to instructions and data).
- Load/Store Architecture.
- Thumb-2 as standard.
- VFP and NEON options which are expected to become standard in general purpose applications processor space.
- Backward compatibility of code from previous ARM cores.
- Full 4GB virtual and physical address spaces, with no restrictions imposed by the architecture.
- Efficient hardware page table walk for virtual to physical address translation.
- Virtual Memory for page sizes of 4kB, 64kB, 1MB and 16MB. Cacheability, access permissions, and may be set on a per-page basis.
- Big-endian and little-endian support.
- Unaligned access support for load/store instructions with 8-bit/ 16-bit/ 32-bit integer data sizes.
- SMP support on MPCore[™] variants, with full data coherency at the L1 cache level.
 Automatic cache and TLB maintenance propagation provides high efficiency SMP operation.
- PIPT (Physically indexed, physically tagged) data caches.

2.4 Processors and pipelines

In this chapter, we briefly look at some ARM processors and identify which processor implements which architecture version. We then take a slightly more detailed look at some of the individual processors which implement architecture version v7-A, which forms the main focus of this book. Some terminology will be used in this chapter which may be unfamiliar to the first-time user of ARM processors and which will not be explained until later in the book.

Table 2-1 indicates the architecture version implemented by a number of older ARM cores.

Table 2-1 Older ARM processors and architectures

Architecture Version	Applications Processor	Embedded Processor
v4T	ARM720T, ARM920T, ARM922T	ARM7TDMI
v5TE		ARM946E-S, ARM966E-S, ARM968E-S
v5TEJ	ARM926EJ-S	
v6K	ARM1136J(F)-S, ARM11 MPCore	
v6T2		ARM1156T2-S
v6K + Security extensions	ARM1176J(F)-S	

Table 2-2 shows processors with the Cortex brand name.

Table 2-2 Cortex Processors and Architecture Versions

v7-A (Applications)	v7-R (Real Time)	v6-M/v7-M (Microcontroller)
Cortex-A5 (Single/MP)	Cortex-R4	Cortex-M0 (ARMv6-M)
Cortex-A8		Cortex-M1 (ARMv6-M)
Cortex-A9 (Single/MP)		Cortex-M3 (ARMv7-M)
		Cortex-M4(F) (ARMv7-M)

In the next section, we'll take a closer look at each of the processors which implement the ARMv7-A architecture.

2.4.1 The Cortex-A5 processor

The Cortex-A5 processor supports all ARMv7-A architectural features, including the TrustZone security extensions and the NEON multimedia processing engine. It is extremely area and power efficient, but has lower maximum performance than the Cortex-A8 or Cortex-A9 processors. Both single and multi-core versions of the Cortex-A5 processor are available.

The Cortex-A5 processor integer core has a single-issue, 8-stage pipeline. It can dual issue branches in some circumstances and contains sophisticated branch prediction logic to reduce penalties associated with pipeline refills. Both NEON and floating-point hardware support are optional. The Cortex-A5 processor VFP implements VFPv4, which adds both the half-precision extensions and the Fused Multiply Add instructions to the features of VFPv3. (Support for half-precision was optional in VFPv3). It supports the ARM and Thumb-2 instruction sets plus the Jazelle-DBX and Jazelle-RCT technology. The size of the level 1 instruction and data caches is configurable (by the hardware designer) from 4kB to 64kB.

2.4.2 The Cortex-A8 processor

The Cortex-A8 processor was the first to implement the ARMv7-A architecture. It is available in a number of difference devices, including the S5PC100 from Samsung, the OMAP3530 from Texas Instruments and the i.MX515 from Freescale. A wide range of device performances are available, with some giving clock speeds of more than 1GHz.

The Cortex-A8 processor has a considerably more complex micro-architecture compared with previous ARM processors. Its integer core has dual symmetric, 13 stage instruction pipelines, with in-order issue of instructions. The NEON pipeline has an additional 10 pipeline stages, supporting both integer and floating point 64/128-bit SIMD. VFPv3 floating point is supported, as is Jazelle-RCT.

Figure 2-3 is a block diagram showing the internal structure of the Cortex-A8 processor, including the pipelines.




Figure 2-3 The Cortex-A8 processor integer and NEON pipelines

The separate instruction and data level 1 caches are 16kB or 32kB in size. They are supplemented by an integrated, unified level 2 cache, which may be up to 1MB in size, with a 16-word line length. The level 1 data cache and level 2 cache both have a 128-bit wide data interface to the core. The level 1 data cache is virtually indexed, but physically tagged, while level 2 uses physical addresses for both index and tags. Data used by NEON is, by default, not allocated to L1 (although NEON can read and write data that is already in the L1 data cache).

2.4.3 The Cortex-A9 processor

The Cortex-A9MPCore and the Cortex-A9 uniprocessor provide higher performance than the Cortex-A5 or Cortex-A8 processors, with clock speeds in excess of 1GHz and performance of 2.5DMIPS/MHz. The ARM, Thumb, Thumb-2, TrustZone, Jazelle-RCT and DBX technologies are all supported.

The level 1 cache system provides hardware support for cache coherency for between one and four cores for multi-core software. A level 2 cache is optionally connected outside of the processor. ARM supplies a level 2 cache controller (PL310/L2C-310) which supports caches of up to 8MB in size. The processor also contains an integrated interrupt controller, an implementation of ARM's *Generic Interrupt Controller* (GIC) architecture specification. This can be configured to provide support for up to 224 interrupt sources.




Figure 2-4 Block Diagram of Cortex-A9 Single Core

Devices containing the Cortex-A9 processor include nVidia's dual-core Tegra-2, the SPEAr1300 from ST and TI's OMAP4 platform.

2.4.4 Qualcomm Scorpion

ARM is not the only company which designs processors compliant with the ARMv7-A Instruction Set Architecture. In 2005, Qualcomm Inc. announced that it was creating its own implementation under license from ARM, with the name Scorpion. The Scorpion processor is available as part of Qualcomm's Snapdragon platform, which contains the features necessary to implement netbooks, smartphones or other mobile internet devices.

Relatively little information has been made publicly available by Qualcomm, although it has been commented that Scorpion has a number of similarities with the Cortex-A8 processor. It is an implementation of ARMv7-A, is superscalar and dual issue and has support for both VFP and NEON (called the VeNum media processing engine in Qualcomm press releases). There are a number of differences, however. Scorpion can process 128 bits of data in parallel in its NEON implementation, compared to 64 bits on the Cortex-A8 processor. Scorpion has a 13-stage load/store pipeline and two integer pipelines. One of these is 10 stages long and can execute only simple arithmetic instructions (for example adds or subtracts), while the other is 12 stages and can execute all data processing operations, including multiplies. Scorpion also has a 23-stage floating-point/SIMD pipeline, and VFPv3 operations are pipelined.

We will not specifically mention Scorpion again in this text. However, as the processor conforms to the ARMv7-A architecture specification, most of the information presented here will apply also to Scorpion.

2.4.5 Marvell Sheeva

Marvell is another company which designs and sells processors based on the ARM Architecture.

At the time of writing, Marvell has four families of ARM processors, the Armada 100, Armada 500, Armada 600, and Armada 1000. Marvell has designed a number of ARM processor implementations, ranging from the Sheeva PJ1 (ARMv5 compatible) to Sheeva PJ4 (ARMv7 compatible). The latter is used in the Armada 500 and Armada 600 family devices.

The Marvell devices do not support the NEON SIMD instruction set, but instead use the Wireless MMX2 technology, acquired from Intel. The Armada 510 contains 32kB I and D caches plus an integrated 512kB level 2 cache and support for VFPv3. The Armada 610 is built on a "low power" silicon process and has a smaller (256kB) level 2 cache and can be clocked at the slightly slower rate than Armada 510. We will not specifically mention these processors again in this text

Chapter 3 **Getting Started**

ARM processors may be found in a very wide range of devices, running a correspondingly wide range of software. Before we proceed to look at the underlying architecture, it may be useful to some readers to present an overview of some readily available tools, ARM-based hardware and Linux operating system distributions.

3.1 Linux distributions

Linux is a Unix-like operating system kernel, originally developed by Linus Torvalds, who continues to maintain the official kernel. It is open source, distributed under the GNU Public License, widely-used and available on a large number of different processor architectures. When you get a device with Linux on it, you are also entitled to receive the Linux source code and with it the right to study, modify and redistribute that code. If you produce a Linux based device yourself, you must release the sources to the recipient, with the same rights. Many of the programs commonly associated with the kernel (for example, the GNU Compiler Collection, GCC) are a product of the GNU project of the Free Software Foundation. Patches are reviewed on public mailing lists and merged through gatekeepers.

A number of free Linux distributions exist for ARM processors, including Debian and Ubuntu, Fedora and Gentoo.

You can obtain pre-built Linux images at, http://www.arm.com/linux or read the ARM Linux Wiki at, http://www.linux-arm.org/.

In Appendix C, we will look at how to build an ARM Linux system. Before doing that, we will briefly look at the basics of ARM Linux.

3.1.1 ARM Linux

ARM Linux is the name given to the port of the Linux kernel to ARM processors. This kernel is actively developed, with significant input from ARM to provide kernel support for new processors and architecture versions. The ARM Embedded Linux distribution includes the kernel, filesystem and U-Boot bootloader.

It may seem strange to some readers that a book about the Cortex-A series of processors contains information about Linux. There are several reasons for this. Linux source code is available to all readers and represents a huge learning resource. In addition, it is easy to program and there are many useful resources with existing code and explanations. Many readers will be familiar with Linux, as it can be run on most processor architectures. By explaining how Linux features like virtual memory, multi-tasking, shared libraries and so forth are implemented in ARM Linux, readers will be able to apply their understanding to other operating systems commonly used on ARM processors. The scalability of Linux is another factor – it can run on the most powerful ARM processors, but is also commonly used on much smaller processors, including the Cortex-M3 processor or ARM7. It can run on both the ARM and Thumb-2 ISAs, in little- or big-endian and with or without a memory management unit.

Linux makes large amounts of system and kernel information available to user applications by using virtual filesystems. These virtual files mean that we don't have to know how to program the kernel to access many hardware features. An example is /proc/cpuinfo. Reading this file on a Cortex-A8 processor might give an output like that in Example 3-1. This lets code determine useful information about the system it is running on, without having to directly interact with the hardware.

Example 3-1 Output of /proc/cpuinfo on the Cortex-A8 processor

```
Processor : ARMv7 Processor rev 7 (v71)
```

BogoMIPS : 499.92

Features : swp half thumb fastmult vfp edsp neon vfpv3

CPU implementer : 0x41
CPU architecture: 7
CPU variant : 0x1
CPU part : 0xc08

CPU revision : 7

In this book, we can merely scratch the surface of what there is to be said about Linux development. What we hope to do here is to show some ways in which programming for an embedded ARM based system differs from a desktop x86 environment and to give some pointers to useful tools, which the reader may care to investigate further.

3.1.2 Linux terminology

Here, we define some terms which we will use when discussing how the Linux kernel interacts with the underlying ARM Architecture.

- *Thread*. A thread is a piece of code running in the system. A *thread group*, or process, is a collection of threads which share a memory map, typically working together as part of an application. In an SMP system, threads may be spread across multiple processors, even if they are part of the same process.
- *Processes* are created using the fork() system call. Creation of new threads is performed with the clone() system call. Each thread has its own stack and associated kernel structures, although threads belonging to the same process may share some kernel structures, including file handles and MMU page tables.
- Scheduler. This is a vital part of the kernel which has a list of all the current threads. It knows which threads are ready to be run and which are currently not able to run. It dynamically calculates priority levels for each thread and schedules the highest priority thread to be run next. It is called after an interrupt has been handled. The scheduler is also explicitly called by the kernel via the schedule() function, for example, when an application executing a system call needs to sleep. The system will have a timer based interrupt which results in the scheduler being called at regular intervals. This allows the OS to implement time-division multiplexing, where many threads share the processor, each running for a certain amount of time, giving the user the illusion that many applications are running simultaneously.
- System Calls. Linux applications run in user (unprivileged) mode. Many parts of the system are not directly accessible in user mode. For example, the kernel may prevent user mode programs from accessing peripherals, kernel memory space and the memory space of other user mode programs. Access to some features of the system control coprocessor (CP15) is not permitted in user mode. The kernel provides an interface (via the SVC instruction) which permits an application to call kernel services. Execution is transferred to the kernel through the SVC exception handler, which returns to the user application when the system call is complete.
- Libraries. Linux applications are, with very few exceptions, not loaded as complete pre-built binaries. Instead, the application relies on external support code linked from files called shared libraries. This has the advantages of saving memory space, in that the library only needs to be loaded into RAM once and is more likely to be in the cache as it may be used by other applications. Also, updates to the library do not require every application to be rebuilt. However, this dynamic loading means that the library code must not rely on being in a particular location in memory.
- Files. These are essentially strings of blocks of data which are referred to using a pathname attached to them. Devices nodes have pathnames like files, but instead of being linked to blocks of data, they are linked to device drivers which handle real I/O devices like an LCD display, disk drive or mouse. When an application opens, read or writes a device, control is passed to specific routines in the kernel that handle that device.

3.1.3 Embedded Linux

Linux-based systems are used all the way from servers via the desktop, through mobile devices and all the way down to high-performance micro-controllers in the form of uClinux for processors lacking an MMU. However, while the kernel source code base is the same, different priorities and constraints mean that there can be some fundamental differences between the Linux running on your desktop and the one running in your set-top-box, as well as between the development methodologies used.

In a desktop system, a form of boot loader executes from ROM - be it a BIOS or UEFI. This has support for mass-storage devices and can then load a second-stage loader (for example GRUB) from a CD, a hard drive or even a USB memory stick. From this point on, everything is loaded from a general-purpose mass storage device.

In an embedded device, the initial boot loader is likely to load a kernel directly from on-board flash into RAM and execute it. In severely memory constrained systems, it might have a kernel built to "execute in place" (XiP), where all of the read-only portions of the kernel remain in ROM, and only the writable portions use RAM. Unless the system has a hard drive, (or perhaps anyway for fault tolerance reasons), the root filesystem on the device is likely to be located in flash. This can be a read-only filesystem, with portions that need to be writable overlaid by tmpfs mounts, or it can be a read-write filesystem. In both cases, the storage space available is likely to be significantly less than in a typical desktop computer. For this reason, they might use software components such as uClibc and Busybox to reduce the overall storage space required for the base system. A general desktop Linux distribution usually is supplied preinstalled with a lot of software that you might find useful at some point. In a system with limited storage space, this is not really optimal. Instead, you want to be able to select exactly the components you need to achieve what you want with your system. Various specific embedded Linux distributions exist to make this easier.

In addition, embedded systems often have lower performance than general purpose computers. In this situation, development can be significantly speeded up by compiling software for the target device on a faster desktop computer and then moving it across - so called cross-compiling.

3.1.4 Board Support Package

Getting Linux to run on a particular platform requires a *Board Support Package* (BSP). We can divide the platform-specific code into a number of areas:

- Architecture-specific code. This is found in the arch/arm/ directory and forms part of the kernel porting effort carried out by the ARM Linux maintainers.
- Processor-specific code. This is found in arch/arm/mm/ and arch/arm/include/asm/. This
 takes care of MMU and Cache functions (page table setup, TLB and cache invalidation,
 memory barriers etc.). On SMP processors, spinlock code will be enabled.
- Generic device drivers are found under drivers/.
- Platform-specific code will be placed in arch/arm/mach-*/. This is code which is most likely to be altered by people porting to a new board containing a processor with existing Linux support. The code will define the physical memory map, interrupt numbers, location of devices and any initialization code specific to that board.

3.2 Useful tools

Let's take a brief look at some available tools which can be useful to developers of ARM Linux systems. These are all extensively documented elsewhere. In this chapter, we will simply point out that these tools may be useful, and provide a short description of their purpose and function.

3.2.1 **QEMU**

QEMU is a fast, open source machine emulator. It was originally developed by Fabrice Bellard and is available for a number of architectures, including ARM. It can run operating systems and applications made for one machine (for example, an ARM processor) on a different machine, such as a PC or Mac. It uses dynamic translation of instructions and can achieve useful levels of performance, allowing it to boot complex operating systems like Linux, without the need for any target hardware.

3.2.2 Busybox

Busybox is a piece of software which provides many standard Unix tools, in a very small executable, which is ideal for many embedded systems and could be considered to be a *de facto* standard. It includes most of the Unix tools which can be found in the GNU Core Utilities, with less commonly used command switches removed, and many other useful tools including init, dhclient, wget and tftp.

Busybox calls itself the "Swiss Army Knife of Embedded Linux" – a reference to the large number of tools packed into a small package. BusyBox is a single binary executable which combines many applications. This reduces the overheads introduced by the executable file format and allows code to be shared between multiple applications without needing to be part of a library.

3.2.3 Scratchbox

If your development experience has been limited to writing code for personal computers, you may not be familiar with cross-compiling. The general principle is to use one system (the host) to compile software which runs on some other system (the target).

The target is a different architecture to the host and so cannot natively run the resulting image. For example, you may have a powerful desktop x86 machine and wish to develop code for a small battery-powered ARM based device which has no keyboard. Using the desktop machine will make code development simpler and compilation faster. There are some difficulties with this process. Some build environments will try to run programs during compilation and of course this is not possible. In addition, tools which during the build process try to discover information about the machine, (for software portability reasons) do not work correctly when cross-compiling.

Scratchbox is a cross-compilation toolkit which solves these problems and gives the necessary tools to cross-compile a complete Linux distribution. It can use either QEMU or a target board to execute the cross-compiled binaries it produces.

3.2.4 U-Boot

"Das U-Boot" (Universal Bootloader) is a universal boot loader that can easily be ported to new hardware processors or boards. It provides serial console output which makes it easy to debug and is designed to be small and reliable. In an x86 system, we will have BIOS code which initializes the processor and system and then loads an intermediate loader such as GRUB or syslinux which then loads and starts the kernel. U-Boot essentially covers both functions.

3.3 GNU toolchain

The GNU toolchain is a collection of programming tools from the GNU project used both to develop the Linux kernel and to develop applications (and indeed other operating systems). Like Linux, the GNU tools are available on a large number of processor architectures and are actively developed, to make use of the latest features incorporated in ARM processors.

The toolchain includes the following components:

- GNU make
- GNU Compiler Collection (GCC)
- GNU binutils (linker, assembler etc.)
- GNU Debugger (GDB)
- GNU build system (autotools)
- GNU C library (glibc or eglibc).

Although glibc is available on all GNU/Linux host systems and provides portability; wide compliance with standards, and is performance optimized, it is quite large for some embedded systems (approaching 2MB in size). Other libraries may be preferred in smaller systems., For example, uClibc provides most features and is around 400kB in size, and produces significantly smaller application binaries.

Figure 3-1 shows how the various GNU tools interact to produce an executable image.




Figure 3-1 Example tools flow

3.4 Example platforms

Here, we'll mention a few widely available, off-the-shelf platforms which are suitable for use by students or hobbyists for ARM Linux development. This list is likely to become outdated quickly, as newer and better boards are frequently announced.

3.4.1 Beagleboard

The BeagleBoard is a readily available, inexpensive board which provides performance levels similar to that of a laptop from a single fan-less board, powered through a USB connection. It contains the OMAP 3530 device from Texas Instruments, which includes a Cortex-A8 processor with a 256kB level 2 cache, clocked at 720MHz. The board provides a wide range of connection options, including DVI-D for monitors, S-Video for televisions, stereo audio and compatibility with a wide range of USB devices, while code and data may be provided through an MMC+/SD interface. It is highly extensible and the design information is freely available. It is intended for use by the Open Source community and not to form a part of any commercial product.

3.4.2 Pandora

The Pandora device also uses OMAP3530 (a Cortex-A8 processor clocked at 600MHz). It has controls typically found on a gaming console and in fact, looks like a typical handheld gaming device, with an 800x480 LCD.

3.4.3 nVidia Tegra 200 series developer board

This board is intended for smartbook/netbook development and contains nVidia's Tegra2 high-performance dual-core implementation of a Cortex-A9 processor running at 1GHz, along with 1GB DDR2 and a wide range of standard laptop peripherals. It is a small 10cm square board that includes 2x mini-PCI-E slots, onboard Ethernet, 3xUSB, SDcard, HDMI and analog VGA. nVidia provides BSP support for WindowsCE, Android and Linux. The performance exceeds many low-cost x86 platforms, at much lower power.

3.4.4 ST Ericsson STE MOP500

This has a dual-core ARM Cortex-A9 processor, based on the U8500 chip design with 256MB of memory and the Mali-400 GPU.

3.4.5 Gumstix

This derives its name from the fact that the board is the same size as a stick of chewing gum. The Gumstix Overo uses the OMAP3503 device from TI, containing a Cortex-A8 processor clocked at 600MHZ and runs Linux 2.6 with the BusyBox utilities and OpenEmbedded build environment.

3.4.6 Pandaboard

PandaBoard is a Single-board computer based on the Texas Instruments OMAP4430 device, including a Dual-Core 1GHz ARM Cortex-A9 processor, a 3D Accelerator video processor and 1GB of DDR2 RAM. Its features include ethernet, Bluetooth plus DVI and HDMI interfaces.

3.5 Linaro

Linaro is a non-profit organization which works on a range of open source software running on ARM processors, including kernel related tools and software and middleware. It is a collaborative effort between a number of technology companies to provide engineering help and resources to the open source community. Linaro does not produce a Linux distribution, nor is it tied to any particular distribution or board. Instead, Linaro works to produce software and tools which interact directly with the ARM processor, to provide a common software platform for use by board support package developers. See, http://www.linaro.org for more information about Linaro.

Chapter 4

ARM Registers, Modes and Instruction Sets

In this chapter, we will introduce the fundamental features of ARM processors, including details of registers, modes and instruction sets. We will also touch on some details of processor implementation features including instruction pipelines and branch prediction.

ARM is a 32-bit processor architecture. It is a load/store architecture, meaning that data-processing instructions operate on values in registers rather than external memory. Only load and store instructions access memory. Internal registers are also 32 bits. Throughout the book, when we refer to a word, we mean 32 bits. A doubleword is therefore 64 bits and a halfword is 16 bits wide.

Individual processor implementations do not necessarily have 32-bit width for all blocks and interconnections. For example, we may have 64-bit wide paths for instruction fetches or for data load and store operations.

Processors which implement the ARMv7-A architecture do not have a memory map which is fixed by the architecture. The core has access to a 4GB address space and memory and peripherals can be mapped freely within that space. We will discuss memory further, in Chapter 7 and Chapter 8, when we look at the caches and Memory Management Unit (MMU).

4.1 Instruction sets

Historically, most ARM Processors support more than one instruction set.

- ARM a full 32-bit instruction set
- Thumb a 16-bit compressed subset of the full ARM instruction set, with better code density (but reduced performance compared with ARM code).

The processor can switch back and forth between these two instruction sets, under program control.

Newer ARM cores, such as the Cortex-A series covered in this book, implement a newer version of the Thumb instruction set, called Thumb-2. This gives a mixture of 32-bit and 16-bit instructions which gives approximately the code density of the original Thumb instruction set with the performance of the original ARM instruction set. For this reason, most code developed for Cortex-A series processors will use Thumb-2.

4.2 Modes

The ARM architecture has seven processor modes. There are six privileged modes and a non-privileged user mode. In this latter mode, there are limitations on certain operations, such as MMU access. Table 4-1 summarizes the available modes. Note that modes are associated with exception events, which are discussed further in Chapter 10 *Exception Handling*.

Table 4-1 ARM Processor modes

Mode	Mode encoding	Function
Supervisor (SVC)	10011	Entered on reset or when a supervisor call instruction (SVC) is executed
FIQ	10001	Entered on a fast interrupt exception
IRQ	10010	Entered on a normal interrupt exception
Abort (ABT)	10111	Entered on a memory access violation
Undef (UND)	11011	Entered when an undefined instruction executed
System (SYS)	11111	Privileged mode, which uses the same registers as User mode
User (USR)	10000	Non-Privileged mode in which most applications run

There is an extra mode (Secure Monitor), which we will discuss when we look at the ARM Security extensions, in Chapter 26.

4.3 Registers

The ARM architecture has 37 registers, as shown in Figure 4-1.




Figure 4-1 The ARM register set

Thirty of the registers are general purpose registers. In addition, there is R15, the program counter) and six program status registers, which contain flags, modes etc. Many of these registers are banked and not visible to the processor, except in specific processor modes. These banked-out registers are automatically switched in and out when a different processor mode is entered.

So, for example, if the processor is in IRQ mode, we can see R0, R1 ... R12 (the same registers we can see in user mode), plus R13_IRQ and R14_IRQ (registers visible only while we are in IRQ mode) and R15 (the program counter, PC). R13_USR and R14_USR are not directly visible, as they are now banked out. We do not normally need to specify the mode in the register name in the way we have just done. If we (for example), refer to R13 in a line of code, the processor will access the R13 register of the mode we are currently in.

At any given moment, the programmer has access to 16 registers (R0-R15) and the *Current Program Status Register* (CPSR). R15 is hard-wired to be the program counter and holds the current program address (actually, it always points eight bytes ahead of the instruction that is executing in ARM state and four bytes ahead of the current instruction in Thumb state). We can write to R15 to change the flow of the program. R14 is the link register, which holds a return address for a function or exception (although it can occasionally be used as a general purpose register when not holding either of these values). R13, by convention is used as a stack pointer. R0-R12 are general purpose registers. Some 16-bit Thumb instructions have limitations on which registers they can access – the accessible subset is called the low registers and comprises R0-R7. Figure 4-2 shows the subset of registers visible to general data processing instructions.




Figure 4-2 Programmer visible registers for user code

The reset value of R0-R14 is unpredictable, boot code must initialize these registers to a known state. Later, we shall see that there are conventions on the use of this pool of general purpose registers and that ARM C compilers use specific registers for specific purposes.

4.3.1 Program Status Registers

The six program status registers form an additional set of banked registers. Five are used as saved program status registers (SPSR) and save a copy of the pre-exception CPSR when switching modes upon an exception. These are not accessible from system or user modes. So, for example, in user mode, we can see only CPSR. In FIQ mode, we can see CPSR and SPSR_FIQ, but have no direct access to SPSR_IRQ, SPSR_ABT etc.

The ARM Architecture Reference Manual describes how program status is reported in the 32-bit *Application Program Status Register* (APSR), with other status and control bits (system level information) remaining in the CPSR. In the ARMv7-A architecture covered in this book, the APSR is in fact the same register as the CPSR, despite the fact that they have two separate names. The APSR must be used only to access the N, Z, C, V, Q, and GE[3:0] bits. These bits are not normally accessed directly, but instead set by condition code setting instructions and tested by instructions which are executed conditionally. The renaming is therefore an attempt to clean-up the mixed access CPSR of the older ARM Architectures. Figure 4-3 on page 4-6 shows the make-up of the CPSR.




Figure 4-3 CPSR Bits

The individual bits represent the following:

- N Negative result from ALU.
- Z Zero result from ALU.
- *C* ALU operation Carry out.
- *V* ALU operation oVerflowed.
- *Q* Cumulative Saturation (also described as "sticky").
- *J* Indicates if processor is in Jazelle state.
- *GE[3:0]* Used by some SIMD instructions.
- IT [7:2] IF THEN conditional execution of Thumb2 instruction groups.
- E bit controls load/store endianness.
- A bit disables imprecise data aborts.
- I Disables IRQ.
- F Disables FIQ.
- T T = 1 Indicates processor in Thumb state.
- M[4:0] Specify the processor mode (FIQ, IRQ etc.).

The processor may change between modes using instructions which directly write to the CPSR mode bits (not possible when in user mode). More commonly, the processor changes mode as a result of exception events.

We will consider these bits in more detail in Chapter 6 and Chapter 10.

4.4 Instruction pipelines

All modern processors use an instruction pipeline, as a way to increase instruction throughput. The basic concept is that the execution of an instruction is broken down into a series of independent steps. Each instruction moves from one step to another, over a number of clock cycles, with each pipeline stage being used for different instructions. The total time to execute an individual instruction does not change much compared with a non-pipelined implementation, but the overall throughput is significantly raised. The overall speed of the processor is then governed by the speed of the slowest step, which is significantly less than the time needed to perform all steps. A non-pipelined architecture is inefficient because some blocks within the processor will be idle most of the time during the instruction execution.

The classic (ARM7 or Cortex-M3) pipeline comprises three stages – Fetch, Decode and Execute. More generally, an instruction pipeline might be divided into the following broad definitions:

- Instruction prefetch (deciding from which locations in memory instructions are to be fetched and performing associated bus accesses).
- Instruction fetch (reading instructions to be executed from the memory system).
- Instruction decode (working out what instruction is to be executed and generating appropriate control signals for the datapaths).
- Register fetch (providing the correct register values to act upon).
- Issue (issuing the instruction to the appropriate execute unit).
- Execute (the actual ALU or multiplier operation, for example).
- Memory access (performing data loads or stores).
- Register write back (updating processor registers with the results).

In individual processor implementations, some of these steps may be combined into a single pipeline stage and/or some steps may be spread over several cycles. A longer pipeline means fewer logic gates in the critical path between each pipeline stage which results in faster execution. However, there are typically many dependencies between instructions. If an instruction depends on the result of a previous instruction, the control logic may need to insert a stall (or bubble) into the pipeline until the dependency is resolved. Additional logic is needed to detect and resolve such dependencies (for example, forwarding logic, which feeds the output of a pipeline stage back to earlier pipeline stages). This makes processors with longer pipelines significantly more complex to design and validate. More importantly, it makes the processor larger and therefore more expensive.

In general, the ARM architecture tries to hide pipeline effects from the programmer. This means that the programmer can determine the pipeline structure only by reading the processor manual. Some pipeline artifacts are still present, however. For example, the program counter register (R15) points two instructions ahead of the instruction that is currently executing in ARM state, a legacy of the three stage pipeline of the original ARM1 processor.

A further drawback of a long pipeline is that sometimes the sequential execution of instructions from memory will be interrupted. This can happen as a result of execution of a branch instruction, or by an exception event (such as an interrupt). When this happens, the processor cannot determine the correct location from which the next instruction should be fetched, until the branch is resolved. In typical code, many branch instructions are conditional (as a result of loops or if statements). Therefore, whether or not the branch will be taken cannot be determined at the time the instruction is fetched. If we fetch instructions which follow a branch and the

branch is taken, the pipeline must be flushed and a new set of instructions from the branch destination must be fetched from memory instead. As pipelines get longer, the cost of this "branch penalty" becomes higher.

Cortex-A series processors have branch prediction logic, which the aims to reduce the effect of the branch penalty. In essence, the processor guesses whether a branch will be taken or not and fetches instructions either from the instructions immediately following the branch (if the prediction is that the conditional branch will *not* be taken), or from the target instruction of the branch (if the prediction is that the branch *will* be taken). If the prediction is correct, then the branch does not flush the pipeline. If the prediction is wrong, the pipeline must be flushed and instructions from the correct location fetched to refill it. We will look at this in more detail later in the chapter.

Multi-issue pipelines

A refinement of the processor pipeline is that we may duplicate logic within pipeline stages. In the ARM11 family, for example, there are three parallel pipelines at the execute stages of the pipeline – an ALU pipeline, a load/store pipeline and a multiply pipeline. Instructions may be issued into any of these pipelines. A logical development of this idea is to have multiple instances of the execute hardware – for example two ALU pipelines. We can then issue more than one instruction per cycle into these parallel pipelines – an example of instruction level parallelism. Such a processor is said to be *superscalar*. The Cortex-A8 and Cortex-A9 processors are superscalar processors – they can potentially decode and issue more than one instruction in a single clock cycle. The Cortex-A5 processor is more limited and can only dual-issue certain combinations of instructions – for example a branch and a data-processing instruction may be issued in the same cycle. The instructions are still issued from a sequential stream of instructions in memory. Extra hardware logic is required to check for dependencies between instructions – clearly we cannot dual-issue instructions in the case where one instruction must wait for the result of the other.




Figure 4-4 Cortex-A9 Pipeline

As seen in Figure 4-4, the core pipeline can be quite complex. Therefore, it is not really possible for the programmer to take care of all pipeline effects and dependencies.

Out-of-order execution also provides scope for increasing pipeline efficiency. Often, an instruction must be stalled due to a dependency (for example, the need to use a result from a previous instruction). We can execute following instructions which do not share this dependency, provided that logical hazards between instructions are rigorously respected. The Cortex-A9 processor achieves very high levels of efficiency and instruction throughput using this technique. It may be considered to have a pipeline of variable length, as the pipeline length depends upon which back-end execution pipeline an instruction uses. It can execute instructions speculatively and can sustain two instructions per clock, but has the ability to issue up to four instructions on an individual clock cycle. This can improve performance if the pipeline has become unblocked having previously been stalled for some reason.

4.4.1 Register renaming

The Cortex-A9 processor has an interesting micro-architectural implementation which makes use of a register renaming scheme. The set of registers which form a standard part of the ARM architecture are visible to the programmer, but the hardware implementation of the processor actually has a much larger pool of physical registers, with logic to dynamically map the programmer visible registers to the physical ones. Figure 4-5 shows the separate pools of architectural and physical registers.

Consider the case where code writes the value of a register to external memory and shortly thereafter reads the value of a different memory location into the same register. This might cause a pipeline stall in previous cores, even though in this particular case, there is no actual data dependency. Register renaming avoids this problem by ensuring that the two instances of R0 are renamed to different physical registers, removing the dependency. This permits a compiler or assembler programmer to reuse registers without the need to consider architectural penalties for reusing registers when there are no inter-instruction dependencies. Importantly, it also allows out-of-order execution of write-after-write and write-after-read sequences. (A write-after-write hazard could occur when we write values to the same register in two separate instructions. The processor must ensure that an instruction which comes after the two writes sees the result of the later instruction).




Figure 4-5 Register renaming

To avoid dependencies between instructions related to flag setting and comparisons, the APSR flags (N, Z, C, V, Q, and GE[3:0]) also use a separate pool of physical registers (9-bits in size).

4.5 Branch prediction

As we have seen, branch prediction logic is an important factor in achieving high throughput in Cortex-A series processors. With no branch prediction, we would have to wait until a conditional branch executes before we could correctly determine where to fetch the next instruction from.

The first time that a conditional jump instruction is fetched, there is little information on which to base a prediction about the address of the next instruction. Older ARM cores used static branch prediction. This is the simplest branch prediction method as it needs no prior information about the branch. We simply guess that backward branches will be taken, and forward branches will not be. A backward branch has a target address that is lower than its own address and this can easily be recognized in hardware as the branch offset is encoded as a two's complement number. We can therefore look at a single opcode bit to determine the branch direction. This technique can give reasonable prediction accuracy owing to the prevalence in code of loops, which almost always contain backward-pointing branches and are taken more often than not taken. Due to the pipeline length of Cortex-A series processors, we get better performance by using more complex branch prediction schemes, which give better prediction accuracy. This comes with a small price, as additional logic is required.

Dynamic prediction hardware can further reduce the average branch penalty by making use of history information about whether conditional branches were taken or not taken on previous execution. A *Branch Target Address Cache* (BTAC), also called *Branch Target Buffer* (BTB) in the Cortex-A8 processor, is a cache of branch instruction addresses, their associated branch target address and with each entry having a 2-bit value which encodes four states for the prediction – strongly predicted taken, weakly predicted taken, weakly predicted not-taken and strongly predicted not-taken. Each entry may be thought of as a saturating counter or as a state machine with four states. When a branch is executed, the state machine is updated. Branches which are not taken move the state towards strongly not taken, and taken branches move the state towards strongly taken. Figure 4-6 shows the operation of this state machine.




Figure 4-6 Four-state branch prediction

The reason why four states give better performance than two is that it requires a conditional branch to change twice from previous behavior to cause a change in the next prediction. For example, a branch which terminates a loop will therefore be incorrectly predicted only on the last iteration of the loop. If we used only a simple two-state predictor (taken/not-taken) then a mispredict would occur on both the first and last iteration of a loop.

Such a prediction scheme does not cope well with certain patterns of branch execution (for example, a branch which alternates between taken and not-taken). Therefore it is supplemented with a global history buffer (which contains 4096 2-bit entries in the Cortex-A8 processor). This keeps a history of recent conditional branches and whether they were taken or not.

The advantage of a shared history is that any correlation between branch instructions will be incorporated in predictions. The Cortex-A5 processor uses only branch taken information. This means that it can recognize a pattern of branch execution and predict what will happen next based on what happened last time it encountered this pattern.

The Cortex-A8 and Cortex-A9 processors use a small part of the branch address in their much larger history tables, and so are able to predict what will happen next based on what happened the last time this particular pattern of branch execution was seen *at this address*.

In all of these cases, we still actually evaluate the condition code attached to a branch instruction. If the branch prediction hardware predicts correctly, the pipeline does not need to be stalled. If the branch prediction hardware guesses wrong, we have to flush the pipeline and refill it.




Figure 4-7 Cortex-A9 BTAC Structure

The Branch Target Address Cache layout of the Cortex-A9 processor is shown in Figure 4-7. It has entries for the address of the branch instructions and the target address of the branch and is 2-way set associative, for performance reasons. We will cover cache structure in more detail in Chapter 7.

4.5.1 Return stack

Readers who are not at all familiar with ARM assembly language may wish to omit this section until they have read Chapter 5 and Chapter 6.

The above discussion looked at strategies the processor can use to predict whether branches are taken or not. For most branch instructions, the target address is fixed (and encoded in the instruction). However, there is a class of branches where the branch target destination cannot be determined simply by looking at the instruction. For example, if we perform a data processing operation which modifies the PC (for example, MOV, ADD or SUB) we must wait for the ALU to evaluate the result before we can know the branch target. Similarly if we load the PC from memory, using an LDR, LDM or POP instruction, we cannot know the target address until the load completes.

Such branches (often termed *indirect branches*) cannot, in general, be predicted in hardware. There is, however, one common case that can usefully be optimized, using a last-in-first-out stack in the pre-fetch hardware (the *return stack*). Whenever a function call (BL or BLX) instruction is executed, we enter the address of the following instruction into this stack. Whenever we encounter an instruction which can be recognized as being a function return instructions (BX LR, or a stack pop which contains the PC in its register list), we can speculatively pop an entry from the FIFO and start fetching instructions from that address. When the return instruction actually executes, the hardware compares the address generated by the instruction with that predicted by the FIFO. If there is a mismatch, the pipeline is flushed and we restart from the correct location.

The return stack is of a fixed size (eight entries in the Cortex-A8 or Cortex-A9 processors, for example). If a particular code sequence contains a large number of nested function calls, the return stack can predict only the first eight function returns. The effect of this is likely to be very small, as functions which are more than eight down the function stack will be a tiny proportion of the overall number of function calls.

4.5.2 Programmer's view

For the majority of application level programmers, branch prediction is a part of the hardware implementation which can safely be ignored. However, knowledge of the processor behavior with branches can be useful when writing highly optimized code. The hardware performance monitor counters can generate information about the numbers of branches correctly or incorrectly predicted. This hardware is discussed further in Chapter 17.

Branch prediction logic is disabled at reset. Part of the boot code sequence will typically be to set the Z bit in the CP15:SCTLR, System Control Register, which enables branch prediction. There is one other situation where the programmer may need to take care. When moving or changing code at an address from which code has already been executed in the system, it may be necessary (and is always prudent) to remove stale entries from the branch history logic by using the CP15 instruction which invalidates all entries.

Chapter 5 Introduction to Assembly Language

Assembly language is a human-readable representation of machine code. There is in general, a one-to-one relationship between assembly language instructions (mnemonics) and the actual binary opcode executed by the processor. The purpose of this chapter is not to teach assembly language programming. We simply describe the ARM and Thumb-2 instruction sets, highlighting features and idiosyncrasies that differentiate it from other microprocessor families.

Many programmers writing at the application level will have little need to code in assembly language. However, knowledge of assembly code can be useful in cases where highly optimized code is required, when writing JIT compilers, or where low level use of features not directly available in C is needed. It may be required for portions of boot code, device drivers or when performing OS development. Finally, it can be useful to be able to read assembly code when debugging C, and particularly, to understand the mapping between assembly instructions and C statements.

Programmers seeking a more detailed description of ARM Assembly Language should also refer to the ARM Compiler Toolchain Assembler Reference (available from, http://infocenter.arm.com/) and to the ARM *Architecture Reference Manual*.

The ARM architecture supports implementations across a very wide range of performance points. Its simplicity leads to very small implementations, and this allows very low power consumption. Implementation size, performance, and very low power consumption are key attributes of the ARM architecture.

5.1 Comparison with other assembly languages

All processors have basic data processing instructions which allow them to perform arithmetic operations (such as ADD) and logical bit manipulation (for example, AND). They also need to transfer program execution from part of the program to another, in order to support loops and conditional statements. Processors always have instructions to read and write external memory, too.

The ARM instruction set is generally considered to be simple, logical and efficient. It has features not found in other processors, while at the same time lacking operations found in some other processors. For example, it cannot perform data processing operations directly to memory. To increment a value in a memory location, the value must be loaded to an ARM register, the register incremented and a third instruction is required to write the updated value back to memory. The *Instruction Set Architecture* (ISA) includes instructions that combine a shift with an arithmetic or logical operation, auto-increment and auto-decrement addressing modes for optimized program loops, Load and Store Multiple instructions which allow efficient stack and heap operations plus block copying capability and conditional execution of almost all instructions

As many readers will be already familiar with one or more assembly languages, it may be useful to compare some code sequences, showing the x86, 68K and ARM instructions to perform equivalent tasks.

Like the x86 (but unlike the 68K), ARM instructions typically have a two or three operand format, with the first operand in most cases specifying the destination for the result (LDM and store instructions being the exception to this rule). The 68K, by contrast, places the destination as the last operand. For ARM instructions, there are generally no restrictions on which registers can be used as operands. Example 5-1 and Example 5-2 give a flavor of the differences between the different assembly languages.

Example 5-1 Instructions to add 100 to a value in a register

x86:	add	eax, #100
68K:	ADD	#100, D0
ARM:	add	r0, r0, 100

Example 5-2 Load a register with a 32-bit value from a register pointer

```
x86: mov eax, DWORD PTR [ebx]
68K: MOVE.L (A0), D0
ARM: ldr r0, [r1]
```

The ARM core is a RISC (Reduced Instruction Set Computer) processor. CISC (Complex Instruction Set Computer) processors, like the x86, have a rich instruction set capable of doing complex things with a single instruction. Such processors often have significant amounts of internal logic which decode machine instructions to sequences of internal operations (microcode). RISC architectures, in contrast, have a smaller number of more general purpose instructions, which may be executed with significantly fewer transistors, making the silicon cheaper and more power efficient. Like other RISC architectures, ARM processors have a large

number of general-purpose registers and many instructions execute in a single cycle. It has simple addressing modes, where all load/store addresses can be determined from just register contents and instruction fields.

In practice, ARM processors combine features of both classical RISC and CISC architectures.

5.2 Instruction sets

As described in Chapter 4, many ARM processors are able to natively execute two or even three different instruction sets, while some (for example, the Cortex-M3 processor) do not in fact execute the original ARM instruction set. There are at least two instruction sets that ARM cores can use.

- ARM (32-bit instructions). This is the original ARM instruction set.
- Thumb. The Thumb instruction set was first added in the ARM7TDMI processor and contained only 16-bit instructions, which gave much smaller programs (memory footprint can be a major concern in smaller embedded systems) at the cost of some performance. Recent processors, including those in the Cortex-A series, support Thumb-2, which contains a mix of 16-bit and 32-bit instructions. This gives the best of both worlds, performance similar to that of ARM, with code size similar to that of Thumb. Due to its size and performance advantages, it increasingly common for all code to be compiled or assembled to Thumb-2.

The currently used instruction set is indicated by the CPSR T bit and the processor is said to be in ARM state, or Thumb state. Code has to be explicitly compiled or assembled to one state, or the other. An explicit instruction is used to change between instruction sets. Calling functions which are compiled for a different state is known as inter-working. We'll take a more detailed look at this later in the chapter.

For Thumb-2 assembly code, there is often a choice of 16-bit and 32-bit instruction encodings, with the 16-bit versions being generated by default. The .W (32) and .N (16) width specifiers may be used to force a particular encoding (if it is possible).

5.3 ARM tools assembly language

The *Unified Assembly Language* format (UAL) now used by ARM tools allows the same canonical syntax to be used for both ARM and Thumb instruction sets. The assembler syntax of ARM tools is not identical to that used by the GNU Assembler, particularly for preprocessing and pseudo-instructions which do not map directly to opcodes. In the next chapter, we will look at the individual assembly language instructions in a little more detail. Before doing that, we take a look at the basic syntax used to specify instructions and registers. Assembly language examples in this book use both UAL and GNU Assembly syntax.

UAL gives the ability to write assembler code which can be assembled to run on all ARM processors. In the past, it was necessary to write code explicitly for ARM or Thumb state. Using UAL, the same code can be assembled for different instruction sets at the time of assembly, not at the time the code is written. This may be either through the use of command line switches, or inline directives. Legacy code will still assemble correctly.

The format of assembly language instructions consists of a number of fields. These comprise the actual opcode or an assembler directive or pseudo-instruction, plus (optionally) fields for labels, operands and comments. Each field is delimited by a space or tab, with commas being used to separate operands and a semicolon marking the start of the comment field on a line. Entire lines can be marked as comment with an asterisk. Instructions, pseudo-instructions and directives may be written in either lower-case, or upper-case (the convention used in this book), but cases may not be mixed. Symbol names are case-sensitive.

We shall go through each of these fields in turn.

5.3.1 Label

A label is required to start in the first character of a line. If the line does not have a label, a space or tab delimiter is needed to start the line. If there is a label, the assembler makes the label equal to the address in the object file of the corresponding instruction. Labels may then be used as the target for branches or for loads and stores.

Example 5-3 A simple example showing use of a label

Loop: MUL R5, R5, R1 SUBS R1, R1,#1 BNE Loop

In Example 5-3 Loop is a label and the conditional branch instruction (BNE Loop) will be assembled in a way which makes the offset encoded in the branch instruction point to the address of the MUL instruction which is associated with the label Loop.

5.3.2 Directives

Most lines will normally have an actual assembly language instruction, to be converted by the tool into its binary equivalent, but can also be a directive which tells the assembler to do something. It can also be a pseudo-instruction (one which will be converted into one or more real instructions by the assembler). We'll look at the actual instructions available in hardware in the next chapter and focus mainly on the assembler directives here. These perform a wide range of tasks. They can be used to place code or data at a particular address in memory, create references to other programs and so forth.

The DEFINE CONSTANT (DCD, DCB, DCW) directive lets us place data into a piece of code. This can be expressed numerically (in decimal, hex, binary) or as ASCII characters. It may be a single item or a comma separated list. DCB is for byte sized data, DCD or DCW can be used for word sized data items.

For example, we might have:

```
MESSAGE DCB "Hello World!",0
```

This will produce a series of bytes corresponding to the ASCII characters in the string, with a 0 termination. MESSAGE is a label which we can use to get the address of this data. Similarly, we might have data items expressed in hex:

```
Masks DCD 0x100, 0x80, 0x40, 0x20, 0x10
```

The EQU pseudo-instruction lets us assign names to address or data values. For example:

```
CtrlD EQU 4
TUBE EQU 0x30000000
```

We can then use these labels in other instructions, as parts of expressions to be evaluated. EQU does not actually cause anything to be placed in the program executable – it merely equates a name to a value, for use in other instructions, in the symbol table for the assembler. It is convenient to use such names to make code easier to read, but also so that if we change the address or value of something in a piece of code, we need only modify the original definition, rather than having to change all of the references to it individually. It is usual to group together EQU definitions, often at the start of a program or function, or in separate include files.

The AREA pseudo-instruction is used to tell the assembler about how to group together code or data into logical sections for later placement by the linker. For example, exception vectors may need to be placed at a fixed address. The assembler keeps track of where each instruction or piece of data is located in memory and the AREA directive can be used to modify that.

END is used to denote the end of the assembly language source program. Failure to use the END directive will result in an error being returned. INCLUDE tells the assembler to include the contents of another file into the current file. Include files can be used as an easy mechanism for sharing definitions between related files.

5.4 Introduction to the GNU Assembler

The GNU Assembler, part of the GNU Tools, is used to convert assembly language source code into binary object files. The assembler is extensively documented in the GNU Assembler Manual, which may be found online at, http://sourceware.org/binutils/docs/as/index.html or which (if you have GNU tools installed on your system) may be found in the gnutools/doc sub-directory.

What follows is a brief description, intended to highlight differences in syntax between the GNU Assembler and standard ARM Assembly language and to provide enough information to allow programmers to get started with the tools.

The names of GNU tool components will have prefixes indicating the target options selected, including operating system. An example would be arm-none-eabi-gcc, which might be used for bare metal systems using the ARM EABI (described later in this book).

5.4.1 Invoking the GNU Assembler

You assemble the contents of an ARM assembly language source file by running the arm-none-eabi-as program.

```
arm-eabi-as -marm -g -o filename.o filename.s
```

The option -g requests the assembler to include debug information in the output file.

Once all of your source files have been assembled into binary object files (with the extension .o), you use the GNU Linker to create the final executable in ELF format.

This is done by executing:

```
arm-none-eabi-ld -o filename.elf filename.o
```

For more complex programs, where there are many separate source files, it is more common to use a utility like make to control the build process.

You can use the simulator provided by either arm-none-eabi-gdb or arm-none-eabi-insight to run the executable files on your host, as an alternative to a real target processor.

5.4.2 GNU assembly language syntax

The GNU Assembler can target many different processor architectures and is not ARM specific. This means that its syntax is somewhat different to other ARM assemblers, such as ARM's own toolchain. The GNU Assembler uses the same syntax for all of the many processor architectures that it supports.

Assembly language source files consist of a sequence of statements, one per line.

Each statement has three optional parts, ordered as follows:

```
label: instruction @ comment
```

A *label* lets you identify the address of this instruction. This can then be used as a target for branch instructions or for load and store instructions. A label can be a letter followed (optionally) by a sequence of alphanumeric characters, followed by a colon.

Everything on the line after the @ symbol is treated as a comment and ignored (unless it is inside a string). C style comment delimiters "/*" and "*/" may also be used.

The *instruction* can be either an ARM assembly instruction, or an assembler directive. These are pseudo-instructions that tell the assembler itself to do something. These are required, amongst other things, to control sections and alignment, or create data.

There must always be a symbol *_start*, which tells the Linker the entry address of the program. This must always be defined as global and exist in only one source file.

5.4.3 Sections

An executable program with code will have at least one section, which by convention will be called .text. Data may be included in a .data section.

Directives with the same names allow you to specify which of the two sections should hold what follows in the source file. Executable code should appear in a .text section and read/write data in the .data section. Also read-only constants may appear in a .rodata section. Zero initialized data will appear in .bss. The Block Started by Symbol (bss) segment defines the space for uninitialized static data.

5.4.4 Assembler directives

This is a key area of difference between GNU tools and other assemblers.

All assembler directives begin with a period "." A full list of these is described in the GNU documentation. Here, we give a subset of commonly used directives.

- align This causes the assembler to pad the binary with bytes of zero value, in data sections, or NOP instructions in code, ensuring the next location will be on a word boundary.
- ascii "string" Insert the string literal into the object file exactly as specified, without a NUL character to terminate. Multiple strings may be specified using commas as separators.
- .asciiz does the same as .ascii, but this time additionally followed by a NUL character (a byte with the value 0).
- . byte expression, .hword expression, .word expression Inserts a byte, halfword, or word value into the object file. Multiple values may be specified using commas as separators. The synonyms .2byte and .4byte may also be used.
- .data Causes the following statements to be placed in the data section of the final executable.
- .end Marks the end of this source code file.
- . equ symbol, expression Sets the value of *symbol* to *expression*. The "=" symbol and .set have the same effect.
- .extern symbol Indicates to the assembler (and more importantly, to anyone reading the code) that *symbol* is defined in another source code file.
- .global symbol Tells the assembler that *symbol* is to be made globally visible to other source files and to the linker.
- .include "filename" Inserts the contents of filename into the current source file and is typically used to include header files containing shared definitions.
- . .ltorg This tells the assembler to insert the literal pool of constants at this point. The assembler will usually place literal pools at convenient locations within the program (for example, at the end of one function and before the start of another). Sometimes, it can be useful for the programmer to explicitly control literal pool placement with this directive.
- . text This switches the destination of following statements into the text section of the final output object file. Assembly instructions should always be in the text section.

5.4.5 Expressions

Assembly instructions and assembler directives often require an integer operand. In the assembler, this is represented as an expression to be evaluated. Typically, this will be an integer number specified in decimal, hexadecimal (with a θx prefix) or binary (with a θb prefix) or as an ASCII character surrounded by quotes.

In addition, standard mathematical and logical expressions may be evaluated by the assembler, to generate a constant value. These may utilize labels and other pre-defined values. These expressions produce either *absolute*, or *relative* values. Absolute values are position-independent and constant. Relative values are specified relative to some linker-defined address, determined when the executable image is produced – an example might be some offset from the start of the .data section of the program.

5.4.6 GNU tools naming conventions

Registers are named in GCC as follows:

• General registers: R0 - R15

• Stack pointer register: SP

• Frame pointer register: FP

• Link register: LR

Program counter: PC

• Status register flags (x = C current or S saved): xPSR, xPSR_all, xPSR_f, xPSR_x, xPSR_ctl, xPSR_fs, xPSR_fx, xPSR_f, xPSR_cs, xPSR_cf. xPSR_cx etc.

5.5 Interworking

When the processor executes ARM instructions, it is said to be operating in *ARM state*. When it is executing Thumb instructions, it is operating in *Thumb state*. A processor in a particular state cannot execute instructions from another instruction set. We must make sure that the processor does not receive instructions of the wrong instruction set.

Each instruction set includes instructions to change processor state. ARM and Thumb code can be mixed, if the code conforms to the requirements of the ARM and Thumb Procedure Call Standards (discussed in a later chapter). Compiler generated code will always do so, but assembly language programmers must take care to follow the specified rules.

Selection of processor state is controlled by the T bit in the current program status register. When T is 1, the processor is in Thumb state. When T is 0, the processor is in ARM state. However, when the T bit is modified, it is also necessary to flush the instruction pipeline (to avoid problems with instructions being decoded in one state and then executed in another). Special instructions are used to accomplish this. These are BX (Branch with eXchange) and BLX (Branch and Link with eXchange). In addition to changing the processor state with these instructions, assembly programmers must also use the appropriate directive to tell the assembler to generate code for the appropriate state.

The BX or BLX instruction branches to an address contained in the specified register, or an offset specified in the opcode. The value of bit [0] of the branch target address determines whether execution continues in ARM state or Thumb state. Both ARM (aligned to a word boundary) and Thumb (aligned to a halfword boundary) instructions do not use bit [0] to form an address. This bit can therefore safely be used to provide the additional information about whether the BX or BLX instruction should change the state to ARM (address bit [0]=0) or Thumb (address bit [0]=1). BL label will be turned into BLX label as appropriate at link time if the instruction set of the caller is different from the instruction set of label.

A typical use of these instructions is when a call from one function to another is made using the BLX instruction, and a return from that function is made using the BX LR instruction. Alternatively, we may have a non-leaf function, which pushes the link register onto the stack on entry and pops the stored link register from the stack into the program counter, on exit. Here, instead of using the BX LR instruction to return, we instead have a memory load. Memory load instructions which modify the PC may also change the processor state depending upon the value of bit [0] of the loaded address.

5.6 Identifying assembly code

When faced with a piece of assembly language source code, it can be useful to be able to quickly determine which instruction set will be used and which kind of assembler it is targeted at.

Older ARM Assembly language code may have three (or even four) operand instructions present (for example, ADD R0, R1, R2) or conditional execution of non-branch instructions (for example, ADDNE R0, R0, #1). Filenames will typically be .s or .S

Code targeted for the newer unified assembly language, UAL, will contain the directive .syntax unified but will otherwise appear similar to traditional ARM Assembly language. The pound (or hash) symbol # may be omitted in front of immediate operands. Conditional instruction sequences must be preceded immediately by the IT instruction (described in Chapter 6). Such code assembles either to fixed-size 32-bit (ARM) instructions, or mixed-size (16-/32-bit) Thumb-2 instructions, depending on the presence of the directives .code, .thumb or .arm

You may, on occasion, encounter code written in 16-bit Thumb assembly language. This may contain directives like .code 16, .thumb or .thumb_func but will not specify .syntax unified. It uses two operands for most instructions, although ADD and SUB may sometimes have three. Only branches may be executed conditionally.

All GCC inline assembler (.c, .h, .cpp, .cxx, .c++ and so on) code may build for Thumb-2 or ARM, depending on GCC configuration and command-line switches (-marm or -mthumb).

Chapter 6 **ARM/Thumb Unified Assembly Language Instructions**

This chapter is a general introduction to ARM/Thumb assembly language; we do not aim to provide detailed coverage of every instruction. As mentioned in the previous chapter, instructions can broadly be placed in one of a number of classes:

- *data operations* (ALU operations like ADD)
- *memory operations* (load and stores to memory)
- branches (for loops, goto, conditional code and other program flow control)
- *DSP* (operations on packed data, saturated mathematics and other special instructions targeting codecs)
- *miscellaneous* (coprocessor, debug, mode changes and so forth).

We'll take a brief look at each of those in turn. Before we do that, let us examine capabilities which are common to different instruction classes.

6.1 Instruction set basics

There are a number of features common to all parts of the instruction set.

6.1.1 Constant values

ARM or Thumb-2 assembly language instructions have a length of either 16- or 32-bits. This presents something of a problem. It means that we cannot encode an arbitrary 32-bit value within the opcode.

Constant values encoded in an instruction can be one of the following in Thumb:

- A constant that can be produced by shifting an 8-bit value left by any number of bits within a 32-bit word
- a constant of the form 0x00XY00XY
- a constant of the form 0xXY00XY00
- a constant of the form 0xXYXYXYXY.

Where X and Y are hexadecimal numbers in the range 00 to FF.

In the ARM instruction set, as opcode bits are used to specify condition codes, the instruction itself and the registers to be used, only 12 bits are available to specify an immediate value. We have to be somewhat creative in how these 12 bits are used. Rather than simply allowing a constant of size -2048 to +2047 to be specified, instead the 12 bits are divided into an 8-bit constant and 4-bit rotate value. The rotate value allows the 8-bit constant value to be rotated right by a number of places from 0 to 30 in steps of 2 (that is, 0, 2, 4, 6, 8 and so on)

So, we can have immediate values like 0x23 or 0xFF. And we can produce other useful immediate values (for example, addresses of peripherals or blocks of memory). For example, 0x23000000 can be produced by expressing it as 0x23 R0R 24. But many other constants, like 0x3FF, cannot be produced within a single instruction. For these values, you must either construct them in multiple instructions, or load them from memory. Programmers do not typically concern themselves with this, except where the assembler gives an error complaining about an invalid constant. Instead, we can use assembly language pseudo-instructions to generate the required constant.

The MoVW instruction (move wide), will move a 16-bit constant into a register, while zeroing the top 16 bits of the target register. MoVT (move top) will move a 16-bit constant into the top half of a given register, without changing the bottom 16 bits. This permits a MoV32 pseudo-instruction which is able to construct any 32-bit constant. The assembler provides some further help here. The prefixes :upper16: and :lower16: allow you to extract the corresponding half from a 32-bit constant:

```
MOVW R0, #:lower16:label MOVT R0, #:upper16:label
```

Although this needs two instructions, it does not require any extra space to store the constant, so no extra memory is used.

We can also use pseudo-instructions LDR Rn, =<constant> or LDR Rn, =label. (This was the only option for older cores which lacked MOVW and MOVT). The assembler will then use the best sequence to generate the constant in the specified register (one of MOV, MVN or an LDR from a *literal pool*). A literal pool is an area of constant data held within the code section, typically after the end of a function and before the start of another. The register loaded could be the program counter, which would cause a branch. This can be useful for absolute addressing or for references outside the current section; obviously this will result in position- dependent code. The value of the constant may be determined either by the assembler, or by the linker.

ARM assembler also provides the related pseudo-instruction ADR Rn, =label. This uses a PC-relative ADD or SUB, to place the address of the label into the specified register, using a single instruction. If the address is too far away to be generated this way, the ADRL pseudo-instruction is used. This requires two instructions, which gives a better range. This can be used to generate addresses for position independent code, but only within the same code section.

6.1.2 Conditional execution

A feature of the ARM instruction set is that nearly all instructions are conditional. On most other architectures, only branches/jumps may be executed conditionally. This can be useful in avoiding conditional branches in small if/then/else constructs or for compound comparisons.

As an example of this, consider code to find the smaller of two values, in registers R0 and R1 and place the result in R2. This is shown in Example 6-1. The suffix LT indicates that the instruction should be executed only if the most recent flag-setting instruction returned "less than"; GE means "greater than or equal."

Example 6-1 Example code showing branches (GNU)

```
@ Code using branches
  CMP
          R0, R1
  BLT
           .Lsmaller
                       @ if R0<R1 jump over
  MOV
          R2, R1
                       @ R1 is smaller
  В
                       @ finish
           .Lend
.Lsmaller:
  MOV
          R2, R0
                       @ R0 is smaller
.Lend:
```

Now look at the same code written using conditional MOV instructions, rather than branches, in Example 6-2

Example 6-2 Same example using conditional execution

```
CMP R0, R1
MOVGE R2, R1 @ R1 is smaller
MOVLT R2, R0 @ R0 is smaller
```

The latter piece of code is both smaller and on older ARM cores, is faster to execute. However, as we shall see when we look further at optimization later in the book, this code may actually be slower on cores like the Cortex-A9 processor, where inter-instruction dependencies could cause longer stalls than a branch.

As a reminder, this style of programming relies on the fact that status flags may be set optionally on some instructions. If the MOVGE instruction above automatically set the flags, the program might not work correctly. Load and Store instructions never set the flags. For data processing operations, however, the programmer has a choice. By default, flags will be preserved during such instructions. If the instruction is suffixed with an S, (for example, MOVS rather than MOV), then the instruction will set the flags. The flags can also set manually, by using the dedicated PSR manipulation instruction (MSR). Some instructions set the Carry flag (C) based on the carry from the ALU and others based on the barrel shifter carry.

Thumb-2 also introduces an If-Then (IT) instruction, which makes the following one to four instructions conditional. The conditions may all be identical, or some may be the inverse of the others. Instructions within an IT block must also specify the condition code to be applied.

Typically, IT instructions are auto-generated by the assembler, rather than being hand-coded. 16-bit instructions which normally change the condition code flags, will not do so inside an IT block, exception for CMP, CMN and TST whose only action is to set flags. There are some restrictions on which instructions may be used within an IT block. (Exceptions can occur within IT blocks.) The current if-then status is stored in the CPSR and so is copied into the SPSR upon exception entry, so that when the exception returns, the execution of the IT block proceeds correctly.

Certain instructions always set the flags and have no other effect. These are CMP, CMN, TST and TEQ (which are analogous to SUBS, ADDS, ANDS and EORS but with the result of the ALU calculation being used only to update the flags and not being placed in a register).

Table 6-1 below lists the 15 condition codes that can be attached to most instructions.

Table 6-1 Conditional Execution Suffixes

Flags	Description
	·
Z=1	Zero (Equal to 0)
Z=0	Not zero (Not Equal to 0)
C=1	Carry Set / unsigned Higher or Same
C=0	Carry Clear / unsigned Lower
N=1	Negative (Minus)
N=0	Positive or zero (Plus)
V=1	Sign overflow (oVerflow Set)
V=0	No sign overflow (oVerflow Clear)
C=1 AND Z=0	Unsigned Higher
C=0 OR Z=1	Unsigned Lower or Same
N=V	Signed Greater or Equal
N != V	Signed Less Than
Z=0 AND N=V	Signed Greater Than
Z=1 OR N != V	Signed Less or Equal
-	Always (default)
	C=1 C=0 N=1 N=0 V=1 V=0 C=1 AND Z=0 C=0 OR Z=1 N=V N != V Z=0 AND N=V

Thumb-2 code has a somewhat different mechanism for conditional execution. Branches may be executed conditionally. Instructions can also be conditionally executed by using the Conditional Branch on Zero (CBZ) and Conditional Branch on Non-Zero (CBNZ) instructions. These compare the value of a register against zero and branch on the result. In addition, instructions may be conditionally executed using the if-then (IT) construct.

IT is a 16-bit instruction that allows nearly all Thumb instructions to be conditionally executed, depending on the value of the ALU flags, using the condition code suffix. Each IT instruction provides conditional execution for up to four following instructions.

```
ITT EQ
SUBEQ r1, r1, #1
ADDEQ r0, r0, #60
```

6.1.3 Status flags and condition codes

When we looked at the register set, it was stated that the ARM processor has a *Current Program Status Register* (CPSR) which contains 4 status flags, (*Z*)ero, (*N*)egative, (*C*)arry and o(*V*)erflow. Table 6-2 indicates when these bits are set or cleared.

Table 6-2 Summary of PSR Flag bits

Flag	Description
N (Bit [31])	<i>Negative</i> . Set to bit[31] of the result. When it is '1', the result is negative (when dealing with signed integers)
Z (Bit [30])	Zero. Set to '1' when the result is 0.
C (Bit [29])	Carry. Set to '1' when overflow occurs on an unsigned operation.
V (Bit [28])	Overflow. Set to 1 when overflow or underflow occurs on a signed operation.

The operation of the negative and zero flags should be easily understood. The C flag will be set if the result of an unsigned operation overflows the 32-bit result register. This bit might be used to implement 64-bit (or longer) arithmetic using 32-bit operations, for example.

The V flag operates in the same way as the C flag, but for signed operations. 0x7FFFFFFF is the largest signed positive integer that can be represented in 32 bits. If, for example, we add 2 to this value, we will produce 0x80000001, a large negative number. The V bit is set to indicate the overflow or underflow, from bit [30] to bit [31].

6.2 Data processing operations

This is essentially the fundamental arithmetic and logical operations of the processor. Multiplies may be considered a special case of these – they typically have slightly different format and rules and are executed in a dedicated unit of the processor.

The ARM can only perform data processing on registers, never directly on memory. Data processing instructions (for the most part) use one destination register and two source operands. The basic format may be considered to be the opcode, optionally followed by a condition code, optionally followed by S (set flags), as follows:

Operation{cond}{s} Rd, Rn, Operand2

Table 6-3 summarizes the data processing assembly language instructions, giving their mnemonic operand, operands and a brief description of their function. Appendix A gives a fuller description of all of the available instructions.

Table 6-3 Summary of data processing operations in assembly language

Opcode	Operands	Function		
Arithmetic	Arithmetic operations			
ADC	Rd, Rn, Op2 (Add with Carry)	Rd = Rn + Op2 + C		
ADD	Rd, Rn, Op2 (Add)	Rd = Rn + Op2		
MOV	Rd, Op2 (Move)	Rd = Op2		
MVN	Rd, Op2 (Move negative)	Rd = NOT Op2		
RSB	Rd, Rn, Op2 (Reverse subtract)	Rd = Op2 - Rn		
RSC	Rd, Rn, Op2 (Reverse subtract with carry)	Rd = Op2 - Rn - !C		
SBC	Rd, Rn, Op2 (Subtract with carry)	Rd = Rn - Op2 -!C		
SUB	Rd, Rn, Op2 (Subtract)	Rd = Rn - Op2		
Logical ope	Logical operations			
AND	Rd, Rn, Op2 (AND)	Rd = Rn & Op2		
BIC	Rd, Rn, Op2 (Bit clear)	Rd = Rn & NOT Op2		
EOR	Rd, Rn, Op2 (Exclusive OR)	$Rd = Rn \wedge Op2$		
ORR	Rd, Rn, Op2 (OR)	Rd = Rn Op2		
Flag Setting instructions				
CMP	Rn, Op2 (Compare)	Rn – Op2		
CMN	Rn, Op2 (Compare Negative)	Rn + Op2		
TEQ	Rn, Op2 (Test equality)	Rn & Op2		
TST	Rn, Op2 (Test)	Rn ^ Op2		

The purpose and function of many of these instructions will be readily apparent to most programmers, but some require additional explanation.

In the arithmetic operations, notice that the move operations MOV and MVN require only one operand (and this is treated as an operand2 for maximum flexibility, as we shall see). RSB does a reverse subtract – that is to say it subtracts the first operand from the second operand. This

instruction is needed because the first operand is inflexible – it can only be a register value. So to write R0 = 100-R1, we must do RSB R0, R1, #100, as we cannot write SUB R0, #100, R1. ADC and SBC perform additions and subtractions with carry. This lets the programmer synthesize arithmetic operations on values larger than 32 bits.

The logical operations are essentially the same as the corresponding C operators. Notice the use of ORR rather than OR (this is because the original ARM instruction set had three letter acronyms for all data-processing operations). The BIC instruction does an AND of a register with the inverted value of operand 2. If, for example, we wish to clear bit [11] of register R0, we can do this with the instruction BIC R0, R0, #0x800. The second operand 0x800 has only bit [11] set to one, with all other bits at zero. The BIC instruction inverts this operand, giving all bits except bit [11] at a logical one. ANDing this value with the value in R0 has the effect of clearing bit [11] and this result is then written back into R0.

The flag setting instructions modify the Program Status Register (and have no other effect).

6.2.1 Operand 2 and the barrel shifter

The first operand for all data processing operations must always be a register. The second operand is much more flexible and may be either an immediate value (#x), a register (Rm), or a register shifted by an immediate value or register "Rm, shift #x" or "Rm, shift Rs" There are five shift operations: left shift (LSL), logical right-shift (LSR), arithmetic right-shift (ASR), rotate-right (ROR) and rotate-right extended (RRX).

A right shift creates empty positions at the top of the register. In that case, we must differentiate between a logical shift, which simply inserts 0 into the most significant bit(s) and an arithmetic shift, which fills vacant MSBs with the sign bit, from bit [31] of the register. So an ASR operation might be used on a signed value, with LSR used on an unsigned value. No such distinction is required on left-shifts, which always insert 0 to the least significant position.

So, unlike many assembly languages, ARM assembly language does not require explicit shift instructions. Instead, the MOV instruction can be used for shifts and rotates. R0 = R1 >> 2 is done as MOV R0, R1, LSR #2. Equally, it is common to combine shifts with ADD, SUB or other instructions. For example, to multiply R0 by 5, we might write:

```
ADD R0, R0, R0, LSL #2
```

A left shift of n places is effectively a multiply by 2 to the power of n, so this effectively makes R0 = R0 + (4 * R0). A right shift provides the corresponding divide operation, although ASR rounds negative values differently than would division in C.

Apart from multiply and divide, another common use for shifted operands is array index look-up. Consider the case where R1 points to the base element of an array of int (32-bit) values and R2 is the index which points to the nth element in that array. We can obtain the array value with a single load instruction which uses the calculation R1 + (R2 * 4) to get the appropriate address.

Example 6-3 Examples of different ARM instructions showing a variety of operand2 types:

```
add R0, R1, #1 R0 = R2 + 1
add R0, R1, R2 R0 = R1 + R2
add R0, R1, R2, LSL R4 R0 = R1 + R2<<R4
add R0, R1, R2, LSL R3 R0 = R1 + R2<<R3
```

6.3 Multiplication operations

The multiply operations are readily understandable. A key limitation to note is that there is no scope to multiply by an immediate value. Multiplies operate only on values in registers. Multiplication by a constant may need that constant to be loaded into a register first. Later versions of the ARM processor add significantly more multiply instructions, giving a range of possibilities for 8-, 16- and 32-bit data. We will consider these later in the chapter when looking at the DSP instructions.

Table 6-4 summarizes the multiplication assembly language instructions, giving their mnemonic operand, operands and a brief description of their function.

Table 6-4 Summary of multiplication operations in assembly language

Opcode	Operands	Function
Multiplies		
MLA	Rd, Rm, Rs, Rn (Multiply accumulate MAC)	Rd = Rm * Rs + Rn
MLS	Rd,Rn,Rm,Ra (Multiply and Subtract)	Rd = Ra - (Rm * Rs)
MUL	Rd, Rm, Rs (Multiply)	Rd = Rm * Rs
SMLAL	RLo, RHi, Rm, Rs (Signed 64-bit MAC)	RHiLo += Rm * Rs
SMULL	RLo, RHi, Rm, Rs (Signed 64-bit multiply)	RHiLo = Rm * Rs
UMLAL	RLo, RHi, Rm, Rs (Unsigned 64-bit MAC)	RHiLo += Rm * Rs
UMULL	RLo, RHi, Rm, Rs (Unsigned 64-bit multiply)	RHiLo = Rm * Rs

6.3.1 Additional multiplies

We saw in the data-processing instructions that we have the ability to multiply one 32-bit register with another, to produce either a 32-bit result or a 64-bit signed or unsigned result. In all cases, there is the option to accumulate further 32-bit or 64-bit value into the result. Additional multiply instructions have been added, as follows. There are signed most-significant word multiplies, SMMLA, SMMLA and SMMLS. These perform a 32x32-bit multiply in which the result is the top 32 bits of the result, with the bottom 32 bits discarded. The result may be rounded by applying an R suffix, otherwise it is simply truncated. The UMAAL (Unsigned Multiply Accumulate Accumulate Long) performs a 32x32-bit multiply and adds in the contents of two 32-bit registers.

6.4 Memory instructions

ARM processors perform ALU operations only on registers. The only supported memory operations are those which read data from memory into registers, a *load*, or which write registers to memory a *store*. LDR and STR can be conditionally executed, in the same fashion as other instructions.

The LDR (Load Register) instruction has the following possible formats:

```
LDR Rd, [Rn, op2]

or

LDR Rd, [Rn], 0p2
```

Rn + op2 provides the memory address read. Rd is the register to write to. Rn is known as the *base register*, with op2 providing an offset from that base.

A STR (Store Register) instruction has the following format:

```
STR Rd, [Rn, op2]

or

STR Rd, [Rn], op2
```

Again, Rn+op2 gives the address and Rd the register to be stored out to memory.

We may specify the size of the load or store transfer by appending a B for Byte, H for Halfword, or D for Doubleword (64 bits). For loads only, an extra S may be used to indicate a signed byte or halfword (SB for Signed Byte or SH for Signed Halfword). This can be useful because if we load an 8-bit or 16-bit quantity into a 32-bit register we must decide what to do with the most significant bits of the register. For an unsigned number, we simply zero-extend (we write the most significant 16 or 24 bits of the register to zero), but for a signed number, it is necessary to copy the sign bit (bit [7] for a byte, or bit 15 for a halfword) into the top 16 (or 24) bits of the register.

6.4.1 Addressing modes

There are multiple addressing modes which may be used for loads and stores:

- Register addressing: the address is in a register
- *Pre-indexed addressing*: an offset to the base register is added before the memory access. The base form of this is LDR Rd, [Rn, op2]. The offset may be positive or negative and may be an immediate value or another register with an optional shift applied.
- *Pre-indexed with writeback*: This is indicated with a exclamation mark (!) added to the instruction and updates the base register with the offset value.
- *Post-index with writeback*: Here, the offset value is written after the square bracket and is applied after the memory access.

Examples of each of these are shown in Example 6-4 below:

Example 6-4 Examples of addressing modes

```
LDR R0, [R1] @ address pointed to by R1
LDR R0, [R1, R2] @ address pointed to by R1+R2
LDR R0 [R1, R2, LSL #2] @ address is R1 + (R2*4)
LDR R0, [R1, #32]! @ address pointed to by R1+32, then R1:=R1+32
```

6.4.2 Multiple transfers

Load and Store Multiple instructions allow successive words to be read from or written to memory. These are extremely useful for stack operations and for memory copying. Only word values can be operated on in this way and a word aligned address should be used.

The operands are a base register (with an optional! denoting write-back of the base register) with a list of registers between braces. The register list is comma separated, with hyphens used to indicate a range. The order in which the registers are loaded or stored has nothing to do with the order specified in this list. Instead, the operation proceeds in a fixed fashion, with the lowest numbered register always going to the lowest address.

For example:

This instruction reads five registers from the addresses pointed to by register (R10) and because write-back is specified, increments R10 by 20 (5 * 4 bytes) at the end.

```
LDMIA R10!, { R0-R3 ,R12 }
```

The instruction must also specify how to proceed from the base register Rd. The four possibilities are: -IA/-IB (Increment After/Before) and -DA/-DB (Decrement After/Before). These may also specified using aliases (-FD, -FA, -ED and -EA) which work from a stack point of view and specify whether the stack pointer points to a full or empty top of the stack and whether the stack ascends or descends in memory.

By convention, only the FD option is used for stacks in ARM-based systems. This means that the stack pointer points to the last filled location in stack memory and will decrement with each new item of data pushed to the stack.

Figure 6-1 on page 6-11 shows a push of two registers to the stack. Before the STMFD (PUSH) instruction is executed, the stack pointer points to the last occupied word of the stack. After the instruction is completed, the stack pointer has been decremented by 8 (two words) and the contents of the two registers have been written to memory, with the lowest numbered register being written to the lowest memory address.




Figure 6-1 Stack push operation

6.5 Branches

The instruction set provides a number of different kinds of branch instruction. For simple relative branches (those to an offset from the current address), the B instruction is used. Calls to a function, where it is necessary for the return address to be stored in the link register, use the BL instruction.

If we wish to change instruction set (from ARM to Thumb or vice-versa), we use BX, or BLX. These latter cases may also use a value in a register, allowing a jump to anywhere within the 32-bit address space.

We can also specify the PC as the destination register for the result of normal data processing operations such as ADD or SUB, but this is generally deprecated or unsupported in Thumb-2. An additional type of branch instruction can be implemented using either a load (LDR) with the PC as the target, or load multiple (LDM) instruction with PC in the list of registers to be loaded.

Thumb-2 has the compare and branch instruction, which fuses a CMP instruction and a conditional branch, but does not change the CPSR condition code flags. There are two opcodes, CBZ (compare and branch to label if Rn is zero and CBNZ (compare and branch to label if Rn is not zero). These instructions can only branch forward between 4 and 130 bytes. Thumb-2 also has the TBB (Table Branch Byte) and TBH (Table Branch Halfword) instructions. These instructions read a value from a table of offsets (either byte or halfword size) and perform a forward PC-relative branch of twice the value of the byte or the halfword returned from the table. The instruction requires the base address of the table to be specified in one register, and the index in another.

6.6 Integer SIMD instructions

These instructions were first added in the ARMv6 architecture and provide the ability to pack, extract and unpack 8- and 16-bit quantities within 32-bit registers and to perform multiple arithmetic operations such as add, subtract, compare or multiply to such packed data, in a single instruction.

6.6.1 Integer register SIMD instructions

This section describes the SIMD (single instruction, multiple data) operations added in v6 of the ARM Architecture. These should not be confused with the significantly more powerful Advanced SIMD operations which were introduced in the ARM-v7 architecture and are covered in detail in Chapter 19, Chapter 20 and Appendix B.

The v6 SIMD operations make use of the GE (greater than or equal) flags within the CPSR. There is a flag corresponding to each of the four byte positions within a word. Normal data processing operations produce one value and set the N, Z, C and V flags. The SIMD operations produce up to four outputs and set only the GE flags, to indicate overflow. The MSR and MRS instructions can be used to write or read these flags directly.

The general form of the SIMD instructions are that subword quantities in each register are operated on in parallel (for example, four ADDs on four bytes may be performed) and the GE bits are set or cleared according to the results of the instruction. Different types of add and subtract may be specified using appropriate prefixes. For example, QADD16 performs saturating addition on halfwords within a register. ADD8 and SUB8 set the GE bits individually while ADD16 and SUB16 set GE bits [3:2] together based on the top halfword result and [1:0] together on the bottom halfword result.

Also available are ASX and SAX, which reverse halfwords of one operand and add/subtract or subtract/add parallel pairs.




Figure 6-2 ADD v6 SIMD example

The ADD16 instruction shown in Figure 6-2 shows how two separate addition operations are performed by a single instruction. The top halfwords of registers R3 and R0 are added, with the result going into the top halfword of register R1and the bottom halfwords of registers R3 and R0 are added, with the result going into the bottom halfword of register R1. GE[3:2] bits in the CPSR are set based on the top halfword result and GE[1:0] based on the bottom halfword result.

6.6.2 Integer register SIMD multiplies

Like the other SIMD operations, these operate in parallel, on sub-word quantities within registers. The instruction may also include an accumulate option, with add or subtract being able to be specified. The instructions are SMUAD (SIMD multiply and ADD with no accumulate), SMUSD (SIMD multiply and SUB with no accumulate), SMLA (multiply and add with accumulate) and SMLS (multiply and subtract with accumulate). Three suffixes may be added to these instructions.

- X (eXchange) indicates halfwords in Rs are swapped before calculation.
- L (long) indicates 64-bit accumulation.
- *Q* flag set if accumulation overflows.




Figure 6-3 v6 SIMD multiply example

The SMUSD instruction shown in Figure 6-3 performs two signed 16-bit multiplies (top x top and bottom x bottom) and then subtracts the two results. This kind of operation is useful when performing operations on complex numbers (with a real and imaginary component), a common task for filter algorithms.

6.6.3 Sum of absolute differences

Calculating the sum of absolute differences is a key operation in the motion vector estimation component of common video codecs and is carried out over arrays of pixel data. The USAD instruction performs this operation on the bytes within a word.




Figure 6-4 Sum of absolute differences

The USADA8 Rd, Rn, Rm, Ra instruction is illustrated in Figure 6-4. It calculates the sum of absolute differences of the bytes in registers Rn and Rm, adds in the value stored in Ra and places the result in Rd.

6.6.4 Data packing/unpacking

Packed data is common in many video/audio codecs (video data is usually expressed as packed arrays of 8-bit pixel data, audio data may use packed 16-bit samples), and also in network protocols. Before additional instructions were added in architecture v6, this data had to be either loaded with LDRH/LDRB instructions or loaded as words and then unpacked using shift and bit clear operations, both are relatively inefficient. Pack (PKHBT, PKHTB) instructions allow 16-bit or 8-bit values to be extracted from any position in a register and packed into another register. Unpack instructions (UXTH, UXTB, plus many variants, including signed, with addition etc.). can extract 8-bit or 16-bit values from any bit position within a register.

This allows sequences of packed data in memory to be efficiently loaded using word or doubleword loads, unpacked into separate register values, operated upon and then packed back into registers for efficient writing out to memory.




Figure 6-5 Packing and unpacking of 16-bit data in 32-bit registers

In the simple example shown in Figure 6-5, R0 contains two separate 16-bit values, denoted A and B. We can use the UXTH instruction to unpack the two halfwords into registers for further processing and we can then use the PKHBT instruction to pack halfword data from two registers into one.

6.6.5 Byte selection

The SEL instruction allows us to select each byte of the result from the corresponding byte in either the first or the second operand, based on the value of the GE[3:0] bits in the CPSR. The packed data arithmetic operations set these bits as a result of add or subtract operations and SEL can be used after these to extract parts of the data – for example, to find the smaller of the two bytes in each position.

6.7 Saturating arithmetic

Saturated mathematics is commonly used in DSP algorithms. Calculations which return a value higher (or lower) than the largest positive (or negative) number which can be represented do not overflow. Instead the result is set to the largest +/- value (saturated). The ARM instruction set includes a number of instructions which allow easy implementation of such algorithms.

6.7.1 Saturated math instructions

The ARM saturated math instructions operate on either word or halfword sized values. The result of the operation will be saturated to the largest possible positive or negative number. If the result would have overflowed and has been saturated, the overflow flag (CPSR Q bit) is set. This flag is said to be "sticky". Once set it will remain set until explicitly cleared by a write to the CPSR.

The instruction set provides special instructions with this behavior, QSUB and QADD. Additionally, we have QDSUB and QDADD which are provided in support of Q15 or Q31 fixed point arithmetic. These instructions double and saturate their second operand before performing the specified add or subtract.

The Count Leading Zeros (CLZ) instruction returns the number of 0 bits before the most significant set that is set. This can be useful for normalization and for certain division algorithms. To saturate a value to a specific bit position (effectively saturate to a power of two), we may use the USAT or SSAT (unsigned or signed) saturate operations. USAT16 and SSAT16 allow saturation of two halfword values packed within a register.

6.8 Miscellaneous instructions

The remaining instructions cover coprocessor, supervisor call, PSR modification, byte reversal, cache preload, bit manipulation and a few others.

6.8.1 Coprocessor instructions

Coprocessor instructions occupy part of the ARM instruction set. Up to 16 coprocessors may be implemented, numbered 0 to 15 (CP0, CP1 ... CP15). These may either be internal (built-in to the core) or connected externally, through a dedicated interface. Use of external coprocessors is uncommon in older processors and is not supported at all in the Cortex-A series.

- Coprocessor 15 is a built-in coprocessor which provides control over many processor features, including cache and MMU.
- Coprocessor 14 is a built-in coprocessor which controls the hardware debug facilities of the core, such as breakpoint units (discussed in Chapter 27).
- Coprocessor 14 is a built-in coprocessor which controls the hardware debug facilities of the core, such as breakpoint units (discussed in Chapter 27).
- Coprocessors 10 and 11 give access to the floating point and/or NEON hardware in the system.(discussed in Chapter 16-Chapter 18)

If a coprocessor instruction is executed, but the appropriate coprocessor is not present in the system, an undefined instruction exception occurs.

There are five classes of coprocessor instruction

- CDP: Initiate a coprocessor data processing operation
- MRC: Move to ARM register from coprocessor register
- MCR: Move to Coprocessor register from ARM register
- LDC: Load coprocessor register from memory
- STC: Store from coprocessor register to memory.

Multiple register and other variants of these instructions are also available. (MRRC, MCCR, LDCL, STCL etc.).

6.8.2 Coprocessor 15

CP15, the System Control coprocessor, is (despite the name coprocessor) an integral part of the processor and provides control of many features. It can contain up to 16 primary registers, each of size 32-bits. Note, however that access to CP15 is privilege controlled and not all registers are available in user mode. The CP15 register access instructions specify the required primary register, with the other fields in the instruction used to define the access more precisely and increase the number of physical 32-bit registers in CP15. The 16 primary registers in CP15 are named c0 to c15, but are often referred to by a series of letters. For example, the CP15 System Control Register is named CP15.SCTLR. Table 6-5 on page 6-19 summarizes the function of each register used in Cortex-A family processors and we will consider some of these in more

detail when we look at the operation of the cache and MMU. (The list is not exhaustive – the large number of instruction attribute and processor feature registers has been omitted, for example).

Table 6-5 CP15 Register Summary

Main ID Register (MIDR)	Gives identification information for the processor (including part number and revision).
Cache Type Register (CTR)	Gives information about cache hardware (such as cacheline size, indexing and tagging policies).
TCM Type Register (TCMTR)	Gives information about TCM hardware.
TLB Type Register (TLBTR)	Gives information about TLB hardware.
Multiprocessor Affinity Register (MPIDR)	Provides a way to uniquely identify individual processors within a multi-processor system.
Debug Feature Register 0 (ID_DFR0)	Gives information about debug and trace hardware supported.
Auxiliary Feature Register 0 (ID_AFR0)	An Implementation Defined register (one whose purpose is defined by the processor implementer and not mandated by the ARM Architecture).
Cache Size ID Registers (CCSIDR)	Provides information about supported cache policies, associativity and set size (see Chapter 7 <i>Caches</i>).
Cache Level ID Register (CLIDR)	Identifies the cache type at each level and gives information about coherency and unification (see Chapter 7 <i>Caches</i>).
Auxiliary ID Register (AIDR)	Implementation defined.
Cache Size Selection Register (CSSELR)	A Read/Write register which indicates which cache level the CCSIDR applies to.
CP15 c1 System control registers	
System Control Register (SCTLR)	The main processor control register (see Chapter 8 <i>Memory Management Unit</i>).
Auxiliary Control Register (ACTLR) Implementation defined	Implementation specific additional control and configuration options.
Coprocessor Access Control Register (CPACR)	Controls access to all coprocessors except CP14 and CP15.
Secure Configuration Register (SCR)	Used by TrustZone (Chapter 26 Security).
Secure Debug Enable Register (SDER)	Used by TrustZone (Chapter 26 Security).
Non-Secure Access Control Register (NSACR)	Used by TrustZone (Chapter 26 Security).

Table 6-5 CP15 Register Summary (continued)

CP15 c0 ID code, Processor Feature, Memory Model Feature and Instruction Attribute registers		
Translation Table Base Register 0 (TTBR0)	Base address of level 1 page table (see Chapter 8 <i>Memory Management Unit</i>).	
Translation Table Base Register 1 (TTBR1)	Base address of level 1 page table (see Chapter 8 <i>Memory Management Unit</i>).	
Translation Table Base Control Register (TTBCR)	Controls use of TTB0 and TTB1 (see Chapter 8 <i>Memory Management Unit</i>).	
Domain Access Control Register (DACR)	Defines memory access permission for domains (see Chapter 8 <i>Memory Management Unit</i>).	
CP15 c4, Not used		
CP15 c5 and c6, Memory system fault registers		
Data Fault Status Register (DFSR)	Gives status information about the last data fault (see Chapter 12 <i>Other Exception Handlers</i>).	
Instruction Fault Status Register (IFSR)	Gives status information about the last instruction fault (see Chapter 12 Other Exception Handlers).	
Auxiliary Data and Instruction Fault Status Registers (ADFSR and AIFSR)	Gives extra implementation-specific status information about the last fault (see Chapter 12 <i>Other Exception Handlers</i>).	
Data Fault Address Register (DFAR)	Gives the virtual address of the access that caused the most recent precise data abort (see Chapter 12 Other Exception Handlers).	
Instruction Fault Address Register (IFAR)	Gives the virtual address of the access that caused the most recent precise prefetch abort (see Chapter 12 Other Exception Handlers).	
CP15 c7, Cache maintenance and other functions		
Cache and branch predictor maintenance functions	See Chapter 7 Caches.	
Virtual Address to Physical Address translation operations	See Chapter 8 Memory Management Unit.	
Data and Instruction Barrier operations	See Chapter 9 Memory Ordering.	
No Operation (NOP)	This encoding was used for WFI and PLI in ARMv6. These now exist as separate dedicated instructions in ARMv7.	
CP15 c8, TLB maintenance operations		
CP15 c9, Cache and TCM lockdown registers and performance mor	nitors	
CP15 c10, Memory remapping and TLB control registers		
Primary Region Remap Register (PRRR)	Controls mapping of the TEX[0], C, and E memory region attributes (see Chapter 8 <i>Memory Management Unit</i>).	

Table 6-5 CP15 Register Summary (continued)

CP15 c0 ID code, Processor Feature, Memory Model Feature and Instruction Attribute registers		
Normal Memory Remap Register (NMRR)	Gives additional mapping controls for normal memory.	
CP15 c11, Reserved for TCM DMA registers (Not used in C	Cortex-A5, Cortex-A8 or Cortex-A9)	
CP15 c12, Security Extensions registers		
Vector Base Address Register (VBAR)	Used by TrustZone (Chapter 26 Security).	
Monitor Vector Base Address Register (MVBAR)	Used by TrustZone (Chapter 26 Security).	
Interrupt Status Register (ISR)	Used by TrustZone (Chapter 26 Security).	
CP15 c13, Process, context and thread ID registers		
FCSE Process ID Register (FCSEIDR)	See FCSE description Chapter 8 <i>Memory Management Unit</i>).	
Context ID Register (CONTEXTIDR)	See description of ASID Chapter 8 Memory Management Unit).	
Software Thread ID registers	See description of ASID Chapter 8 <i>Memory Management Unit</i>).	
CP15 c14 is not used		
CP15 c15, Implementation defined registers		

All system architecture functions are controlled by reading or writing a general purpose processor register (Rd) from/to a set of registers (Rn) located within coprocessor 15. The opcode_1, opcode_2, and Rm fields of the instruction may also be used to select registers or operations. The format is shown in Example 6-5.

Example 6-5 CP15 Instruction syntax

MRC p15, op1, Rd, CRn, CRm, op2; to read a CP15 register into an ARM register (specified in Rd)

MCR p15, op1, Rd, CRn, CRm, op2; to write a CP15 register from an ARM register (specified in Rd)

We will not go through each of the various CP15 registers in detail, as this would simply duplicate reference information which can readily be obtained from the ARM *Architecture Reference Manual* or product documentation. We will look at one example – the read-only Main ID Register (MIDR).




Figure 6-6 Main ID Register format

In a privileged mode, we can read this register, using the instruction

The result, placed in register Rd, tells software which processor it is running on. The interpretation of the results is as follows

- Bits [31:24] Implementer will be 0x41 for an ARM designed processor.
- Bits [23:20] Major revision number, shows a revision number of the processor.
- Bits [19:16] Architecture code, will be 0xF for architecture v7.
- Bits [15:4] ARM part number. (for example 0xC08 for the Cortex-A8 processor).
- Bits [3:0] Minor revision number, shows a patch revision number of the processor.

6.8.3 SVC

The SVC (supervisor call) instruction, when executed, causes an SVC exception. This is discussed further in Chapter 10 *Exception Handling*. The instruction includes a 24-bit (ARM) or 8-bit (Thumb) number value, which can be examined by the SVC handler code. Through the SVC mechanism, an operating system can specify a set of privileged operations which applications running in user mode can request. This instruction was originally called SWI (Software Interrupt).

6.8.4 PSR modification

Several instructions allow the PSR to be written to, or read from.

- MRS transfers the CPSR or SPSR value to a general purpose register. MSR transfers a general
 purpose register to the CPSR or SPSR. Either the whole status register, or just part of it
 can be updated. In User Mode, all bits may be read, but only the condition flags (_f) are
 permitted to be modified.
- The Change Processor State (CPS) instruction can be used to directly modify the mode and interrupt enable/disable bits in the CPSR.
- SETEND modifies a single CPSR bit, the E (Endian) bit. This can be used in systems with mixed endian data to temporarily switch between little and big-endian memory access.

6.8.5 Bit manipulation

There are instructions which allow bit manipulation of values in registers.

- The Bit Field Insert (BFI) instruction allows a series of adjacent bits from one register (specified by supplying a width value and LSB position) to be placed into another.
- Bit Field Clear (BFC) allows adjacent bits within a register to be cleared.

- The SBFX and UBFX instructions (signed and unsigned bit field extract) Signed and Unsigned Bit Field Extract copy adjacent bits from one register to the least significant bits of a second register, and sign extend or zero extend the value to 32 bits.
- RBIT reverses the order of all bits within a register.

6.8.6 Cache preload

Cache preloading is discussed further in Chapter 17 *Optimizing Code to Run on the ARM Processor*. Two instructions are provided, PLD (Data Cache preload) and PLI (Instruction Cache preload). Both instructions act as hints to the memory system that an access to the specified address is likely to occur soon. Implementations that do not support these operations will treat a preload as a NOP, but all of the Cortex-A family processors described in this book are able to preload the cache.

6.8.7 Byte reversal

Instructions to reverse byte order may be useful for dealing with quantities of the opposite endianness or other data re-ordering operations.

- The REV instruction reverses the bytes in a word.
- REV16 reverses the bytes in each halfword of a register.
- REVSH reverses the bottom two bytes, and sign extends the result to 32 bits.

Figure 6-7 illustrates the operation of the REV instruction, showing how four bytes within a register have their ordering within a word reversed.




Figure 6-7 Operation of the REV instruction

6.8.8 Other instructions

A few other instructions are available.

• The breakpoint instruction (BKPT) will either cause a prefetch abort or cause the processor to enter debug state (depending on the whether the core is in monitor or halt mode debug). This instruction is used by debuggers and does not form part of actual application code.

- Wait For Interrupt (WFI) puts the core into standby mode, which is discussed further in Chapter 21 *Power Management*, along with WFE (Wait for Event). The core stops execution until "woken" by an interrupt or debug event. Note that if WFI is executed with the interrupts disabled, an interrupt will still wake the processor, but no interrupt exception is taken. The processor simply proceeds to the instruction after the WFI. In older ARM processors, WFI was implemented as a CP15 operation.
- A NOP instruction (no-operation) does nothing. It may or may not take time to execute, so the NOP instruction should not be used to insert timing delays into code, instead it is intended to be used as padding to align following instructions.

Chapter 7 Caches

The word cache derives from the French verb cacher, "to hide". A cache is a hidden storage place. The application of this word to a processor is obvious – a cache is a place where the processor can store instructions and data, hidden from the programmer and system. In many cases, it would be true to say that the cache is indeed transparent to, or hidden from the programmer. But very often, as we shall see, it is important to understand the operation of the cache in detail.

When the ARM architecture was first developed, the clock speed of the processor and the access speeds of memory were broadly similar. Today's processors are much more complicated and can be clocked orders of magnitude faster. However, the frequency of the external bus and of memory devices has not scaled to the same extent. It is possible to implement small blocks of on-chip SRAM which can operate at the same speeds of the processor, but such RAM is very expensive in comparison to standard DRAM blocks, which may have thousands of times more capacity. In many ARM-based systems, access to external memory will take tens or even hundreds of cycles.

Essentially, a cache is a small, fast block of memory which (conceptually at least) sits between the processor core and main memory. It holds copies of items in main memory. Accesses to the cache memory happen significantly faster than those to main memory. As the cache holds only a subset of the contents of main memory, it must store both the address of the item in main memory and the associated data. Whenever the processor wants to read or write a particular address, it will first look for it in the cache. Should it find the address in the cache, it will access the data in the cache, rather than having to perform an access to main memory. This significantly increases the potential performance of the system, by reducing the effect of slow external memory access times. An access to an external off-chip memory may require hundreds of processor cycles. It also reduces the power consumption of the system, by avoiding the need to drive external devices.

Cache sizes are small relative to the overall memory used in the system. Larger caches make for more expensive chips. In addition, making an internal processor cache larger can potentially limit the maximum speed of the processor. Significant research has gone into identifying how hardware can determine what it should keep in the cache. Efficient use of this limited resource is a key part of writing efficient applications to run on a processor.

So, we use on-chip SRAM to implement caches, which hold temporary copies of instructions and data from main memory. Code and data have the properties of temporal and spatial locality. This means that programs tend to re-use the same addresses over time (temporal locality) and tend to use addresses which are near to each other (spatial locality). Code, for instance, can contain loops, meaning that the same code gets executed repeatedly or a function may be called multiple times. Data accesses (for example, to the stack) may be limited to small regions of memory. When the memory used over short time periods is not close together, it is often likely that the same data will be re-used. It is this fact that access to RAM by the processor exhibits such locality, and is not truly random, that allows caches to be successful.

Access ordering rules obey the "weakly ordered" model. A read from a location followed by a write to the same location by the same core guarantees that the read returns the value that was at the address before the write occurred.

We will also look at the write buffer. This is a block which decouples writes being done by the processor (when executing store instructions, for example) from the external memory bus. The processor places the address, control and data values associated with the store into a set of FIFOs. This is the write buffer. Like the cache, it sits between the processor core and main memory. This allows the processor to move on and execute the next instructions without having to stop and wait for the slow main memory to actually complete the write operation.

7.1 Why do caches help?

Caches speed things up, as we have seen, because program execution is not random. Programs access the same sets of data repeatedly and execute the same sets of instructions repeatedly. By moving code or data into faster memory when it is first accessed, following accesses to that code or data become much faster. The initial access which provided the data to the cache is no faster than normal. It is the subsequent accesses to the cached values (if there are any such accesses) which are faster and it is from this the performance increase derives. The processor hardware will check all instruction fetches and data reads or writes in the cache, although obviously we need to mark some parts of memory (those containing peripheral devices, for example) as non-cacheable. As the cache holds only a subset of main memory, we need a way to determine (quickly) whether the address we are looking for is in the cache.

7.2 Cache drawbacks

It may seem that caches and write buffers are automatically a benefit, as they speed up program execution. However, they also add some problems which are not present in an uncached core. One such drawback is that program execution time can become non-deterministic.

What this means is that, because the cache is small and holds only a subset of main memory, it fills rapidly as a program executes. Once full, existing code or data is replaced, to make room for new items. So, at any given time, it is typically not possible to be certain whether a particular instruction or data item is to be found in the cache or not.

This means that the execution time of a particular piece of code may vary significantly. This can be something of a problem in hard real-time systems where strongly deterministic behavior is needed.

Furthermore, as we shall see, we need a way to control how different parts of memory are accessed by the cache and write buffer. In some cases, we want the processor to read an external device, such as a peripheral. It would not be sensible to use a cached value of a timer peripheral, for example. Sometimes we want the processor to stop and wait for a store to complete. So caches and write buffers give the programmer some extra work to do.

Sometimes, we need to think about the fact that data in the cache and data in external memory may not be the same. This is referred to as coherency. This can be a particular problem when we have multiple processors or memory agents like an external DMA. We will consider such coherency issues in greater detail later in the book.

7.3 Memory hierarchy

A memory hierarchy in computer science refers to a hierarchy of memory types, with faster/smaller memories closer to the processor and slower/larger memory further away. In most systems, we may have secondary storage, such as disk drives and primary storage such as flash, SRAM and DRAM. In embedded systems, we typically further sub-divide this into on-chip and off-chip memory. Memory which is on the same chip (or at least in the same package) as the processor will typically be much faster.

A cache can be included at any level in the hierarchy and should improve system performance where there is an access time difference between parts of the memory system.

In ARM-based systems, we typically have level 1 (L1) caches, which are connected directly to the processor logic that fetches instructions and handles load and store instructions. These are Harvard caches (that is, there are separate caches for instructions and for data) in all but the lowest performing members of the ARM family and effectively appear as part of the processor. Over the years, the size of L1 caches has increased, due to SRAM size and speed improvements. At the time of writing, 16kB or 32kB cache sizes are most common, as these are the largest RAM sizes capable of providing single cycle access at a processor speed of 1GHz or more.

Many ARM systems have, in addition, a level 2 (L2) cache. This is larger than the L1 cache (typically 256kB, 512kB or 1MB), but slower and is unified (holding both instructions and data). It may be inside the processor itself, as in the Cortex-A8 processor, or be implemented as an external block, placed between the processor and the rest of the memory system. ARM's PL310 is an example of such an external L2 cache controller block.

In addition, we have processors which can be implemented in multi-core clusters in which each core has its own cache. Such systems require mechanisms to maintain coherency between caches, so that when one core changes a memory location, that change is made visible to other cores which share that memory. We discuss this in more detail when we look at multi-processing.

7.4 Cache terminology

A brief summary of terms used in the description may be helpful.

- A *Line* refers to the smallest loadable unit of a cache, a block of contiguous words from main memory.
- The *Index* is the part of a memory address which determines in which line(s) of the cache the address may be found.
- A *Way* is a subdivision of a cache, each way being of equal size and indexed in the same fashion. The line associated with a particular index value from each cache way grouped together forms a set.
- The *Tag* is the part of a memory address stored within the cache which identifies the main memory address associated with a line of data.




Figure 7-1 Cache terminology

7.5 Cache architecture

In a von Neumann architecture, there is a single cache used for instruction and data (a unified cache). A Harvard architecture has separate instruction and data buses and therefore there are two caches, an instruction cache (I-cache) and a data cache (D-cache). In many ARM systems, we may have Harvard level 1 caches backed by a unified level 2 cache.

Let's consider how a cache memory is constructed. The cache needs to hold an address, some data and some status information. The address tells the cache where the information came from in main memory and is known as a *tag*. The total cache size is a measure of the amount of data it can hold; the RAMs used to hold tag values are not included in the calculation. The tag does, however, take up physical space on the silicon. It would be inefficient to hold one word of data for each tag address, so we typically store a *line* of data – normally 8 words for the Cortex-A5, and Cortex-A9 processors or 16 words for the Cortex-A8 processor, with each address. This means that the bottom few bits of the address are not required to be stored in the tag – we need to record the address of a line, not of each byte within the line, so the five or six least significant bits will always be 0.

Associated with each line of data are one or more status bits. Typically, we will have a valid bit, which marks the line as containing data that may be used. (This means that the address tag represents some real value). We will also have one or more dirty bits which mark whether the cache line (or part of it) holds data which is not the same as (newer than) the contents of main memory. We will treat this in more detail later in the chapter.

7.6 Cache controller

This is a hardware block which has the task of managing the cache memory, in a way which is (largely) invisible to the program. It automatically writes code or data from main memory into the cache. It takes read and write memory requests from the processor and performs the necessary actions to the cache memory and/or the external memory.

When it receives a request from the processor, it must check to see whether the requested address is to be found in the cache. This is known as a cache look-up. It does this by comparing a subset of the address bits of the request with tag values associated with lines in the cache. If there is a match (a hit) and the line is marked valid then the read or write will happen using the cache memory.

If there is no match with the cache tags or the tag is not valid, then we have a cache miss and the request must be passed to the next level of the memory hierarchy – an L2 cache, or external memory. It may also cause a cache linefill. A cache linefill causes the contents of a piece of main memory to be copied into the cache. At the same time, the requested data or instructions are streamed to the processor. This process happens transparently and is not directly visible to the programmer.

The processor need not wait for the linefill to complete before using the data. The cache controller will typically access the critical word within the cache line first. For example, if we perform a load instruction which misses in the cache and triggers a cache linefill, the first read to external memory will be that of the actual address supplied by the load instruction. This critical data is supplied to the processor pipeline, while the cache hardware and external bus interface then read the rest of the cache line, in the background.

7.7 Direct mapped caches

We now look at various different ways of implementing caches used in ARM processors, starting with the simplest, a *direct mapped* cache.




Figure 7-2 Direct mapped cache operation

In a direct mapped cache, each location in main memory maps to a single location in the cache. As main memory is many times larger than the cache, many addresses map to the same cache location. Figure 7-2 shows a small cache, with four words per line and four lines. This means that the cache controller will use two bits of the address (bits 3:2) as the offset to select a word within the line and two bits of the address (bits 5:4) as the index to select one of the four available lines. The remaining bits of the address (bits 31:6) will be stored as a tag value.

To look up a particular address in the cache, the hardware simply extracts the index bits from the address and reads the tag value associated with that line in the cache. If the two are the same and the valid bit indicates that the line contains valid data, it has a hit. It can then extract the data value from the relevant word of the cache line, using the offset and byte portion of the address. If the line contains valid data, but does not generate a hit (that is, the tag shows that the cache holds a different address in main memory), then the cache line is removed and is replaced by data from the requested address.

It should be clear that all main memory addresses with the same value of bits [5:4] will map to the same line in the cache. Only one of those lines can be in the cache at any given time. This means that we can easily get a problem called *thrashing*. Consider a loop which repeatedly accesses address 0x40 and 0x80, as in Figure 7-2. When we first read address 0x40, it will not be in the cache and so a linefill takes place putting the data from 0x40 to 0x4F into the cache. When we then read address 0x80, it will not be in the cache and so a linefill takes place putting the data from 0x80 to 0x8F into the cache – and in the process we lose the data from address 0x40 to 0x4F from the cache. The same thing will happen on each iteration of the loop and our

software will perform poorly. Direct mapped caches are therefore not typically used in the main caches of ARM processors, but we do see them in some places – for example in the branch target address cache of the ARM1136 processor.

Processors may have hardware optimizations for situations where the whole cache line is being written to. This is a condition which can take a significant proportion of total cycle time in some systems. For example, this may happen when memcpy() or memset() like functions which perform block copies or zero initialization of large blocks are executed. In such cases, there is no benefit in first reading the data values which will be over-written. Some ARM processors may contain logic to look for the situation where the whole cache line is to be written, or where streams of zeros are written and choose not to perform an initial read in that case.

Cache allocate policies act as a "hint" to the processor, they do not guarantee that a piece of memory will be read into the cache, and as a result, programmers should not rely on that.

7.8 Set associative caches

The main cache(s) of ARM processors are always implemented using a set associative cache. This significantly reduces the likelihood of the cache thrashing seen with direct mapped caches, thus improving program execution speed and giving more deterministic execution. It comes at the cost of increased hardware complexity and a slight increase in power (because multiple tags are compared on each cycle).

With this kind of cache organization, we divide the cache into a number of equally-sized pieces, called ways. The index field of the address continues to be used to select a particular line, but now it points to an individual line in each way. Commonly, there are 2- or 4-ways, but some ARM implementations have used higher numbers (for example, the ARM920T processor has a 64-way cache). Level 2 cache implementations (such as ARM's PL310) may have larger numbers of ways (higher associativity) due to their much larger size. The cache lines with the same index value are said to belong to a set. To check for a hit, we must look at each of the tags in the set.




Figure 7-3 A 2-way set-associative cache

In Figure 7-3, a cache with 2-ways is shown. Data from address 0 (or 0x40, or 0x80) may be found in line 0 of either (but not both) of the two cache ways.

Increasing the associativity of the cache reduces the probability of thrashing. The ideal case is a fully associative cache, where any main memory location can map anywhere within the cache. However, building such a cache is impractical for anything other than very small caches (for example, those associated with MMU TLBs – see Chapter 8). Research shows that the performance improvements are minimal for L1 caches above 4-way associativity, with 8-way or 16-way associativity being more useful for larger level 2 caches.

7.9 A real-life example

Before, we move on to look at write buffers, let's consider an example which is more realistic than the previous two diagrams. Figure 7-4 is a 4-way set associative 32kB Data Cache, with an 8-word cache line length. This kind of cache structure might be found on the Cortex-A9 or Cortex-A5 processors.

The cache line length is eight words (32 bytes) and we have 4-ways. 32kB divided by 4, divided by 32 gives us a figure of 256 lines in each way. This means that we need the eight bits to index a line within a way (bits [12:5]). We need to use bits [4:2] of the address to select from the eight words within the line. The remaining bits [31:13] will be used as a tag.




Figure 7-4 A 32kB 4-way set associative cache

7.10 Virtual and physical tags and indexes

This section assumes some knowledge of the address translation process. Readers unfamiliar with virtual addressing may wish to revisit this section after reading Chapter 8.

In the real-life example above, we were a little imprecise about specification of exactly which address is used to perform cache lookups. Early ARM cores (for example, the ARM720T or ARM926EJ-S processors) used virtual addresses to provide both the index and tag values. This has the advantage that the core can do a cache look-up without the need for a virtual to physical address translation. The drawback is that changing the virtual to physical mappings in the system means that the cache must first be cleaned and invalidated and this can have a significant performance impact. (We will discuss the terms clean and invalidate later in this chapter.)

ARM11 family processors use a different cache tag scheme. Here, the cache index is still derived from a virtual address, but the tag is taken from the physical address. The advantage of a physical tagging scheme is that changes in virtual to physical mappings do not now require the cache to be invalidated. This can have significant benefits for complex multi-tasking operating systems which may frequently modify page table mappings. Using a virtual index has some hardware advantages. It means that the cache hardware can read the tag value from the appropriate line in each way in parallel with actually performing the virtual to physical address translation, giving a fast, single cycle cache response. Such a cache is often described as *Virtually Indexed, Physically Tagged* (VIPT). The Cortex-A8 processor uses a VIPT implementation in its instruction cache, but not its data cache.

However, there is a drawback to a VIPT implementation. For a 4-way set associative 32kB or 64kB cache, bits [12] and/or [13] of the address are needed to select the index. If 4kB pages are used in the MMU, bits [13:12] of the virtual address may not be equal to bits [13:12] of the physical address. There is therefore scope for potential cache coherence problems if multiple virtual address mappings point to the same physical address. This is resolved by placing certain restrictions on such multiple mappings which kernel page table software must obey. This is described as a "page coloring" issue and exists on other processor architectures, for the same reasons.

This problem is avoided by using a physically indexed and physically tagged (PIPT) cache implementation, shown in Figure 7-4 on page 7-12. The Cortex-A series of processors described in this book use such a scheme for their data caches. It means that page coloring issues are avoided, but at the cost of hardware complexity.

7.11 Cache policies

There are a number of different choices which can be made in cache operation. We need to consider what causes a line from external memory to be placed into the cache (*allocation policy*). We need to look at how the controller decides which line within a set associative cache to use for the incoming data (*replacement policy*). And we need to control what happens when the processor performs a write which hits or misses in the cache (*write policy*).

7.12 Allocation policy

When the processor does a cache look-up and the address it wants is not in the cache, it must determine whether or not to perform a cache linefill and place that address in memory.

- A read allocate policy allocates a cache line only on a read. If a write is performed by the
 processor which misses in the cache, the cache is not affected and the write goes to main
 memory.
- A *write allocate* policy allocates a cache line for either a read or write which misses in the cache (and so might more accurately be called a read-write cache allocate policy). For both memory reads which miss in the cache and memory writes which miss in the cache, a cache linefill is performed. This is typically used in combination with a *writeback* write policy on current ARM cores, as we shall see later.

7.13 Replacement policy

When there is a cache miss, the cache controller must select one of the cache lines in the set for the incoming data. The cache line selected is called the *victim*. If the victim contains valid, dirty data, the contents of that line must be written to main memory before new data can be written to the victim cache line. This is called *eviction*.

The *replacement policy* is what controls the victim selection process. The index bits of the address are used to select the set of cache lines, and the replacement policy selects the specific cache line from that set which is to be replaced.

- Round-robin or cyclic replacement means that we have a counter (the victim counter) which simply cycles through the available ways and is incremented each time a cache linefill happens and cycles back to 0 when it reaches the maximum number of ways.
- Pseudo-random replacement randomly selects the next cache line in a set to replace. The
 victim counter is incremented in a pseudo-random fashion and may point to any line in
 the set.

Most ARM cores support both policies. Some cores have additional intelligence which can slightly improve performance, for example by never selecting a full line as the victim when there is still an empty line in the set.

A round-robin replacement policy is generally more predictable, but can suffer from poor performance in certain rare use cases and for this reason, the pseudo-random policy is often preferred.

7.14 Write policy

When the processor executes a store instruction, a cache lookup on the address(es) to be written is performed. For a cache hit on a write, there are two choices.

- Write-through. In which writes are performed to both the cache and main memory. This
 means that the cache and main memory are kept coherent. As there are more writes to
 main memory, a write-through policy is slower than a writeback policy if the write buffer
 fills and therefore is less commonly used in today's systems (although it can be useful for
 debug).
- Writeback. In this case, writes are done only to the cache, and not to main memory. This means that cache lines and main memory may contain different data. The cache line holds newer data, and main memory contains older data (said to be stale). To mark these lines, each line of the cache has an associated dirty bit (or bits). When a write happens which updates the cache, but not main memory, the dirty bit is set. If the cache later evicts a cache line whose dirty bit is set (a dirty line), it writes the line out to main memory. Using a writeback cache policy can significantly reduce traffic to slow external memory and therefore improve performance and save power. However, if there are other agents in the system which can access memory at the same time as the processor, we may need to worry about coherency issues. This is discussed in more detail later. Some ARM processors actually have two dirty bits per cache line, one for each half of the line. This means that if only half of the line is dirty, we need write out only that half. The Cortex-A9 and Cortex-A5 processors both use only a single dirty bit per line.

7.15 Write buffers

A write buffer is a hardware block inside the processor (but sometimes in other parts of the system as well), implemented using a number of FIFOs. It accepts address, data and control values associated with processor writes to memory. When the processor executes a store instruction, it may place the relevant details (the location to write to, the data to be written, the transaction size and so forth) into the buffer. The processor does not have to wait for the write to be completed to main memory. It can simply proceed with executing the next instructions. The write buffer itself will drain the writes accepted from the processor, to the memory system.

A write buffer can increase the performance of the system. It does this by freeing the processor from having to wait for stores to complete. In effect, provided there is space in the write buffer, the write buffer is simply a way to hide latency. If the number of writes is low or well spaced, the write buffer will not become full. If the processor generates writes faster than they can be drained to memory, then the write buffer will eventually fill and there will be little performance benefit.

There is a potential hazard to be considered when thinking about write buffers. What happens if a write goes into a write buffer and then we read from a location that we are going to write to? This is called a *read-after-write* hazard. Different processors handle this problem in different ways. A simple solution is to simply stall the processor on a read to the main memory system, until all pending writes have completed. A more sophisticated approach is to *snoop* into the write buffer and detect the existence of a potential hazard. Hardware may then resolve the hazard either by stalling the read until the relevant write has completed, or it may read the value directly from the write buffer.

Some write buffers have an additional behavior. In particular, they may support write merging (also called write combining). They may take multiple writes (for example, a stream of writes to adjacent bytes) and merge them into one single burst. This can reduce the write traffic to external memory and therefore boost performance.

It will be obvious to the experienced programmer that sometimes the behavior of the write buffer is not what we want when accessing a peripheral, we might want the processor to stop and wait for the write to complete before proceeding to the next step. Sometimes we really want a stream of bytes to be written and we don't want the stores to be combined. Later, we'll look at memory types supported by the ARM architecture and how to use these to control how the caches and write buffers are used for particular devices or parts of the memory map.

7.16 Fetch buffers

Similar components, called fetch buffers, may be used for reads in some systems. In particular, processors typically contain prefetch buffers which read instructions from memory ahead of them actually being inserted into the pipeline. In general, such buffers are transparent to the programmer. We will consider some possible hazards associated with this when we look at memory ordering rules.

7.17 Cache performance and hit rate

The *hit rate* is defined as the number of cache hits divided by the number of memory requests made to the cache during a specified time (normally calculated as a percentage). Similarly, the *miss rate* is the number of total cache misses divided by the total number of memory requests made to the cache. One may also calculate the number of hits or misses on reads and/or writes only.

Clearly, a higher hit rate will generally result in higher performance. It is not really possible to quote example figures for typical software, the hit rate is very dependent upon the size of the critical parts of the code or data operated on and of course, the size of the cache.

There are some simple rules which can be followed to give better performance. The most obvious of these is to enable caches and write buffers and to use them wherever possible (typically for all parts of the memory system which contain code and more generally for RAM and ROM, but not peripherals). Cortex-A family processors will perform extremely poorly if instruction memory is not cached.

Placing frequently accessed data together in memory may be helpful. Fetching a data value in memory involves fetching a whole cache line; if none of the other words in the cache line will be used, there will be little or no performance gain. Smaller code may cache better than larger code and this can sometimes give (seemingly) paradoxical results. For example, a piece of C code may fit entirely within cache when compiled for Thumb (or using the gcc-0space option) but not when compiled for ARM (or when using gcc -03) and as a consequence may actually run faster than the more "optimized" version. We discuss cache considerations in much more detail in Chapter 17 Optimizing Code to Run on the ARM Processor.

7.18 Invalidating and cleaning cache memory

Cleaning and/or invalidation may be required when the contents of external memory have been changed and the programmer wishes to remove stale data from the cache. It may also be required after MMU related activity such as changing access permissions, cache policies, or virtual to physical address mappings.

The word *flush* is often used in discussions of clean/invalidate operations. We avoid the term in this text, as it is not used in a consistent fashion on different microprocessor architectures. ARM generally uses only the terms *clean* and *invalidate*.

- Invalidation of a cache (or cache line) means to clear it of data. This is done by clearing the valid bit of one or more cache lines. The cache always needs to be invalidated after reset. This may be done automatically by hardware, but may need to be done explicitly by the programmer (for example, the Cortex-A9 processor does not do this automatically). If the cache might contain dirty data, it is generally incorrect to simply invalidate it. Any updated data in the cache from writes to writeback cacheable regions would be lost by simple invalidation.
- Cleaning a cache (or cache line) means to write the contents of dirty cache lines out to
 main memory and clear the dirty bit(s) in the cache line. This makes the contents of the
 cache line and main memory coherent with each other. Clearly, this is only applicable for
 data caches in which a writeback policy is used.

Copying code from one location to another (or other forms of "self-modifying" code) may require the programmer to clean and/or invalidate the cache. The memory copy code will use load and store instructions and these will operate on the data side of the processor. If the data cache is using a writeback policy for the area to which code is written, it will be necessary to clean that data from the cache before the code can be executed. This ensures that the instructions stored as data go out into main memory and are then available for the instruction fetch logic. In addition, if the area to which code is written was previously used for some other program, the instruction cache could contain stale code (from before main memory was re-written). Therefore, it may also be necessary to invalidate the instruction cache before branching to the newly copied code.

The commands to clean and/or invalidate the cache are CP15 operations. They are available only to privileged code and may not be executed in user mode. In systems where the TrustZone security extensions are in use, there may be hardware limitations applied to non-secure usage of some of these operations.

CP15 instructions exist which will clean, invalidate, or clean *and* invalidate level 1 data or instruction caches. Invalidation without cleaning is safe only when it is known that the cache cannot contain dirty data – for example a Harvard instruction cache. The programmer may perform the operation on the entire cache, or just on individual lines. These individual lines may be specified either by giving a virtual address to be clean and/or invalidated, or by specifying a line number in a particular set, in cases where the hardware structure is known. The same operations may be performed on the L2 or outer caches and we will look at this later in the chapter.

Of course, these operations will be accessed through kernel code – in Linux, you will use the __clear_cache() function, which you can find in arch/arm/mm/cache-v7.S. Equivalent functions exist in other operating systems – Google Android has cacheflush(), for example.

A common situation where cleaning or invalidation may be required is DMA (Direct Memory Access). When it is required to make changes made by the processor visible to external memory, so that it may be read by a DMA controller, it might be necessary to clean the cache. When external memory is written by a DMA controller and it is necessary to make those changes visible to the processor, the affected addresses will need to be invalidated from the cache.

7.19 Cache lockdown

One of the problems with caches is their unpredictability. It is not generally possible to be certain that a particular piece of code or data is within the cache. This can be problematic because sometimes (particularly in systems with hard real-time requirements), variable and unpredictable execution times cannot be tolerated.

Cache lockdown allows the programmer to place critical code/or and data into cache memory and protect it from eviction, thus avoiding any cache miss penalty. A typical usage scenario might be for code and data of a critical interrupt handler. As cache memory used for lockdown is unavailable for other parts of main memory, use of lockdown effectively reduces the usable cache size. Note that locked down code or data may be still be invalidated and the locked down area may still be immune from replacement. This can make use of lockdown impractical in systems which frequently invalidate the cache.

The smallest lockable unit for the cache is typically quite large—normally one or more cache ways. In a 4-way set associative cache, for example, lockdown of a single way therefore uses a quarter of the available cache space.

7.20 Level 2 cache controller

At the start of this chapter, we briefly described the partitioning of the memory system and explained how many systems have a multi-layer cache hierarchy. The Cortex-A5 and Cortex-A9 processors do not have an integrated level 2 cache. Instead, the system designer may opt to connect an L2 cache controller (named PL310 by ARM) outside of the processor or MPCore instance. This cache controller can support a cache of up 8MB in size, with a set associativity of between four and sixteen ways. The size and associativity are fixed by the SoC designer. The level 2 cache may be shared between multiple processors (or indeed between the processor and other agents, for example a graphics processor). It is possible to lockdown cache data on a per-master per-way basis, allowing management of cache sharing between multiple components.

7.20.1 Level 2 cache maintenance

We saw earlier how the programmer may need the ability to clean and/or invalidate some or all of a cache. This can be done by writing to memory-mapped registers within the L2 cache controller in the case where the cache is external to the processor, (as with the Cortex-A5 and Cortex-A9 processors), or through CP15 (where the level 2 cache is implemented inside the processor (as with the Cortex-A8 processor). Where such operations are performed by having the processor perform memory-mapped writes, the processor needs a way of determining when the operation is complete. It does this by polling a further memory-mapped register within the L2 cache.

The PL310 Level 2 cache controller operates only on physical addresses. Therefore, to perform cache maintenance operations, it may be necessary for the program to perform a virtual to physical address translation. The PL310 provides a "cache sync" operation which forces the system to wait for pending operations to complete.

7.21 Point of coherency and unification

For set/way based clean or invalidate, the point to which the operation can be defined is essentially the next level of cache. For operations which use a virtual address, the architecture defines two conceptual points.

- Point of coherency (PoC). For a particular address, the PoC is the point at which all blocks (for example, processors, DSPs, or DMA engines) which can access memory, are guaranteed to see the same copy of a memory location. Typically, this will be the main external system memory.
- Point of unification (PoU). The PoU for a processor is the point at which the instruction and data caches and the translation table walks of the processor are guaranteed to see the same copy of a memory location. For example, a unified level 2 cache would be the point of unification in a system with Harvard level 1 caches and a TLB to cache page table entries. Readers unfamiliar with the terms page table walk or TLB will find these described in Chapter 8. If no external cache is present, main memory would be the Point of unification.

In the case of an MPCore (an example of a Inner Shareable shareability domain, using the terminology from Chapter 9 *Memory Ordering*), the point of unification is where instruction and data caches and page table walks of all the processors within the MPCore are guaranteed to see the same copy of a memory location.

Knowledge of the PoU allows self-modifying code to ensure future instruction fetches are correctly from the modified version of the code. They may do this by using a two-stage process:

- clean the relevant data cache entries (by address)
- invalidate instruction cache entries (by address)

Similarly, we can use the clean data cache entry and invalidate TLB operations to ensure that all writes to the translation tables are visible to the MMU.

7.21.1 Exclusive cache mode

The Cortex-A series processors can be connected to a level 2 cache controller which supports an exclusive cache mode. This makes the processor data cache and the L2 cache exclusive. At any specific time, an address may be cached in either a L1 data cache or in the L2 cache, but not both. This increases the usable space and efficiency of the L2 cache connected to the processor. In practice, exclusive mode is not widely used. It can be difficult to correctly invalidate lines in multi-processor systems, for example.

Both the processors and the L2 cache controller have to be explicitly placed into this mode by software. The processor bit to do this is found in the CP15.ACTLR (Auxiliary Control Register). The effects of this are as follows:

- When a data cache line is evicted from the L1 data cache (due to replacement by a linefill), the victim line is always evicted to the L2 cache, even if it is clean
- For dirty lines in the L2 Cache, any read request to this address from the processor causes clean and invalidate of the L2 line to external memory and a linefill to the L1 Cache. This means the data is now in the L1 cache and no longer in the L2 cache.

7.22 Parity and ECC in caches

So-called *soft errors* are increasingly a concern in today's systems. Smaller transistor geometries and lower voltages give circuits an increased sensitivity to perturbation by cosmic rays and other background radiation, alpha particles from silicon packages or from electrical noise. This is particularly true for memory devices which rely on storing small amounts of charge and which also occupy large proportions of total silicon area. In some systems, mean-time-between-failure could be measured in seconds if appropriate protection against soft errors was not employed.

The ARM architecture provides support for parity and *Error Correcting Code* (ECC) in the caches (and TCMs). Parity simply means that we have an additional bit which marks whether the number of bits with the value one is even (or odd, depending upon the scheme chosen). This provides a simple check against single bit errors. An ECC scheme allows detection of multiple bit failures and possible recovery from soft errors, but recovery calculations may take several cycles. Implementing a processor which is tolerant of level 1 cache RAM accesses taking multiple clock cycles significantly complicates the processor design. ECC is therefore more commonly used only on blocks of memory (for example, the Level 2 Cache), outside the processor.

Tag RAMs are written only on cache linefills and during certain cache maintenance operations. At the time the write is performed, hardware calculates the parity bit and stores it in the tag. On every cache lookup, parity is calculated for the value read back and compared with the stored value. If the parity is not correct, a prefetch or data abort exception will be generated. In this situation, the (CP15.DFSR) fault status and (CP15.DFAR) fault address registers (see Chapter 12) are set appropriately. The cache data RAMs can be protected in a similar fashion, although in the data cache it is also necessary to update the parity information on stores which hit in the cache. Detection of soft errors on valid and dirty bits is less straightforward as these may be written one bit at a time, which makes recalculating the parity difficult.

7.23 Tightly coupled memory

An alternative to using cache lockdown is the so-called *Tightly Coupled Memory* (TCM). TCM is a block of fast memory located next to the core. It appears as part of the memory system within the address map and gives similar response times to a cache. It may be used to hold instructions or data required for real-time code which needs deterministic behavior. It may be regarded as fast scratchpad memory local to the processor. The contents of TCM are not initialized by the processor. It is the responsibility of the programmer to copy required code and data into the tightly coupled memory, before enabling use of the TCM. The programmer may also have to tell the ARM which physical address to locate the TCMs within the memory map.

As TCM is more suited to systems running simpler operating systems and where determinism is a key requirement, it is not supported in Cortex-A series processors and so is not described further here.

Chapter 8 **Memory Management Unit**

This chapter describes the main concepts of virtual memory systems and memory management. An important function of a Memory Management Unit (MMU) is to allow us to manage tasks as independent programs running in their own private virtual memory space. A key feature of such a virtual memory system is address relocation, which is the translation of the (virtual) address issued by the processor core to a different (physical) address in main memory. The translation is done by the MMU hardware and is transparent to the application (ignoring for the moment any performance issues).

In multi-tasking embedded systems, we typically need a way to partition the memory map and assign permissions and memory attributes to these regions of memory. In more advanced systems, running more complex operating systems, like Linux, we need even greater control over the memory system. More advanced operating systems typically need to use a hardware-based MMU.

The MMU allows tasks or applications to be written in a way which requires them to have no knowledge of the physical memory map of the system, or about other programs which may be running at the same time. This makes programming of applications much simpler, as it allows us to use the same virtual memory address space for each. This virtual address space is separate from the actual physical map of memory in the system. The MMU translates addresses of code and data from the virtual view of memory to the physical addresses in the real system. Applications are written, compiled and linked to run in the virtual memory space. Virtual addresses are those used by the programmer, compiler and linker when placing code in memory. Physical addresses are those used by the actual hardware system. It is the responsibility of the operating system to program the MMU to translate between these two views of memory. Figure 8-1 on page 8-2 shows an example system, illustrating the virtual and physical views of memory.




Figure 8-1 Virtual and physical views of memory

The ARM MMU carries out this translation of virtual addresses into physical addresses. In addition, it controls memory access permissions and memory ordering, cache policies etc. for each region of memory. When the MMU is disabled, all virtual addresses map one-to-one to the same physical address (a "flat mapping"). If the MMU cannot translate an address, it generates an abort exception on the core and provides information to the core about what the problem was.

8.1 Virtual memory

The MMU allows multiple programs to be run simultaneously at the same virtual address while being actually stored at different physical addresses. In fact, the MMU allows us to build systems with multiple virtual address maps. Each task can have its own virtual memory map. The OS Kernel places code and data for each application in physical memory, but the application itself does not need to know where that is.

The key feature of the MMU hardware is address translation. It does this using *Page Tables*. These contain a series of entries, each of which describes the physical address translation for part of the memory map. Page table entries are organized by virtual address. In addition to describing the translation of that virtual page to a physical page, they also provide access permissions and memory attributes for that page.

Addresses generated by the processor core are virtual addresses. The MMU essentially replaces the most significant bits of this virtual address with some other value, to generate the physical address (effectively defining a base address of a piece of memory). The lower bits are the same in both addresses (effectively defining an offset in physical memory from that base address). The portion of memory which is represented by these lower bits is known as a page. The ARM MMU supports a multi-level page table architecture with two levels of page table: level 1 (L1) and level 2 (L2). We will discuss the meaning of level 1 and level 2 in a moment. A single set of page tables is used to give the translations and memory attributes which apply to instruction fetches and to data reads or writes. The process in which the MMU accesses page tables to translate addresses is known as *page table walking*.

8.2 Level 1 page tables

Let's take a look at the process by which a virtual address is translated to a physical address using level 1 page table entries on an ARM processor. The first step is to locate the page table entry associated with the virtual address.

There is usually a single level 1 page table (sometimes called a master page table). It can contain two basic types of page table entry. The L1 page table divides the full 4GB address space into 4096 equally sized 1MB sections. The L1 page table therefore contains 4096 entries, each entry being word sized. Each entry can either hold a pointer to the base address of a level 2 page tables or a page table entries for translating a 1MB section. If the page table entry is translating a 1MB section, then it gives the base address of the 1MB page in physical memory.

To locate the relevant entry in the page table, we simply take the top 12 bits of the virtual address and use those to index to one of the 4096 words within the page table.

The base address of the L1 page table is known as the translation table base address and is held within a register in CP15 c2. It must be aligned to a 16kB boundary.




Figure 8-2 Finding the address of the level 1 page table entry

To take a simple example, we place our L1 page table at address 0x12300000. The processor core issues virtual address 0x00100000. The top 12 bits [31:20] define which 1MB of virtual address space is being accessed. In this case 0x001, so we need to read table entry [1]. Each entry is one word (4 bytes). To get the offset into the table we must multiply the entry number by entry size:

0x001 * 4 = Address offset of 0x004

The address of the entry is 0x12300000 + 0x004 = 0x12300004.

So, upon receiving this virtual address from the processor, the MMU will read the word from address 0x12300004. That word is an L1 page table entry. Figure 8-3 on page 8-5 shows the format of a L1 page table entry.

An L1 page table entry can be one of four possible types:

- A fault entry that generates an abort exception. This may be either a prefetch or data abort, depending on the type of memory access. This effectively indicates virtual addresses which are unmapped.
- A 1MB section translation entry
- An entry that points to an L2 page table. This allows a 1MB piece of memory to be further sub-divided into smaller pages.
- A 16MB supersection. This is a special kind of 1MB section entry, which requires 16 entries in the page table.

The least significant two bits [1:0] in the entry define which one of these the entry contains (with bit [18] being used to differentiate between a section and supersection).




Figure 8-3 Level 1 page table entry format

It can be seen that the page table entry for a section (or supersection) contains the physical base address used to translate the virtual address. You can also observe that many other bits are given in the page table entry, including the access permissions (AP) and cacheable (C)/bufferable(B) types, which we will examine later in this chapter. This is all of the information required to access the corresponding physical address and in these cases, the MMU does not need to look beyond the L1 table.

Figure 8-4 on page 8-6 summarizes the translation process for an address translated by a section entry in the L1 page table.




Figure 8-4 Generating a physical address from a level 1 page table entry

In a page table entry for a 1MB section of memory, the upper 12 bits of the page table entry replace the upper 12 bits of the virtual address when generating the physical address, as Figure 8-3 on page 8-5 shows.

A supersection is a 16MB piece of memory, which must have both its virtual and physical base address aligned to a 16MB boundary. As L1 page table entries each describe 1MB, we need 16 consecutive, identical entries within the table to mark a supersection. In *Choice of page sizes* on page 8-11, we discuss why supersections can be useful.

8.3 Level 2 page tables

An L2 page table has 256 word-sized entries, requires 1kB of memory space and must be aligned to a 1kB boundary. Each entry translates a 4kB block of virtual memory to a 4kB block in physical memory. A page table entry can give the base address of either a 4kB or 64kB page.

There are three types of entry used in L2 page tables, identified by the value in the two least significant bits of the entry.

- A large page entry points to a 64kB page.
- A small page entry points a 4kB page.
- A fault page entry generates an abort exception if accessed.

Figure 8-5 shows the format of L2 page table entries.




Figure 8-5 Format of a level 2 page table entry

As with the L1 page table entry, a physical address is given, along with other information about the page. Type extension (TEX), shareable (S), and access permission (AP, APX) bits are used to specify the attributes necessary for the ARMv7 memory model. The C and B bits control (along with TEX) the cache policies for the memory governed by the page table entry. The nG bit defines the page as being global (applies to all processes) or non global (used by a specific process). We will discuss all of these bits in more detail later in this chapter.




Figure 8-6 Generating the address of the level 2 page table entry

In Figure 8-6 on page 8-7 we see how the address of the L2 page table entry (PTE) that we need is calculated by taking the (1kB aligned) base address of the level 2 page table (given by the level 1 page table entry) and using 8 bits of the virtual address (bits [19:12]) to index within the 256 entries in the L2 page table.

Figure 8-7 summarizes the address translation process when using two layers of page tables. Bits [31:20] of the virtual address are used to index into the 4096-entry L1 page table, whose base address is given by the CP15 TTB register. The L1 page table entry points to an L2 page table, which contains 256 entries. Bits [19:12] of the virtual address are used to select one of those entries which then gives the base address of the page. The final physical address is generated by combining that base address with the remaining bits of the physical address.




Figure 8-7 Summary of generation of physical address using the L2 page table entry

8.4 The Translation Lookaside Buffer

We have seen that a single memory request from the processor core can result in a total of three memory requests to external memory – one for the level one page table walk, a second access for the L2 page table walk and then finally the original request from the core. This seems like it would be ruinous for performance of the system. Fortunately, page table walks are relatively uncommon events in the majority of systems, due to another part of the MMU.

The *Translation Lookaside Buffer* (TLB) is a cache of page translations within the MMU. On a memory access, the MMU first checks whether the translation is cached in the TLB. If the requested translation is available, we have a TLB hit, and the TLB provides the translation of the physical address immediately. If the TLB does not have a valid translation for that address, we have a TLB miss and an external page table walk is required. This newly loaded translation can then be cached in the TLB for possible reuse.

The exact structure of the TLB differs between implementations of the ARM processors. What follows is a description of a typical system, but individual implementations may vary from this. There are one or more micro-TLBs, which are situated close to the instruction and data caches. Addresses with entries which hit in the micro-TLB require no additional memory look-up and no cycle penalty. However, the micro-TLB has only a small number of mappings (typically eight on the Instruction side and eight on the Data side). This is backed by a larger main TLB (typically 64 entries), but there may be some penalty associated with accesses which miss in the micro-TLB but which hit in the main TLB. Figure 8-8 shows how each TLB entry contains physical and virtual addresses, but also attributes (such as memory type, cache policies and access permissions) and potentially an ASID value (discussed later in the chapter).

The TLB is like other caches and so has a TLB line replacement policy and victim pointer, but this is effectively transparent to the programmer (although see the next section on maintaining TLB coherency). If the page table entry is a valid one, the virtual address, physical address and other attributes for the whole page or section are stored as a TLB entry. If the page table entry is not valid, the TLB will not be updated. The ARM architecture requires that only valid page table descriptors are cached within the TLB.




Figure 8-8 Illustration of TLB structure

8.5 TLB coherency

When the operating system changes page table entries, it is possible that the TLB could contain stale translation information. The OS should therefore take steps to invalidate TLB entries. There are several CP15 operations available, which allow a global invalidate of the TLB or removal only of specific entries. As speculative instruction fetches and data reads may cause page table walks, it is essential to invalidate the TLB when a valid page table entry is changed. Invalid page table entries cannot be cached in TLB and so may be changed without invalidation.

The Linux kernel has a number of functions which use these CP15 operations, including flush_tlb_all() and flush_tlb_range(). Such functions are not typically required by device driver or application code.

Many processors provide support for locking individual entries into the TLB. This can be useful in systems which require a deterministic response time for a particular piece of code (for example an interrupt service routine) and don't want to worry about cycle counts being affected by occasional page table walks. This is less commonly encountered in architecture v7-A profile devices, where deterministic behavior is not typically required.

8.6 Choice of page sizes

This is essentially controlled by the operating system, but it is worth being aware of the considerations involved when selecting page sizes. Smaller page sizes allow finer control of a block of memory and potentially can reduce the amount of unused memory in a page. If a task needs 7kB of data space, then there is less unused space if it is allocated two 4kB pages as opposed to a 64kB page or a 1MB section. Smaller page sizes also allow increased precision of control over permissions, cache properties and so forth.

However, with increased page sizes, each entry in the TLB holds a reference to a larger piece of memory. It is therefore more likely that a TLB hit will occur on any access and so there will be fewer page table walks to slow external memory. For this reason, 16MB supersections may be used with large pieces of memory which do not require detailed mapping. In addition, each L2 page table requires 1kB of memory. In some systems, memory usage by page tables may be important.

8.7 Memory attributes

We have seen how page table entries allow the MMU hardware to translate virtual to physical addresses. However, they also specify a number of attributes associated with each page, including access permissions, memory type and cache policies.

8.7.1 Memory Access Permissions

The Access Permission (AP and APX) bits in the page table entry give the access permission for a page. SeeTable 8-1.

An access which does not have the necessary permission (or which faults) will be aborted. On a data access, this will result in a precise data abort exception. On an instruction fetch, the access will be marked as aborted and if the instruction is not subsequently flushed before execution, then a prefetch abort exception will be taken. Faults generated by an external access will not, in general, be precise.

Information about the address of the faulting location and the reason for the fault is stored in CP15 (the fault address and fault status registers). The abort handler may then take appropriate action – for example, modifying page tables to remedy the problem and then returning to the application to re-try the access. Alternatively, the application which generated the abort may have a problem and need to be terminated. Later in the chapter, we shall see how Linux uses faults and aborts as a mechanism to manage use of memory by applications.

APX AP **Privileged** Unprivileged Description 0 00 No Access No Access Permission Fault 0 01 Read/Write No Access Privileged Access only 0 10 Read/Write Read No user mode write Read/Write Read/Write 0 Full Access 11 1 00 Reserved 1 01 Read No Access Privileged Read Only 1 10 read Read Read Only Reserved 1 11

Table 8-1 Summary of Access Permission encodings

In addition, there are two bits in the CP15:CTLR that act to over-ride the Access Permissions from the page table entry. These are the system (S) bit and the ROM (R) bit and their use is deprecated in ARMv6 and later versions of the ARM architecture. Setting the S bit changes all pages with "no access" permission to allow read access for privileged modes. Setting the R bit changes all pages with "no access" permission to allow read access. These bits can be used to provide access to large blocks of memory without the need to change lots of page table entries.

8.7.2 Memory attributes

ARM architecture versions 4 and 5 allowed the programmer to specify the memory access behavior of pages by configuring whether the cache and write buffer could be used for that location. This simple scheme is inadequate for today's more complex systems and processors, where we may have multiple levels of caches, hardware managed coherency between multiple

processors sharing memory and/or processors which can speculatively fetch both instructions and data. The new memory attributes added to the ARM architecture in ARMv6 and extended in the ARMv7 architecture are designed to meet the above needs.

Table 8-2 shows how the TEX, C and B bits within the page table entry are used to set the memory attributes of a page and also the cache policies to be used. The meaning of memory attributes is discussed in Chapter 9, while the cache policies were described in Chapter 7.

The final entry within the table needs further explanation. For normal cacheable memory, the two least significant bits of the TEX field are used to provide the outer cache policy (perhaps for level 2 or level 3 caches) while the C and B bits give the inner cache policy (for level 1 and any other cache which is to be treated as inner cache). This allows us to specify different cache policies for both the inner and outer cache. For example, on some older processors, outer cache may support write allocate, while the L1 cache may not. Such processors should still behave correctly when running code which requests this cache policy, of course.

Table 8-2 Memory type and cacheable properties encoding in page table entry

TEX	С	В	Description	Memory Type
000	0	0	Strongly Ordered	Strongly Ordered
000	0	1	Sharable Device	Device
000	1	0	Outer and Inner Writethrough, no allocate on write	Normal
000	1	1	Outer and Inner Writeback, no allocate on write	Normal
001	0	0	Outer and Inner Non-cacheable	Normal
001	-	-	Reserved	-
010	0	0	Non-shareable device	Device
010	-	-	Reserved	-
011	-	-	Reserved	-
1XX	Y	Y	Cached memory XX = Outer Policy YY = Inner Policy	Normal

It is clear that five bits to define memory types gives 32 possibilities. It is unlikely that a kernel will wish to use all 32 possibilities. In practice only a handful will actually be needed. Therefore the hardware provides CP15 registers (the "primary region remap registers") which allow us to remap the interpretation of TEX, C and B bits, so that TEX[0], C and B are used to describe memory types. This means that up to 8 different mappings from the above table can be used and a particular value of TEX[0], C and B associated with the mapping. In this mode of operation, the TEX[2:1] bits are freed up and can be used in an OS defined way. Later in this chapter, we will see why an OS may wish to have "spare" bits within a page table entry that it is able to modify freely. This mode is selected through the TRE bit (TEX Remap) in the CP15 control register.

8.7.3 Domains

The ARM architecture has an unusual feature which allows regions of memory to be tagged with a domain ID. There are 16 domain IDs provided by the hardware and CP15 c3 contains the domain access control register (DACR) which holds a set of 2-bit permissions for each domain number. This allows each domain to be marked as no-access, *manager* mode or *client* mode.

No-access causes an abort on any access to a page in this domain, irrespective of page permissions. Manager mode ignores all page permissions and allows full access. Client mode uses the permissions of the pages tagged with the domain.

The use of domains is deprecated in the ARMv7 architecture, but in order for access permissions to enforced, it is still necessary to assign a domain number to a section and to ensure that the permission bits for that domain are set to client.

8.8 Multi-tasking and OS usage of page tables

In most systems using Cortex-A series processors, we will have a number of applications or tasks running concurrently. Each task will have its own unique page tables residing in physical memory. Typically, much of the memory system is organized so that the virtual-to-physical address mapping is fixed, with page table entries that never change. This typically is used to contain operating system code and data and also the page tables used by individual tasks.

Whenever an application is started, the operating system will allocate it a set of page table entries which map both the actual code and data used by the application to physical memory. If the application requires to map in code or extra data space (for example through a malloc() call), then the kernel may subsequently modify these tables. When a task completes and the application is no longer running, the kernel may remove any associated page table entries and re-use the space for a new application. In this way, multiple tasks can be resident in physical memory. Upon a task switch, the kernel switches page table entries to page in the next thread to be run. In addition, the dormant tasks are completely protected from the running task. This means that the MMU does not allow the running task to access the code or data of the kernel or of other user privilege tasks.

When the page table entries are changed, an access by code to a particular virtual address may now translate to different location in physical memory. This can give rise to several possible problems. The ARM architecture has some key features to try to mitigate the performance impact of these.

Older ARM processor cores (from the ARM7 and ARM9 family) have cache tags which store virtual addresses. When page table mappings are changed, the caches may contain invalid data from the old page table mapping. To ensure memory coherency, the caches would need to be cleaned and invalidated. This can have a significant performance impact, as often instructions and data from a location which has just been invalidated would then need to be re-fetched from external memory. However, all Cortex-A series processors use physically tagged caches. This means that no coherency problems are created by changing page table entries.

In addition, the TLB may also have cached old page table entries and these will need to be invalidated. We will discuss ways in which this can be avoided later in the chapter.

8.8.1 Application Space ID

When we described the page table bits earlier, we noted a bit called nG (not Global). If the nG bit is set for a particular page, it means that the page is associated with a specific application and is not global. This means that when the MMU performs a translation, it uses both the virtual address and an ASID value.

The ASID is a number assigned by the OS to each individual task. This value is in the range 0-255 and the value for the current task is written in the ASID register (accessed via CP15 c13). When a page table walk occurs and the TLB is updated and the entry is marked as non-global, the ASID value will be stored in the TLB entry in addition to the normal translation information. Subsequent TLB look-ups will only match on that entry if the current ASID matches with the ASID that is stored in the entry. This means that we can have multiple valid TLB entries for a particular page (marked as non-global), but with different ASID values. This significantly reduces the software overhead of context switches, as it avoids the need to flush the on-chip TLBs. The ASID forms part of a larger (32-bit) process ID register that can be used in task aware debugging.

Figure 8-9 on page 8-16 illustrates this. Here, we have multiple applications (A, B and C), each of which is linked to run from virtual address 0. Each application is located in a separate address space in physical memory. There is an ASID value associated with each application and this

means that we can have multiple entries within the TLB at any particular time, which will be valid for virtual address 0. Only the entry which matches the current ASID will be used for translation, if the mapping is marked as non-global.




Figure 8-9 ASIDs in TLB mapping same virtual address

8.8.2 Translation Table Base Register 0 and 1

A further potential difficulty associated with managing multiple applications with their individual page tables is that there may need to be multiple copies of the L1 page table, one for each application. Each of these will be 16kB in size. Most of the entries will be identical in each of the tables, as typically only one region of memory will be task-specific, with the kernel space being unchanged in each case. Furthermore, if there is a need to modify a global page table entry, then the change will be needed in each of the tables.

To help reduce the effect of these problems, a second translation table base register can be used. CP15 contains two translation table base registers, TTBR0 and TTBR1. A control register (the TTB Control Register) is used to program a value in the range 0 to 7. This value (denoted by N) tells the MMU how many of the upper bits of the virtual address it should check to determine which of the two TTB registers to use.

When N is 0 (the default), all virtual addresses are mapped using TTBR0. With N in the range 1-7, the hardware looks at the most significant bits of the virtual address. If the N most significant bits are all zero, then TTBR0 is used, otherwise TTBR1 is used.

For example, if N is set to 7, any address in the bottom 32MB of memory will use TTBR0 and the rest of memory will use TTBR1. This means that the application-specific page table pointed to by TTBR0 will contain only 32 entries (128 bytes). The global mappings are in the table pointed to by TTBR1 and only one table needs to be maintained.

When these features are used, a context switch will typically require the Operating System to simply change the TTBR0 and ASID values, using CP15 instructions. However, as these are two separate, non-atomic operations, some care is needed to avoid problems associated with speculative accesses occurring using the new value of one register together with the older value of the other. OS Programmers making use of these features should become familiar with the sequences recommended for this purpose in the ARM *Architecture Reference Manual*.

8.8.3 The Fast Context Switch Extension

The Fast Context Switch Extension (FCSE) is a deprecated feature which was added to the ARMv4 architecture. It allows multiple independent tasks to run in a fixed, overlapping area at the bottom of the virtual memory space without the need to clean the cache or TLB on a context switch. It does this by modifying virtual addresses by substituting a process ID value into the top seven bits of the virtual address (but only if that address lies within the bottom 32MB of memory). Some ARM documentation distinguishes modified virtual addresses (MVA) from virtual addresses (VA). This distinction is useful only when the FCSE is used. Since it is deprecated, we will not discuss the FCSE any further.

8.9 ARM Linux use of page tables

We will start with a brief look at how Linux uses page tables and then move on to how this maps to the ARM architecture implementation of page tables. The reader may find it helpful to refer also the source code of the Linux kernel, in particular the ARM specific code associated with page tables which may be found in the following file:-

```
arch/arm/include/asm/pgtable.s
```

Some parts of the following discussion rely on a basic understanding of the Linux kernel, exception handling and/or the memory ordering concepts explained in Chapter 9. The first-time reader may therefore wish to skip over this section.

8.9.1 Levels of page tables in Linux

Linux uses a three level page table structure, but this can be implemented in a way which uses only two levels of page tables – *Page Global Directory* (PGD) and *Page Table Entry* (PTE). The intermediate third level *Page Middle Directory* (PMD) is defined as being of size 1 and folds back into the PGD.

The ARCH include file /asm-arm/page.h contains the definition:-

```
#define __pmd(x) ((pmd_t) { (x) } )
```

This tells the kernel that PMD has just one entry, effectively bypassing it.

8.9.2 Emulation of dirty and accessed bits

Linux makes use of a bit associated with each page which marks whether the page is dirty (the page has been modified by the application and may therefore need to be written from memory to disk when the page is no longer needed).

This is not directly supported in hardware by ARM processors, and must therefore be implemented by kernel software. When a page is first created, it is marked as read-only. The first write to such a page (a clean page) will cause an MMU permission fault and the kernel data abort handler will be called. The Linux memory management code will mark the page as dirty, if the page should indeed be writable, using the function handle_pte_fault(). The page table entry is modified to make it allow both reads and writes and the TLB entry invalidated from the cache to ensure the MMU now uses the newly modified entry. The abort handler then returns to re-try the faulting access in the application.

A similar technique is used to emulate the Accessed bit, which shows when a page has been accessed. Read and Write accesses to the page generate an abort. The Accessed bit is then set within the handler, the access permissions are changed and we then return. This is all done transparently to the application which actually accessed the memory. The kernel makes use of these bits when swapping pages in and out of memory – it is preferred to swap out pages which have not been used recently and of course we have to ensure that pages which have been written to have their new contents copied to the backing store.

On older cores, it was necessary for Linux to maintain two hardware PTE tables – one that was actually used by the processor and another one holding Linux state information (for example, Young and Dirty bits). The extensions to the TEX field mean that there are spare bits within the page table entry, available for use by the operating system, potentially removing the need for two tables. A detailed description of this is not useful to most programmers. Essentially, three TEX bits, plus a C bit and a B bit giving five bits in each PTE which give information about the memory type, which allows 32 possible types of memory. Most operating systems need only

five or six different types. Therefore we can use a feature called TEX Remap which allows us to specify which settings we will actually use and encode those within 3 bits of the PTE, leaving two bits free.

8.9.3 Kernel MMU initialization

Linux creates an initial set of page tables when it boots. The kernel execution starts in arch/arm/kernel/head. S with the MMU and both caches disabled. After determining the type of processor it is running on, the function __create_page_tables() is called. This sets up an initial set of MMU tables used only during this initialization. It finds the physical address of RAM in the system and determines where to place the initial page table. This is immediately below the kernel entry point. (Recall that an L1 page table is 16kB, so must start 16kB below). Mappings are created using 1MB sections, with no L2 page tables. After these initial page tables are setup, we then branch to a function which invalidates the caches and TLB. The next step is to enable the MMU. Once the MMU is enabled, we are now working with virtual rather than physical addresses. The code in __enable_mmu() enables the caches, branch predictors and then the MMU. It is important that this is code is in a location which has identical virtual and physical addresses. If the virtual address and physical address of the section which holds this code is not identical, the behavior may be unpredictable.

The page table mappings discussed above will allow the position dependent code of kernel startup to run. These mappings will later be overwritten (albeit with identical entries) by the function paging_init(). This is called from start_kernel() via setup_arch() and creates the master L1 page table. The mdesc->mapio() function creates these mappings and must be modified when porting Linux to a new system. The master L1 page table (init_mm) also maps the System RAM. The virtual address range PAGE_OFFSET to (PAGE_OFFSET + ram size) are mapped to the physical address range of the RAM in the system.

8.9.4 Memory allocation (vmalloc)

Applications running under Linux may need to make system calls for memory allocation. kmalloc() allocates memory which is contiguous in physical memory, while vmalloc() allocates memory which is contiguous only in virtual memory space.

When a process calls <code>vmalloc()</code>, a range of virtual addresses are allocated and this may cause a change to the L1 page table. Processes which were created before this may have L1 tables which do not contain the newly allocated region. What happens is that the master L1 page table is updated, but we do not at the same time modify all of the L1 tables for all processes. Instead, when a process whose page table does not contain the new mapping tries to access the <code>vmalloc</code> region, an abort occurs and the kernel handler copies the new mapping from the master table into the table for that process.

8.9.5 Protecting the bottom of memory

Linux allows us to define the lowest virtual address for a user space mapping. This allows the exception vector table (if it is placed at address 0) to be protected. It also permits a safe test for null pointers. If we try to load data from address 0, we know something has gone wrong! Typically, the first 4kB page of memory is protected.

#define FIRST_USER_ADDRESS PAGE_SIZE

8.9.6 Linux use of page table entries and ASIDs

Linux will typically make use only of 4kB pages. 1MB sections can be used for linear kernel mapping and I/O regions. A total of six different page types are used.

- Pages which contain code (applications or shareable libraries) will, by default, be marked as read-only and may be mapped by multiple applications.
- Data pages are writable but may have the XN bit set, to trap erroneous execution of data.
- User mmap() files (and pages which hold stack or heap) will be marked as "Normal cacheable", as will pages for kernel modules, kernel linear mapping, and vmalloc() space. Pages which hold heap or stack are typically allocated as a result of a page fault. New heap pages are mapped to a read-only zero initialized page. They are allocated on the first write to the page. The page table entries themselves are accessed through the kernel linear mapping.
- Device mapped pages are created as a result of a call to the function mmap() for a /dev file, with the device driver code responsible for the memory mapping. mmap() allows driver code to associate a range of user-space addresses to device memory.
- The page which contains the exception vectors will be read-only for user mode code and will be normal, cacheable.
- Static and Dynamic I/O mappings will be marked as Device memory, with no user mode access

Strongly Ordered memory is not used directly by the kernel, by default, but may be selected for specific tasks such as Power management code.

ASIDs are dynamically allocated and not guaranteed to be constant during the lifetime of a process. As the ASID register provides only eight bits of ASID space and we may have more than 256 processes, Linux has a scheme for allocating ASIDs. For a new process, we simply increment the last ASID value used. When the last value is reached, we have to take some action. The TLB is flushed (across all processors in an SMP system). The value in the top 24 bits in the Context ID register, which may be considered as a "generation" number, is incremented. Stepping to a new generation means that all ASID values from the previous generation are now invalid and ASID numbering is restarted. On a context switch, processes which use an older generation version of the Context ID value are assigned a new ASID.

The ASID numbering scheme is global across cores. Individual threads within a process have the same memory map and therefore share an ASID, but may run independently on separate processors in an MP (multi-processing) system. We will consider multi-processing in much greater detail later in this book.

Chapter 9 **Memory Ordering**

Older implementations of the ARM architecture (for example, ARM7TDMI) execute all instructions in program order and each instruction is completely executed before the next instruction is started.

Newer micro-processors employ a number of optimizations which relate to the way memory accesses are performed. As we saw in previous chapters, the speed of execution of instructions by the processor is significantly higher than the speed of external memory. Caches and write buffers are used to hide the latency associated with this difference in speed. One potential effect of this is to re-order memory accesses. The order in which load and store instructions are executed by the processor will not necessarily be the same as the order in which the accesses are seen by external devices.




Figure 9-1 Memory ordering example

In Figure 9-1, we have three instructions listed in program order. The first instruction performs a write to external memory which in this example, misses in the cache (Access 1). It is followed in program order by two reads, one which misses in the cache (Access 2) and one which hits in the cache (Access 3). Both of the read accesses can potentially complete before the write buffer completes the write associated with Access 1. Hit-under-miss behaviors in the cache mean that a load which hits in the cache (like Access 3) can complete before a load earlier in the program which missed in the cache (like Access 2).

In the main, it is still possible to preserve the illusion that the hardware executes instructions in the order written to the programmer. There are generally only a few cases where the programmer has to worry about such effects. For example, when modifying CP15 registers or when copying or otherwise changing code in memory, it may be necessary for the programmer to explicitly make the processor wait for such operations to complete.

For very high performance processors, such as the Cortex-A9 processor, which supports speculative data accesses, multi-issuing of instructions, cache coherency protocols and out-of-order execution in order to make further performance gains, there are even greater possibilities for reordering. In general, the effects of this reordering are invisible to the programmer, in a single processor system. The processor hardware takes care of many possible hazards for us. It will ensure that address dependencies are respected and ensure the correct value is returned by a read, allowing for potential modifications caused by earlier writes.

However, in cases where we have multiple processors which communicate through shareable memory (or share data in other ways), then memory ordering considerations become more important. In general, we are most likely to care about exact memory ordering at points where multiple execution threads must be synchronized.

Processors which conform to the ARM v7-A architecture employ a weakly ordered model of memory. Reads and writes to normal memory may be re-ordered by hardware, with such re-ordering being subject only to address dependencies and explicit memory barrier instructions. In cases where we need stronger ordering rules to be observed, we must communicate this to the processor through the memory type attribute of the page table entry

which describes that memory. Enforcing ordering rules on the processor limits the possible hardware optimizations and therefore reduces performance and increases power consumption. The programmer therefore needs to understand when to apply such ordering constraints.

In this chapter, we will consider the memory ordering model of the ARM architecture. We will look at the different types of memory (and other memory attributes) which are assigned to pages using translation table entries. We will look at the barrier instructions in ARM Assembly language (and accessible through C intrinsics). Finally we will look at the support for coherency between SMP clusters and the concept of coherency domains, as well as considering some common cases where memory ordering problems may be encountered.

9.1 ARM memory ordering model

Three memory types are defined in the ARM Architecture. All regions of memory are configured as one of these three types.

- Strongly Ordered
- Device
- Normal.

In addition, for normal and device memory, it is possible to specify whether the memory is shareable (accessed by other agents) or not. For normal memory, inner and outer cacheable properties may be specified.

9.1.1 Strongly Ordered

Accesses to Strongly Ordered memory follow a strong memory-ordering model. Access rules for this memory are as follows:

- The number and size of accesses will be preserved. Accesses will be atomic, and will not be interrupted part way through.
- Both read and write accesses may have side-effects on the system. Accesses are never cached. Speculative accesses will never be performed.
- Accesses cannot be unaligned.
- The order of accesses to Strongly Ordered memory is guaranteed to correspond to the program order of instructions which access Strongly Ordered or Device memory. In the ARM v7 architecture, the processor can re-order Normal memory accesses around Strongly Ordered memory accesses.
- Accesses to Strongly Ordered memory locations will incur a significant performance penalty. The programmer is therefore recommended to avoid the use of Strongly Ordered memory where possible.

9.1.2 Device

Access rules for this memory are as follows:

- The number and size of accesses will be preserved. Accesses will be atomic, and will not be interrupted part way through.
- Both read and write accesses may have side-effects on the system. Accesses are never cached. Such accesses, though, may be buffered. The processor is not, in general, required to wait for the access to complete. Speculative accesses will never be performed.
- Accesses cannot be unaligned.
- The order of accesses is preserved so that they correspond to the order of memory access instructions in code, with respect to other Device accesses of the same memory type.

Device memory is usually used for system peripherals.

Regions of device memory type are further described using the Shareable attribute. The ordering requirements for Device memory are that program order is respected only between device accesses of the same type. An access to device, shareable memory does not have to be performed in program order with respect to an access to Device, non-Shareable memory and vice-versa. On some ARM processors, memory accesses to areas marked as Device, non-Shareable will be performed using a separate interface, the private peripheral port.

9.1.3 Normal memory

Normal memory is used to describe most parts of the memory system. All ROM and RAM devices are considered to be normal memory. All code to be executed by the processor must be in normal memory. Code is not architecturally permitted to be in a region of memory which is marked as Device or Strongly Ordered.

The properties of normal memory are as follows:

- The processor may repeat both read and write accesses because there are no side-effects associated with either action and repeated read accesses return the last value written to that address.
- The processor can pre-fetch or speculatively access additional memory locations, with no side-effects (if permitted by MMU access permission settings). The processor will not perform speculative writes, however.
- Unaligned accesses can be performed.
- Multiple accesses can be merged by processor hardware into a smaller number of accesses
 of a larger size. Multiple byte writes could be merged into a single double-word write, for
 example.

Regions of normal memory must also have cacheability attributes described (see cache chapter for details of the supported cache policies). The ARM architecture supports cacheability attributes for Normal memory for two levels of cache, the inner and outer cache. The mapping between these levels of cache and the implemented physical levels of cache is implementation defined.

Inner refers to the innermost caches, and always includes the processor level 1 cache. An implementation might not have any outer cache, or it may apply the outer cacheability attribute to L2 and/or L3 cache. For example, in a system containing a Cortex-A9 processor and the PL310 Level 2 Cache controller, the PL310 is considered to be the outer cache. The Cortex-A8 Level 2 Cache can be configured to use either inner or outer cache policy.

Normal memory must also be specified either as shareable or non-shareable.

A region of Normal memory with the non-shareable attribute is one which is used only by this core. There is no requirement for the processor to make accesses to this location coherent with other processors. If other processors do share this memory, then any coherency issues must be handled in software. For example, this can be done by having individual processors perform cache maintenance and barrier operations.

A region with the shareable attribute set is one which may be accessed by other processors or masters in the system. Data accesses to memory in this region by other processors within the same "shareability domain" are coherent. This means that the programmer does not need to take care of the effects of data or unified caches. In situations where cache coherency is not maintained between processors for a region of shared memory, the programmer would have to explicitly manage coherency themselves.

Architecture version 7 allows the programmer to specify shareable memory as "inner, shareable" or "outer, shareable" (this latter case means that the location is both inner and outer shareable).

The outer shareable attribute allows the definition of systems containing clusters of processors. Within a cluster, the data caches of the processors are coherent for all data accesses which have the inner shareable attribute. Between clusters, the caches are not coherent for data accesses which only have the inner shareable attribute, but are for data accesses which have the outer

shareable attribute. Each cluster is said to be in a different shareability domain for the inner shareable attribute and in the same shareability domain for the outer shareable attribute. Such clusters are not supported in the Cortex-A5, Cortex-A8 or Cortex-A9 processors.

9.2 Memory barriers

A memory barrier is an instruction which requires the processor to apply an ordering constraint to memory operations which occur before and after the memory barrier instruction in the program. Such instructions may also be known as memory fences in other architectures (for example, the x86).

The term memory barrier may also be used to refer to a compiler instruction which prevents the compiler from scheduling data access instructions across the barrier when performing optimizations. For example in GCC, we can use the inline assembler memory "clobber", to indicate that the instruction changes memory and therefore the optimizer may not re-order memory accesses across the barrier. The syntax is as follows:

```
asm volatile("" ::: "memory");
```

Here, however, we are looking at hardware memory barriers, provided through dedicated ARM assembly language instructions. As we have seen, processor optimizations such as caches, write buffers and out-of-order execution can result in memory operations occurring in an order different from that specified in the executing code. Normally, this re-ordering is invisible to the programmer and application developers do not normally need to worry about memory barriers. However, there are cases where we may need to take care of such ordering issues, for example in device drivers or when we have multiple observers of the data which need to be synchronized.

The ARM architecture specifies memory barrier instructions, which allow the programmer to force the processor to wait for memory accesses to complete. These instructions are available in both ARM and Thumb code, in both user and privileged modes. In older versions of the architecture, these were performed using CP15 operations in ARM code only. Use of these is now deprecated, although preserved for compatibility.

Let's start by looking at the practical effect of these instructions in a uni-processor system. Note that this description is a simplified version of that given in the Architecture Reference Manual, what is written here is intended to introduce the usage of these instructions. The term explicit access is used to describe a data access resulting from a load or store instruction in the program. It does not include instruction fetches.

- DSB (Data Synchronization Barrier) This instruction forces the processor to wait for all pending explicit data accesses to complete before any further instructions can execute. There is no effect on pre-fetching of instructions.
- DMB (Data Memory Barrier) This instruction ensures that all memory accesses in program order before the barrier are observed in the system before any explicit memory accesses that appear in program order after the barrier. It does not affect the ordering of any other instructions executing on the processor, or of instruction fetches.
- *ISB* (*Instruction Synchronization Barrier*) This flushes the pipeline and prefetch buffer(s) in the processor, so that all instructions following the ISB are fetched from cache or memory, after the instruction has completed. This ensures that the effects of context altering operations, (for example, CP15 or ASID changes or TLB or branch predictor operations) executed before the ISB instruction are visible to any instructions fetched after the ISB. This does not in itself cause synchronization between data and instruction caches, but is required as a part of such an operation.

Several options may be specified with the DMB or DSB instructions, to provide the type of access and the shareability domain it should apply to, as follows:

- SY This is the default and means that the barrier applies to the full system.
- ST A barrier which waits only for stores to complete.
- *ISH* A barrier which applies only to the inner shareable domain.

- ISHST A barrier which combines the above two (that is, it only stores to the inner shareable.
- *NSH* A barrier only to the point of unification. (See Chapter 7).
- NSHST A barrier that waits only for stores to complete and only out to the point of unification.
- *OSH* Barrier operation only to the outer shareable domain.
- OSHST Barrier operation that waits only for stores to complete, and only to the outer shareable domain.

To make sense of this, we need to use a more general definition of the DMB and DSB operations in a multi-core system. The use of the word processor (or agent) in the following text does not necessarily mean a processor and also could refer to a DSP, DMA, hardware accelerator or any other block that accesses shared memory.

The DMB instruction has the effect of enforcing memory access ordering within a shareability domain. All cores within the sharability domain are guaranteed to observe all explicit memory accesses before the DMB instruction, before they observe any of the explicit memory accesses after it.

The DSB instruction has the same effect as the DMB, but in addition to this, it also synchronises the memory accesses with the full instruction stream, not just other memory accesses. This means that when a DSB is issued, execution will stall until all outstanding explicit memory accesses have completed. Once all outstanding reads have completed and the write buffer is drained, execution resumes as normal.

It may be easier to appreciate the effect of the barriers by considering an example. Consider the case of a Cortex-A9 MPCore containing four cores. These cores operate as an SMP cluster and form a single shareability domain. When a single core within the cluster executes a DMB instruction, that core will wait for all data memory accesses in program order before the barrier to complete, before any explicit memory accesses that appear in program order after the barrier. This way, it can be guaranteed that all cores within the cluster will see the accesses on either side of that barrier in the same order as the core that performs them. If the DMB ISH variant is used, the same is not guaranteed for external observers such as DMA controllers or DSPs.

9.2.1 Memory barrier use example

Consider the case where we have two processors A and B and two addresses in normal memory (Addr1 and Addr2) held in processor registers. Each processor executes two instructions as shown in Example 9-1:

Example 9-1 Code example showing memory ordering issues

Processor A:

STR R0, [Addr1] LDR R1, [Addr2]

Processor B:

STR R2, [Addr2] LDR R3, [Addr1]

Here, there is no ordering requirement and we can make no statement about what value will be in Addr1 and Addr2 at the end. The addresses Addr1 and Addr2 are independent and there is no requirement on either processor to execute the load and store in the order written in the program, or to care about the activity of the other processor.

There are therefore four possible legal outcomes of this piece of code, with four different sets of values from memory ending up in Processor A R1 and Processor B R3:

- A gets the "old" value, B gets the "old" value.
- A gets the "old" value, B gets the "new" value.
- A gets the "new" value, B gets the "old" value.
- A gets the "new" value, B gets the "new" value.

If we were to involve a third processor, C, we should also note that there is no requirement that it would observe either of the stores in the same order as either of the other processors. It is perfectly permissible for both A and B to see an old value in Addr1 and Addr2, but for C to see the new values.

So, let's consider the case where the code on B looks for a flag being set by A and then reads memory – for example if we are passing a message from A to B. We might now have code similar to that shown in Example 9-2

Example 9-2 Possible ordering hazard with postbox

Processor A:

```
STR R0, [Msg] @ write some new data into postbox STR R1, [Flag] @ new data is ready to read
```

Processor B:

```
Poll_loop:
LDR R1, [Flag]
CMP R1,#0 @ is the flag set yet?
BEQ Poll_loop
LDR R0, [Msg] @ read new data.
```

Again, this might not behave in the way that is expected. There is no reason why Processor B is not allowed to perform the read from [Msg] before the read from [Flag]. This is normal, weakly ordered memory and the processor has no knowledge about a possible dependency between the two. The programmer must explicitly enforce the dependency by inserting a memory barrier. In this example, we actually need TWO memory barriers. Processor A needs a DMB between the two store operations, to make sure they happen in the programmer specified order. Processor B needs a DMB before the LDR R0, [Msg] to be sure that the message is not read until the flag is set.

9.2.2 Address dependencies

The architecture specifies that when a value returned by a load is used in the generation of an address for a subsequent memory access, the two accesses must occur in program order. This is known as an address dependency. The address dependency persists even if the value from the first load does not actually change the address (because, for example, it is masked off). An address dependency is not created, however, by using the data from the load to set the PSR condition code flags and then executing a load or store conditionally.

Programmers familiar with the Alpha architecture are likely to be familiar with this concept, as it did not enforce such address dependencies and so, for example, could load data before it had loaded the pointer to the data.

So, taking our previous example, in place of the second DMB, we could have the code shown in Example 9-3:

Example 9-3 Code to illustrate an address dependency

Processor A:

```
STR R0, [Msg] @ write some new data into postbox
DMB [ST]@ make sure other CPUs see message before flag
STR R1, [Flag] @new data is ready to read
```

Processor B:

```
Poll_loop:

LDR R1, [Flag]

CMP R1,#0 @ is the flag set yet?

BEQ Poll_loop

AND R1,R1,#0

LDR R0, [Msg] @ read new data.
```

As we use R1 to calculate the address to load R0 from, the load cannot be done speculatively before we know what the value of R0 is (in this case, it will always be 0 and therefore not affect the address!)

9.2.3 Avoiding deadlocks with a barrier

Here is another case which can cause a deadlock if barrier instructions are not used. Consider a situation where one processor (A) writes to an address and then polls for an acknowledge value from another processor (B).

Example 9-4 shows the type of code which can cause a problem.

Example 9-4 Deadlock example

Processor A:

```
STR R0, [Addr] @ write some data
Poll_loop:
    LDR R1, [Flag]
    CMP R1,#0 @ is the flag set yet?
    BEQ Poll_loop
```

Processor B:

```
Poll_loop2:

LDR R1, [Addr]

CMP R1,#0 @ is the flag set yet?

BEQ Poll_loop2

STR R0, [Flag]
```

As there is no requirement for processor A's store to [Addr] to ever complete (it could be sitting in a write buffer while the memory system is kept busy reading the flag), both processors could deadlock, waiting for the other. Inserting a DMB after the STR of processor A forces its store to be observed by processor B before processor A will read from Flag. In fact, for the Cortex-A5MP

and Cortex-A9MP processors, this DMB is not actually required as the MP extensions will make it unnecessary. However, most programmers prefer not to think too hard about whether a barrier is needed and are advised to include one anyway!

9.2.4 WFE and WFI Interaction with barriers

The WFE (Wait For Event) and WFI (Wait For Interrupt) instructions, discussed further in the chapter on Power Management, allow us to stop execution and enter a low-power state. If we need to ensure that all memory accesses prior to executing WFI or WFE have been completed (and made visible to other processors), we must insert a DSB instruction.

A further consideration relates to usage of WFE (Wait For Event) and SEV (Send Event) in an MP system. These instructions allow us to reduce the power consumption associated with a lock acquire loop (a spinlock). A processor which is attempting to acquire a mutex may find that some other processor already has the lock. Instead of having the processor repeatedly poll the lock, we can suspend execution and enter a low-power state, using the WFE instruction. We wake either when an interrupt or other asynchronous exception is recognized, or another processor sends an event (with the SEV instruction). The processor that had the lock will use the SEV instruction to wake-up other processors in the WFE state after the lock has been released. For the purposes of memory barrier instructions, the Event signal is not treated as an explicit memory access. We therefore need to take care that the update to memory which releases the lock is actually visible to other processors before the SEV instruction is executed. This requires the use of a DSB. DMB is not sufficient as it only affects the ordering of memory accesses without synchronizing them to a particular instruction, whereas DSB will prevent the SEV from executing until all preceding memory accesses have been seen by other processors.

9.3 Cache coherency implications

The caches are largely invisible to the application programmer. However they can become visible when there is a breakdown in the coherency of the caches, when memory locations are changed elsewhere in the system or when memory updates made from the application code must be made visible to other parts of the system.

A system containing an external DMA device and a processor provides a simple example of possible problems. There are two situations in which a breakdown of coherency can occur. If the DMA reads data from main memory while newer data is held in the processor's cache, the DMA will read the old data. Similarly, if a DMA writes data to main memory and stale data is present in the processor's cache, the processor may continue to use the old data.

Therefore dirty data which is in the ARM Data Cache must be explicitly cleaned before the DMA starts. Similarly, if the DMA is copying data to be read by the ARM, then it must be certain that the ARM data cache does not contain stale data (the cache will not be updated by the DMA writing memory and this may need the ARM to clean and/or invalidate the affected memory areas from the cache(s) before starting the DMA. As all ARMv7-A processors can do speculative memory accesses, it will also be necessary to clean and/or invalidate after using the DMA.

9.3.1 Issues with copying code

Boot code, kernel code or JIT compilers may copy programs from one location to another, or modify code in memory. There is no hardware mechanism to maintain coherency between instruction and data caches. The programmer must invalidate stale data from the instruction cache by invalidating the affected areas, and ensure that the data written has actually reached the main memory. Specific code sequences including instruction barriers are needed if the processor is then intended to branch to the modified code.

9.3.2 Compiler reordering optimizations

It is important to understand that memory barrier instructions apply only to hardware re-ordering of memory accesses. Inserting a hardware memory barrier instruction may not have any direct effect on compiler re-ordering of operations. The volatile type qualifier in C tells the compiler that the variable may be changed by something other than the code that is accessing it. This is often used for C language access to memory mapped I/O, allowing such devices to be safely accessed through a pointer to a volatile variable. The C standard does not provide rules relating to the use of volatile in systems with multiple processors. So, although we can be sure that volatile loads and stores will happen in program specified order with respect to each other, there are no such guarantees about re-ordering of accesses relative to non-volatile loads or stores. This means that we cannot rely on solely the use of volatile to implement mutexes.

Note				
ARM's RVCT	includes a similar	intrinsic, called	lschedule_ba	arrier().

9.4 Linux use of barriers

ARM Linux has a number of memory barrier primitives which map to ARM Assembly instructions in a portable fashion. They are as follows:

mb(): Memory Barrier. Load and stores preceding the memory barrier are

committed to memory before any load and stores following the barrier

rmb() Read Memory Barrier: Orders loads only

wmb() Write Memory Barrier: Orders stores only

These also force the compiler not to perform instruction rescheduling around the barrier. All of Linux's locking primitives include any needed barrier.

There are also SMP capable versions of these barriers, smp_mb(), smp_rmb() and smp_wmb(). We will consider SMP programming in Chapter 23.

Chapter 10 **Exception Handling**

In this chapter, we look at how ARM processors respond to exceptions – also known as traps or interrupts in other architectures. All microprocessors need to respond to external asynchronous events, such as a button being pressed, or a clock reaching a certain value. Normally, there is specialized hardware which activates input lines to the processor. This causes the microprocessor to temporarily stop the current program sequence and execute a special handler routine. The speed with which a processor can respond to such events may be a critical issue in system design. Indeed in many embedded systems, there is no "main" program as such – all of the functions of the system are handled by code which runs from interrupts and assigning priorities to these is a key area of design. Rather than have the processor constantly polling the flags from different parts of the system to see if there is something to be done, we instead allow the system to tell the processor that something needs to happen, by generating an interrupt. Complex systems have very many interrupt sources with different levels of priority and requirements for nested interrupt handling (where a higher priority interrupt may interrupt a lower priority one).

In normal program execution, the program counter increments through the address space, with branches in the program modifying the flow of execution (for example, for function calls, loops, and conditional code). When an exception occurs, this sequence is interrupted.

In addition to responding to external interrupts, there are a number of other things which can cause the processor to take an exception, both external (reset, external aborts from the memory system) and internal (MMU generated aborts or OS calls using the SVC instruction). Dealing with interrupts and exceptions causes the ARM core to switch between modes and copy some registers into others. Readers new to the ARM architecture may wish to refresh their understanding of the modes and registers previously discussed, before continuing with this chapter.

We start by introducing exceptions and see how the ARM processor handles each of the different types and what they are used for. We then look in more detail at interrupts and discuss mechanisms of interrupt handling on ARM and standard interrupt handling schemes.

10.1 Types of exception

As we have already seen, the A and R classes of architecture support seven processor modes, six privileged modes called *FIQ*, *IRQ*, *SUPERVISOR*, *ABORT*, *UNDEFINED* and *SYSTEM*, and the non-privileged *USER* mode. The current mode may change under software control or when processing an exception.

However, the unprivileged user mode can switch to another mode only by generating an exception.

An exception is any condition that needs to halt normal execution and instead run software associated with each exception type, known as an exception handler.

When an exception occurs, the processor saves the current status and the return address, enters a specific mode and possibly disables hardware interrupts. Execution is then forced from a fixed memory address called an exception vector. This happens automatically and is not under direct control of the programmer.

The following types of exception exist:

Interrupts

There are two types of interrupts provided on ARM processor, called IRQ and FIQ.

FIQ is higher priority than IRQ. FIQ also has some speed advantages owing to its position in the vector table and the higher number of banked registers available in FIQ mode. This potentially saves processor clock cycles on pushing registers to the stack within the handler. Both of these kinds of exception are typically associated with input pins on the processor – external hardware asserts an interrupt request line and the corresponding exception type is raised once the current instruction finishes executing, assuming that the interrupt is not disabled.

Aborts

Aborts may be generated either on instruction fetches (prefetch aborts) or data accesses (data aborts). They may come from the external memory system giving an error response on a memory access (indicating perhaps that the specified address does not correspond to real memory in the system). Alternatively, the abort may be generated by the memory management unit (MMU) of the processor. An operating system may use MMU aborts to dynamically allocate memory to applications. An instruction may be marked within the pipeline as aborted, when it is fetched. The prefetch abort exception is taken only if the processor then actually tries to execute it. The exception takes place before the instruction actually executes. If the pipeline is flushed before the aborted instruction reaches the execute stage of the pipeline, the abort exception will not occur. A data abort exception happens when a load or store instruction executes and is considered to happen after the data read or write has been attempted. The ARMv7 architecture distinguishes between precise and imprecise aborts. Precise aborts are those generated by the MMU or on those external accesses where the processor must actually stop and wait for the access to complete before continuing. The architecture does not require particular classes of externally aborted accesses to be precise.

For example, on a particular processor implementation, it may be the case that an external abort reported on a page table walk is treated as precise, but this is not required to be the case for all processors. For precise aborts, the abort handler can be certain which instruction caused the abort and that no further instructions were executed after that instruction. This is in contrast to an imprecise abort, which results when the external memory system reports an error on an access. In this case, the abort handler cannot determine which instruction caused the problem (or further instructions may have executed after the one which generated the abort). For example, if a buffered write receives an error response from the external

memory system, further instructions will have been executed after the store. This means that it will be impossible for the abort handler to fix the problem and return to the application. All it can do is to kill the application which caused the problem. Device probing therefore needs special handling, as externally reported aborts on reads to non-existent areas will generate imprecise, asynchronous aborts even when such memory is marked as Strongly Ordered, or Device. Generation of imprecise aborts is controlled by the CPSR A bit. If the A bit is set, then imprecise aborts from the external memory system will be recognized by the core, but no abort exception will be generated immediately. Instead, the processor keeps the abort pending until the A bit is cleared and takes an exception at that time. This bit is set by default on reset, and certain other exception types. Kernel code will typically ensure (through the use of a barrier instruction) that pending imprecise aborts are recognized against the correct application. If a thread has to be killed due to an imprecise abort, it needs to be the correct one!

Reset

All processors have a reset input and will take the reset exception immediately after they have been reset. It is the highest priority exception and cannot be masked.

Exceptional Instructions There are two classes of instruction which can cause exceptions on the ARM. The first is the supervisor call (SVC), previously known as Software Interrupt (SWI). This is typically used to provide a mechanism by which user mode programs can pass control to privileged, kernel code in the OS to perform OS-level tasks. The second is an undefined instruction. The architecture defines certain bit-patterns as corresponding to undefined opcodes. Trying to execute one of these causes an undef exception to be taken. In addition, executing coprocessor instructions for which there is no corresponding coprocessor hardware will also cause this trap to happen. Some instructions may be executed only in a privileged mode (for example, SMC) and executing these from user mode will cause an undefined instruction exception.

When an exception occurs, code execution passes to an area of memory called the vector table. Within the table just one word is allocated to each of the various exception types and this will usually contain a branch instruction to the actual exception handler.

You can write the exception handlers in either ARM or Thumb-2 code. The CP15 SCTLR.TE bit is used to specify whether exception handlers will use ARM or Thumb-2. When handling exceptions, the prior mode, state, and registers of the processor must be preserved so that the program can be resumed after the exception has been handled.

10.2 Entering an exception handler

When an exception occurs, the ARM processor automatically does the following things:

- Preserves the address of the next instruction, in the link register (LR) of the new mode.
- Copies CPSR to the SPSR, one of the banked registers specific to each (non-user) mode of operation.
- Modifies the CPSR mode bits to a mode associated with the exception type. The other CPSR mode bits are set to values determined by bits in the CP15 System Control Register. The T bit is set to the value given by the CP15 TE bit. The J bit is cleared and the E bit (endianness) is set to the value of the EE (exception endianness) bit. This allows exceptions to always run in ARM or Thumb-2 state and in little or big-endian, irrespective of the state the processor was in before the exception.
- Forces the PC to point to the relevant instruction from the exception vector table.

It will almost always be necessary for the exception handler software to save registers onto the stack immediately upon exception entry. (FIQ mode has more dedicated registers and so a simple handler may be able to be written in a way which needs no stack usage).

A special assembly language instruction is provided to assist with saving the necessary registers, called SRS (Store Return State). This instruction pushes the LR and SPSR onto the stack of any mode; which stack should be used is specified by the instruction operand.

10.3 Exit from an exception handler

Exiting from an exception and returning to the main program is always done by executing a special instruction. This has the effect of doing both of the following (at the same time).

- Restore the CPSR from the saved SPSR.
- Set the PC to the value of (LR offset) where the offset value is fixed for a particular exception type, shown in Table 10-1 on page 10-6.

This may be accomplished by using an instruction like SUBS PC, LR, #offset if the link register was not pushed on to the stack at the start of the handler. Otherwise, it will be necessary to pop the values to be restored from the stack. Again, there is a special assembly language instruction provided to assist with this. The Return From Exception (RFE) instruction pops the link register and SPSR off the current mode stack.

10.4 Exception mode summary

Table 10-1 summarizes different exceptions and the associated mode. This table contains a great deal of information and we'll take a moment to look at each row and column in turn.

The Priority column gives the priority ranking should multiple exceptions occur on the same cycle, with 1 being the highest priority and 6 the lowest. The CPSR column indicates the setting of the CPSR I and F bits, used to disable IRQ and FIQ respectively.

Table 10-1 Summary of Exception behavior

Vector Address	Exception	Mode	Event	Priority	CPSR	Return instruction
0x0	Reset	Supervisor	Reset input asserted	1	F = 1 I = 1	Not applicable
0x4	Undefined Instruction	Undef	Executing undefined instruction	6	I = 1	MOVS PC, LR (if emulating the instruction) SUBS PC, LR, #4 (if re-executing after for example enabling VFP)
0x8	SVC I (SWI)	Supervisor	SVC Instruction	6	I = 1	MOVS PC,LR
0xC	Prefetch Abort	Abort	Instruction fetch from invalid address5	5	I = 1	SUBS PC, LR, #4
0x10	Data Abort	Abort	Data Read/Write to invalid address	2	I = 1	SUBS PC, LR, #8 (if retry of the aborting instruction is wanted)
0x14	Reserved	-	Unused	-	-	-
0x18	Interrupt	IRQ	IRQ input asserted	4	I = 1	SUBS PC, LR, #4
0x1C	FastInterrupt	FIQ	FIQ input asserted	3	F = 1 I = 1	SUBS PC, LR, #4

The suggested return instructions in Table 10-1 assumes that we wish to retry the aborted instruction in the case of an abort, but to not retry an instruction which caused an undefined instruction exception.

10.4.1 Exception priorities

As some of the exception types can occur simultaneously, the processor assigns a fixed priority for each exception, as shown in Table 10-1. The Undefined Instruction, prefetch abort and SVC exceptions are both due to execution of an instruction (there are specific bit patterns for undef and SVC opcodes) and so can never happen together and therefore have the same priority.

It is important to distinguish between prioritization of exceptions, which happens when multiple exceptions are required at the same time, and the actual exception handler code. You will notice that Table 10-1 contains columns explaining how FIQ and IRQ are automatically disabled by some exceptions. (All exceptions disable IRQ, only FIQ and reset disable FIQ). This is done by the processor automatically setting the CPSR I (IRQ) and F (FIQ) bits.

So, an FIQ exception may interrupt an abort handler or IRQ exception. In the case of a data abort and FIQ occurring simultaneously, the data abort (which has higher priority) is taken first. This lets the processor record the return address for the data abort. But as FIQ is not disabled by data abort, we then take the FIQ exception immediately. At the end of the FIQ we return back to the data abort handler.

10.5 Vector table

The first column in the table gives the vector address within the vector table associated with the particular type of exception. This is a table of instructions that the ARM core goes to when an exception is raised. These instructions are located in a specific place in memory. The normal vector base address is 0x000000000, but most ARM processors allow the vector base address to be moved to 0xFFFF0000. All Cortex-A series processors permit this, and it is the default address selected by the Linux kernel.

You will notice that there is a single word address associated with each exception type. Therefore, only a single instruction may be placed in the vector table for each exception (although, in theory, two 16-bit Thumb instructions could be used). FIQ is different, as we shall see later. Therefore, the vector table entry almost always contains one of the various forms of branches.

B<address> This performs a PC-relative branch. It is suitable for calling exception handler code which is close enough in memory that the 24-bit field provided in the branch instruction is large enough to encode the offset.

LDR PC, **[PC**, **#offset]** This loads the PC from a memory location whose address is defined relative to the PC. This lets the exception handler be placed at any arbitrary address within the full 32-bit memory space (but takes some extra cycles relative to the simple branch above).

The FIQ exception is the entry at the end of the vector table and so potentially the FIQ handler code may be placed directly after the vector table, eliminating the need for a branch to the actual handler (which saves clock cycles).

10.6 Distinction between FIQ and IRQ

FIQ is reserved for a single, high-priority interrupt source that requires a guaranteed fast response time, with IRQ used for all of the other interrupts in the system.

As FIQ is the last entry in the vector table, the FIQ handler can be placed directly at the vector location and run sequentially from that address. This avoids a branch instruction and any associated delay, speeding up FIQ response times. The extra banked registers available in FIQ mode relative to other modes allows state to be retained between calls to the FIQ handler, again increasing execution speed by potentially removing the need to push some registers before using them.

A further key difference between IRQ and FIQ is that the FIQ handler is not expected to generate any other exceptions. FIQ is therefore reserved for special system-specific devices which have all their memory mapped (that is, no MMU page table faults) and no need to make SVC calls to access kernel functions (so FIQ can be used only by code which does not need to use the kernel API). FIQ is not typically used by Linux. As the kernel is architecture-independent, it does not have a concept of multiple forms of interrupt. Some systems running Linux may still make use of FIQ, but as the Linux kernel never disables FIQs they have priority over anything else in the system and so some care is needed.

10.7 Return instruction

The link register (LR) is used to store the appropriate return address for the PC after the exception has been handled. Its value needs to be modified as shown in Table 10-1 on page 10-6, depending upon the type of exception occurred. The ARM *Architecture Reference Manual* defines the LR values that must be used (the definition derives from the values which convenient for early hardware implementations).

Chapter 11 **Interrupt Handling**

In this section, we will look at a range of methods by which interrupts are handled in ARM processors, and briefly consider the Generic Interrupt Controller (GIC).

11.1 External interrupt requests

As we discussed in *Types of exception* on page 10-2, all ARM processors have two external interrupt requests, FIQ and IRQ. Both of these are level-sensitive active low inputs. Individual implementations have interrupt controllers which accept interrupt requests from a wide variety of external sources and map them onto FIQ or IRQ, causing the processor to take an exception.

In general, an interrupt exception can be taken only when the appropriate CPSR disable bit (the F and I bits respectively) is clear.

The CPS assembly language instruction provides a simple mechanism to enable or disable the exceptions controlled by CPSR A, I and F bits (imprecise abort, IRQ and FIQ respectively). CPS can be used additionally to change mode, as shown below.

```
CPS #<mode>
CPS IE/ID <if>
```

where

<mode> is the number of the mode to change to. If this option is omitted, no mode change occurs. The values of these modes are listed in Table 4-1 on page 4-3.

IE or ID will enable or disable exceptions respectively. The exceptions to be enabled or disabled are specified using one or more of the letters A, I and/or F. Exceptions whose corresponding letters are omitted will not be modified.

In Cortex-A series processors, it is possible to configure the core so that Fits cannot be masked by software. This is known as Non-Maskable FIQ and is controlled by a hardware configuration input signal which is sampled when the core is reset. They will still be masked automatically upon taking an FIQ exception.

11.1.1 Assigning interrupts

A system will always have an interrupt controller which accepts interrupt requests from multiple pieces of external hardware. This typically contains a number of registers allowing software running on the ARM to mask individual interrupt sources, to acknowledge interrupts from external devices and to determine which interrupt sources are currently active.

This interrupt controller may be a design specific to the system, or it may be an implementation of ARM's *Generic Interrupt Controller* (GIC), which is described later.

11.1.2 Interrupt latency

In embedded systems with real-time requirements, interrupt latency is an important consideration. This is generally defined as the maximum time taken from the external interrupt request to execution of the first instruction of the interrupt service routine (ISR) for that request.

In normal operation, ARM processors will take an interrupt exception when the currently executing instruction completes. This could be a load-multiple operation which could cause page table walks, cache linefills and writeback of dirty data, each potentially taking a number of cycles to complete. Some processors provide support for a low-latency interrupt mode. When this is selected, the processor can abandon multiple loads or stores to normal memory upon receiving an interrupt. After processing the interrupt it returns to the original instruction and re-executes it from the start. This can give significantly lower interrupt latency, at the cost of reduced overall processor performance. The reduced performance is due to the fact that the processor cannot utilize hit-under-miss memory access methods and must execute instructions strictly in-order.

An access to Device or Strongly Ordered memory cannot be abandoned in this way, because, as we saw in Chapter 9, there are certain rules which apply to these memory types. The processor must not repeat accesses to such memory, or modify the size or number of accesses.

In addition to latency caused by these hardware effects, a key factor in interrupt latency is how long interrupts are disabled for, since this also prevents high-priority interrupts from pre-empting processing of lower-priority interrupts. This is the responsibility of the operating system and any device drivers, and will often exceed the hardware latency.

Total worst-case interrupt latency (for the highest priority interrupt in your entire system. Latencies for lower-priority ones can be much higher) = (maximum CPU latency) + (maximum cycles of interrupts disabled).

11.1.3 Non-nested interrupt handling

This represents the simplest kind of interrupt handler. An interrupt occurs and while processing that interrupt, further interrupts are disabled. We can only handle further interrupts at the completion of the first interrupt request and there is no scope for a higher priority or more urgent interrupt to be handled during this time. This is not generally suitable for complex embedded systems, but it is useful to examine before proceeding to a more realistic example.

The steps taken to handle an interrupt are as follows:

- An IRQ exception is raised by external hardware. The processor performs several steps automatically. The contents of the PC in the current execution mode are stored in LR_IRQ. The CPSR register is copied to SPSR_IRQ. The bottom byte of the CPSR is updated to change to IRQ mode, and to disable IRQ which prevent further exceptions from occurring. The PC is set to IRQ entry in the vector table.
- The instruction at the IRQ entry in the vector table (a branch to the interrupt handler) is executed.
- The interrupt handler saves the context of the interrupted program (that is, it pushes onto the stack any registers which will be corrupted by the handler).
- The interrupt handler determines which interrupt source needs to be processed and calls the appropriate ISR.
- After the ISR has executed, the context of the interrupted program is restored, which re-enables further IROs.
- Finally, the SPSR_IRQ is copied back into CPSR, which switches the system back to the previous execution mode. At the same time, the PC is restored from the LR IRQ.

11.1.4 Nested interrupt handling

In a nested handler, we re-enable interrupts before the handler has fully served the current interrupt. This allows us to prioritize interrupts and make significant improvements to the latency of high priority events at the cost of additional complexity.

A reentrant interrupt handler must save the IRQ state and then switch processor modes, and save the state for the new processor mode, before it branches to a nested subroutine or C function with interrupts enabled. This is because a fresh interrupt could occur at any time, which would cause the processor to store the return address of the new interrupt in LR_IRQ, overwriting the original When the original interrupt attempts to return to the main program, it will cause the system to fail. The nested handler must change into an alternative kernel mode before re-enabling interrupts in order to prevent this. This is not the case within Linux, for example, and unlikely to be the case for most cross-platform operating systems.

A reentrant interrupt handler must therefore take the following steps after an IRQ exception is raised and control is transferred to the interrupt handler in the way previously described.

- The interrupt handler saves the context of the interrupted program (that is, it pushes onto the alternative kernel mode stack any registers which will be corrupted by the handler, including the return address and SPSR IRQ).
- It determines which interrupt source needs to be processed and clears the source in the external hardware (preventing it from immediately triggering another interrupt).
- The interrupt handler changes the processor to the other kernel mode, leaving the CPSR I bit set (interrupts are still disabled).
- The interrupt handler saves the exception return address on the stack (a stack for the new mode, located in kernel memory) and re-enables interrupts.
- It calls the appropriate C handler for the original interrupt (interrupts are still disabled).
- Upon completion, the interrupt handler disables IRQ and pops the exception return address from the stack.
- It restores the context of the interrupted program directly from the alternative kernel mode stack. This includes restoring the PC, and the CPSR which switches back to the previous execution mode.

11.1.5 Vectored interrupts

Some processors have optional hardware support of a *Vectored Interrupt Controller* (VIC). This provides automatic prioritization and preemption in hardware. More importantly, it speeds up exception entry, bypassing the normal IRQ vector address at 0x18 and instead allowing the interrupt hardware to supply the core with address of the handler for the highest priority active source. This avoids the need to have a branch from the vector table to the handler, then read the interrupt controller to determine which handler to call followed by a further branch. The use of the VIC is disabled by default and must be enabled by setting the CP15 Control Register (CP15:SCTLR) VE bit. FIQ is not vectored in this way.

Vectored interrupts are typically not used in systems running Linux. Some extra hardware is required in the system to support vectored interrupts (a VIC). The saving of an additional load to memory to go from the interrupt number to the handler routine address is small in relation to the overall interrupt latency. A VIC is more likely to be found in systems with hard real-time response requirements.

11.2 Interrupt controllers

Older versions of the ARM architecture allowed implementers considerable freedom in their external interrupt controller, with no agreement over the number or types of interrupts or the software model to be used to interface to the interrupt controller block. The GIC architecture provides a much more tightly controlled specification, with a much greater degree of consistency between parts from different manufacturers. This allows interrupt handler code to be more portable.

The GIC Architecture defines a *Generic Interrupt Controller* (GIC) which comprises a set of hardware resources for managing interrupts in a single or multi-processor system. The GIC provides memory mapped registers which can be used to manage interrupt sources and behavior and (in multi-processor systems) for routing interrupts to individual processors. It allows software to mask, enable and disable interrupts from individual sources, to prioritize (in hardware) individual sources and to generate software interrupts. It also provides support for the TrustZone security extensions described later in this book. The GIC accepts interrupts asserted at the system level and can signal them to each processor it is connected to, potentially resulting in an IRQ or FIQ exception being taken.

Each interrupt may be considered to be in one of four states:

- Inactive.
- *Pending*. This means that the interrupt source has been asserted, but is waiting to be handled by a processor.
- *Active*. This describes an interrupt that has been acknowledged by a processor and is currently being serviced.
- Active and pending. This describes the situation where a processor is servicing the interrupt and the GIC also has a pending interrupt from the same source.

Access to the Generic Interrupt Controller registers is memory-mapped. In an MPCore cluster which uses the GIC, this is done using an interface private to each processor (see *Handling interrupts in an SMP system* on page 23-5 for further detail of interrupt handling in MPCore Systems). The base address of these registers is defined by the SoC implementer, by setting the value of **PERIPHBASE** signals. The value of this base address is readable by software, with individual registers being accessed by adding an offset to the base.

Interrupts may be of a number of different types

What follows is a brief overview of GIC terminology and its usage model.

- Software Generated Interrupt (SGI). This is generated by writing to a dedicated register, the Software Generated Interrupt Register (ICDSGIR). It is most commonly used for inter-processor communication.
- *Private Peripheral Interrupt* (PPI). This is generated by a peripheral that is private to an individual processor.
- Shared Peripheral Interrupt (SPI). This is generated by a peripheral that the Interrupt Controller can route to more than one processor.

Interrupts may either be edge-triggered (considered to be asserted when the interrupt controller detects a rising edge on the relevant input – and to remain asserted until cleared) or level-sensitive (considered to be asserted only when the relevant input to the interrupt controller is high).

The source of an individual interrupt may be determined using an ID number. The GIC assigns a specified range of ID values to different types of interrupt.

The processor hardware then compares the interrupt priority with the current interrupt priority for the processor. If the interrupt has sufficient priority, an interrupt exception request is signaled.

When the processor takes the interrupt exception, it reads the Interrupt Acknowledge Register (ICCIAR), to acknowledge the interrupt. This read returns an Interrupt ID, which is used to select the correct interrupt handler. When the GIC sees this read, it changes the state of the interrupt from pending to active or to active and pending, as appropriate. When the interrupt service routine has completed handling the interrupt, it signals this by writing to the End of Interrupt Register (ICCEOIR) in the GIC.

We will return to the subject of the GIC in Chapter 23. More detailed information on GIC behavior may be found in Technical Reference Manuals for the individual processors and in the ARM *Generic Interrupt Controller Architecture* specification.

- Interrupt numbers ID1020-ID1023 are reserved for special purposes.
- Interrupt ID values in the range ID32-ID1019 are used for SPIs.
- Interrupt numbers ID0-ID31 are used for interrupts that are private to a processor interface. In MPCore systems, (or non-MPCore GICs implemented with more than one processor interface) these numbers are banked on a per processor basis. ID0-ID15 are used for SGIs and ID16-ID31 are used for PPIs.

Other Exception Handlers

In this section, we will briefly look at handlers for aborts, undefined instructions and SVC instructions and look at how interrupts are handled by the Linux Kernel. Reset handlers are covered in depth in Chapter 13 *Boot Code*.

12.1 Abort handler

Abort handler code can vary significantly between systems. In many embedded systems, an abort indicates an unexpected error and the handler will simply record any diagnostic information, report the error and have the application (or system) quit gracefully.

In systems which support virtual memory using an MMU, the abort handler may load the required virtual page into physical memory. In effect, it tries to fix the cause of the original abort and then return to the instruction which aborted and re-execute it. Chapter 8 *Memory Management Unit* gives further information about how Linux does this.

CP15 registers provide the address of the data access which caused an abort (the Fault Address Register) and the reason for the abort (Fault Status Register). The reason might be lack of access permission, an external abort, a page table translation fault etc. In addition, the link register (with a -8 or -4 adjustment, as appropriate), gives the address of the instruction executing before the abort exception. By examining these registers, the last instruction executed and possibly other things in the system (for example, page table entries), the abort handler can determine what action to take.

The format of the CP15.DFSR (Data Fault Status Register) is shown in Figure 12-1. The EXT bit can provide classification of external aborts on some implementations, while the WR bit indicates whether the abort was on a data write (1) or data read (0).




Figure 12-1 Data Fault Status Register format

Table 12-1 shows the encoding of the Fault Status bits (FS[10] and FS[3:0]) from the DFSR. It also indicates whether the address stored in the CP15.DFAR (Data Fault Address Register) is valid and correctly indicates the memory address which received the abort.

Table 12-1 CP15 DFSF	R Fault Status Encoding
----------------------	-------------------------

DFSR [10,3:0]	Source		DFAR
00001	Alignment Fault		Valid
00100	Instruction cache maintenance fault		Valid
01100	Translation table walk synchronous external abort	1st level	Valid
01100		2nd level	Valid
11100	Translation table walk synchronous parity error	1st level	Valid
11100		2nd level	Valid
00101	Translation fault	Section	Valid
00111		Page	Valid
00011	Access flag fault	Section	Valid
00110		Page	Valid
01001	Domain fault	Section	Valid
01011		Page	Valid

Table 12-1 CP15 DFSR Fault Status Encoding (continued)

DFSR [10,3:0]	Source		DFAR
01101	Permission fault	Section	Valid
01111		Page	Valid
00010	Debug event		
00001	Alignment fault		Valid
01000	Synchronous external abort		Valid
10100	IMPLEMENTATION DEFINED		-
11010	IMPLEMENTATION DEFINED		-
11001	Memory access synchronous parity error		Valid
10110	Asynchronous external abort		
11000	Memory access asynchronous parity error		

12.2 Undefined instruction handling

An undefined instruction exception is taken if the processor tries to execute an instruction with an opcode which is defined within the ARM rehitecture Specification as Undefined, or when a coprocessor instruction is executed but no coprocessor recognizes it as an instruction that it can execute.

In some systems, it is possible that code includes instructions for a coprocessor (such as a VFP coprocessor), but that no corresponding VFP hardware is present in the system. In addition, it may be that the VFP hardware cannot handle the particular instruction and wishes to call software to emulate it. Alternatively, the VFP hardware is disabled, and we take the exception so that we can enable it and reexecute the instruction.

Such emulators are called through the undefined instruction vector. They examine the instruction opcode which caused the exception and determine what action to take (for example, perform the appropriate floating point operation in software). In some cases, such handlers may need to be daisy-chained together (for example, there may be multiple coprocessors to emulate).

If there is no software which makes use of undefined or coprocessor instructions, then the handler for the exception should record suitable debug information and kill the application which failed due to this unexpected event.

An additional use for the undefined instruction exception in some cases is to implement user breakpoints, see Chapter 27 *Debug* for more information on breakpoints. (See also the discussion on Linux context switch for VFP in Chapter 18.)

12.3 SVC exception handling

An SVC call is typically used to allow user mode code to access OS functions. For example, if user code wishes to access privileged parts of the system (for example to perform file I/O) it will typically do this using an SVC instruction. (In fact, not every OS does this – Windows CE uses calls to an aborting address range to do this.)

Parameters may be passed to the SVC handler either in registers or (less frequently) by using the comment field within the opcode.

Code to illustrate SVC usage with the Linux kernel is shown in Example 12-1.

Example 12-1 Linux kernel SVC usage

```
_start:
     MOV
             R0, #1
                                 @ STDOUT
     ADR
               R1, msqtext
                                 @ Address
     MOV
             R2, #13
                                 @ Length
     MOV
             R7, #4
                                 @ sys_write
     SVC
  .align 2
  msgtxt:
     .asciz "Hello World\n"
```

The SVC 0 instruction makes the ARM take the SVC exception, which is the mechanism to access a kernel function. Register R7 defines which system call we want (in this case, sys_write). The other parameters are passed in registers; for sys_write we have R0 telling where to write to, R1 pointing to the characters to be written and R2 giving the length of the string.

There is a further usage of the SVC instruction which may be seen by application developers. Tools developed by ARM use SVC 0x123456 (ARM state) or SVC 0xAB (Thumb) to represent semi-hosting debug functions (for example to output a character on a debugger window).

For Linux application programmers, it is better practice to access such kernel functions through calls to the C library, rather than by direct use of system calls. Typically, the library code will perform some checks, call the kernel and set errno (if needed). Duplicating this code will waste memory, and increase the risk of introducing bugs in your software.

12.4 ARM Linux exception program flow

In ARM Linux, all exceptions are handled in (privileged) SVC mode, regardless of which exception type occurred. A branch instruction is placed in each vector table entry, to call the first part of the exception handler – the so-called exception stub. This is written in assembly code and simply performs stack maintenance operations, return address calculation and the switch into SVC mode. The stub is provided as a macro, with different argument values used to specify the exception type.

The stub then calls the code which does the actual exception specific operation, again written in assembler code and then the corresponding exception handler function, (written in C code). After the exception is handled, the processor may return (through the exception stub) back to the originally executing code.

The ARM Linux exception related code is (mostly) under arch/arm/kernel/ directory. The most interesting files are as follows:

- entry-armv.S
- entry-common.S
- entry-header.S

We'll start by looking at the exception stubs and then move onto the actual exception handlers, which can be re-configured dynamically and are rather more complex.

12.4.1 Exception stubs

The file entry-armv. S contains the exception vector table and the stub code for each exception. It has the symbols shown below:

Example 12-2 entry-armv.S vector table and stubs

```
.__vectors_start
.__vectors_end
```

The first thing to consider is how does Linux fill the ARM's exception vector table, the space between __vectors_start and __vectors_end, above?

Example 12-3 ARM Linux Exception vector table

```
.globl __vectors_start
__vectors_start
swi SYS_ERROR0
b vector_und + stubs_offset
ldr pc, .LCvswi + stubs_offset
b vector_pabt + stubs_offset
b vector_dabt + stubs_offset
b vector_addrexcptn + stubs_offset
b vector_irq + stubs_offset
b vector_fiq + stubs_offset
c vector_fiq + stubs_offset
```

At system boot, the code shown in Example 12-3 on page 12-6 is copied into memory at the location of the exception vector table of the ARM. So, when an exception occurs, the appropriate stub within the kernel will be run. (Note that the addrexcptn entry above is not used on any current ARM processor.)

You may observe that we have a SWI (SVC) as the first entry in the table. SWI is the former name for the SVC instruction. Once the system has booted, we do not expect the reset exception to happen. The assembly instruction swi SYS_ERROR0 causes a kernel dump, should this unexpected situation arise. The most likely cause of execution from PC=0 is unexpected use of a null pointer.

Now let's look at the stub definitions. The kernel defines a macro, which generates the common stub entry routines used for all exceptions except FIQ and SVC.

Example 12-4 Exception vector stub code

```
macro vector_stub, name, mode, correction=0
.align 5
vector_\name:
.if \correction
sub lr, lr, #\correction
.endif
@ Save r0, 1r_<exception> (parent PC) and spsr_<exception>
@ (parent CPSR)
stmia sp, {r0, lr} @ save r0, lr
mrs 1r, spsr
str lr, [sp, #8] @ save spsr
@ Prepare for SVC32 mode. IRQs remain disabled.
mrs r0, cpsr
eor r0, r0, #(\mode ^ SVC_MODE)
msr spsr_cxsf, r0
a
@ the branch table must immediately follow this code
and 1r, 1r, #0x0f
mov r0, sp
ldr lr, [pc, lr, lsl #2]
movs pc, 1r @ branch to handler in SVC mode
.endm
```

The macro code in Example 12-4 is straightforward. It makes a mode dependent correction to the value in the link register, to calculate the correct return address. It saves R0 and the link register to the stack, followed by the saved program status register (SPSR). It has to save R0, as we need to use a register for SPSR modification. Recall that IRQ interrupts are automatically disabled upon exception entry and therefore this code may all be treated as atomic. It copies the CPSR into the SPSR, modifying the mode bits so that they select supervisor (SVC) mode. Finally, we use the mode bits of the SPSR (now copied into LR) as the index to a jump table, to get the address of the handler itself. The MOVS PC, LR instruction is a special one – it copies the link register to the PC, but also the SPSR to the CPSR. This means it both does the branch to the handler and changes the mode to supervisor in one shot.

ARM Linux code runs either in user mode, or in supervisor mode. Therefore, only two of the entries in this jump table should be valid. Example 12-5 shows the jump table for IRQ. Each entry corresponds to a value of SPSR bits [3:0] – the first being user mode, the second FIQ, the third IRQ and so forth.

Example 12-5 ARM Linux IRQ jump table

```
vector_stub irq, IRQ_MODE, 4

.long __irq_usr @ 0 (USR_26 / USR_32)
.long __irq_invalid @ 1 (FIQ_26 / FIQ_32)
.long __irq_invalid @ 2 (IRQ_26 / IRQ_32)
.long __irq_svc @ 3 (SVC_26 / SVC_32)
.long __irq_invalid @ 4
.long __irq_invalid @ 5

etc.
```

So, __irq_usr is the function which handles IRQ exceptions that happened in User mode and __irq_svc looks after IRQ exceptions which happened in Supervisor mode.

12.4.2 Boot process

During the boot process, the kernel will allocate a 4Kb page as the vector page. It maps this to the location of the exception vectors, virtual address 0xFFFF0000 and/or 0x000000000. This is done by devicemaps_init() in the file arch/arm/mm/mmu.c. This is invoked very early in the ARM system boot. After this, trap_init (in arch/arm/kernel/traps.c), copies the exception vector table, exception stubs and kuser helpers into the vector page. The exception vector table obviously has to be copied to the start of the vector page, the exception stubs being copied to address 0x200 (and kuser helpers copied to the top of the page, at 0x1000 - kuser_sz), using a series of memcpy() operations, as shown in Example 12-6.

Example 12-6 Copying exception vectors during Linux boot

```
unsigned long vectors = CONFIG_VECTORS_BASE;

memcpy((void *)vectors, __vectors_start, __vectors_end - __vectors_start);
memcpy((void *)vectors + 0x200, __stubs_start, __stubs_end - __stubs_start);
memcpy((void *)vectors + 0x1000 - kuser_sz, __kuser_helper_start, kuser_sz);
```

Once the copying is complete, the kernel exception handler is in its runtime dynamic status, ready to handle exceptions

12.4.3 Interrupt dispatch

There are two different handlers, __irq_usr and __irq_svc. These save all of the processor registers and use a macro get_irqnr_and_base which indicates if there is an interrupt pending. The handlers loop around this code until no interrupts remain. If there is an interrupt, then the code will branch to do_IRQ which exists in arch/arm/kernel/irq.c.

At this point, the code is the same in all architectures and we simply call an appropriate handler written in C.

There is however, a further point to consider. When the interrupt is completed, we would normally need to check whether or not the handler did something which needs the kernel scheduler to be called. If the scheduler decides to go to a different thread, then the one that was originally interrupted stays dormant until it is selected to run again.

Chapter 13 **Boot Code**

In this chapter, we will look at the work which needs to be undertaken within the boot code running in an ARM based system. We will focus on two distinct areas:

- Code to be run immediately after the core comes out of reset, on a so-called bare-metal system, that is, one in which code is run without the use of an operating system. This is a situation which is often encountered when first bringing-up a chip or system.
- The operation of an ARM Linux bootloader.

If you are writing an application to run on an existing OS port, it is unlikely that you will need to make use of the contents of this chapter. On the other hand, if you are porting from one ARM-based platform to another, it is highly likely that you might have to work on such code.

13.1 Booting a bare-metal system

Once the processor has been reset, it will commence execution at the location of the reset vector within the exception vector table (at either address 0 or 0xFFFF0000). The reset handler code will need to do some, or all of the following:

- In a multi-processor system, put non-primary processors to sleep
- Initialize exception vectors
- Initialize the memory system, including the MMU
- Initialize processor mode stacks and registers
- Initialize variables required by C
- Initialize any critical I/O devices
- Perform any necessary initialization of NEON/VFP
- Enable interrupts

start B

Reset Handler

- Change processor mode and/or state
- Handle any set-up required for the Secure world (see Chapter 26)
- Call the main() application.

The first consideration is placement of the exception vector table. We need to make sure that it contains a valid set of instructions which branch to the appropriate handlers. The _start directive in the GNU assembler tells the linker to locate code at a particular address and can be used to place code in the vector table. The initial vector table will be in non-volatile memory and may contain branch to self instructions (other than the reset vector) as no exceptions are expected at this point. Typically, the reset vector contains a branch to the boot code in ROM. The ROM may be aliased to the address of the exception vector. The ROM then writes to some memory-remap peripheral, which maps RAM into address 0 and the real exception vector table is copied into RAM. This means the initial instructions which handle remapping must be position-independent, as only PC-relative addressing can be used. Example 13-1 shows an example of typical code which will be placed in the exception vector table.

Example 13-1 Typical exception vector table code

```
B Undefined_Handler
B SWI_Handler
B Prefetch_Handler
B Data_Handler
NOP @ Reserved vector
B IRQ_Handler
@ FIQ_Handler will follow directly after this table
```

We may then need to initialize stack pointers for the various modes that our application may make use of. Example 13-2 gives a simple example, showing code which initializes the stack pointers for FIQ and IRQ modes.

Example 13-2 Code to initialize the stack pointers

```
LDR R0, stack_base
@ Enter each mode in turn and set up the stack pointer
MSR CPSR_c, #Mode_FIQ:OR:I_Bit:OR:F_Bit;
MOV SP, R0
SUB R0, R0, #FIQ_Stack_Size
```

```
MSR CPSR_c, #Mode_IRQ:OR:I_Bit:OR:F_Bit;
MOV SP, R0
```

The next step is to set up the caches, MMU and branch predictors. An example of such code is shown in Example 13-3. We begin by disabling the MMU and caches and invalidating the caches and TLB. The example code is for the Cortex-A9 processor. For the Cortex-A8 and Cortex-A5 processors, the cache invalidation can be done automatically by a hardware state machine at reset, but for the Cortex-A9 processor, boot code must explicitly cycle through the lines of the cache and invalidate them. The MMU TLBs must be invalidated. The branch target predictor hardware may not need to be explicitly invalidated, but it should be enabled by boot code. Branch prediction may safely be enabled at this point; this will improve performance.

Example 13-3 Setting up caches, MMU and branch predictors

```
; Disable MMU
MRC
      p15, 0, r1, c1, c0, 0 @ Read Control Register configuration data
BIC
      r1, r1, #0x1
MCR
      p15, 0, r1, c1, c0, 0 @ Write Control Register configuration data
@ Disable L1 Caches
      p15, 0, r1, c1, c0, 0 @ Read Control Register configuration data
BIC
      r1, r1, #(0x1 << 12) @ Disable I Cache
BIC
      r1, r1, #(0x1 << 12) @ Disable I Cache
MCR
      p15, 0, r1, c1, c0, 0 @ Write Control Register configuration data
@ Invalidate L1 Caches
@ Invalidate Instruction cache
MOV
      r1, #0
MCR
      p15, 0, r1, c7, c5, 0
@ Invalidate Data cache
@ to make the code general purpose, we calculate the
@ cache size first and loop through each set + way
MRC
                                      @ Read Cache Size ID
      p15, 1, r0, c0, c0, 0
MOV
      r3, #0x1ff
AND
      r0, r3, r0, LSR #13
                                      0 \text{ r} = 0 \text{ no. of sets } -1
MOV
      r1, #0
                                      @ r4 = way counter way_loop
MOV
                                      @ r3 = set counter set_loop
      r3, #0
MOV
      r2, r1, LSL #30
ORR
      r2, r3, LSL #5
                                      @ r2 = set/way cache operation format
MCR
      p15, 0, r2, c7, c6, 2
                                      @ Invalidate line described by r2
ADD
                                      @ Increment set counter
      r2, r2, #1
CMP
      r0, r2
                                      @ Last set reached yet?
BNE
      set_loop
                                      @ if not, iterate set_loop
ADD
      r1, r1, #1
                                      @ else, next
CMP
      r1, #4
                                      @ Last way reached yet?
BNE
      way_loop
                                      @ if not, iterate way_loop
@ Invalidate TLB
      r1, #0
MOV
MCR
      p15, 0, r1, c8, c7, 0
```

After this, we can create some page tables, as shown in the example code of Example 13-4 on page 13-4. The variable ttb_address is used to denote the address to be used for the initial page table. This should be a 16kB area of memory (whose start address is aligned to a 16kB boundary), to which an L1 page table can be written by this code.

```
@ Branch Prediction Enable
       p15, 0, r1, c1, c0, 0 @ Read Control Register configuration data
       r1, r1, \#(0x1 \ll 11) @ Global BP Enable bit
       p15, 0, r1, c1, c0, 0 @ Write Control Register configuration data
  ; Enable D-side Prefetch
       p15, 0, r1, c1, c0, 1 @ Read Auxiliary Control Register
       r1, r0, #(0x1 <<2) Enable D-side prefetch
 ORR
       p15, 0, r1, c1, c0, 1;@ Write Auxiliary Control Register
 MCR
 DSB
 ISB
 @ DSB causes completion of all cache maintenance operations appearing in program
 @ order before the DSB instruction
 @ An ISB instruction causes the effect of all branch predictor maintenance
 @ operations before the ISB instruction to be visible to all instructions
 @ after the ISB instruction.
 @ Initialize PageTable
  @ We will create a basic L1 page table in RAM, with 1MB sections containing a flat
(VA=PA) mapping, all pages Full Access, Strongly Ordered
 @ It would be faster to create this in a read-only section in an assembly file
 LDR r0, =2_0000000000000000000000110111100010 @ r0 is the non-address part of
descriptor
 LDR r1, ttb_address
       r3, = 4095 @ loop counter
 write_pte
       r2, r0, r3, LSL #20 @ OR together address & default PTE bits
       r2, [r1, r3, LSL #2] @ write PTE to TTB
  SUBS r3, r3, #1
                            :@ decrement loop counter
       write_pte
 BNE
 @ for the very first entry in the table, we will make it cacheable, normal,
writeback, write allocate
       r0, r0, #2_1100
                                    @ clear CB bits
 BIC
  ORR
       r0, r0, #2_0100
                                    @ inner write back, write allocate
 BIC
       r0, r0, #2_111000000000000
                                   @ clear TEX bits
       r0, r0, #2_101000000000000
                                   @ set TEX as write back, write allocate
 ORR
       r0, r0, #2_1 00000000000000 @ shareable
 STR
       r0, [r1]
 @ Initialize MMU
 MOV
       r1,#0x0
 MCR
       p15, 0, r1, c2, c0, 2 @ Write Translation Table Base Control Register
 LDR
       r1, ttb_address
 MCR
       p15, 0, r1, c2, c0, 0 @ Write Translation Table Base Register 0
 @ In this simple example, we don't use TRE or Normal Memory Remap Register.
 @ Set all Domains to Client
 LDR r1, =0x5555555
 MCR p15, 0, r1, c3, c0, 0 @ Write Domain Access Control Register
 @ Enable MMU
 MRC
       p15, 0, r1, c1, c0, 0 @ Read Control Register configuration data
 ORR
       r1, r1, #0x1
                            @ Bit 0 is the MMU enable
 MCR
       p15, 0, r1, c1, c0, 0 @ Write Control Register configuration data
```

It is usual to leave the cache disabled, as C library initialization may require copying of code and thus create cache coherency issues. The Level 2 cache, if present, may also need to be invalidated and enabled. NEON/VFP access must also be enabled. If the system makes use of the TrustZone security extensions, it may need to switch to the Normal world once the Secure world is initialized.

The next steps will depend upon the exact nature of the system. It may be necessary, for example, to zero-initialize memory which will hold uninitialized C variables, copy the initial values of other variables from a RAM image to ROM, and set up application stack and heap spaces. It may also be necessary to initialize C library functions, call top-level constructors (for C++ code) and other standard embedded C initialization.

We will examine MPCore programming in more detail in Chapter 22-Chapter 25, but we can touch briefly on how these are booted here. A common approach is to allow a single core within the MPCore to perform system initialization, while the same code, if run on a different core, will cause it to sleep (that is, enter WFI state, as discussed in Chapter 21). The other cores might be woken after core0 has created a simple set of L1 page table entries, as these could be used by all cores in the system. Example 13-5 shows example code which determines which core it is running on and either branches to initialization code (if running on core 0), or goes to sleep otherwise. The secondary cores are typically woken up later by an SMP OS.

Example 13-5 Determining which CPU is running

```
@ Only CPU 0 performs initialization. Other CPUs go into WFI
@ to do this, first work out which CPU this is
@ this code typically is run before any other initialization step

MRC p15, 0, r1, c0, c0, 5 @ Read Multiprocessor Affinity Register
AND r1, r1, #0x3 @ Extract CPU ID bits
CMP r1, #0
BEQ initialize @ if we're on CPU0 goto the start

wait_loop:
@ Other CPUs are left powered-down

Initialize:
@ next section of boot code goes here
```

13.2 Configuration

There are a number of control register bits within the ARM processor which will typically be set by bootcode. In all cases, for best performance, code should run with the MMU, instruction and data caches and branch prediction enabled. Page table entries for all regions of memory which are not peripheral I/O devices should be marked as L1 Cacheable and (by default) set to read-allocate, writeback cache policy. For MPCore systems, pages should be marked as Shareable and the broadcasting feature for CP15 maintenance operations should be enabled.

In addition to the CP15 registers mandated by the ARM architecture, processors typically also have registers which control implementation-specific features. Programmers of bootcode should refer to the relevant technical reference manual for the correct usage of these. We will consider an example here. Figure 13-1 shows recommended settings for the auxiliary control register of the Cortex-A9 processor when trying to maximize performance for memset() or memcpy() code.




Figure 13-1 Cortex-A9 Auxiliary Control Register

The "Allocate in one way" bit forces only a single cache way to be used. This minimizes pollution of the cache when large blocks of memory are being copied.

L2 exclusive mode was described in Exclusive cache mode on page 7-24

"Full of Zeros" mode is applicable only when a PL310 Level 2 Cache Controller is present and has had its own "Full of Zeros" mode already enabled. When this mode is used, writing zero to memory will not cause a linefill. This can avoid unnecessary cache accesses, achieving performance achievement and some power savings, when running memset() like operations which write zero to blocks of memory to initialize them.

Data prefetching refers to the ability of the caches to detect repeated access patterns and to automatically speculatively fetch further data in accordance with that pattern. CP15 Broadcast will be discussed in Chapter 23.

13.3 Booting Linux

It is useful to understand what happens from the ARM coming out of reset and executing its first instruction at address 0 (or 0xFFFF0000 if HIVECS is selected) until the Linux command prompt appears. When the kernel is present in memory, the sequence on an ARM based system is similar to what might happen on a desktop computer. However, the bootloading process may be very different, as ARM based phones or more deeply embedded devices may lack a hard drive or PC-like BIOS.

Typically, what happens when we power the system on is that hardware specific boot code runs (from flash or ROM). This code initializes the system, including any necessary hardware peripheral code and then launches the bootloader (for example U-Boot). This initializes main memory and copies the compressed Linux kernel image into main memory (from a flash device, memory on a board, MMC, host pc or elsewhere). The bootloader passes certain initialization parameters to the kernel. The Linux kernel then decompresses itself and initializes its data structures and running user processes, before starting the command shell environment. Let's take a more detailed look at each of those processes.

13.3.1 Reset handler

As we saw earlier in this chapter, there is typically a small amount of system-specific boot monitor code, which configures memory controllers and performs other system peripheral initialization. It sets up stacks in memory and typically copies itself from ROM into RAM, before changing the hardware memory mapping so that RAM is not mapped to the exception vector address, rather than ROM. It may also perform some actions on the C library I/O functions to target particular devices (for example selecting output to a particular UART). In essence this code is independent of which operating system is to be run on the board and performs a function similar to a PC BIOS. Once it has completed execution, it will call a Linux bootloader, such as U-Boot.

13.3.2 Bootloader

ARM Linux needs a certain amount of code to be run out of reset, to initialize the system. This performs the basic tasks needed to allow the kernel to boot.

- Initializing the memory system and peripherals.
- Loading the kernel image to an appropriate location in memory (and possibly also an initial RAM disk).
- Generate the boot parameters to be passed to the kernel (including machine type).
- Set up a console (video or serial) for the kernel.
- Enter the kernel.

The exact steps taken vary between different bootloaders, so for detailed information, please refer to documentation for the one that you wish to use. U-Boot is a widely used example, but other bootloader possibilities include Apex, Blob, Bootldr and Redboot.

When the bootloader starts, it is typically not present in main memory. It must start by allocating a stack and initializing the processor (for example invalidating its caches) and installing itself to main memory. It must also allocate space for global data and for use by malloc() and copy exception vector entries into the appropriate location.

13.3.3 Initialize memory system

This is very much a board/system specific piece of code. The Linux kernel has no responsibility for the configuration of the RAM in the system. It is presented with the physical memory layout (through ATAG_MEM), but has no other knowledge of the memory system. ATAG_MEM is a Linux tag which describes a physical area of memory and allows for multiple blocks of specified size and base address, It is therefore the task of the bootloader to provide this information and to perform any required setup. This can be done with the kernel command line option mem=. In many systems, the available RAM and its location are fixed and the bootloader task is straightforward. In other systems, code must be written which discovers the availability of RAM.

The kernel image from the build process is typically compressed, in zImage format. Its head code contains a magic number, used to verify the integrity of the decompression, plus start and end addresses. The kernel code is position independent and can be located anywhere in memory. Conventionally, it is placed at a 0x8000 offset from the base of Physical RAM. This gives space for the parameter block placed at a 0x100 offset (used for page tables etc).

Many systems need an initial RAM disk (initrd), as this lets us have a root filesystem available without other drivers being setup. The bootloader can place an initial ramdisk image into memory and pass the location of this to the kernel using ATAG_INITRD2 (a tag which describes the physical location of the compressed RAM disk image) and ATAG_RAMDISK.

The bootloader will typically setup a serial port in the target, allowing the kernel serial driver to detect the port and use it for a console. In some systems, another output device such as a video driver may be used as a console. The kernel command line parameter console= can be used to pass the information.

13.3.4 Kernel parameters

The parameters passed to the kernel are in the form of a tagged list, placed in physical RAM with register R2 holding the address of the list. Tag headers hold two 32-bit unsigned ints, with the first giving the size of the tag in words and the second providing the tag value (indicating the type of tag). For a full list of parameters which may be passed, consult appropriate documentation. Examples include ATAG_MEM to describe the physical memory map and ATAG_INITRD2 to describe where the compressed ramdisk image is located. The bootloader must also provide an ARM Linux machine type number (MACH_TYPE). This may be a hard-coded value, or the boot code may inspect the available hardware and assign a value accordingly

13.3.5 Kernel entry

Kernel execution must commence with the ARM in a fixed state. The bootloader calls the kernel image by branching directly to its first instruction – the 'start' label in arch/arm/boot.compressed/head.S. The MMU and data cache must be disabled. The core must be in supervisor mode, with CPSR I and F Bits set (IRQ and FIQ disabled). R0 must contain 0, R1 the MACH_TYPE value and R2 the address of the tagged list of parameters.

The first step in getting the kernel working is to decompress it. This is mostly architecture independent. The parameters passed from the bootloader are saved and the caches and MMU are enabled. Checks are made to see if the decompressed image will overwrite the compressed image, before calling decompress_kernel() in arch/arm/boot/compressed/misc.c, The cache is then cleaned and invalidated before being disabled again. We then branch to the kernel startup entry point in arch/arm/kernel/head.S.

13.3.6 ARM-specific actions

A number of architecture specific tasks are now undertaken. The first checks processor type using __lookup_processor_type() which returns a code specifying which processor it is running on. The function __lookup_machine_type() is then used to look up machine type. A basic set of page tables is then defined which map the kernel code. The Cache and MMU are initialized and other control registers set. The data segment is copied to RAM and start_kernel() is called.

13.3.7 Kernel start-up code

In principle, the rest of the startup sequence is the same on any architecture, but in fact some functions are still hardware dependent.

IRQ interrupts are disabled, with <code>local_irq_disable()</code> and <code>lock_kernel()</code> is used to stop FIQ interrupts from interrupting the kernel. It initializes the tick control, memory system and architecture-specific subsystems and deals with the command line options passed by the bootloader. Stacks are setup and the Linux scheduler is initialized. The various memory areas are set-up and pages allocated. The interrupt and exception table and handlers are setup, along with the GIC. The system timer is setup and at this point IRQs are enabled. Further memory system initialization occurs and then a value called <code>BogoMips</code> is used to calibrate the CPU clock speed. Internal components of the kernel are set up, including the filesystem and the init process, followed by the thread daemon which creates kernel threads. The kernel is unlocked (FIQ enabled) and the scheduler started. The function <code>do_basic_setup()</code> is called to initialize drivers, sysctl, work queues and network sockets. At this point, the switch to user mode is performed.




Figure 13-2 ARM Linux virtual memory view

The memory map used by ARM Linux is shown in Figure 13-2. There is a broad split between kernel memory, above address 0xBF000000 and user memory, below that address. Kernel memory uses global mappings, while user memory uses non-global mappings, although both code and data may be shared between processes. As already mentioned, code starts at 0x1000, leaving the first 4kB page unused, to allow for trapping of NULL pointer references. ZI refers to zero-initialized data.

Chapter 14 **Porting**

New projects will normally use an existing operating system and re-use code from existing applications. New code may already be targeted at the ARMv7-A architecture, but may need porting to a different board. In this chapter, we will mainly cover issues associated with porting code from a different architecture to run on an ARM processor, or from older versions of the ARM architecture to ARMv7-A.

For many applications (particularly those coded with portability issues in mind), this will simply mean recompiling the source code. For example, a large amount of Linux application software is designed to run in many different environments and tends to make fewer assumptions about the underlying hardware. However, there are a number of areas where C code is not fully portable. We shall look at these further and see what problems this causes and how to resolve them. In particular, low level, hardware-specific code such as device drivers tends not to be portable and such code is often written from scratch.

There is a further consideration when porting code between processors, that of efficiency. It may be the case that optimizations applied to code running on another processor, or to older versions of the ARM architecture, do not apply to that code when running on ARMv7-A. Equally, there may be scope for making code smaller and/or faster on ARMv7-A class processors. Optimizations may differ between processors or systems. Code which is optimal for one processor may not be optimal for others. We will consider the area of ARM-specific optimization in Chapter 17.

14.1 Endianness

The term endianness is used to describe the ordering of individually addressable quantities, which means bytes and halfwords in the ARM architecture. The term byte-ordering may also be used rather than endian. Other kinds of endianness do exist, notably middle-endian and bit-endian, but we will not discuss these further.

The use of the terms "Little-Endian" and "Big-Endian" was introduced by Danny Cohen in his 1980 paper "On Holy Wars and a Plea for Peace". Cohen has also been responsible for many advances in the fields of networks and computer graphics. It is a reference to *Gulliver's Travels*, a famous satire from the early 18th century, by Irish writer Jonathan Swift, in which a war is fought between the fictional countries of Lilliput and Blefuscu over the correct end to open a boiled egg.

There are two basic ways of viewing bytes in memory - Little-endian and Big-endian. On big-endian machines, the most significant byte of an object in memory is stored at the least significant (closest to zero) address. On little-endian machines, the least significant byte is stored at the address closest to zero (lowest address).

Consider the following simple piece of code (Example 14-1):

Example 14-1 Endian access example

```
int i = 0x11223344;
unsigned char c = *(unsigned char *)&i;
```

On a big-endian machine, c becomes the most significant byte of i: 0x11. On little-endian machines, c is the least significant byte of i: 0x44.

Figure 14-1 on page 14-3 illustrates the two differing views of memory. It should be stated at this point that many people find endianness confusing and that even the act of drawing a diagram to illustrate it can reveal a personal bias! The diagram shows a 32-bit value in a register being written to address 0x1000, using a STR instruction. The processor then performs a read of a byte, using a LDRB instruction. A different value will be returned by this instruction sequence depending upon whether we have a little- or big-endian memory system.




Figure 14-1 Different endian behavior

ARM processors support either mode, but typically default to, and are most commonly used in, little-endian mode. Most ARM Linux distributions tend to be little-endian only. The x86 architecture is little-endian. The PowerPC or the venerable 68K, on the other hand, are generally big-endian (although the Power architecture can also handle little-endian). Several common file formats and networking protocols specify different endianness. For example, .BMP and .GIF files are little-endian, while .JPG is big-endian, and TCP/IP is big-endian, but USB and PCI are little-endian.

So, there are two issues to consider – code portability and data sharing. Systems are built from multiple blocks and may include one or more processors, DSPs, peripherals, memory, network connections and so forth. Whenever data is shared between these elements, there is a potential endianness conflict. If code is being ported from a system with one endianness to a system with different endianness, it may be necessary to modify that code, either to make it endian-neutral or to work with the opposite byte-ordering.

Cortex-A series processors provide support for systems of either endian configuration, controlled by the CPSR E bit, which allows software to switch dynamically between viewing data as little- or big-endian. (Instructions in memory are always treated as little-endian). Multi-byte loads and stores will make use of built-in byte reversing hardware to allow big-endian accesses by the core. The REV instruction (see *Byte reversal* on page 6-23) may be used to reverse bytes within an ARM register, providing simple conversion between big and little-endian formats.

In principle, it is straightforward to support mixed endian systems (typically this means the system is natively of one endian configuration, but there are peripherals which are of the opposite endianness). The CPSR E bit can be modified dynamically by software, and there is a SETEND assembly instruction provided to do this. The CP15:SCTLR (System control register, c1), contains the EE bit (see *Coprocessor 15* on page 6-18), which defines the endian mode to switch to upon an exception. It would be difficult if exception code had to worry about which

endian state the processor was in upon arrival at the handler. In practice, however, it can be difficult to tell the compiler that part of the system is of a different endian configuration to the rest of memory. Linux does not support such mixed-endian operation.

Processors conforming to the ARM v7-A architecture have a byte-invariant view of endianness. This means that they access a byte in the same way in both little and big-endian modes of operation. This is sometimes described as BE-8 in ARM documentation.

On the other hand, older ARM processors use a word-invariant view of endianness. This means that a word is the same in both little- and big-endian states, but bytes and halfword accesses occur differently. This is often referred to as BE-32. This is the only big-endian mode available on ARM7 and ARM9 processors and is also available for legacy support on ARM11 family devices.

Let's look at a simple piece of example code (Example 14-2) which will behave differently when run on architectures with different endianness.

Example 14-2 Example of non-portable code

```
int i;
char *buf = (char*)&i;
char i0, i1, i2, i3;

i0 = buf[0];
i1 = buf[1];
i2 = buf[2];
i3 = buf[3];
```

The values of i0...i3 are not guaranteed to be the same if the system endianness changes. This kind of code is therefore inherently non-portable.

When inspecting code in which you suspect endianness problems, you should look for the following potential causes of problems:

- Unions. A union may hold objects of different types and sizes. The programmer must keep track of what the data member represents at any particular time. Code which uses unions should be carefully checked. If the union is used to access the same data, but with different data types, there exists a possible endian (and alignment) problem. Any time that halfword, word (or longer) data types are combined or viewed as an array of bytes is a potential issue.
- Casting of data types. Anywhere that data is accessed in a way outside of its native data type is a potential problem. Similarly, if there are arrays of bytes, they should not be accessed other than as a byte data type. Casting of pointers changes how data is addressed and can be endian sensitive.
- *Bit fields*. Code that defines bitfields or performs bit operations will always be a potential source of endian problems.
- Data sharing. Any code which reads shared data from another block, or exports data to
 another block, should be checked to see whether the two blocks agree endian definitions.
 If the two are different, it may be necessary to implement byte swapping at one location.
- *Network code*. Code which accesses networking or other I/O devices needs to be reviewed to see if there is any endian dependency. Again, it may be necessary to re-write code for greater efficiency, or simply swap bytes at the interface.

14.2 Alignment

ARM processors care about the alignment of accesses. On older ARM processors, accesses to addresses which are not aligned are possible, but with a different behavior to those using the ARMv7 architecture. On ARM7 and ARM9 processors, an unaligned LDR is performed in the memory system in the same way as an aligned access, but with the data returned being rotated so that the data at the requested address is placed in the least significant byte of the loaded register. Some older compilers and operating systems were able to use this behavior for clever optimizations. This can represent a portability problem when moving code from an ARMv4 or ARMv5 to ARMv7 architecture.

ARM MMUs can be configured to automatically detect such unaligned accesses and abort them (using the CP15:SCTL A bit), see *Coprocessor 15* on page 6-18.

For the Cortex-A series of processors, unaligned accesses are supported (although one must enable this by setting the U bit in the CP15:SCTL register, indicating that unaligned accesses are permitted). This means that instructions to read or write words or halfwords may access addresses which are not aligned to word or halfword boundaries. However, load and store multiple instructions (LDM and STM) and load and store double-word (LDRD/STRD) must be aligned to at least a word boundary. Furthermore, loads and stores of floating point values must always be aligned.

These unaligned accesses may take additional cycles in comparison with aligned accesses and therefore alignment is also a performance issue. In addition, such accesses are not guaranteed to be atomic. This means that a external agent (another processor in the system) might perform a memory access which appears to occur part way through the unaligned access. For example, it might read the accessed location and see the 'new' value of some bytes and the 'old' value of others.




Figure 14-2 Aligned words at address 0 or 8

A word aligned address is one which is a multiple of four, for example 0x100,0x104,0x108,0x10C,0x110 etc. Figure 14-2 shows examples of aligned accesses.




Figure 14-3 An unaligned word

An unaligned word at address 1 is shown in Figure 14-3. It takes three bytes from the word at 0 and one byte from the word at 4.

A simple example where alignment effects may have significant performance effects is the use of memcpy(). Copying small numbers of bytes between word aligned addresses will be replaced with inline LDM/STM instructions. Copying larger blocks of memory aligned to word boundaries will typically be done with an optimized library function which will also use LDM/STM. Copying blocks of memory whose start or end points do not fall on a word boundary may result in a call to a generic memcpy() function which may be significantly slower. (Although, if the source and destination are similarly unaligned then only the start and end fragments are non-optimal.) Furthermore, if pointer alignment (or lack of alignment) has not been correctly indicated to the tools, the compiler may make incorrect assumptions and do the wrong thing.

14.3 Miscellaneous C porting issues

In this section we consider some other possible causes of problems when porting C code.

14.3.1 Unsigned char and signed char

The following piece of code illustrates a very simple example of a possible issue when porting code to ARM.

Example 14-3 Example of unsigned char usage

```
char c = -1;
if (c > 0) printf("c is positive \n");
else    printf("c is negative \n");
```

On some architectures (for example x86), the result is the one you might intuitively expect, which is that it reports the variable c as negative, but compiling the code on an ARM compiler will produce code which reports c as positive (and typically a warning will be emitted by the compiler, too).

The ANSI C standard specifies a range for both signed (at least -127 to +127) and unsigned (at least 0 to 255) chars. Simple chars are not specifically defined and it is compiler dependent whether they are signed or unsigned. Although the ARM architecture now has the instruction LDRSB (which loads a signed byte into a 32-bit register with sign extension), the earliest versions of the processor did not. And so it made sense for the compiler to treat simple chars as unsigned, whereas on the x86 simple chars are, by default, treated as signed.

One workaround for users of GCC is to use the -fsigned- char command line switch, (or --signed chars for RVCT), which forces all chars to become signed, but a better practice is to write portable code by declaring char variables appropriately. Unsigned char should be used for accessing memory as a block of bytes or for small unsigned integers. Signed char should be used for small signed integers and simple char should be used only for ASCII characters and strings. In fact, on an ARM processor, it is usually better to use ints rather than chars, even for small values, for performance reasons. Read more on this in Chapter 17 *Optimizing Code to Run on the ARM Processor*.

A second piece of code, in Example 14-4, illustrates another possible problem with chars. Here we compare EOF with a char. On the ARM, the while loop will never complete. The value of EOF is defined as -1 and when it is converted to be compared with a char (which is unsigned and therefore in the range 0 to 255), it can never be equal and so the loop does not terminate.

Example 14-4 Use of EOF

```
char c;
while ((c = getchar()) != EOF) putchar(c);
```

Here, we should declare the variable as int instead of char to avoid the problem – in fact, this is how the functions in stdio.h are defined.

Similar cases to look out for include the use of getopt() and getc() – both are defined as returning an int.

14.3.2 Compiler packing of structures

Compilers are not allowed to re-order members of a structure and have to follow the alignment restrictions of the processor architecture. This means that compilers may have to add unused bytes into user defined structures, for best performance and code size. Such padding is architecture specific and may therefore lead to portability problems if assumptions have been made about the location and size of this padding.

Marking a structure as __packed in the ARM Compiler or using the attribute __packed__ in GCC, will remove any padding. This reduces the size of the structure and can be useful when porting code or for structures being passed from external hardware, but can reduce performance and/or increase code size, although generally it will be relatively efficient on Cortex-A series processors.

If we have some simple struct code, as shown in Example 14-5:

Example 14-5 Example C struct

```
struct test
{
     unsigned char c;
     unsigned int i;
     unsigned short s;
}
```

Then the arrangement of data within the struct will be as in Figure 14-4.




Figure 14-4 Packed vs unpacked

If we now mark the structure as packed, as in Example 14-6:

Example 14-6 Packed Structure

```
struct test
{
```

```
unsigned char c;
unsigned int i ;
unsigned short s;
} __attribute__((__packed__));
```

The layout is now that byte 0 holds c, bytes 1-4 hold i and bytes 5-6 will hold s. To access s or i will require the processor to perform an unaligned access.

14.3.3 Use of the stack

Code which makes assumptions about the stack structure may require porting effort. For example, functions with a variable number and type of arguments may receive their variables through the stack. The <stdarg.h> macros dealing with accessing these arguments will walk through the stack frame and provide compatibility between systems, but code which does not use standard libraries or macros may have a problem.

14.3.4 Other issues

A function prototype is a declaration that omits the function body but gives the function's name, argument and return types. It effectively gives a way to specify the interface of a function separately from its definition. Incorrectly prototyped functions may behave differently between different compilers.

Compilers may allocate different numbers of bytes to enum. Care is therefore required when enumerations are used; cross-linking of code and libraries between different compilers may not be possible if enums are used.

Code written for 8-bit or 16-bit microprocessors may assume that integer variables are 16-bit. On ARM processors, they will always be 32-bits. The program may rely on 16-bit behaviors. In general, this is easily fixed by the use of the C short type. Use of short ints may be less efficient, as we shall see in the chapter on optimization and in cases where the code does not rely on 16-bit behavior, it is usually better to promote these variables to a 32-bit int.

14.4 Porting ARM assembly code to ARMv7

So far in this chapter, we have looked at porting C code from other architectures to ARM. It is sometimes necessary to port assembly code from older ARM processors to the Cortex-A series. Sometimes, it can be difficult to determine which ARM architecture variant your code was originally targeting. GCC has a series of macros, with names like __ARM_ARCH_6__ which are mutually exclusive. In general, ARM code is backward compatible and will work unmodified.

There are a few special cases to look for.

- CP15 Operations. The architecture specifies a consistent mapping of CP15 to designed system control operations. In general, one should attempt to understand the purpose of code which performs CP15 instructions and ensure that this code is appropriate for the ARMv7-A architecture. In addition, a number of CP15 registers (for example CP15:ACTL, the Auxiliary Control Register) are implementation specific. Code which references such registers will always need attention when being ported.
- SWAP. The SWP (or SWPB) instruction was used to implement atomic operations in older versions of the ARM Architecture, but such use is strongly deprecated in the ARMv7 architecture. There is no encoding for SWP in Thumb-2 at all, so SWP is not allowed when building for Thumb-2. In the ARMv7 architecture, SWP is disabled by default, but can be re-enabled by setting CP15:SYSCTL bit 10. Code which uses SWP should be rewritten to make use of LDREX/STREX (and possibly also barrier instructions see Chapter 9). Alternatively, the GCC __sync_... intrinsics could be used. It is usually preferable to use library functions for such things as spinlocks, semaphores, and mutexes, rather than writing such primitives yourself. The mechanisms used are different from those used by SWP, so it is necessary to port all code accessing an atomic object, not just some of it. Usually an atomic object will be managed by a piece of library code shared between the threads which access it, so this is not typically a problem.

14.4.1 Memory access ordering and memory barriers

The ARMv7 architecture has a weakly-ordered memory model. Code for older processors which makes implicit assumptions about ordering of memory accesses may not operate correctly on ARMv7 devices. This may be particularly true for code which interacts with other devices, such as a DMA controller or other bus master. Such code should be inspected and modified, possibly by the insertion of appropriate barrier instructions or by the use of suitable atomic primitives. See Chapter 9 for a more detailed discussion of memory ordering and memory barriers.

14.5 Porting ARM code to Thumb-2

We also consider problems associated with porting code written for the ARM instruction set to the Thumb-2 instruction set. As we saw in earlier chapters, use of Thumb-2 is often preferred due to its combination of small code size with higher performance relative to the older 16-bit only Thumb instruction set.

14.5.1 Use of PC as an operand

Instructions which use PC (R15) as an explicit operand may cause problems when assembling in Thumb-2. As we have seen, it is not possible to encode any arbitrary 32-bit address into any instruction as an operand. For this reason, it is common to address data stored in a literal pool using offsets relative to the current instruction location. In ARM code, the PC value may be used (with some adjustment) to determine the address of the currently executing instruction, for this purpose and this allows position-independent coding. However, the PC value obtained in this way may show some inconsistencies between ARM and Thumb state and may also depend upon the type of instruction executed. For this reason, ARM assembly code which directly references the PC register may need to be modified in order to work correctly in Thumb-2. We will consider a number of examples here:

Example 14-7 shows two different methods of loading a literal from the text section. This would most often be needed if the code is trying to load a value which cannot be encoded in the immediate operand portion of a MOV instruction, but could also be used for the address of an object which needs link-time relocation.

Example 14-7 Two potentially problematic ways of loading a literal value

```
LDR r0, [pc, #(data - . - 8)]
LDR r0, [pc, #<some offset>]
...
data:
.long 0x12345678
```

In ARM state, either of these statements would work, although the second method is highly likely to cause problems. For example if an instruction is added to, or removed from, the code, or the data location is moved, the load will return incorrect data.

In all such cases, it is better to avoid explicit PC arithmetic and instead to use an instruction like:

```
LDR r0, =<value>
```

This automatically puts <value> somewhere in the text section and assembles an appropriate PC-relative LDR instruction. You can still do a load from a local text section label which you declare explicitly, as shown below, but again, the assembler/linker should be allowed to perform the PC offset calculation:

```
LDR r0, data
...
data: .long <value>
```

Sometimes the required PC-relative address offset is too large to encode in a single LDR instruction, causing the assembler to complain that a literal pool is out of range. This can be resolved by explicitly placing a literal pool, using the .1torg directive, which tells the assembler where to insert literal data. The programmer must ensure that the literal data is not located where it might be executed as code. This typically means the .1torg directive is placed after an unconditional branch or function return instruction.

Sometimes, code needs to get the address of local data in the text section. It is tempting to do this using PC-relative arithmetic, usually an ADD or SUB instruction using the PC as an operand, as in Example 14-8.

Example 14-8 PC-relative arithmetic

```
ADD r1, pc, #(data - . - 8) ... data:
```

However, this will not work in the same way in Thumb state, where the -8 value will be incorrect. Instead, the ADR pseudo-instruction should be used. The assembler will produce a PC-based ADD or SUB with the correct offset value.

14.5.2 Branches and interworking

When using Thumb-2, the system will typically have both ARM and Thumb-2 functions (even if we compile our application for Thumb-2, we may still need to think about such things as libraries and prebuilt binaries). The processor does not know which instruction set is to be used for the code being executed after a branch, procedure call or return. This "interworking" between instruction sets was discussed in *Interworking* on page 5-10. When writing C code, the linker takes care of this for us, but a little more care is needed when porting assembly code.

The target instruction set state is determined in different ways depending on the type of branch. We can consider a number of different instructions

- Function Return. Code written for ARMv4 may use the MOV PC, LR instruction. This is unsafe for systems which contain a mix of ARM and Thumb code and should simply be replaced by BX LR for code running on all later architectures.
- Function Return from the stack. This is done using the LDMFD SP!, {registers, pc} instruction, which will continue to work correctly in ARMv7-A (although a newer, equivalent form, POP {<registers>, pc} is also available). This is used when the LR and other registers which need to be preserved by the function are PUSHed at the start of the function.
- Branch. A simple B instruction will work in the same fashion on all ARM architectures. If ARM and Thumb are mixed in a single source file (this is unusual), there is no automatic instruction set switch for local symbols. The assembler may or may not introduce a veneer depending on whether it knows that the destination is in a different instruction set and is definitely a code symbol (such as a .type <symbol>, %function or .thumb_func). Note that just because a symbol appears in a code section it is not assumed to be a code symbol unless specifically tagged in this way. If the label is in a different file, the linker will take care of any necessary instruction set change. Similar considerations apply for a function call (BL).
- *PC Modification*. Care may be needed with other instructions which modify the PC and produce a branch effect. For example, MOV PC, register must be replaced with BX register in systems which contain both ARM and Thumb code.
- Function call to register address. If code contains a sequence like MOV LR, PC followed by MOV PC, register, this will not work in a system which has both ARM and Thumb code. It should be replaced with the single instruction BLX <register>.

When a destination or return address is variable or calculated at run-time, care is needed to appropriately set the "Thumb bit" (bit [0]) in the address correctly and to do the correct type of branch, to make sure that the call (and return, if applicable) switches instruction set appropriately.

If an external label or function defined in another object is referenced, the linker will produce an address with the "Thumb bit" (bit [0]) set appropriately. However, if you reference a symbol internal to the object, things are more complicated. For C functions, or code tagged as Thumb, bit [0] will be set appropriately, but it will not be set appropriately for other symbols. In particular, GNU assembler local labels will not have the Thumb bit set appropriately, nor will the GNU current assembly location symbol (".")

Therefore, when coding in assembler, if an address will be passed to any other function or object (as a return address, method address, callback etc.), you must handle the Thumb bit setting yourself, setting bit [0] of the address where required.

14.5.3 Use of PC, "." and position-independent addressing

In ARM code, for many instructions, we can use the PC as one of the operands and typically, it will give the address of the current instruction+8. (There are some exceptions – a STR pc instruction, for example, is not guaranteed to do this.) In Thumb code, things are more complex. Most instructions are not able to use the PC as an operand. Those instructions which can access the PC as a source operand do not all produce a value with an identical offset from the current instruction.

Sometimes, we wish to get the address of a function or piece of code, to use as a callback, either by passing it to another function or by storing it in a structure. In ARM code, we could simply write LDR r0,=foo or ADR r0, foo and have the address of function foo() in a register. ADR works only for nearby labels in the same section of the same source file, but can be more efficient. However, ADR never sets the "Thumb bit". LDR <reg>, <symbol> will give you a value with the Thumb bit set appropriately for external symbols, but for local symbols, LDR <reg>, <symbol> will not set the Thumb bit unless the symbol is designated as a function symbol. Therefore, the LDR r0,= method is preferred, along with an appropriate definition like ".type foo, %function"

This ensures that the Thumb bit in the address gets set correctly. If the code which uses the value performs a correct interworking function call, it doesn't need to know whether your assembler was ARM or Thumb when calling back into it.

14.5.4 Operand combinations

Thumb-2 and ARM Assembly code have different restrictions on instruction operands. You may therefore find that existing ARM code may produce assembler errors when targeted for Thumb-2.

"Branch out of range" errors occur when the distance between the current instruction and the branch target is too large to be encoded in a Thumb-2 instruction. To resolve this, it may be necessary to use a different type of branch, move code sections or to use a two-stage branch, a so-called "trampoline".

Similarly, "index out of range" errors maybe produced on load and store operations and to resolve these, it may be necessary to manually add part (or all) of the required index offset to the base register in a separate explicit instruction.

Generally, use of SP should be limited to stack operations — other usage may not be permitted in Thumb-2 code. This means that PUSH, POP, LDMFD SP!, STMFD SP!, ADD, SUB or MOV instructions which use the SP are allowed, but other operations should be treated as possible problems. Similarly, operations which directly operate on the PC should be checked (other than the usual function or exception return operations, or literal pool loads).

14.5.5 Other ARM/Thumb-2 differences

There are a number of other differences which may need attention by the assembly language programmer.

- The RSC instruction is not available in Thumb-2. Therefore, code which uses RSC needs to be re-coded using RSB and/or SBC, or built in ARM state.
- Most ARM instructions may optionally be made conditional. This is not the case in Thumb-2, other than for branches. Instead, small instruction sequences can be executed conditionally by preceding them with the IT instruction. For compatibility with both ARM and Thumb, the IT block construct is always understood when using unified assembler syntax. Manually modifying code to use IT instructions can be tedious. Fortunately, the assembler command-line option -mimplicit-it=<when>, where <when> can be one of never, arm, thumb or always. When assembling for Thumb-2, it is therefore sensible to use -mimplicit-it=thumb.

Chapter 15 **Application Binary Interfaces**

The C compiler (and indeed compilers for other languages) is able to generate code from many separately compiled modules. These modules must be able to work together with each other and with the operating system code and any code which is written in assembler or any other compiled language. For that reason, we must define a set of conventions to govern inter-operability between pieces of code.

The Application Binary Interface (ABI) for the ARM architecture specification describes a set of rules which an executable must adhere to execute in a specific environment. It specifies conventions for executables, including file formats and ensures that objects from different compilers, assemblers etc. can be linked together successfully. There are variants of the ABI for specific purposes, for example, we may consider the Linux ABI for the ARM architecture or the Embedded ABI (EABI).

The ARM Architecture Procedure Call Standard (AAPCS) is part of the ABI and specifies conventions for register and stack usage by the compiler and during subroutine calls. Knowledge of this is vital for inter-working C and Assembly code and can be useful for writing optimal code. The AAPCS supersedes the previous ARM-Thumb Procedure Call Standard (ATPCS).

The AAPCS mandates specific things that must be done by a caller to allow a callee function to run and what the called routine must do to preserve the program state of the caller through a function. It describes the way that data is laid out in memory and how the stack is laid out, plus allowed variations for processor extensions. It defines how code which has been separately compiled and/or assembled works together.

15.1 Procedure call standard

As we have seen, there are 16 integer registers available in the processor, each of size 32-bits. These are labeled R0-R15. Table 15-1 shows the role assigned to registers within the procedure call standard.

Table 15-1 APCS registers

Register	PCS Name	PCS Role
R0	a1	argument 1/scratch register/ result
R1	a2	argument 2/scratch register/ result
R2	a3	argument 3/scratch register/ result
R3	a4	argument 4/scratch register/ result
R4	v1	register variable
R5	v2	register variable
R6	v3	register variable
R7	v4	register variable
R8	v5	register variable
R9	tr/sb/v6	static base/ register variable
R10	s1/v7	Stack limit/stack chunk handle/register variable
R11	FP/v8	Frame pointer/ register variable
R12	IP	scratch register/ new -sb in inter-link-unit calls
R13	SP	Lower end of the current stack frame
R14	LR	link register/ scratch register
R15	PC	program counter

For the purposes of function calls, the registers are divided into 3 groups:

- *argument* registers R0-R3 (a1-a4). These may be used as scratch registers or as caller-saved register variables which can hold intermediate values within a routine, between calls to other functions.
- *callee-saved* registers, normally used as register variables. Typically, the registers R4-R8, R10 and R11 (v1-v5, v7 and v8) are used for this purpose.
- registers which have a dedicated role. The function of the program counter, link register and stack pointer should by now be obvious. The role of IP (R12) is that it can be used by the linker, as a scratch register between a routine and any subroutine it calls, or as an additional local variable within a function. As the BL instructions cannot address the full 32-bit address space, the linker may need to insert a veneer between the caller and callee. Veneers may also be used for ARM-Thumb inter-working or dynamic linking. Veneers are allowed to modify the contents of IP (R12). Register R9 has a role which is specific to a particular environment. It may be used as the static base register (SB) to point to position-independent data, or as the thread register (TR) where thread-local storage is used. In code that has no need for such a special register, it may be used as an extra callee-saved variable register, v6.

The first four word-sized parameters passed to a function will be transferred in registers R0-R3. Sub-word sized arguments (for example, char) will still use a whole register. Arguments larger than a word will be passed in multiple registers. If more arguments are passed, then the fifth and subsequent words will be passed on the stack. Passing arguments on the stack always requires additional instructions and memory accesses and therefore reduces performance. For optimal code, therefore, the programmer should always try to limit arguments to four words or fewer. If not possible, the most commonly used parameters should be defined in the first four positions of the function definition. If the arguments are part of a structure then it is more optimal to pass a pointer to the structure instead. C++ uses the first argument to pass the "this" pointer to member functions, so only three arguments can be passed in registers.

There are additional rules about 64-bit types. 64-bit types must always be 8-byte aligned in memory (recall that earlier we described how there are limitations on use of LDRD and STRD double-word instructions to unaligned addresses). In addition, 64-bit arguments to functions must be passed in an even + consecutive odd register pair (for example, R0+R1 or R2+R3). If passed on the stack, they must be at an 8-byte aligned location. Again, this is because of restrictions on LDRD and STRD instructions. If such 64-bit arguments are listed in a sub-optimal fashion, then there may be "wasted" space in registers or on the stack. When considering such issues, it is important to take into account the "this" argument in R0 present in all non-static C++ member functions.




Figure 15-1 Efficient Parameter Passing

Figure 15-1 shows some examples of how sub-optimal listing of arguments can cause unnecessary spilling of variables to the stack. The figure shows how two different function calls, which pass identical parameters, make use of the registers and stack. The first function passes an int, a double and a further int. The first parameter is passed in R0. The second argument is 64-bits and must be passed in an even and consecutive odd register (or in an 8-byte aligned location on the stack). It is therefore passed in R2 and R3. This means that the final argument is passed on the stack. As the stack pointer needs to be 8-word aligned, there will be an additional unused word pushed and popped. In the second function call, we can pass the two int values in registers R0 and R1 and the double value in R2 and R3. This means that no values are spilled to the stack, which gives more efficient code, requiring both fewer instructions and fewer memory accesses.

The registers R4-R11 (v1-v8) are used to hold the values of a subroutine's local variables. A subroutine is required to preserve (on the stack), the contents of the registers R4-R8, R10, R11 and SP (and R9 in PCS variants that designate R9 as v6), if they are used by that subroutine.

A caller function will have code like this:

```
@ may need to preserve r0-r3
@ does not need to preserve r4-r11
BL Func:
```

Func:

While the callee function will have code like this:

```
@ Must preserve r4-r11, lr (if used)
@ May corrupt r0-r3, r12
PUSH {r4-r11, lr}
...
...
```

POP {r4-r11, pc} @ Returns value in r0 - char, short or int

@ Returns value in r0 & r1 - double

The PUSH/POP must be of an even number of registers for function calls beyond an external boundary, to maintain 8-byte stack alignment. Leaf functions do not to do so. The example callee code as shown pushes/pops R4-R11 and LR, which would not preserve an 8-byte aligned stack. It is shown like this to indicate which registers need to be saved. In practise, the compiler will normally push an extra register, depending on whether the function is leaf and which

registers are modified by the function. Actual instructions will usually be one of PUSH/POP {r4-r8,

lr}, PUSH/POP {r4-r10, lr} or PUSH/POP {r4-r12, lr}.

15.1.1 VFP and NEON register usage

Readers unfamiliar with ARM floating point may wish to refer to Chapter 18 *Floating Point* before reading this section.

VFPv3 has 32 single-precision registers s0-s31, which may also be accessed as double precision registers d0-d15. There are a further 16 double-precision registers, d16-d31. NEON can also view these as quadword registers q0-q15. Registers s16-s31 (d8-d15, q4-q7) must be preserved across subroutine calls; registers s0-s15 (d0-d7, q0-q3) do not need to be preserved (and can be used for passing arguments or returning results in standard procedure-call variants). Registers d16-d31 (q8-q15), do not need to be preserved.

The Procedure Call Standard specifies two ways in which floating-point parameters may be passed. For software floating point, they will be passed using ARM Registers R0-R3 and on the stack, if required. An alternative, where floating-point hardware exists in the processor, is to pass parameters in the VFP/NEON registers.

This hardware floating point variant behaves in the following way:

• Integer arguments are treated in exactly the same way as in softfp. So, if we consider the function f, shown below, we see that the 32-bit value a will be passed to the function in R0, and because the value b must be passed in an even/odd register pair, it will go into R2/R3 and R1 is unused.

```
void f(uint32_t a, uint64_t b)
   r0: a
   r1: unused
   r2: b[31:0]
   r3: b[63:32]
```

- FP arguments fill d0-d7 (or s0-s15), independently of any integer arguments. This means that integer arguments can flow onto the stack and FP arguments will still be slotted into FP registers (if there are enough available).
- FP arguments are able to back-fill, so it's less common to get the unused slots that we see in integer arguments. Consider the following examples:

```
void f(float a, double b)
    d0:
     s0: a
    s1: unused
    d1: b
```

Here, b is aligned automatically by being assigned to d1 (which occupies the same physical registers as VFP s2/s3).

```
void f(float a, double b, float c)
    d0:
    s0: a
    s1: c
    d1: b
```

In this example, the compiler is able to place c into s1; it does not need to be placed into s4.

In practice, this is implemented (and described) by using separate counters for s, d and q arguments, and the counters always point at the next available slot for that size. In the second FP example above, a is allocated first because it's first in the list, and it goes into first available s register, which is s0. Next, b is allocated into the first available d register, which is d1 because a is using part of d0. When c is allocated, the first available s register is s1. A subsequent double or single argument would go in d2 or s4, respectively.

 There is a further case when filling FP registers for arguments: Once an argument must be spilled to the stack, no back-filling can occur, and stack slots are allocated in exactly the same way for further parameters as they are for integer arguments.

```
void f( double a, double b, double c, double d,
        double e, double f, float g, double h,
        double i, float j)
    d0: a
    d1: b
    d2: c
    d3: d
    d4: e
    d5: f
    d6:
      s12: q
      s13: unused
    d7: h
    *sp:
    *sp+8: j
    *sp+12: unused (4 bytes of padding for 8-byte sp alignment)
```

Arguments a-f are allocated to d0-d5 as expected.

The single-precision g is allocated to s12, and h goes to d7.

The next argument, i, can't fit in registers, so it is stored on the stack. (It would be interleaved with stacked integer arguments if there were any.) However, whilst s13 is still unused, j must go on the stack because we cannot back-fill to registers once FP arguments have hit the stack.

• Double-precision and quad-precision registers can also be used to hold vector data. This would not occur in typical C code.

• No VFP registers are used for variadic procedures, that is, a procedure which does not have a fixed number of arguments. They are instead treated as in softfp, in that they are passed in integer registers (or the stack). Note that single-precision variadic arguments are converted to doubles, as in 'softfp'.

15.1.2 Stack and heap

The stack is an area of memory used for storage of local variables (and for passing additional arguments to subroutines when there are insufficient argument registers available, as we have seen). The stack implementation is full-descending, with the current top of the stack pointed to by R13 (SP). The stack must be contiguous in the virtual memory space. The stack will typically have both a base address and a limit. The base address is that of the bottom entry on the stack. The limit represents the lowest address that the stack may grow down to. This may be able to change dynamically in some systems. An application may not be able to determine either value. The stack limit must, of course, always be lower than the current value of the stack pointer. Detection of a stack overflowing this limit is usually handled with memory management. The stack must always be aligned to a word boundary, except at a public interface, when it must be double-word aligned. This means that interrupt handler code cannot rely on the stack being double word-aligned (an interrupt could occur at a time when the stack is merely word-aligned).

The heap is an area (or areas) of memory that are managed by the process itself (for example, with the C malloc() function). It is typically used for the creation of dynamic data objects.

15.1.3 Returning results

A function which returns a char, short, int or single-precision float value will do so using R0. A function which returns a 64-bit value (a double precision float or long long) does so in R0 and R1. As mentioned above, floating point and NEON return values will be in s0, d0, or q0 when using hardware linkage.

15.2 Mixing C and assembly code

One example of why it can be useful to understand the AAPCS is to write assembly code which is compatible with C code. One way to do this is write separate modules and assemble them with GNU gas. They can be defined as extern functions in C and called; provided the AAPCS rules are followed, there should be no problem.

We can also insert assembly code into our C code. Let's have a looked at such inline or embedded assembly, through the GCC asm statement. This is very simple to use. For example, we can implement a NOP as shown in Example 15-1.

Example 15-1 NOP

asm("nop");

The time taken to carry out a NOP is undefined.

In fact, it is likely that this NOP will have no effect, because the C compiler will optimize it away! When you include assembly language code by with inline assembler, the resulting code is still subject to optimization by the C compiler. This is a very important point which must be taken into account whenever inline assembly is used.

Inline assembly code has a different syntax than regular assembly code. Registers and constants have to be specified differently, if they refer to C expressions.

Let's look at a slightly more complicated example; we take the value of an int and use the USAD8 assembly instruction to calculate the sum of difference of bytes and then store the result in a different int. Example 15-2 shows the relevant code.

Example 15-2 Using the USAD8 instruction.

```
asm("usad8 \ \%[result], \ \%[value]" : [result] \ "=r" \ (xrev) : [value] \ "r" \ (x));
```

The colons divide the statement up into three parts. The first part "rev %[result], %[value]" is the actual assembly instruction. The second part is an (optional) list of output values from the sequence. If more than one output is needed, commas are used to separate the entries. Each entry has a symbolic name surrounded by square brackets, followed by a constraint string and finally a C expression surrounded by brackets – in our example this is [result]="r"(xrev). We may then optionally have a list of input values for the sequence, with the same format as the output. If you don't specify an output operand for an assembly sequence, it is quite likely that the C compiler optimizer will decide that it is not serving any useful purpose and optimize it away! A way to avoid this is to use the volatile attribute, which tells GCC not to optimize the sequence.

In the actual assembly language statement, operands are referenced by a percent sign followed by the symbolic name in square brackets. The symbolic name references the item with the same name in either the input or output operand list. This name is completely distinct from any other symbol within your C code (although clearly it is less confusing to use symbols which do have a meaning within your code). Alternatively, operand may be specified using a percent sign followed by a digit (that is,%0, %1 ... %9).

There is an optional fourth part to an asm statement, called the "clobber" list. This allows us to specify to the compiler what will be changed by the assembly code. We can specify registers (for example, "R0"), the condition code flags ("cc") or memory.

This makes the compiler store affected values before and reload them after executing the instruction.

The constraints mentioned when we talked about input and output operand lists relate to the fact that assembly language instructions have specific operand type requirements. When passing parameters to inline assembly statements, the compiler must know how they should be represented. For example, the constraint "r" specifies one of the registers R0-R15 in ARM state, while "m" is a memory address and "w" is a single precision floating point register. These characters have an = placed before them to indicate a write-only output operand, a "+" for a read/write output operand (that is, one that is both input and output to the instruction). The "&" modifier instructs the compiler not to select any register for the output value, which is used for any of the input operands.

You can force the inline assembler to use a particular register to hold a local variable by doing something like the code shown in Example 15-3.

Example 15-3 Inline assembler local variable usage

```
void func (void) {
  register unsigned int regzero asm("r0");
and later
  asm volatile("rev r0, r0");
```

This usage can interfere with the compiler optimization and does not guarantee that the register will not be re-used, for example when the local variable is no longer referenced. Hard coding register usage is always bad practice. It is almost always better to use local variables instead.

Example 15-4 Inline assembler example

```
void __naked get_fiq_regs(struct pt_regs *regs)
  register unsigned long tmp;
  asm volatile (
  "mov
         ip, sp\n\
  stmfd sp!, \{fp, ip, lr, pc\}\n
  sub
         fp, ip, \#4\n\
         %0, cpsr\n\
  mrs
         cpsr_c, %2 @ select FIQ mode\n\
  msr
         r0, r0\n\
  mov
         %1, \{r8 - r14\}\n
  stmia
  msr
         cpsr_c, %0 @ return to SVC mode\n\
  mov
         r0, r0\n\
  ldmfd sp, {fp, sp, pc}"
  : "=&r" (tmp)
    "r" (&regs->ARM_r8), "I" (PSR_I_BIT | PSR_F_BIT | FIQ_MODE));
```

Example 15-4 gives a longer example of inline assembler, taken from the Linux kernel. It shows how a series of inline assembly language instructions can be used. The code manipulates the CPSR, to change modes. This would not be possible using C code.

ARM's Compiler tools have a similar concept, albeit with different syntax. In addition to inline assembly, they also support "embedded" assembly which is assembled separately from the C code and produces a compiled object which is combined with the object from the C compilation.

A global index gives unique data for each thread within a process. A thread allocates the index when the process starts. The other threads use this to retrieve the unique data associated with the index. When a thread starts, it allocates a block of dynamic memory and stores a *Thread Local Storage* (TLS) pointer to this memory. This may either be located in memory, or in ARM MPCore systems, a dedicated CP15 register.

Chapter 16 **Profiling**

The computer scientist Donald Knuth famously observed that "Premature optimization is the root of all evil." However, Knuth's comment does not argue against appropriate optimization.

Code optimization is an important part of the work of software engineers—modifying software so that it runs more quickly, uses less power and/or makes less use of memory or other resources. In order to do this, we must first identify which part (or parts) of the code should be optimized.

Profiling is a technique that lets us identify functions (or other pieces of code) which consume large proportions of the total execution time. It is usually more productive to focus optimization efforts on code segments which are executed very frequently, or which take a long time to execute than to optimize rarely used functions or code which takes little time to execute. A profiler will tell us which parts of the code are frequently executed and which occupy the most CPU cycles. A profiler may help us identify *bottlenecks*, situations where the performance of the system is constrained by a small number of functions (or just one). This data is collected using instrumentation, an execution trace or sampling, and can often be a good method for finding hidden bugs, too.

When you have identified some slow part of your code it's important to first consider whether you can change the algorithm, before trying to improve the existing code. For example, if the time is being spent searching a linked list it's probably much more beneficial to change to using a tree or hash table instead of spending effort to speed up the linked list searching.

Profiling may be considered as a form of dynamic code analysis. Profiling tools can gather information in a number of different ways. We can distinguish two basic approaches to gathering information.

• *Time Based Sampling*. Here, the state of the system is sampled at a periodic, time-based interval. The size of this interval may affect the results – a smaller sampling interval may increase execution time but produce more detailed data.

• Event Based Sampling. Here, sampling is driven by occurrences of an event, which means that the time between sampling intervals is usually variable. Events may often be hardware related – for example, cache misses.

It is also important to understand that profilers typically operate on a statistical basis – they may not necessarily produce absolute counts of events. In complex systems, it may be necessary to control profiling information by use of annotation options to specify which events are to be recorded, which events shown, or thresholds to avoid counting large numbers of functions with low count numbers.

16.1 Profiler output

Profiler tools normally provide two kinds of information:

Call Graph

The call graph tells us the number of times each function was called. This can help point out which function calls can be eliminated or replaced and shows inter-relations between different functions. Viewing a call graph may suggest code to optimize and reveal hidden bugs (for example, if code is unexpectedly calling an error function many times). Collecting call graph information may require building the code with special options.

Flat Profile

A flat profile, as in Example 16-1 shows how much processor time each function uses and the number of times it was called. This allows a simple identification of which functions consume large fractions of run-time and should therefore be considered first for possible optimizations.

Example 16-1 Example flat profile

Flat p	rofile:
--------	---------

Each sample counts as 0.01 seconds.								
% cu	mulative	self		self	total			
time	seconds	seconds	calls	ms/call	ms/call	name		
33.34	0.02	0.02	6275	0.00	0.00	start		
16.67	0.03	0.01	192	0.07	0.21	func1		
16.67	0.04	0.01	15	1.20	1.20	memcpy		
16.67	0.05	0.01	7	1.41	1.41	write		

It may be useful at this point to consider some example profiling tools which can be used in Cortex-A series processors:

16.1.1 Gprof

GProf is a GNU tool which provides an easy way to profile your C/C++ application and find the locations that need work.

Using GCC, you can generate profile information by compiling with a special flags. The source code has to be compiled with the -pg option. For line-by-line profiling, the -g option would also be needed. You then execute the compiled program and the profiling data is collected. You then run gprof on the resulting statistics file to view the data, in a variety of convenient formats.

When you compile with -pg the compiler adds profiling instrumentation that collects data at function entry and exits at runtime. It therefore profiles only the user application code and not anything that happens in code that has not been built for profiling (for example, libc) or the kernel. Gprof may give misleading results if the performance limitations of the code come from kernel or I/O issues (memory fragmentation or file accesses for example).

It may be necessary to remove GCC optimization flags, as some compiler optimizations can cause problems while profiling. It is also the case that the use of the profiling flags will actually slow the program down. This can be an important consideration in some types of real-time system, where it may be that the interaction of real-time events has a significant effect on the performance of the profiled code. A binary file called gmon.out containing profiling information is generated. This file may then be operated on by the gprof tool.

16.1.2 OProfile

OProfile is a system profiling tool which runs on Linux. Unlike gprof, it works using a statistical sampling method. Oprofile can examine the system at regular intervals, determine what code is running, and update appropriate counters. If a long enough profile is taken, with a sufficient sample rate, an accurate picture of the execution is obtained. Like other profilers which make use of interrupts, code which disables interrupts can cause inaccuracies. For this reason, the Linux function spinlock_irq_restore(), which re-enables interrupts after a spinlock has been relinquished may erroneously appear to be a major system bottleneck, as the time for which interrupts were disabled may be counted against it. OProfile can also be made to trigger on hardware events and will record all system activity including kernel and library code execution.

OProfile does not need code to be recompiled with any special flags (provided symbol information is available). It provides useful hardware information about clock cycles, cache misses etc. Call graphs are statistically generated, so may not be completely accurate. If OProfile did not make use of such sampling, the execution speed of the system would be reduced (and of course would just result in a profile of the profiler itself).

16.1.3 Streamline

ARM Streamline is a graphical performance analysis tool, which can be used to profile your code. It combines a kernel driver, target daemon, and an Eclipse-based user interface. Streamline takes sampling data and system trace information and produces reports that present the data visually and in a statistical form. ARM Streamline uses the hardware performance counters, as well as kernel metrics to provide an accurate representation of system resources.

16.1.4 ARM Performance Monitor

The performance monitor hardware is able to count several events, using multiple counters. Typically, we combine together multiple values to generate useful parameters to optimize. For example, we may choose to count the total number of clock cycles and the number of instructions executed and use this to derive a cycles per instruction figure which is a useful proxy for the efficiency with which the processor is operating. We can generate information about cache hit or miss rates (separately for both L1 data and instruction caches) and examine how code changes can affect these.

Cortex-A series processors contain event counting hardware which can be used to profile and benchmark code, including generation of cycle and instruction count figures and to derive figures for cache misses and so forth. The performance counter block contains a cycle counter which can count core cycles, or be configured to count every 64 cycles. There are also a number of configurable 32-bit wide event counters which can be set to count instances of events from a wide-ranging list (for example, instructions executed, or MMU TLB misses). These counters can be accessed through debug tools, or by software running on the processor, through the CP15 *Performance Monitoring Unit* (PMU) registers. They provide a non-invasive debug feature and do not change the behavior of the core. CP15 also provides a number of controls for enabling and resetting the counters and to indicate overflows (there is an option to generate an interrupt on a counter overflow). The cycle counter can be enabled independently of the event counters.

It is important to understand that information generated by such counters may not be exact. In a superscalar, out-of-order processor, for example, it can be difficult to guarantee that the number of instructions executed is precise at the time any other counter is updated.

The standard countable events, common to all ARMv7-A processors are listed in Table 16-1. The *Technical Reference Manual* for the specific processor being used provides further information on the lists of events which can be monitored, which may include a large number of additional possibilities above those listed here.

Table 16-1 Performance Monitor events

Number	Event Counted	
0x00	Software increment of the Software Increment Register	
0x01	Instruction fetch that causes a refill	
0x02	Instruction fetch that causes a TLB refill	
0x03	Memory Read or Write operation that causes a cache line refill	
0x04	Memory Read or Write operation that causes cache access	
0x05	Memory Read or Write operation that causes a TLB refill	
0x06	Memory-reading instruction executed	
0x07	Memory-writing instruction executed	
0x09	Exception taken	
0x0A	Exception return executed	
0x0B	Instruction that writes to the Context ID register	
0x0C	Software change of program counter	
0x0D	Immediate branch instruction executed	
0x0F	Unaligned access	
0x10	Branch mispredicted or not predicted	
0x11	Cycle count. The register is incremented on every cycle	
0x12	Branch or other change in program flow that could have been branch predicted	
0x13-0x3F	Reserved	

MPCore versions of the Cortex-A5 and Cortex-A9 processors include a significant number of additional events relating to SMP capabilities, discussed later in this book. These include numbers of barrier instructions executed, measures of coherent cache activity and counts of exclusive access failures.

In Linux, these counters are normally accessed through the kernel via Linux "OProfile" or Linux "Perf Events" framework. However, user mode access to these counters can be enabled for direct access if required.

16.1.5 Linux perf events

ARM Linux contains recent patches (linux-2.6.34) to support the new Ingo Molnar perf events framework. This was added to the mainline kernel during 2009. It handles multiple events, including CPU cycles and cache-misses but also measures kernel events like context switches. It provides simple, platform independent access to the ARM's performance counter registers and also to software events. Through this framework, tools can produce graphs and statistics about function calls etc. You can also record execution traces, profile on a per-processor, per-application and per-thread basis and generate summaries of events.

16.1.6 Ftrace

Ftrace is an increasingly widely used trace tool on ARM Linux. It provides visualization of the flow within the kernel by tracing each function call. It allows interactions between parts of the kernel to be viewed and allows to developers to investigate potential problem paths where interrupts or pre-emption are disabled for long periods.

16.1.7 Valgrind/Cachegrind

Valgrind is a widely used tool, commonly used for detection of memory leaks and other memory handling problems; however, it can also be used for profiling memory usage and is potentially able to give much more detailed results than OProfile. Valgrind translates a program into a processor-neutral intermediate representation. Other tools associated with Valgrind are able to operate on this and then Valgrind translates the code back into native machine code. This process makes the code run an order of magnitude slower, but allows checks for accesses to undefined memory, off-by-one errors and so forth to be performed by tools like Memcheck.

For memory access optimization, the Cachegrind tool can be used. As Valgrind simulates the execution of the program, we can use this to record all uses of program memory. By simulating the operation of the processor caches, we can generate statistics about cache usage. Some care is needed – this is a simulation of the cache and it is possible that it does not 100% accurately represent the real cache hardware. Nevertheless, it can be a very useful tool to examine cache and memory usage by an application. When writing high level applications, it can be difficult for the programmer to have much appreciation for (or control over) addresses used by a program. The linker will typically generate many of the virtual addresses used within an image, while the runtime loader will control positioning of libraries and so forth. Finally, the kernel is responsible for placement of code and data in physical memory. Memory profiling tools can therefore be a useful aid.

Chapter 17

Optimizing Code to Run on the ARM Processor

In Chapter 16, we looked at how to identify which parts of the program are suitable for optimization. In this chapter we will look at some possible software optimizations. Much of what is presented will apply equally to any system, but some of the suggested optimizations are specific to ARM systems, or indeed to particular ARM cores.

Optimization does not necessarily mean optimizing to make programs faster. In embedded systems, we may prefer to optimize for battery life, code density or memory footprint, for example. Writing code which is more efficient delivers not only higher levels of performance, but can also be crucial in conserving battery life. If we can get a job done faster, in fewer cycles, we can turn off the power for longer periods.

Many compilers provide options to help with this. For example, the GNU GCC compiler has the -0 flags to specify the level of optimization. So, we will spend some time looking at the effects of these and how to trade off optimizations of code density, speed and debug visibility.

We will then continue by looking at ways in which the programmer may modify his program in order to generate more optimized code. In a book of this size, we cannot cover such topics of algorithm design which may lead to significant performance gains, but we will instead concentrate our efforts on those things where an understanding of the underlying ARM architecture can help to optimize code.

Although cycle timing information can be found in the *Technical Reference Manual* (TRM) for the processor that you are using, it is very difficult to work out how many cycles even a trivial piece of code will take to execute. The movement of instructions through the pipeline is dependent on the progress of the surrounding instructions and may be significantly affected by memory system activity. Pending loads or instruction fetches which miss in the cache may stall code for tens of cycles. Standard data processing instructions (logical and arithmetic) will take only one or two

cycles to execute, but this does not give the full picture. Instead, we must use profiling tools, or the system performance monitor built-in to the core, to extract useful information about performance.

17.1 Compiler optimizations

GNU GCC gives us a wide range of options which aim to increase the speed, or reduce the size, of the executable files it generates. For each line in the source code there are generally many possible choices of assembly instructions that could be used. The compiler must trade-off a number of resources, such as registers, stack and heap space, code size (number of instructions) and number of cycles per instruction in order to produce the "best" image file.

We'll begin by looking at some of the source-level optimization options available to the compiler.

17.1.1 Function in-lining

When a function is called, there is a certain overhead. On the ARM, the instruction pipeline must be invalidated, which costs cycles. For non-leaf functions, it must store the function return address on the stack. Instructions may be required to place arguments in the appropriate registers and push registers on the stack, in accordance with the procedure call standard. There is a corresponding overhead when returning to the original point of execution when the function ends, again requiring a branch (and corresponding instruction pipeline flush) and possibly popping registers from the stack. This function-call overhead can become important when there are functions which contain only a few instructions, and where these functions represent a significant amount of the total run-time. Function in-lining eliminates this overhead by replacing calls to a function by a copy of the actual code of the function itself (known as placing the code *in-line*).

In-lining is always a worthwhile optimization if there is only one place where the function is called. It is always worthwhile if calling the function requires more instructions (memory) than in-lining the function body. A further consideration is that in-lining can help permit other optimizations. Clearly, increasing the number of times that a function is called will increase the number of in-lined copies of the function that are made and this will increase the cost in code size.

GCC performs in-lining only within each object file. The inline keyword can be used to request that a specific function should be inlined wherever possible, even in other files. The GCC documentation gives more details of this (and how its use may be combined with static and extern).

We will look at in-lining in a little more detail when we consider cache optimizations.

17.1.2 Eliminating common sub-expressions

Another simple source-level optimization is re-using already computed results in a later expression. This *common sub-expression elimination* is performed automatically when optimization command line switches are used and can make code both smaller and faster.

Example 17-1 illustrates how this works.

Example 17-1 Common sub-expression example

```
i = a * b + c;

j = a * b * d;
```

The compiler may treat this code as if it had been written as in Example 17-2 on page 17-4:

Example 17-2 Common sub-expression elimination

```
tmp = a * b;
i = tmp + c;
j = tmp * d;
```

This reduces both the instruction count and cycle count.

17.1.3 Loop unrolling

Every iteration of a loop has a certain penalty associated with it. Every conditional loop must include a test for the end of loop on each iteration. Furthermore, there is a branch instruction to iterate over the loop, which may take a number of cycles to execute. We can avoid this penalty by unrolling loops, partially or fully.

Consider the simple code shown in Example 17-3, to initialize an array.

Example 17-3 Loop termination assembly code

```
CMP i,#10
BLT for_loop
```

A large proportion of the total run time will have been spent checking if the loop has terminated and in executing a branch to re-execute the loop.

The same code can be written by unrolling the loop, as shown in Example 17-4.

Example 17-4 Unrolled loop

```
x[0] = 0;

x[1] = 1;

x[2] = 2;

x[3] = 3;

x[4] = 4;

x[5] = 5;

x[6] = 6;

x[7] = 7;

x[8] = 8;

x[9] = 9;
```

When the code is written in this way, we remove the compare and branch instruction and simply have a sequence of stores and adds. This is clearly larger than the original code but may execute considerably faster.

Conventionally, loop unrolling is often considered to increase the speed of the program but at the expense of an increase in size (except for very short loops). However, this is not always the case on true hardware. In many systems, an access to external memory takes significant numbers of cycles and an instruction cache is provided. Code which loops will typically cache very well. The code is fetched into the cache during the first loop iteration and is executed directly from cache after that. Unrolling the loop may mean that the code is executed only once and so does not cache so well. This is more likely to be the case for functions which are executed only once – loops which are frequently executed may well be cached whether they are unrolled or not. A further consideration is that modern ARM processors typically include branch

prediction logic which can hide the effect of pipeline flushes from the programmer by speculatively predicting whether a branch will or will not be taken ahead of the actual evaluation of a condition. In some cases, the branch instruction can be 'folded', so that it does not require an actual CPU cycle to execute

The Cortex-A series processors may have long, complex instruction pipelines, with interdependencies between instructions, particularly loads and instructions which set condition code flags. The compiler understands the rules associated with a particular processor and can often re-arrange instructions so that pipeline interlocks are avoided. This is called "scheduling" and typically involves re-arranging the order of assembly language instructions in ways which do not alter the logical correctness of the program or its size, but which reduce its execution time. This can significantly increase the compiler effort, increasing both the time and memory required for the compilation. It can also restrict the ability to perform source level debug. There may no longer be a strict one-to-one link between a line of C source and a sequence of assembly instructions. We may instead have a couple of instructions from a C statement followed by instructions for the next statement and then some more instructions for the first statement.

17.1.4 GCC Optimization options

GCC has a range of optimization levels, plus individual options to enable or disable particular optimizations.

The command line option -OLEVEL gives a choice of optimization levels, as described below:

- -00. (default). No optimization is performed. Each source code command relates directly
 to the corresponding instructions in the executable file. This gives the clearest view for
 source level debugging.
- -01. This enables most common forms of optimization that requires no size versus speed decisions. It can often actually produce a faster compile than -O0, due to the resulting files being smaller.
- -02. This enables further optimizations, such as instruction scheduling. Again, optimizations which may have speed versus size implications will not be used.
- -03. This enables further optimizations, such as function inlining and may therefore increase the speed at the expense of image size.
- funroll-loops. This option is independent of the above and enables loop unrolling. As
 previously discussed, loop unrolling may increase code size and may not have a beneficial
 effect in all cases.
- -0s. This selects optimizations which attempt to minimize the size of the image, even at the expense of speed.

Higher levels of optimization can restrict debug visibility and increase compile times. It is usual to use -00 for debugging, and -02 for finished code. When using the above optimization options with the -g (debug) switch, it can be difficult to see what is happening. The optimizations can change the order of statements, remove (or add) temporary variables etc. But an understanding of the kinds of things the compiler will do means that satisfactory debug is normally still possible with -02 -g.

For optimal code, it is important to specify to the compiler which ARM processor you are using; without knowledge of that (and in many cases what optional hardware like VFP or NEON is available), it cannot do a good job.

17.2 ARM Memory system optimization

Writing code which is optimal for the system it will run on is a key part of the art of programming. It requires the programmer to understand how the compiler and underlying hardware will carry out the tasks described in the lines of code. If we can do the job with less access to external memory, we can save power by keeping everything on-chip. Furthermore, by accessing the cache more frequently, we improve the performance of the system, allowing software to run faster (or the processor to be clocked more slowly or for shorter periods, to save power).

17.2.1 Data cache optimization

In most Cortex-A series processors, there is a significant gap in performance between memory accesses which hit in the cache and those that do not. Cache hits will normally not stall the processor pipeline. Cache misses may take tens of cycles to resolve. For most algorithms, therefore, ensuring that cache misses are minimized is the most important possible optimization. The most important improvements are those which affect the level 1 cache.

Let us consider the problem of data cache misses first. Optimization is particularly significant for pieces of code which use a dataset larger than the available cache size. It is important for the programmer of such code to understand the arrangement of data in memory and how that corresponds to data cache accesses. Code should be structured in a way which ensures maximum re-use of data already loaded into the cache. It is this principle of *data locality*, the degree to which accesses to the same cache line are concentrated during program execution, in both space and time, which gives best performance.

Several techniques to improve this locality may be considered.

17.2.2 Loop tiling

Loop tiling divides loop iterations into smaller pieces, in a way which promotes data cache re-use. Large arrays are divided into smaller blocks (tiles), which match the accessed array elements to the cache size. The classic example to illustrate this approach is a large matrix vector product.

Consider two square matrices a and b, each of size 1024x1024. Example 17-5 shows code to compute a matrix vector product. This requires us to multiply each element in each array with each element in the other array:

Example 17-5 Matrix vector product code

```
for (i = 0; i < 1024; i++)
for (j = 0; j < 1024; j++)
  for (k = 0; k < 1024; k++)
    result[i][j] = result[i][j] + a[i][k] * b[k][j];</pre>
```

In this case, the contents of matrix a are accessed sequentially, but matrix b advances in the inner loop, by row. It is therefore, highly probable that we will encounter a cache miss for each multiply operation.

It is obvious that the order in which the additions for each element of the result matrix are calculated does not change the result (ignoring the effect of overflows etc.). It should therefore be possible to rewrite the code in a way which improves the cache hit rate. The elements of matrix b are accessed in the following way (0,0), (1,0), (2,0)... (1023,0), (0,1), (1,1)... (1023,1). The elements are stored in memory in the order (0,0), (0,1) etc. For word sized elements, it means that the elements (0,0), (0,1)...(0,7) will be stored in the same cache line. (For simplicity,

we will assume that the start address of the matrix is aligned to a cache line. Alignment will be mentioned again later in the chapter.) Therefore, elements (0,0), (0,1), (0,2) etc. will be in the same cache line; when we load (0,0) into the cache, we get (0,1..7) too. By the time the inner loop completes, it is likely that this cache line will be evicted.

If we modify the code so that two (or indeed four, or eight) iterations of the middle loop are performed at once while executing the inner loop, we can make a big improvement. Similarly, we should unroll the outer loop two (or four, or eight) times as well.

Example 17-6 Code using tiles

There are now six nested loops. The outer loops iterate with steps of 8, representing the fact that eight int sized elements are stored in each line of the level 1 cache. Some further optimizations have also been introduced. The order of ji and ki has been reversed as only one expression uses ki, but two use ji. In addition, we optimize by removing common expressions from the inner loops. All pointer accesses are potential sources of aliasing in C, so by using result, ra and rb to access array elements, the array indexing is speeded up. We cover this in more detail later.




Figure 17-1 Effect of tiling on cache usage

17.2.3 Loop interchange

In many programs, there will be nested loops – a very simple example would be code that stepped through the items in a 2-dimensional array. For reasonably complex code, we can sometimes get better performance by re-arrangement of the loops. It is better to have the loop with the smaller number of iterations as the outer loop and the one with the highest iteration count as the innermost loop.

This gives two potential advantages. One is that the compiler may potentially unroll the inner loop. Perhaps more importantly for complex loops where the size of the nested loop is sufficiently large that it may not all be held in level 1 cache at the same time, the overall cache

hit rate will be improved by this change. Some compilers can make this change automatically at higher levels of optimization. For example, GCC 4.4 adds the switch "-floop-interchange" to do this.

17.2.4 Structure alignment

Efficient placement of structure elements and alignment are not the only aspects of data structures which influence cache efficiency. Where code has a large working data set, it is important to make efficient use of the available cache space. To achieve this, it might be necessary to rearrange data structures.

It is common to have data structures which span multiple cache lines, but where the program uses only a few parts of the structure at any particular time. If there are many objects of this type, it can make sense to try to compress the structure so that it fits within a cache line. This only makes sense if the object itself is aligned to a cache boundary. For example, consider the case where we have a very large array of instances of a 64-byte structure (much larger than the cache size). Within that structure, we have a byte-sized quantity and we have a commonly used function which iterates through the array looking only at that byte-sized quantity. This function would probably make inefficient use of the cache, as we would need to load an entire cache line simply to read the 8-bit value. If instead those 8-bit values were stored in their own array (rather than as part of a larger structure), we would get 32 (or 64 on the Cortex-A8 processor) values per cache linefill.

Furthermore, as we saw in the chapter on porting code to the ARM Architecture, unaligned accesses are supported, but may take extra cycles in comparison to aligned accesses. For performance reasons, therefore, it can be sensible to remove or reduce unaligned accesses.

17.2.5 Associativity effects

ARM L1 Caches are typically 4-way set-associative, as we saw in Chapter 17, but L2 caches typically have 8- or 16-way associativity. There can be performance problems if more than four of the locations in the data fall into the same cache set, as there may be repeated cache misses, even though other parts of the cache may be unused. The ARM L1 Cache uses physical rather than virtual addresses, so it can be difficult for programmers operating in user mode to take care of this.

A particularly common cause of this problem is arranging data so that it is on boundaries of powers of two. If the cache size is 16kB, then each way is 4kB in size. If you have multiple blocks of data arranged on boundaries which are multiples of 4KB, then the first access to each block will go into line 0 of a way. If code accesses the first line in several such blocks then we may get cache misses even if only five cache lines in total are being used. Unaligned accesses can increase the likelihood of this, as each access might require two cache lines rather than one.

17.2.6 Optimizing instruction cache usage

The C programmer does not directly have control over how the instruction cache is used by code. Code is linear between branch instructions and this pattern of sequential accesses uses the cache efficiently. The branch prediction logic of the core will try to minimize the stalls due to branches, so there is little the C programmer can do to assist. So, the main goal for the programmer is to reduce the code footprint. Many of the compiler optimizations enabled at -02 and -03 for GCC, deal with loop optimizations and function inlining. These optimizations will improve performance if the code accounts for a significant part of the total program execution. In particular, function inlining has multiple potential benefits. Obviously, it can reduce branch penalties, by removing branches on both function call and exit, and potentially also stack usage. Equally importantly, it allows the compiler to optimize over a larger block of code which can lead to better optimizations for value range propagation and elimination of unused code.

However, apparent speed optimizations which increase code size can actually reduce performance due to cache issues. Larger code is less likely to fit in the L1 cache (or indeed the L2 cache) and the performance lost by the additional cache linefills may well outweigh any benefits of the optimization. It is often better to use the gcc -0s option to optimize for code density rather than speed. Clearly, using Thumb-2 code will also improve code density and cache efficiency.

There are some interesting decisions to be made around function inlining and in some cases human judgment can improve on that of the compiler. A function which is only ever called from one place will always give a benefit if inlined. One might think that inlining very small functions always gives a benefit, but this is not the case. An instance of a tiny function which is called from many places is likely to be re-used many times within the instruction cache. If the same function is repeatedly inlined, it is much more likely that it will cause a cache miss (and also evict other potentially useful code from the cache). The branch prediction logic within Cortex-A series cores is efficient and an unconditional function call and return consumes few cycles — much less than would be used for a cache linefill. The programmer may wish to use the GCC function attributes noinline and always_inline to control such cases.

This is a general problem and not specific to inlining functions. Whenever conditional execution is used and it is lopsided (that is, the expression far more often leads to one result than the other) there is the potential for false static branch prediction and thus bubbles in the pipeline. It is usually better to order conditional blocks so that the often-executed code is linear, while the less commonly executed code has to be branched to and does not get pre-fetched unless it is actually used. The GCC attribute __builtin_expect used with the -freorder-blocks optimization option can help with this.

The performance monitor block of the processor (and OProfile) can be used to measure branch prediction rates in code. Note that there are two effects at play here. Correct branch prediction saves clock cycles by avoiding pipeline flushes, but taking fewer conditional branches which skip forward over code can help performance by making more of the program fit within the L1 cache.

17.2.7 Fast loop mode

The Cortex-A9 processor contains special hardware which can optimize execution of fast loops. If the loop is sufficiently short, the code for the whole loop can be maintained within the decode and prefetch stages of the processor and subsequent iterations of the loop do not need to be refetched from the cache. This mode applies for loops which fit into one or two cache lines (that is, up to 64 bytes, provided the start of the loop is aligned to a cache line boundary) and are terminated with a conditional branch backward. The loop is allowed to contain predicted non-taken branches. This permits loops which have an if statement to be handled.

17.2.8 Optimizing L2/Outer Cache Usage

Everything said about optimizations for using the L1 cache also applies to the L2 cache accesses. Best performance results from having a working dataset which is smaller than the L2 cache size, and where the data is used more than once; there is little benefit caching data which is used only once, other than possibly producing more optimal bus accesses. If the dataset is larger than the cache size, then the programmer should consider similar techniques to those already described for the L1 cache. There is, however, a further point to consider with outer caches, which is that they may well be shared with other processors and therefore the effective size for an individual processor may be less than the actual size. In addition, when writing generic code to run on a number of ARM families, it can be difficult to make optimal use of the L2 cache. The presence of such a cache is not guaranteed and its size may vary significantly between systems.

17.2.9 Optimizing TLB Usage

In general, the scope for optimizing usage of the TLB (see Chapter 8) is much less than for optimizing cache accesses. The key points are to minimize the number of pages in use (this obviously gives fewer TLB misses) and to use large MMU mappings (supersections or sections in preference to 4kB pages) as this both reduces the cost of individual page table walks (one external memory access rather than two) and also means that a larger amount of memory is represented within an individual TLB entry (thus also giving fewer TLB misses). In practice, however, an operating system like Linux uses 4KB pages everywhere, so the main optimization technique available is trying to limit the number of active pages to below the maximum number supported by the processor hardware (for example, 128 TLB entries on the Cortex-A9 processor). The main optimization would be to try to process multiple cache lines' worth of data per page, so that the L1 cache is the limiting factor rather than TLB entries.

17.2.10 Data abort optimization

As we saw in the MMU chapter (Chapter 8), in the context of Linux, data aborts will be generated by page faults on the first time that a memory page is accessed and again when the page is first written to. This means that the kernel abort handler is called to take appropriate action and there is a certain performance overhead to this. Simplistically, we can reduce this overhead by using fewer pages. Again, code optimizations which make code smaller will help, as will reducing the size of the data space.

17.2.11 Prefetching a memory block access

ARM Cortex-A series processors contain sophisticated cache systems, and support for speculation and out of order execution which can hide latencies associated with memory accesses. However, accesses to the external memory system are usually sufficiently slow that there will still be some penalty. If we can prefetch instructions or data into the cache before we need them, we can hide this latency.

Many ARM processors provide support for preloading of data under programmer control, using the PLD instruction. This allows the programmer to request that data is loaded to the data cache in advance of it actually being read or written by the application. The PLD operation generates a cache linefill on a data cache miss, independent of load and store instruction execution, and happens in the background while the processor continues to execute other instructions. If used correctly, PLD can significantly improve performance by hiding memory access latencies. In the Cortex-A8 processor, the PLD instruction loads data only to the L2 cache. Assembly language also has a PLI instruction, which allows the programmer to hint to the processor that an instruction load from a particular address is likely in the near future. This may cause the processor to preload the instructions to its cache.

In addition to this programmer-initiated prefetch, the Cortex-A9 processor has support for automatic data prefetching. This must be explicitly enabled using the DP bit in the CP15:ACTLR (Auxiliary Control Register). Essentially, this causes the processor to look out for a series of sequential accesses to memory. When it sees this happen, it automatically requests the following cache lines speculatively, in advance of the program actually using them. It can cope with two independent data streams, such as when a program is performing streams of sequential accesses to two different locations. The state of this bit may not be under programmer control in your system (it may be fixed by boot code, for example), but it can be useful to be aware of this behavior when optimizing code which moves blocks of memory.

In many systems, significant numbers of cycles are consumed initializing or moving blocks of memory, using the memset() or memcpy() functions. Optimized ARM libraries will typically implement such functions by using STM, Store Multiple instructions, with each store aligned to

a cache line boundary. Cortex-A9 processor hardware automatically attempts to optimize such cases. It will ignore page table settings for normal, cacheable memory and dynamically optimize the read and write data cache allocation policies to give best performance.

Consider the case where we have a large block of RAM with a write-allocate policy indicated in the page table. We wish to zero initialize part of that memory by loading zero into eight ARM registers and then executing a tight loop of STM instructions which writes zero into a series of locations in memory. If we were to write-allocate this memory, the cache would first read the uninitialized memory, and then over-write all of the garbage values just written. It therefore makes no sense to perform the initial read. The hardware can detect this situation and optimize accordingly.

17.2.12 Preload engine

The Cortex-A8 processor has a built-in preload engine which can be used to move data to and from the L2 cache under programmer control. It is a dedicated piece of hardware, built into the processor, but completely separate from the processor pipeline. Once programmed, it can perform its memory operations in the background, while the processor runs other code. It contains two channels and is programmed by specifying the start and end address to be transferred. When moving data out of the cache and into external memory, writes will take place only lines which are marked as dirty. The maximum number of cache lines which can be transferred in a single operation is limited by the cache way size. The ability to lock data to a specific cache way is supported. It has hardware outputs which can be used to generate interrupts upon completion or if there is an error.

The Cortex-A9 processor, however, does not have a built-in L2 cache. Instead, it may be implemented in a system which contains a discrete L2 cache block (known as L2C-310, formerly PL310), which supports the use of a *Preload Engine* (PLE). The PLE loads regions of memory into the L2 cache, using a CP15 instruction (MCRR preload channel).

Preload blocks enter a FIFO within the PLE. Each FIFO entry contains a number of parameters: - base address, length of stride, number of blocks, Translation Table Base (TTB) address, Address Space Identifier (ASID) value and valid and secure/non-secure bits. Programmed entries can remain valid through context switches.

The Preload Engine performs cache line preload requests in the same way as a preload request from the PLD instruction, with the difference that it uses its own TTB and ASID parameters. If there is a translation abort from the page table entry, the preload request is ignored and the Preload Engine moves on to the next request, that is, it fails without generating an abort. Translation Lookaside Buffer (TLB) maintenance operations in the core are applied to the PLE FIFO entries too. The reader is advised to refer to the latest Cortex-A9 *Technical Reference Manual* for further information about the Preload engine.

17.3 Source code modifications

We have seen how profiling tools allow us to identify code segments or functions which may benefit from optimization and how different GCC options can enable compiler optimizations to our code. We will now look at a variety of source code modifications which can yield faster or smaller code on the ARM.

17.3.1 Loop termination

Where possible, it is better to have integer loop counters which end at 0 (zero), rather than start from 0 (zero). This is because a compare with zero comes for free with the ADD or SUB instruction used to update the loop counter, whereas a compare with a non-zero value will typically require an explicit CMP instruction.

Replace a loop which counts up to a terminating value:

```
for (i = 1; i <= total; i++)
```

with one which counts down to zero:

```
for (i = total; i != 0; i--)
```

This will remove a CMP instruction from each iteration of the loop.

It is also good practice to use int (32-bit) variables for loop counters, rather than char (8-bit), even when the number of iterations is significantly less than 255. This is because the ARM is natively a 32-bit machine. Its ADD assembly language instruction operates on two 32-bit registers. If it does an ADD (or other data processing operation) with an eight bit quantity, the compiler may need to insert additional instructions to handle overflow to a value larger than 255 (see also *Variable selection* on page 17-13).

17.3.2 Loop choice

A useful optimization may be achieved by correct choice of loop type. If there are times when the loop condition is never met, a for or while loop is the best choice, since these have a comparison only at the end of the loop. If the loop condition is always true on the first iteration, it is better to use a do...while loop.

17.3.3 Loop fusion

This is one of a variety of other possible loop techniques which may be employed either by the programmer, or by an optimizing compiler. It essentially means merging loops which have the same iteration count and no interdependencies.

Example 17-7 Loop Fusion

```
for (i = 0; i < 10; i++)
{
   x[i] = 1;
}
for (j = 0; j < 10; j++)
{
   y[j] = j;
}</pre>
```

It should be immediately apparent that this may be optimized to

Example 17-8 Fused loops

```
for (i = 0; i < 10; i++)
{
    x[i] = 1;
    y[i] = i;
}</pre>
```

17.3.4 Reducing stack/heap usage

In general, it is a good idea to try to minimize memory usage by code. The ARM processor has a register set which provides a relatively limited set of resources for the compiler to keep variables in. Once all registers are allocated with currently live variables, further variables will be spilled to the stack – causing memory operations and extra cycles for the code to execute. There are a number of ways available to the programmer to try to help. A key rule is to try to limit the number of 'live' variables at any one time.

When we looked at the procedure call standard in Chapter 15, it was stated that up to four parameters may be passed to a function. Further parameters are passed on the stack. It is therefore significantly more efficient to pass four or fewer parameters than to pass five or more. Of course, the ARM registers in question are 32-bits in size and therefore if we pass a 64-bit variable, it will take two of our four register slots. For similar reasons, recursive functions do not typically yield efficient processor register usage.

17.3.5 Variable selection

ARM registers are 32-bit sized and optimal code is therefore produced most readily when using 32-bit sized variables, as this avoids the need to provide extra code to deal with the case where a 32-bit result overflows an 8- or 16-bit sized variable.

Consider the following code:

```
unsigned int i, j, k;
i = j+k;
```

The compiler would typically emit assembly code similar to:

```
ADD R0, R1, R2
```

If these variables were instead short (16-bit) or char (8-bit), the compiler must ensure the result does not overflow the halfword or byte.

The same code might need to be as shown in Example 17-9, for signed halfwords (shorts).

Example 17-9 Addition of 2 signed shorts (assembly code)

```
ADD R0, R1, R2
MOV R0, R0, LSL#16
MOV R0, R0, ASR#16
```

Or for unsigned halfwords as in Example 17-10.

Example 17-10 Addition of 2 unsigned shorts (assembly code)

```
ADD R0, R1, R2
```

ID121410

BIC R0, R0, #0x10000

This has the effect of clipping the result to the defined size.

It is therefore best practice for loop counter variables to be defined as type int and not as char. This is less of an issue for later versions of the architecture. The compiler can avoid code like the above by using instructions such as UXTB, which was added in the ARMv6 architecture.

17.3.6 Pointer aliasing

If a function has two pointers *pa and *pb, with the same value, then we say the pointers *alias* each other. This introduces constraints on the order of instruction execution. If two write accesses which alias occur in program order, they must happen in the same order on the processor and cannot be re-ordered. This is also the case for a write followed by a read, or a read followed by a write. Two read accesses to aliases are safe to re-order. As any function pointer argument could alias any other function pointer argument in C, the compiler must assume that any accesses through these pointers can alias, which prevents many possible optimizations. C++ allows more optimizations, as pointer arguments will not be treated as possible aliases if they point to different types.

C99 introduces the restrict keyword which specifies that a particular pointer argument does not alias any other. If you know that pointers do not overlap, using this keyword to give the compiler this information can yield significant improvements. However, misusing it can lead to incorrect program function. This consideration is not specific to the ARM architecture and applies to all processors.

17.3.7 Division/modulo

Many ARM processors do not include hardware for division. The Cortex-M3 and Cortex-R4 processors are two exceptions. C division typically calls a library routine which takes tens of cycles to run for divides of 32-bit integers,

Where possible, divides should be avoided, or removed from loops. Division by a fixed power of two can be done using arithmetic shift right operations provided by the core - it is significantly faster to divide by 8 or 16 than to divide by 10. Division with a fixed divisor is faster than dividing two variable quantities. The compiler may replace a divide by a fixed multiply in this case.

Modulo arithmetic is another case to be aware of, as this will also use division library routines.

The code

```
minutes = (minutes + 1) \% 60;
```

will run significantly faster on machines with no hardware divide, if coded as

```
if (++minutes == 60) minutes=0;
```

which substitutes a two cycle add and compare in place of a call to a library function

17.3.8 Global data

Accessing global variables requires the processor to execute a series of load instructions to acquire the address of the variable through a base pointer and then read the actual variable value. If global variables are defined together, they may share a base pointer, saving cycles and instructions. It is therefore good practice to either declare the variables inside the same source file or place them in an extern struct.

17.3.9 Inline or embedded assembler

In some cases, it can be a worthwhile optimization to use assembly code, in addition to C. The general principle here is for the programmer to code in a high level language, use a profiler to determine which sections will produce the most benefit if optimized and then inspect the compiler-produced assembly code to look for possible improvements.

If a code section is identified as being a performance bottleneck, one should not immediately reach for the assembly language manual. Improvements to the algorithm should first be sought and then compiler optimizations tried before considering use of assembly code. Even then, it is often the case that poor performance is due to cache misses and memory access delays rather than the actual assembly code.

GCC (and most other C compilers) uses the -s flag to tell the compiler to produce assembly code output. The -fverbose-asm command line option may also be useful

Chapter 14 Porting, of this book gives further information about the use of an inline assembler.

17.3.10 Linker optimizations

Some code optimizations can be performed at the link, rather than the compile stage of the build. Multi-file optimization may be carried out across multiple C files, and unused sections can be removed. Similarly, multi-file compilation enables the compiler to perform optimization across multiple files instead of on individual files.

17.3.11 Veneers

Veneers are small pieces of code which are automatically inserted by the linker when it detects that a branch target is out of range or a conditional branch to code in the other state, for example, from Thumb to ARM or vice-versa. The veneer becomes an intermediate target of the original branch with the veneer itself then being a branch to the target address. Often these veneers can be inlined. The linker can reuse a veneer generated for a previous call, for other calls to the same function if it is in range from both calls. Occasionally, such veneers can be a performance factor. If you have a loop which calls multiple functions through veneers, you will get many pipeline flushes and therefore sub-optimal performance. Placing related code together in memory can avoid this. ARM's linker can be made to export information on this by specifying the -info veneers option.

17.4 Microarchitecture optimizations

In some cases, knowledge of the core pipeline can be beneficial for optimization of code. Typically, this information is required only by writers of low-level code, such as compilers, OS code, JITs, and codecs, but there may be some situations where application programmers can make savings by using assembly code. In Chapter 3, we mentioned some features of the Cortex-A9 processor, including its long pipeline, small loop mode, branch prediction and register re-naming. Let's look at how these can affect cycle timings of code.

- *Branches*. Code which has no more than two branches within a single 16-byte block will perform better. This is because the *Branch Target Address Cache* (BTAC) is arranged around lines of 16-byte size and up to two branches per line can be predicted. Using more branches than this will mean that a pipeline flush is likely.
- Loops. The small loop mode of the Cortex-A9 processor is used for loops which fit within 64 bytes (four lines of the BTAC) terminating with a backward branch. This mode saves power by eliminating cache look-ups and also runs faster. There are two lines of microcache and these are not aligned to cache boundaries, so it is not necessary for the 64 bytes used for the small loop to be aligned to any particular address boundary. Very small loops which fit within a single 32-byte cache line will save a BTAC lookup and so save a small amount of power compared with a similar loop spread across two lines.
- Register Renaming. We saw in Chapter 3 that the Cortex-A9 processor has a pool of
 physical registers which are used to hold the programmers model registers, R0-R14. The
 mapping process between these two sets of registers is described as Register Renaming.
 Up to two registers per cycle can be renamed. Therefore, long Load and Store Multiple
 instructions (of five or more registers) will cause stalls, when compared with shorter
 LDM/STMs.
- Freeing registers. The register renaming hardware tries to keep track of which physical registers are in use. Code should use MOV Rd, #0 to "free" the register to the renaming pool. (Simply loading the value 0 from memory does not do this.) The code sequence MOV R1, #0; MOV R2, #0 is better than MOV R1, #0; MOV R2, R1 for this reason. It is sensible to free registers before or after many registers have been used (for example, memcpy()) or just before returning from exceptions, or if there are exception modes which are never used (in some systems, this might mean FIQ and/or secure monitor modes).
- Conditional Execution. It can often be better to branch around single instructions than to have single conditional instructions which fail their condition code. This is opposite to the situation in the ARM7 or ARM9 architectures and is due to the cost of unwinding instructions which fail condition codes. This is true only if the conditional branch is one which is predictable by the global history buffer. This means the branch has some recognizable pattern (for example, it depends upon a counter rather than random data values). The Thumb-2 IT instructions show the same behavior. Data dependent loads are a particularly severe case of this problem.

If we have a code sequence such as that in Example 17-11, then we potentially have two speculative memory loads to unwind. There are two special cases for which hardware optimizations exist. One is the case of a pair of opposite conditions that resolve to a single renamed register (for example, MOVNE R0 followed by MOVEQ R0). The other is for conditional execution of LDM {..., PC} (a conditional function return).

Example 17-11 Worst case conditional execution example

LDREQ	R0,	[R1]
LDR	R2,	[R0]

- Complex Addressing Modes. It is often better to avoid complex addressing modes. In cases where the address to be used for a load or store requires a complex calculation, dual-issue of instructions is not possible. Only the addressing mode which uses a base register plus an offset (specified either by a register or an immediate value) with an optional shift left by an immediate value of two is "fast". Other, less commonly used, addressing modes may be executed more quickly by splitting into two instructions which might be dual-issued. For example, MOV R2, R1 LSL#3; LDR R2, [R0, R2] may be faster than LDR R2, [R0, R1 LSL #3]. LDRH/LDRB have no extra penalty, but LDRSH/LDRSB have a single cycle load-use penalty, but no early forwarding path and may therefore incur additional latency if a subsequent instruction uses the loaded value. Unaligned LDRs have an extra cycle penalty compared with aligned loads, but unaligned LDRs which cross cache-lines have many cycles of additional penalty. In general, stores are less likely to stall the system compared to loads. STRB and STRH have similar performance to STR, due to the merging write buffer. As there are four slots in the load/store unit, more than four consecutive pending loads will always cause a pipeline stall.
- memcpy() and memset(). Best performance for memcpy() is achieved using LDM of a whole cache line and then writing these values with an STM of a whole cache line. Alignment of the stores is more important than alignment of the loads. The PLD instruction should be used where possible. There are four PLD slots in the load/store unit. A PLD instruction takes precedence over the automatic pre-fetcher and has no cost in terms of the integer pipeline performance. The exact timing of PLD instructions for best memcpy() may vary slightly between systems, but PLD to an address three cache lines ahead of the currently copying line is a useful starting point.

Chapter 18 Floating Point

All computer programs deal with numbers. Floating-point numbers, however, can sometimes appear counter-intuitive to programmers who are not familiar with their detailed implementation. For example, numbers which when printed to a certain number of decimal digits can return false using a C == comparison. Before looking at floating point implementation on ARM processors, a short overview of floating-point fundamentals is included. Programmers with prior floating-point experience may wish to skip the following section.

18.1 Floating-Point Basics and the IEEE-754 Standard

The IEEE-754.1985 standard is the reference for almost all modern computer floating point mathematics implementations, including ARM floating point systems. The standard defines precisely what result will be produced by each of the fundamental floating point operations over all of the possible input values. It describes what a compliant implementation should do with respect to rounding of results which cannot be expressed precisely. A simple example of such a calculation would be 1.0/3.0, which would require an infinite number of digits to express precisely in decimal or binary notation. IEEE-754 provides a number of different rounding options to cope with this (round up, round down, round toward zero, or round to nearest, see *Rounding algorithms* on page 18-4). IEEE-754 also specifies the outcome when an *exceptional* operation occurs. This means a calculation which potentially represents a problem. These conditions can be tested, either by querying the FPSCR (on ARM) or by setting up trap handlers (on some systems). Examples of exceptional operations are as follows:

- Overflow. A result which is too large to represent.
- Underflow. A result which is so small that precision is lost.
- *Inexact*. A result which cannot be represented without some loss of precision. It is clear that many floating point calculations will fall into this category.
- *Invalid*. For example, attempting to calculate the square root of a negative number.
- *Infinite*. This can result from attempting to divide by zero.

The specification also describes what action should be taken when one of the above exceptional operations is detected. Possible outcomes include the generation of a *NaN* (Not a Number) result (for invalid operations), positive or negative infinity (for overflow or division by zero) or *denormalized* numbers in the case of underflow. The standard further defines what results should be produced if subsequent floating point calculations operate on NaN or infinities.

One of the things that IEEE-754 defines is how floating point numbers are stored within the hardware. Floating-point numbers are typically represented using either single precision (32-bit) or double precision (64-bit). VFP supports single-precision (32-bit) and double-precision (64-bit) formats in hardware. In addition, VFPv3 can have half-precision extensions to allow 16-bit values to be used for storage. These extensions are supported by the Cortex-A5 and Cortex-A9 processors.

These use the available space to store three pieces of information about a floating point number

- A sign bit which shows whether the number is positive (0) or negative (1).
- An exponent giving its order of magnitude.
- A mantissa giving the fractional binary digits of the number.

For a single precision float, for example, bit [31] of the word is the sign bit, bits [30: 23] give the exponent and bits [22:0] give the mantissa. See Figure 18-1.

The value of the number is then $\pm m * 2^{exp}$, where "m" is derived from the mantissa and "exp" is derived from the exponent.



Figure 18-1 Single precision floating point format

The mantissa is not generated by directly taking the 23-bit binary value, but rather, it is interpreted as being to the right of the binary point, with a 1 present to the left. In other words, the binary mantissa must be greater than or equal to one and less than two. In the case where the number is zero, this is represented by setting all of the exponent and mantissa bits to 0. There are other special-case representations, for positive and negative infinity, and for the not-a-number (NaN) values. A further special case is that of denormalized values (which we will look at later in this section).

The sign bit lets us distinguish positive and negative infinity and NaN representations. Similarly, the 8-bit exponent value is used to give a value in the range +128 to -127, so there is an implicit offset of -127 in the encoding. Table 18-1 summarizes this.

Description Exponent Mantissa -127 0 ± 0 -127!=0 Subnormal values 128 **±INFINITY** 128 !=0 NaN values Other Any Normal values 1.<mantissa> × 2<exp>

Table 18-1 Single precision floating point representation

Let's consider an example:

The decimal value +0.5 will be represented as a single precision float by the hexadecimal value 0x3f000000. This has a sign value of 0 (positive). The value of the mantissa is 1.0, though the integral part (1) is implicit and is not stored. The exponent value is specified in bits [30:23] – which hold 0b111111100, or 126 – offset by 127 to represent an exponent of -1.

The value is therefore given by $(-1)^{\text{sign}}$ * mantissa * $2^{\text{exponent}} = 1 * 1 * 2^{-1} = 0.5$ (decimal)

Denormalized numbers are a special case. If we set the exponent bits to zero, we can represent very small numbers other than zero, by setting mantissa bits. Because normal values have an implied leading 1, the closest value to zero we can represent as a normal value is $\pm 2^{-126}$. To get smaller numbers, the "1.m" interpretation of the mantissa value is replaced with a "0.m" interpretation. Now, the number's magnitude is determined only by bit positions. When using these extremely-small numbers, the available precision does not scale with the magnitude of the value. Without the implied 1 attached to the mantissa, all bits to the left of the lowest set bit are leading zeros, so the smallest representable number is 1.401298464e-45, represented by 0x00000001. For performance reasons, such subnormal values are often ignored and are simply flushed to zero. This is strictly a violation of IEEE-754, but subnormal values are used rarely enough in real programs that the performance benefit is worth more than correct handling of these extremely small numbers. Cortex processors with VFP allow code to select between flush-to-zero mode and full subnormal support.

Because a 32-bit floating point number has a 23-bit mantissa there are many values of a 32-bit int that if converted to 32-bit float cannot be represented exactly. This is referred to as "loss of precision". If you convert one of these values to float and back to int you will get a different, nearby value. In the case of double-precision floating-point numbers, the exponent field has 11 bits (giving an exponent range from -1022 to +1023) and a mantissa field with 52 bits.

In 2008, the IEEE 754 standard was updated. Changes included support for additional formats, such as half precision. Many of the changes are not currently supported by the Cortex-A family of processors, as are some parts of the original standard.

18.1.1 Rounding algorithms

The IEEE 754-1985 standard defines four different ways in which results can be rounded, as follows:

- Round to Nearest. This mode causes rounding to the nearest value. If a number is exactly
 midway between two possible values, it is rounded to the nearest value with a zero least
 significant bit.
- Round toward 0. This causes numbers to always be rounded towards zero (this can be also be viewed as truncation).
- Round toward $+\infty$. This selects rounding towards positive infinity.
- Round toward -\infty. This selects rounding towards negative infinity.

The IEEE 754-2008 standard adds an additional rounding mode. In the case of round to nearest, it is now also possible to round numbers which are exactly halfway between two values, away from zero (in other words, upwards for positive numbers and downwards for negative numbers). This is in addition to the option to round to the nearest value with a zero least significant bit. At the time of writing VFP does not support this rounding mode.

18.1.2 ARM VFP Co-processor

The VFP architecture is an optional co-processor extension to the ARM architecture. It provides both single-precision and double-precision floating point arithmetic, conforming to the IEEE 754-1985 Standard.

VFPv3 is an optional (but rarely omitted) extension to the instruction sets in the ARMv7-A architecture. It can be implemented with either thirty-two, or sixteen double-word registers. The terms VFPv3-D32 and VFPv3-D16 are used to distinguish between these two options. If the Advanced SIMD (NEON) extension is implemented together with VFPv3, then VFPv3-D32 is always present. VFPv3 can also be optionally extended by the half-precision extensions that provide conversion functions in both directions between half-precision floating-point (16-bit) and single-precision floating-point (32-bit). The Cortex-A5 and Cortex-A9 processors both support these half-precision floating point extensions. Besides conversion, there are no operations on half-precision floating point values.

The Cortex-A5 processor also supports Fused Multiply-Accumulate operations, in which only a single rounding occurs. This is one of the new facets of the IEEE 754-2008 specification. Fused operations can improve the accuracy of calculations which repeatedly accumulate products, such as matrix multiplication or dot product calculation.

In addition to the registers described above, there are a number of other VFP registers. These are listed below.

- Floating Point System ID Register (FPSID). This can be read by system software to determine which floating-point features are supported in hardware.
- Floating Point Status and Control Register (FPSCR). This holds comparison results and flags for exceptions. Control bits select rounding options and enable floating-point exception trapping.
- Floating Point Exception Register (FPEXC). The FPEXC register contains bits which allow system software that handles exceptions to determine what has happened.
- *Media and VFP Feature Registers 0 and 1* (MVFR0 and MVFR1). These registers allow system software to determine which Advanced SIMD and floating point features are provided on the processor implementation.

User mode code can only access the FPCSR. One implication of this is that applications cannot read the FPSID to determine which features are supported unless the host OS provides this information. Linux provides this via /proc/cpuinfo, for example, but the information is not nearly as detailed as that provided by the VFP hardware registers.

Unlike ARM integer core instructions, no VFP operations can set the APSR directly. The flags are stored in the FPSCR. Before the result of a floating-point comparison can be used by the integer core, the flags set by a floating point comparison must be transferred to the APSR, using the VMRS instruction. This includes use of the flags for conditional execution, even of other VFP instructions. Example 18-1 shows a simple piece of code to illustrate this. The VCMP instruction performs a comparison the values in VFP registers d0 and d1 and sets FPSCR flags as a result. These flags must then be transferred to the integer core APSR, using the VMRS instruction. We can then conditionally execute instructions based on this.

Example 18-1 Example code illustrating usage of floating point flags

VCMP d0, d1 VMRS APSR_nzcv, FPSCR BNE label

Flag meanings

The integer comparison flags support comparisons which are not applicable to floating-point numbers. For example, floating-point values are always signed, so there is no need for unsigned comparisons. On the other hand, floating-point comparisons can result in the unordered result (meaning that one or both operands was NaN, or "not a number"). IEEE-754 defines four testable relationships between two floating-point values, which map onto the ARM condition codes as follows:

Table 18-2 ARM APSR flags

IEEE-754 Relationship	ARM	APSR	Flags		
	N	Z	С	V	
Equal	0	1	1	0	
Less Than (LT)	1	0	0	0	
Greater Than (GT)	0	0	1	0	
Unordered (At least one argument was NaN.)	0	0	1	1	

Compare with Zero

Unlike the integer instructions, most VFP (and NEON) instructions can operate only on registers, and cannot accept immediate values encoded in the instruction stream. The VCMP instruction is a notable exception in that it has a special-case variant that allows quick and easy comparison with zero.

Interpreting the Flags

Once the flags are in the APSR, they may be used almost as if an integer comparison had set the flags. However, floating-point comparisons support different relationships, so the integer condition codes do not always make sense. The following table is equivalent to the condition code table from the first post in this series, but describes floating-point comparisons rather than integer comparisons:

Table 18-3 Interpreting the flags

Code	Meaning (when set by vcmp)	Meaning (when set by cmp)	Flags Tested
EQ	Equal to.	Equal to.	Z==1
NE	Unordered, or not equal to.	Not equal to.	Z==0
CS or HS	Greater than, equal to, or unordered.	Greater than or equal to (unsigned).	C==1
CC or LO	Less than.	Less than (unsigned).	C==0
MI	Less than.	Negative.	N==1
PL	Greater than, equal to, or unordered.	Positive or zero.	N==0
VS	Unordered. (At least one argument was NaN.)	Signed overflow.	V==1
VC	Not unordered. (No argument was NaN.)	No signed overflow.	V==0
HI	Greater than or unordered.	Greater than (unsigned).	(C==1) && (Z==0)
LS	Less than or equal to.	Less than or equal to (unsigned).	(C==0) (Z==1)
GE	Greater than or equal to.	Greater than or equal to (signed).	N==V
LT	Less than or unordered.	Less than (signed).	N!=V
GT	Greater than.	Greater than (signed).	(Z==0) && (N==V)
LE	Less than, equal to or unordered.	Less than or equal to (signed).	(Z==1) (N!=V)
AL (or omitted)	Always executed.	Always executed.	None tested.

It should be obvious that the condition code is attached to the instruction reading the flags, and the source of the flags makes no difference to the flags that are tested. It is the meaning of the flags that differs when you perform a vcmp rather than a cmp. Similarly, it is clear that the opposite conditions still hold. (For example, hs is still the opposite of lo.)

The flags when set by CMP generally have analogous meanings when set by VCMP. For example, GT still means "greater than". However, the unordered condition and the removal of the signed conditions can confuse matters. Often, for example, it is desirable to use LO, normally an unsigned "less than" check, in place of LT, because it does not match in the unordered case.

18.1.3 Instructions

VFP instructions are provided which perform arithmetic and data processing, load and stores to memory, and register transfers (between VFP registers and to/from ARM registers). These instructions are encoded with ARM coprocessor instructions, but are typically viewed as part of the main instruction set, rather than as coprocessor operations. VFP offers all the common arithmetic operations, format conversions, a few complex arithmetic operations (for example, Multiply accumulate, VMLA, and square root, VSQRT), along with memory access instructions. Appendix B of this book provides a full list of the supported instructions.

18.1.4 Exceptions

The standard VFPv3 and VFPv4 architectures do not support trapped exception handling. Older ARM processors could be configured to bounce exceptional cases which could not be handled in hardware to special software support code. This is supported in the VFPv3U architecture.

VFP hardware has a number of flags in the FPSCR, which are set when an exceptional case is detected. These are cumulative flags, which once set, remain in that state until explicitly cleared by support code. With the exception of IDC (Input Denormal), these correspond to the IEEE exceptions described in section 19.1

- *IOC Invalid Operation*. The flag is set when an operation produced a result which has no mathematical value or cannot be represented. An example of this is multiplying an infinity by zero. IOC may also be set on a floating-point operation with one or more signaling NaNs as operands.
- DZC Division by Zero. The flag is set when a divide operation has a zero divisor and a dividend that is not zero, an infinity or a NaN.
- *OFC Overflow*. The flag is set when the absolute value of the result (after rounding) of an operation is larger than the maximum positive normalized number *and* the rounded result is inexact.
- *UFC Underflow*. The flag is set when the absolute value of the result (before rounding) of an operation is less than the minimum positive normalized number.
- *IXC Inexact*. The flag is set when the result of an operation is not the same as the value that would be produced if that operation was performed with unbounded precision and exponent range.
- *IDC Input Denormal*. The flag is set when a denormalized input operand is replaced with zero.

The performance of floating-point software may be reduced when performing calculations which use denormalized numbers. In many cases, the denormalized operands and intermediate results can be treated as zero, without significantly affecting the result. VFP implementations have Flush-to-zero mode to allow this. Flush-to-zero mode is incompatible with the IEEE 754 standard, and so must not be used when IEEE 754 compatibility is needed.

18.1.5 Enabling VFP

If an ARMv7 processor includes VFP hardware, then bootcode must explicitly enable its use. Several steps are required to do this.

- Access to CP10 and CP11 must be enabled in the Coprocessor Access Control Register (CP15.CACR).
- If access to VFP is required in the Non-Secure world, then access to CP10 and CP11 must be enabled in the Non-Secure Access Control Register (CP15.NSACR).

• The EN bit in the FPEXC register must be set.

18.2 VFP Support in GCC

Use of VFP is fully supported by GCC, (although some builds may be configured to default to assume no VFP support, in which case floating point calculations will use library code).

- -mfpu=vfp specify the target has VFP hardware. (As does specifying the option -mfpu=neon).
 - Other options are -mfpu=vfpv3 and -mfpu=vfpv3-d16. These may be used for code which will run only on these VFP implementations, and do not require backward compatibility.
- -mfloat-abi=softfp (or hard) specify which ABI to use to specify an ABI that enables the
 use of VFP.

softfp uses a procedure-call standard compatible with software floating point, and so provides binary compatibility with legacy code. This permits running older soft float code with new libraries which support hardware floating point, but still makes use of hardware floating-point registers between function calls. hard has floating point values passed in floating point registers. This is more efficient but is not backward compatible with the softfp ABI variant. Particular care is needed with libraries, including the C platform library. See *VFP and NEON register usage* on page 15-4 for more information on efficient parameter passing.

C programmers should note that there can be a significant function call overhead when using -mfloat-abi=softfp, if many floating-point values are being passed.

18.3 VFP Support in Linux

An application which uses VFP (or calls into a library which uses VFP) places some additional requirements on the Linux kernel. For the application to run correctly, the kernel must save and restore the VFP registers at appropriate points. The kernel may also need to decode and emulate VFP instructions where the VFP hardware is not present.

18.3.1 Context switching

In addition to saving and restoring integer registers, the kernel may also need to perform saving and restoring of VFP registers on a context switch. To avoid wasting cycles, this is done only when an application actually used VFP. As the VFP initialization code leaves VFP disabled, the first time a thread actually tries to access the floating point hardware, an undefined exception occurs. The kernel function which handles this, sees that VFP is disabled and that a new thread wishes to use VFP. It saves the current VFP state and restores the state for the new thread. If, after a context switch, execution would return to a thread which bounced an exceptional instruction, the exception is handled before returning (to avoid wasting cycles by repeated bounces).

On systems, with multiple cores, where threads can migrate to a different core, this simple system will no longer work correctly. Instead, the kernel saves the state if the VFP was used by the previous thread.

18.4 Floating point optimization

This section contains some suggestions for developers writing FP assembly code. Some caution is needed when applying these points, as recommendations may be specific to a particular piece of hardware. A code sequence which is optimal for one processor may be sub-optimal on different hardware.

- Avoid mixing of VFP and NEON instructions on the Cortex-A9 processor, as there is a significant overhead in switching between data engines.
 - VLDR/VSTM can be executed by both VFP and NEON, but VLD1/VLD2 can only be executed by NEON. VFP Double Precision instructions which are not NEON can only be executed by the VFP.
- Moves to and from VFP system control registers, such as FPSCR are not typically present in high-performance code, and may not be optimized. These should therefore not be placed in time-critical loops, if possible. For example, accesses to control registers on the Cortex-A9 processor are serializing, and will have a significant performance impact if used in tight loops or performance-critical code.
- Register transfer between the integer core register bank and the floating-point register bank should similarly be avoided in time-critical loops. For the Cortex-A8 processor, this is particularly true of register transfers from VFP registers to integer registers.
- Load/store multiple operations are preferred to the use of multiple, individual floating-point loads and stores, to make efficient use of available transfer bandwidth.
- Unroll tight loops, with different registers for each loop. Again, the floating point
 hardware on the Cortex-A5, Cortex-A8 and Cortex-A9 processors does not perform
 register renaming, but on a processor which did possess this capability, this advice would
 no longer be correct.

Chapter 19 **Introducing NEON**

This chapter provides an introduction to NEON. NEON is ARM's implementation of *Single Instruction Multiple Data* (SIMD) technology. It is a powerful vector extension to the ARM instruction set, allowing data to be processed more quickly in parallel.

NEON is an option on the Cortex-A series processors. Allowing the NEON hardware to be optional allows ARM SoCs to be optimized for specific markets. In most general-purpose applications processor SoCs, NEON will probably be included. However, for an embedded application such as a network router, NEON may well be omitted, allowing a small saving in silicon area which translates to a small cost saving.

We provide only a brief introduction to NEON here. A complete description could fill a book of its own!

19.1 SIMD

SIMD is a technique for processing a number of data values (generally a power of two) using a single instruction, with the data for the operands packed into special wide registers. One instruction can therefore do the work of many. For code which can be parallelized, large speedups can be achieved. SIMD extensions exist on many 32-bit architectures – PowerPC has AltiVec, x86 has several variants of MMX/SSE.

Many pieces of code operate on large datasets. The data items may be less than 32 bits in size (8-bit pixel data is common in video, graphics and image processing, 16-bit samples in audio codecs). In such cases, the operations to be performed are simple, repeated many times and have little need for control code. SIMD can offer considerable performance improvements for this type of data processing. It is particularly beneficial for digital signal processing or multimedia algorithms, such as:

- Block-based data processing
- Audio/video/image processing and codecs
- 2D graphics based on rectangular blocks of pixels
- Gaming (processing of multiple values simultaneously).

NEON is ARM's own implementation of the Advanced SIMD extensions, which form part of the ARM Architecture.

On a 32-bit microprocessor like ARM, it is relatively inefficient to perform large numbers of 8-or 16-bit single operations. The processor ALU, registers and datapath are designed for 32-bit calculations. SIMD allows a single instruction to treat a register value as multiple data elements (for example, as four 8-bit values in a 32-bit register) and to perform multiple identical operations on those elements.




Figure 19-1 Comparing SIMD parallel Add with 32-bit scalar Add

To achieve four separate additions without using SIMD requires us to use four ADD instructions, and additional instructions to prevent one result from overflowing into the adjacent byte. SIMD needs only one instruction to do this.

19.1.1 ARM v6 SIMD instructions

A set of basic 32-bit SIMD instructions was introduced in ARMv6, allowing the processor to operate on packed 8- or 16-bit values in 32-bit general purpose registers. These instructions have an 8 or 16 as a suffix, to show the size of data to operate on. These were described in Chapter 6.

19.2 NEON architecture overview

NEON has been designed with a powerful yet clean load/store architecture to provide good vectorizing compiler support from languages such as C/C++. A rich set of new NEON instructions are defined which operate on wide 64- and 128-bit vector registers, which enables a high level of parallelism. The NEON instructions are straightforward and easy to understand, which also makes hand-coding easy for applications that need the very highest performance.

A key advantage of the NEON technology is that instructions form part of the normal ARM or Thumb code, making programming simpler than with an external hardware accelerator. NEON instructions exist to read and write external memory, move data between NEON Registers and General Purpose ARM registers and to perform SIMD operations.

The NEON architecture uses a 32x64-bit register file. These are actually the same registers used by the floating point unit (VFPv3). It does not matter that the floating-point registers are re-used as NEON registers. All compiled code and subroutines will conform to the EABI, which specifies which registers can be corrupted and which registers must be preserved. The compiler is free to use any NEON/VFPv3 registers for floating-point values or NEON data at any point in the code.

The NEON architecture allows for 64-bit/128-bit parallelism. This choice was made to keep the size of the NEON unit manageable (especially when compared with a small core like ARM, a vector ALU can easily become quite large), while still offering good performance benefits from vectorization




Figure 19-2 Cortex-A8 NEON unit block diagram

The NEON unit of the Cortex-A8 processor is shown in Figure 19-2 on page 19-3. A key point to observe is that we have 128-bit paths for input data from the L1 data and L2 caches, but only a 32-bit path for data to or from the integer core registers.

Table 19-1 NEON performance on current implementations

Max NEON performance (operations per cycle)	Cortex-A9	Cortex-A8	Cortex-A5
VADD integer elements	16 (8-bit elements)	16 (8-bit elements)	8 (8-bit elements)
(Q reg)	8 (16-bit elements)	8 (16-bit elements)	4 (16-bit elements)
	4 (32-bit elements)	4 (32-bit elements)	2 (32-bit elements)
VMLA integer elements	8 (8-bit elements)	8 (8-bit elements)	4 (8-bit elements)
(D or Q reg)	4 (16-bit elements)	4 (16-bit elements)	4 (16-bit elements)
	1 (32-bit elements)	1 (32-bit elements)	1 (32-bit elements)
VADD 32-bit single-precision (D or Q reg)	2	2	1
VMLA 32-bit single precision (D or Q reg)	2	2	1

19.2.1 Commonality with VFP

NEON and Vector Floating Point (VFP) instructions are both defined as coprocessor 10 and 11 operations. The ARM architecture can support a wide range of different options, but in practice we see only the combinations:

- No NEON or VFP
- VFP only
- NEON and VFP.

The key differences between NEON and VFP are that NEON only works on vectors, does not support double precision floating point (double precision is supported by the VFP), and does not support certain complex operations such as square root and divide. NEON has a register bank of 32 64-bit registers. If both NEON and VFPv3 are implemented, this register bank is shared between them in hardware. This means that VFPv3 must be present in its VFPv3-D32 form, which has 32 double-precision floating-point registers. This makes support for context switching simpler. Code which saves and restores VFP context also saves and restores NEON context.

19.2.2 Data types

NEON instructions operate on elements of the following types

- 32-bit single precision floating point
- 8, 16, 32 and 64-bit unsigned and signed integers
- 8 and 16-bit polynomials.

Data type specifiers in NEON instructions comprise a letter indicating the type of data and a number indicating the width. They are separated from the instruction mnemonic by a point. So we have the following possibilities:

- Unsigned integer U8 U16 U32 U64
- Signed integer S8 S16 S32 S64

- Integer of unspecified type I8 I16 I32 I64
- Floating-point number F16 F32 (or F)
- Polynomial over {0,1} P8 P16.

The polynomial type is to help with anything that needs to use power-of-two finite fields or simple polynomials over {0,1}. Normal ARM integer code would typically use a lookup table for finite field arithmetic, but large lookup tables cannot be vectorized. Polynomial operations are hard to synthesize out of other operations, so it is useful having a basic multiply operation (add is EOR) out of which larger multiplies or other operations can be synthesized.

Applications of polynomial arithmetic can include error correction, such as Reed Solomon codes, and CRCs (the field operations typically use a polynomial muliply+mod but this can be reduced to just multiplies, using the Montgomery reduction method). Also elliptic curve cryptography often uses power-of-type fields.

NEON is IEEE 754-1985 compliant, but only supports round-to-nearest rounding mode. This is the rounding mode used by most high-level languages, such as C and Java.

19.2.3 NEON registers

NEON has a unique feature in that the register bank has two views as either as sixteen 128-bit registers (Q0-Q15) or as thirty-two 64-bit registers (D0-D31). Each of the Q0-Q15 registers maps to a pair of D registers, as shown in Figure 19-3. The view of registers is determined by the instruction used; software does not have to explicitly change state. NEON views each register as containing a vector of 1, 2, 4, 8, or 16 elements, each of identical size and type. Individual elements can also be accessed as scalars.




Figure 19-3 NEON register bank

The advantage of the dual view is that it accommodates mathematical operations which widen or narrow the result. For example multiplying two D registers gives a Q register result. The dual-view allows the register bank to be optimized

NEON data processing instructions are typically available in Normal, Long, Wide, Narrow and Saturating variants.

- *Normal* instructions can operate on any vector types, and produce result vectors the same size, and usually the same type, as the operand vectors.
- Long instructions operate on Doubleword vector operands and produce a Quadword vector result. The result elements are usually twice the width of the operands, and of the same type. Long instructions are specified using an L appended to the instruction.

- Wide instructions operate on a Doubleword vector operand and a Quadword vector operand, producing a Quadword vector result. The result elements and the first operand are twice the width of the second operand elements. Wide instructions have a W appended to the instruction.
- *Narrow* instructions operate on Quadword vector operands, and produce a Doubleword vector result. The result elements are usually half the width of the operand elements. Narrow instructions are specified using an N appended to the instruction.
- Saturating instructions are specified using a Q prefix between the V and the instruction mnemonic.

Some NEON instructions act on scalars together with vectors. The scalars can be 8-, 16-, 32-, or 64-bit. Instructions which use scalars can access any element in the register bank, although there are differences for multiply instructions. The instruction uses an index into a doubleword vector to specify the scalar value. Multiply instructions only support 16-bit or 32-bit scalars, and can only access the first 32 scalars in the register bank (that is, D0-D7 for 16-bit scalars or D0-D15 for 32-bit scalars).

19.2.4 NEON instruction set

NEON instructions (as with VFP) all have mnemonics which begin with the letter V. Instructions are generally able to operate on different data types, with this being specified in the instruction encoding. The size is indicated with a suffix to the instruction. The number of elements is indicated by the specified register size.

For example, looking at the instruction

VADD.I8 D0, D1, D2

VADD indicates a NEON ADD operation

18 suffix indicates that 8-bit integers are to be added

D0, D1 and D2 specify the 64-bit registers used (D0 for the result destination; D1 and D2 for the operands)

So this instruction performs eight additions in parallel.

There are operations which have different size registers for input and output.

```
VMULL.S16 Q2, D8, D9
```

This instruction performs four 16-bit multiplies of data packed in D8 and D9 and produces four 32-bit results packed into Q2.

The VCVT instruction converts elements between single-precision floating-point and 32-bit integer, fixed-point and half-precision floating point (if implemented).

NEON includes load and store instructions which can load or store individual or multiple values to a register. In addition, there are instructions which can transfer blocks of data between multiple registers and memory. It is also possible to interleave or de-interleave data during such multiple transfers.

Appendix B lists all NEON and VFP instructions and gives a brief description of their function. Full detail on each can also be found in the ARM *Architecture Reference Manual*.

19.3 NEON comparisons with other SIMD solutions

The ARMv6 architecture introduced a small set of SIMD instructions which operated on multiple 16-bit or 8-bit values packed into standard 32-bit general purpose registers. The mnemonics for these instructions are described in Appendix A and have 8 or 16 appended to the base form to show the size of data they operate on. Other microprocessor architectures support similar sets of SIMD operations. For example, the x86 architecture has the MMX multimedia and SSE Streaming SIMD architecture extensions, while the Power architecture has Altivec. As readers may be familiar with these solutions, we will briefly compare them with NEON.

Table 19-2 NEON compared with MMX and Altivec

	NEON	X86 MMX/SSE	Altivec
Unaligned access	Yes; access can be optimized with known alignment(@64, @128, @256)	Significant penalty if not 16-byte aligned, except certain specific new instructions (LDDQU)	No unaligned support
Number of registers	32x64-bit(dual view as 16x128-bit)	SSE2: 8x128-bit XMM(in x86-32 mode; additional 8 registers in x86-64 mode	32x128-bit
Memory / register operations?	Register-based3-o perand instructions	Mix of register and memory operations	Register-based3-operand instructions
Load/store support for packed data types	Yes: 2,3,4 element	No	No
Move between scalar and vector register	Yes	Yes	No
Floating point support?	Single-precision	Single-precision_ Double-precision	Single-precision

19.3.1 NEON compared with a separate DSP

Many ARM SoCs also incorporate a DSP processor or custom signal processing hardware, so they may include both NEON and a DSP. There are some differences between using NEON compared with using a DSP:

NEON features:

- Part of the ARM processor pipeline.
- Single thread of control providing easier development and debug.
- OS multitasking supported (if OS already saves/restores VFPv3-D32 registers).
- SMP capability. There is one NEON unit per ARM processor within an MPCore. This provides up to N x performance using standard "pthreads".

- Part of the ARM processor architecture. NEON will be available on future faster cores and is supported by many ARM based SoCs.
- Broad NEON tools and open source/commercial ecosystem support.

DSP features:

- Runs in parallel with ARM.
- Lack of OS/task switching overhead can provide guaranteed performance, but only if DSP system design provides predictable performance.
- Generally more difficult to use by applications programmers: two toolsets, separate debugger, potential synchronization issues.
- Less tightly integrated with the ARM core. May be some cache clean/flush overhead with transferring data between DSP and the ARM processor. It makes using a DSP less efficient for processing very small blocks of data.

Chapter 20 Writing NEON Code

Support for NEON is provided in ARM's Compiler and in GNU tools. When writing assembly code with the GNU tools, you must use the -mfpu=neon option to specify that the hardware supports NEON. In ARM's Compiler, you simply specify a target which supports NEON, for example, by using --cpu=Cortex-A5.

20.1 NEON C compiler and assembler

Code targeted at NEON hardware may be written in C and/or in assembly language and a range of tools and libraries is available to support this.

In many cases, it may be preferable to use NEON code within a larger C/C++ function, rather than in a separate file to be processed by the assembler. This can be done using intrinsics, described later in this chapter.

20.1.1 Vectorization

A vectorizing compiler can take your C or C++ source code and parallelize it in a way which allows efficient usage of NEON hardware. This means you can write portable C code, while still obtaining the levels of performance made possible by NEON. The C language does not specify parallelizing behavior, so it may be necessary to provide hints to the compiler about this. For example, it may be necessary to use the __restrict keyword when defining pointers. This has the effect of guaranteeing that pointers will not overlap regions of memory. It may also be necessary to ensure that the number of loop iterations is a multiple of four or eight. Automatic vectorization is specified with the GCC option -ftree-vectorize (along with -mfpu=neon). Using ARM's Compiler, you must specify optimization level -02 (or -03), -0time and --vectorize.

20.1.2 NEON libraries

There is much free open source software which makes use of NEON, for example:

- OpenMAX, a set of APIs for processing audio, video, and still images. It is part of a standard created by the Khronos group. ARM has a free implementation of the OpenMAX DL layer for NEON.
- ffmpeg, a collection of codecs for many different audio/video standards under LGPL license.
- Eigen2, a linear algebra/matrix math C++ template library.
- Pixman, a 2D graphics library (part of Cairographics).
- x264, a GPL H.264 encoder.
- Math-neon.

20.1.3 Intrinsics

NEON C/C++ intrinsics are available in armcc, GCC/g++, and llvm. They use the same syntax, so source code that uses intrinsics can be compiled by any of these compilers.

NEON intrinsics are a way to write NEON code that is more easily maintained than assembler, while still keeping control of the NEON instructions which are generated. There are new data types that correspond to NEON registers (both D-registers and Q-registers) containing different sized elements, allowing C variables to be created that map directly onto NEON registers. These variables are passed to NEON intrinsic functions. The compiler will generate NEON instructions directly instead of performing an actual subroutine call.

NEON intrinsics provide low-level access to NEON instructions but with the compiler doing some of the hard work normally associated with writing assembly language, such as:

Register allocation.

Code scheduling, or reordering instructions to get highest performance. The C compilers
are aware of which processor is being targeted, and they can reorder code to ensure the
minimum number of stalls.

The main disadvantage with intrinsics is that it is not possible to get the compiler to output exactly the code you want, so there is still some possibility of improvement when moving to NEON assembler code.

20.1.4 NEON types in C

Table 20-1 NEON type definitions

64-bit type (D-register)	128-bit type (Q-register)
int8x8_t	int8x16_t
int16x4_t	int16x8_t
int32x2_t	int32x4_t
int64x1_t	int64x2_t
uint8x8_t	uint8x16_t
uint16x4_t	uint16x8_t
uint32x2_t	uint32x4_t
uint64x1_t	uint64x2_t
float16x4_t	float16x8_t
float32x2_t	float32x4_t
poly8x8_t	poly8x16_t
poly16x4_t	poly16x8_t

There are also further types, which combine two, three or four of each of the above, into a larger struct type. These types are used to map the registers accessed by NEON load/store operations, which can load/store up to four registers with a single instruction. For example:

```
struct int16x4x2_t
{
int16x4_t val[2];
}<var_name>;
```

These types are only used by loads, stores, transpose, interleave and de-interleave instructions; to perform operations on the actual data, the individual registers would be selected using, for example, <var_name>.val[0] and <var_name>.val[1] in the example above.

20.1.5 Variables and constants in NEON

In this section we show some example code to access variable or constant data using NEON.

Declaring a variable

Declaring a new variable is as simple as declaring any variable in C:

```
uint32x2_t vec64a, vec64b; // create two D-register variables
```

Using constants

Using constants is straightforward. The following code will replicate a constant into each element of a vector:

```
uint8x8 start_value = vdup_n_u8(0);
```

To load a general 64-bit constant into a vector, use:

```
uint8x8 start_value = vreinterpret_u8_u64(vcreate_u64(0x123456789ABCDEFULL));
```

Moving results back to normal C variables

To access a result from a NEON register, we can either store it to memory using VST, or move it back to ARM using a "get lane" type operation:

```
result = vget_lane_u32(vec64a, 0); // extract lane 0
```

This MRC operation can have some performance impact, particularly on the Cortex-A8 processor.

Accessing two D-registers of a Q-register

This may be done using vget_low and vget_high, as below:

```
vec64a = vget_low_u32(vec128); // split 128 bit vector
vec64b = vget_high_u32(vec128); // into 2x 64 bit vectors
```

Casting NEON variables between different types

NEON instrinsics are strongly typed, so they must be cast between vectors of different types. This is done using vreinterpret, which doesn't actually generate any code, but just allows you to cast the NEON types:

```
uint8x8_t byteval;
uint32x2_t wordval;
byteval = vreinterpret_u8_u32(wordval);
```

Note that the destination type, u8 is listed first after vreinterpret.

20.1.6 NEON assembler and ABI restrictions

For the very highest performance, hand-coded NEON assembler is the best approach for experienced programmers. This requires familiarity with the pipeline and cycle timings of the specific ARM core that is being used, to ensure maximum throughput. Both GNU gas and ARM Compiler Toolchain Assembler armasm support assembly of NEON instructions.

When writing assembler functions, you must be aware of the ARM EABI which defines how registers can be used.

The ARM EABI (Embedded Application Binary Interface) specifies which registers are used to pass parameters, return results, or must be preserved. This specifies the usage of 32 D-registers in addition to the ARM integer registers and is summarized in Table 20-2.

Table 20-2 ARM EABI NEON register use

D0-D7	Argument registers / return value (can be corrupted if not required)
D8-D15	callee-saves registers
D15-D31	caller-save register

Typically, data values are not actually passed to a NEON subroutine, so the best order to use NEON registers is D0-D7, then D15-D31, (then finally D8-D15 only if saved). See also *VFP* and *NEON register usage* on page 15-4.)

20.1.7 Detecting NEON

As NEON hardware may be optionally omitted from a processor implementation, it may be necessary to test for its presence.

Build-time NEON detection

This is the easiest way to detect NEON. In armcc (RVDS 4.0 and later), or GCC, the predefined macro __ARM_NEON__ is defined when a suitable set of processor and FPU options is provided to the compiler.

This could be used to have a C source file which has both NEON and non-NEON optimized versions

Run-time NEON detection

To detect NEON at run-time requires help from the operating system, since the ARM architecture intentionally does not expose processor capabilities to user-mode applications.

Under Linux, /proc/cpuinfo contains this information in human-readable form.

On Tegra2 (a dual-core Cortex-A9processor with FPU), cat /proc/cpuinfo reports:

```
Features : swp half thumb fastmult vfp edsp thumbee vfpv3 vfpv3d16
```

ARM's quad-core Cortex-A9 processor with NEON gives a different result:

```
Features : swp half thumb fastmult vfp edsp thumbee neon vfpv3
```

As the /proc/cpuinfo output is text based, it is often preferred to look at the auxiliary vector /proc/self/auxv. This contains the kernel hwcap in a binary format. The /proc/self/auxv file can be easily searched for the AT_HWCAP record, to check for the HWCAP_NEON bit (4096)

Some Linux distributions (for example, Ubuntu 09.10, or later) take advantage of NEON transparently???. The ld.so linker script is modified to read the hwcap via glibc, and add an additional search path for NEON-enabled shared libraries. In the case of Ubuntu, a new search path /lib/neon/vfp contains NEON-optimized versions of libraries from /lib.

20.2 Optimizing NEON assembler code

To obtain best performance from hand-written NEON code, it is necessary to be aware of some underlying hardware features. In particular, the programmer should be aware of pipelining and scheduling issues, memory access behavior and scheduling hazards. We will briefly discuss each of these here.

20.2.1 NEON pipeline differences between Cortex-A cores

Although there are some small differences in how it is integrated into the processor pipeline, the Cortex-A8 and Cortex-A9 processors share the same basic NEON unit. The Cortex-A5 processor contains a simplified NEON execution pipeline which is fully compatible, but is designed for the smallest and lowest-power implementation possible.

20.2.2 Memory access optimizations

It is likely NEON will be processing large amount of data, such as digital images. One important optimization is to make ensure the algorithm is accessing the data in the most cache-friendly way possible. This gets the maximum hit rate from the L1 and L2 caches. It is also important to consider the number of active memory locations. Under Linux, each 4KB page will require a separate TLB entry. The Cortex-A9 processor has 32 element micro-TLBs and a 128-element main TLB, after which it will start using the L1 cache to load page table entries. A typical optimization is to arrange the algorithm to process image data in suitable-size 'tiles' in order to maximize the cache and TLB hit rate. In general, the memory optimization considerations described in chapter 18 will also apply to NEON code.

The instructions which support interleaving and de-interleaving can provide significant scope for performance improvements. VLD1 loads registers from memory, with no de-interleaving. However, the other VLD operations allow us to load, store and de-interleave structures containing two, three or four equally sized 8-, 16- or 32-bit elements. VLD2 loads two or four registers, de-interleaving even and odd elements. This could, for example, be used to split stereo audio data. Similarly, VLD3 could be used to split RGB pixels into separate channels and correspondingly, VLD4 might be used with ARGB images.




Figure 20-1 Labelled example of load de-interleaving

Figure 20-1 on page 20-6 shows loading two NEON registers with VLD2.16, from memory pointed to by R1. This produces four 16-bit elements in the first register, and four 16-bit elements in the second, with adjacent paired left and right values separated to each register.

20.2.3 Alignment

The NEON architecture provides full unaligned support for NEON data access. However, the instruction opcode contains an "alignment hint" which permits implementations to be faster when the address is aligned and hint is specified.

The base address specified as [<Rn>:<align>]

An alignment hint can be one of :64, :128 or :256 bits depending on the number of D-regs. The ARM *Architecture Reference Manual* uses an "@" symbol to describe this, but this is not recommended in source code.

The GNU gas compiler currently only accepts [Rn,:128] syntax. Note the extra "," before the colon.

20.2.4 Scheduling

To get the very best performance with NEON, you should be aware of how to schedule code for the specific ARM processor you are using. Careful hand-scheduling is recommended to get the best out of any NEON assembler code you write, especially for performance-critical applications such as video codecs.

If writing C or NEON intrinsics, the compiler (GCC or armcc) will automatically schedule code from NEON intrinsics or vectorizable C source code, but it can still help to make the source code as friendly as possible to scheduling optimizations.

Result-use scheduling

This is the main performance optimization when writing NEON code. NEON instructions typically issue in one cycle, but the result is not always ready in the next cycle except for the simplest NEON instructions, such as VADD and VMOV.

In some cases there can be a considerable latency, particularly VMLA multiply-accumulate (five cycles for integer; seven cycles for a floating point). Code using these instructions should be optimized to avoid trying to use the result value before it is ready, otherwise a stall will occur. Despite having a few cycles result latency, these instructions do fully pipeline so several operations can be "in flight" at once.

The result latency is the same between the Cortex-A8 and Cortex-A9 processors for the majority of instructions, since they use the same NEON implementation. The Cortex-A5 processor uses a simplified NEON design more tailored to reduced power and area implementation, and most NEON instructions have a 3-cycle result latency.

Dual-issue scheduling

On the Cortex-A8 processor, certain types of NEON instruction can be issued in parallel (in one cycle). A load/store, permute or MCR/MRC type instruction can be dual issued with a NEON data-processing instruction, such as a floating point add or multiply, or a NEON integer ALU, shift or multiply-accumulate. Programmers may be able to save cycles by ordering code to take advantage of this.

20.2.5 Cortex-A8 specific ARM-NEON memory and NEON-ARM pipeline hazards

The Cortex-A8 NEON coprocessor operates several pipeline stages after the ARM integer pipeline. It receives instructions from the ARM pipeline through a FIFO. Transfer of data from ARM to NEON is quick, but moving data from the NEON pipeline to ARM using an MRC takes 20 cycles.

NEON also has its own load/store unit separate from that of the ARM, with scope to bypass the level 1 cache. To avoid data hazards due to out-of-order memory accesses, there is special hardware to detect such cases and to resolve them. If both NEON and ARM units perform loads and/or stores to addresses within the same cache line, a delay of around 20 cycles is required to resolve ordering issues.

These delays can be avoided with careful coding. Firstly, we must try to minimize a combination of ARM memory accesses and NEON memory accesses to the same region of memory. It can still be sensible to store a NEON result to memory and then load the result into an ARM register from memory. If we don't need the result immediately, it should be possible to hide the 20 cycle latency by having the ARM do some other work before it attempts the load. This is better than using direct NEON to ARM register transfer, which always incurs a penalty because the Cortex-A8 pipeline stalls.

Most compilers use a "softfp" calling convention to pass arguments and return values in ARM integer registers. To return a float value therefore requires passing a value from a NEON register into ARM registers, incurring the 20 cycle delay. A way to avoid this problem is to try to inline such functions.

Conditional branches which depend upon floating point values can also incur this penalty. Although the floating point unit has its own logic to evaluate comparisons and set flags, the contents of this register must be transferred to the ARM to take a conditional branch and this incurs a penalty.

20.3 NEON power saving

Not all code can benefit from NEON. It depends to a large extent how data-intensive an application is and whether the algorithm can operate on multiple values in parallel. In a typical mobile device, NEON will be in a different power domain to the main processor core, which enables it to be powered off when not in use. This can save significant power because NEON is often used intensively by applications (for example, real-time multi-media processing) or not at all. Mobile devices can spend significant amounts of time in standby with the clocked stopped, and it makes sense to ensure NEON is powered down then, as well.

The power saving mechanism would be implemented by the OS, and is expected to be transparent to the user application. Typically the OS will turn off NEON after a period of non-activity, and turning on again when there is an exception caused by attempting to execute a NEON instruction.

NEON power-down sequence (performed by the operating system):

- 1. Disable NEON (for example, setting the Cortex-A9 processor ASEDIS to 1)
- 2. Remove power to the NEON region (SoC specific).

If a NEON instruction is executed when NEON is disabled, the core will take an "undefined instruction" exception (as would any coprocessor if the coprocessor is disabled). The OS "undefined instruction" handler would detect that a NEON instruction (CP10 or CP11) has caused the exception and would execute the power-on sequence:

- 1. Restore power supply (SoC specific) and wait for the power to stabilize.
- 2. Enable NEON (for example, setting the Cortex-A9 processor ASEDIS to 0)
- 3. Re-execute the instruction.

Chapter 21 **Power Management**

Many ARM systems are mobile devices, powered by batteries. In such systems, optimization of power usage (in fact, it would be more accurate to look at total energy usage) is a key design constraint. Programmers often spend significant amounts of time trying to save battery life in such systems. Power-saving may also be of concern even in systems which do not use batteries. For example, we may wish to minimize energy usage for reduction of electricity costs to the consumer or for environmental reasons.

Built in to ARM processors are many hardware design methods aimed at reducing power usage. In this chapter, we will focus on the features available to the programmer to reduce processor power consumption. Before we do so, let's review the components of processor energy usage.

Energy usage can be divided into two components – dynamic and static. Both are important. Static power consumption occurs whenever the processor logic or RAM blocks have power applied to them. In general terms, the leakage currents are proportional to the total silicon area – the bigger the chip, the more the leakage. The proportion of power consumption due to leakage gets significantly higher as we move to more advanced manufacturing process – they are much worse on fabrication geometries of 130nm and below. Dynamic power consumption occurs due to transistors switching and is a function of the processor clock speed and the numbers of transistors which change state per cycle. Clearly, higher clock speeds and more complex processors will consume more power.

21.1 Power and clocking

One way in which we can reduce energy usage is to remove power, which removes both dynamic and static currents (sometimes called *power gating*) or to stop the clock of the processor which removes dynamic power consumption only and may be referred to as *clock gating*.

ARM Processors typically support a number of levels of power management, as follows:

- Run (Normal operation)
- Standby
- Shutdown
- Dormant

In this chapter, we will examine each of these in turn and understand how each saves power. We will also look at the latency associated with each of these modes. For certain operations, there is a requirement to save and restore state before and after removing power and the time taken to do this can be an important factor in software selection of the appropriate power management activity.

The SoC device which includes the ARM processor may have further low power states, with names such as "STOP" and "Deep sleep." These refer to the ability for the hardware *Phase Locked Loop* (PLL) and voltage regulators to be controlled by power management software.

21.1.1 Standby mode

In the standby mode of operation, the device is left powered-up, but most of its clocks are stopped, or *clock-gated*. This means that almost all parts of the processor are in a static state and the only power drawn is due to leakage currents and the clocking of the small amount of logic which looks out for the wake-up condition.

This mode is entered using either the WFI (wait-for-interrupt) or WFE (wait-for-event) instructions, which we'll take a more detailed look at in a moment. We recommend use of a DSB memory barrier before WFI or WFE, to ensure that pending memory transactions complete.

If a debug channel is active, it will remain active. The processor stops execution until a wakeup event is detected. The wakeup condition is dependent on the entry instruction. For WFI an interrupt or external debug request will wake the processor. For WFE, a number of specified events exist, including another processor in an MP system executing the SEV instruction. A request from the *Snoop Control Unit* (SCU) may also wake up the clock for a cache coherency operation in an MP system. This means that the cache of a processor which is in standby state will continue to be coherent with caches of other processorss. A processor Reset will always force the processor to exit from the standby condition.

Various forms of dynamic clock gating may also be implemented in hardware. For example the SCU, GIC, Timers, CP15, instruction pipeline and/or NEON blocks may be automatically clock gated when an idle condition is detected, to save power.

Standby mode can be entered and exited quickly (typically a two-clock-cycle wake-up). It therefore has an almost negligible affect on the latency and responsiveness of the processor.

21.1.2 Dormant mode

In dormant mode, the actual processor logic is powered down, but the cache RAMs are left powered up. Often the RAMs will be held in a low-power retention state where they hold their contents but are not otherwise functional. This provides a far faster restart than complete shutdown, as live data and code persists in the caches. Again, in a multi-core system, individual cores may be placed in dormant mode.

In an MPCore system which allows individual cores within the SMP cluster to go into dormant mode, there is no scope for maintaining coherency while the processor has its power removed. Such processors must therefore first isolate themselves from the coherence domain. (Of course, in an AMP system, they may already not be coherent). They will clean all dirty data before doing this and will be typically be woken up via another processor telling the external logic to re-apply power. The woken processor will then need to restore the original processor state before rejoining the coherency domain. As the memory state may have changed while the processor was in dormant mode, it may well need to invalidate the caches anyway. Dormant mode is therefore much more likely to be useful in a single core environment rather than in a multi-core set-up. In an MPCore cluster, dormant mode is typically likely to be used only by the last core when the other cores have already been shutdown.

21.1.3 Assembly language power instructions

ARM Assembly Language includes instructions which can be used to place the processor in a low power state. The architecture defines these instructions as "hints" – the processor is not required to take any specific action when it executes them. In the Cortex-A processor family, however, these instructions are implemented in a way which shuts down the clock to almost all parts of the processor. This means that the power consumption of the processor is significantly reduced – only static leakage currents will be drawn, and there will be no dynamic power consumption.

The WFI instruction (wait for interrupt) has the effect of suspending execution until the processor is "woken up" by one of the following conditions:

- an IRQ interrupt (even if CPSR I-bit is set)
- an FIQ interrupt (even if CPSR F-bit is set)
- an Imprecise Data abort
- a Debug Entry request (even if JTAG Debug is disabled).

In the event of the processor being woken by an interrupt when the relevant CPSR interrupt flag is disabled, the processor will simply implement the next instruction after WFI. On older versions of the ARM Architecture, the wait for interrupt function (also called standby mode) was accessed using a CP15 operation, rather than a dedicated instruction.

The WFI instruction is widely used in systems which are battery powered. For example, mobile telephones may place the processor in standby mode many times a second, while waiting for the user to press a button.

WFE is similar to WFI. It suspends execution until an event occurs. This may be one the events listed above, or an additional possibility – an event signaled by another processor in an MPCore. Other processors can signal events by executing the SEV instruction. SEV signals an event to all cores in a multi-processor system. We will discuss WFE further when we look at multi-core systems.

There is a further related instruction (YIELD) described in the ARM *Architecture Reference Manual*. This is treated as a hint by most Cortex-A processors and does not actually do anything.

21.1.4 Dynamic Voltage/Frequency Scaling

Many systems operate under conditions where their workload is very variable. It would be useful to have the ability to reduce or increase the processor performance to match the expected processor workload. If we could clock the processor more slowly when it is less busy, we could

save dynamic power consumption. The dynamic power consumption has a linear correlation with clock frequency, but a quadratic relationship with voltage (it is proportional to the square of the supply voltage).

If the processor is running more slowly, it is also the case that its supply voltage may be reduced somewhat (but not past the point where it can no longer operate correctly at the reduced clock frequency). This hardware approach is called *Dynamic Voltage and Frequency Scaling* (DVFS). The advantage of reducing supply voltage is that it reduces both dynamic and static power. Compared to the alternative of running fast, then entering standby, then running fast and so forth, the approach of running slowly at a lower supply can save energy. To do this successfully requires two difficult engineering problems to be solved. The SoC needs a way in which software running on the ARM processor can reliably modify the clock speed and supply voltage of the processor, without causing problems in the system. (This needs things like voltage level-shifters and split power supplies on chip to cope with the variable supply, plus synchronizers between voltage domains to cope with timing changes). Of equal importance is the ability of software running in the system to make accurate predictions about future workloads to set the voltage and clock speed accordingly.

Chapter 22 **Introduction to Multi-processing**

In the chapters that follow we look at systems with multiple processors and examine programming techniques for these. We distinguish between systems that contain multiple separate processor elements (a majority of today's embedded systems) and true multi-processors, with multiple cores closely coupled together in hardware. We will introduce terminology to describe and categorize such systems, in terms of both hardware and software and we look at some example ARM implementations.

Multi-processing can be defined simply as running two or more sequences of instructions within a device containing two or more processors. The concept of multi-processing has been a subject of research for a number of decades, and has seen widespread commercial use over the past 15 years. Multi-processing is now a widely adopted technique in both systems intended for general-purpose application processors and in areas more traditionally defined as embedded systems.

Multi-core and multi-processor systems can deliver higher performance, due to the simple fact that more processing units are available. This allows multiple tasks to be executed in parallel, potentially reducing the amount of time required to perform the allocated task.

The overall energy consumption of a multi-core system can be significantly lower than that of a system based on a single processor core. Multiple cores allow execution to be completed faster and so some elements of the system might be completely powered down for longer periods. Alternatively, a system with multiple cores may be able to operate at a lower frequency than that required by a single processor to achieve the same throughput. A lower power silicon process and/or a lower supply voltage can result in lower power consumption and reduced energy usage. Note that most current systems do not allow the frequency of cores to be changed on an individual basis. However, each core may be dynamically clock gated, giving further power/energy savings.

Multi-core systems also add flexibility and scalability to system designs. A system that contains one or two cores could be scaled up for more performance simply by adding further cores, without requiring redesign of the whole system or significant changes to software.

Having multiple cores at our disposal also allows more options for system configuration. For example, we might have a system which uses separate cores – one to handle a hard real-time requirement and another for an application requiring high, uninterrupted performance. These could be consolidated into a single multi-processor system.

A multi-core device is also likely to be more responsive than one with a single core. When interrupts are distributed between cores there will be more than one core available to respond to an interrupt and fewer interrupts per core to be serviced. Multiple cores will also allow an important background process to progress simultaneously with an important but unrelated foreground process.

Multi-core systems can also extract more performance from high latency memory systems (for example, DDR memory) by allowing a memory controller to queue up and optimize requests to the memory. Processors working on coherent data can benefit from reductions in linefills/evictions. When the data is not shared, the result is likely to be negative. An L2 cache can mean improved utilization for shared memory regions (including file caches), shared libraries and kernel code. Of course, if the number of cores is increased and they are not sharing code or data, then without a corresponding increase in memory bandwidth performance will instead go down.

In the past, much software was written to operate within the context of a single processor. Similarly, operating systems were implemented to optimally handle the case of a single processor. Some operating systems provide support for time-slicing, this gives the illusion of multiple processes/tasks running simultaneously. It is important to clearly understand the difference between multi-threading (for example POSIX threads, or Java) and multi-processing. A multi-threaded application can be run on a single core, but only with multi-processing can the threads truly execute in parallel.

Migrating multi-threaded software from a single processor system to a multi-processing one can trigger problems with incorrect programs that could not be exposed by running the same program time-sliced on a single processor. It can also cause very infrequent bugs to become very frequently triggered. What it cannot do is to cause correctly written multi-threaded programs to misbehave — only expose previously unnoticed errors.

22.1 Multi-processing ARM systems

From early in the history of the architecture, ARM processors were likely to be implemented in systems which contained other processors. This commonly meant a *heterogeneous* system, perhaps containing an ARM plus a separate DSP processor. Such systems have different software executing on different cores and the individual processors may have differing privileges and views of memory. Many widely used ARM systems (for example, TI's OMAP series, or Freescale i.MX) provide examples of this.




Figure 22-1 Example of a system with multiple processors

We may distinguish between systems which contain:

- a single processor
- multiple processors (such as that shown in figure 22-1), which contain multiple independent processing elements
- a multi-core processor, which contain multiple cores capable of independent instruction execution, which can be externally viewed like a single unit, either by the system designer or by an operating system that can abstract the underlying resources from the application layer. In this chapter (and those which follow), we will focus on such processors.

ARM was among the first companies to introduce such multi-core processors to the System-on-Chip market, when it introduced the ARM11MPCore processor, in 2004. The Cortex-A5MPCore and Cortex-A9MPCore processors described in this book provide further examples of such systems.

An ARM MPCore processor can contain between one and four processing cores. Each core can be individually configured to take part (or not) in a data cache coherency management scheme. A *Snoop Control Unit* (SCU) device inside the processor has the task of automatically maintaining cache coherency, between cores within the processor without software intervention.

ARM MPCore processors include an integrated Interrupt Controller. Multiple external interrupt sources can be independently configured to target one or more of the individual processor cores. Furthermore, each core is able to signal (or *broadcast*) any interrupt to any other core or set of

cores in the system, from software (Software Triggered Interrupts). These mechanisms allow the OS to share and distribute the interrupts across all cores and to coordinate activities using the low-overhead signaling mechanisms provided.

Cortex-A MPCore processors also provide hardware mechanisms to accelerate OS kernel operations such as system wide cache and TLB maintenance operations. (This feature is not found in the ARM11MPCore.)

In summary, each of the Cortex-A series MP processors can have the following features:

- Configurable between one and four cores (at design time)
- Data cache coherency
- Integrated interrupt controller
- Local timers and watchdogs
- (Optional) Accelerator Coherency Port (ACP).

We will discuss each of these features in more detail in the course of this chapter and those which follow.

22.2 Symmetric multi-processing

Symmetric multi-processing (SMP) is a software architecture which dynamically determines the roles of individual processors. Each core has the same view of memory and of shared hardware. Any application, process or task can run on any core and the operating system scheduler can dynamically migrate tasks between cores to achieve optimal system load.

We expect that readers will be familiar with the fundamental operating principles of an OS, but OS terminology will be briefly reviewed here. An application which executes under an operating system is known as a *process*. It performs many operations through calls to the system library, which provides certain functions from library code, but also acts a wrapper for system calls to kernel operations.

For the purposes of describing SMP operation, we will use the term *kernel* to represent that portion of the operating system which contains exception handlers, device drives and other resource and process management code. We will assume also the presence of a *scheduler*, which typically is called using a timer interrupt and which has the task of time-slicing the available cycles on processors between multiple tasks and dynamically determining the priority level of individual processes and deciding which process to run next. Individual processes have associated resources (including stack, heap and constant data areas) and properties (such as scheduling priority settings). The kernel view of a process is called a *task*.

A *context switch* denotes the scheduler transferring execution from one process to another. This typically requires saving the current process state and restoring the state of the next process waiting to be run. *Threads* are separate tasks executing within the same process space, which allow separate parts of the application to execute in parallel on different cores. They also permit one part of an application to keep executing while another part is waiting for a resource.

In general, all threads within a process share a number of global resources (including the same memory map and access to any open file and resource handles). Threads also have their own local resources, including their own stacks and register usage, which will be saved and restored by the kernel on a context switch. The fact that these resources are local does not, however, mean that the local resources of any thread are guaranteed to be protected from incorrect accesses by other threads. Threads are scheduled individually and can have different priority levels even within a single process.

An SMP capable operating system provides an abstracted view of the available processor resources to the application. Multiple applications can run concurrently in an SMP system without re-compilation or source code changes. A conventional multitasking OS allows the system to perform several task or activities at the same time, in both single-core and multi-core processors. There is, however, a key distinction. In the single (uniprocessor) case, multitasking is performed through time slicing of a single processor, giving the illusion of many tasks being performed at the same time. In the multi-core system, we can have true concurrency: Multiple task are actually carried out at the same time, in parallel, on separate cores. The role of managing the distribution of such tasks across the available cores is performed by the operating system.

To provide the best possible energy usage, it may be desirable for the OS to distribute the concurrent tasks evenly across the available processors. This enables us to maximize the benefits of dynamic voltage and frequency scaling (DVFS) power management techniques, since, typically, DVFS applies to the whole multi-core cluster. Such activity is known as *load balancing*. It attempts to ensure that there is an even spread of workloads across all available cores. To do this, it must be able to dynamically re-prioritize tasks and have the ability to monitor the workload of each core.

Interrupt handling can also be load balanced. By default on ARM processors all interrupts are sent to CPU0. This allows for using user space software to rebalance interrupts. Under Linux this can be performed by the *irqbalance* daemon, http://irqbalance.org/. Irqbalance monitors the interrupt handling load on each core and tries to shift interrupts around, using the

irq_set_affinity system call, to achieve an even load across the system. This is not as trivial a task as it might first appear. For example, a single device might have more than one interrupt output, or separate devices might be feeding data into the same kernel subsystems. Both these situations, if ignored, could lead to a lot of data being shuffled back and forth between cores by the cache coherency hardware. To combat this, irqbalance tries to make clever decisions about which interrupts should be grouped together on a specific core. However, it provides additional facilities for controlling this behavior if the default parameters are not optimal for your system. It is possible to manually configure interrupt targets for load balancing, for example, you may want to do this for interrupts associated with an individual peripheral. On ARM and Intel processors, the default in-kernel behavior is NOT to do interrupt load balancing.

The scheduler in an SMP system can dynamically reprioritize tasks. This *dynamic task prioritization* allows for other tasks to run while the current task sleeps. In Linux, for example, tasks whose performance is bound by I/O activity may have their priority decreased in favor of tasks whose performance is limited by processor activity. The I/O-bound task will typically schedule I/O activity and then sleep pending such activity.

22.3 Asymmetric multi-processing

It is conventional to distinguish between SMP (Symmetric) and AMP (Asymmetric) multi-processing. In an AMP system, the programmer statically assigns individual roles to a core, so that in effect, we have separate cores, each performing separate jobs. This may be referred to as a function-distribution software architecture and typically means that we have separate operating systems running on the individual cores. The system may appear to the programmer as a single-core system with dedicated accelerators for certain critical system services. In general AMP does not refer to systems in which tasks or interrupts are associated with a particular core.


In an AMP system, each task may have a different view of memory and there is no scope for a core which is highly loaded to pass work to one which is lightly loaded. There is no need for hardware cache coherency in such systems, although there will typically be mechanisms for communication between the cores through shared resources, possibly requiring dedicated hardware. The Cortex-A9 processor cache coherence management hardware (described later) can help reduce the overheads associated with sharing data between the systems.

Reasons for implementing an AMP system using a multi-core processor might include security, need for guaranteeing meeting of real-time deadlines, or because individual cores are dedicated to perform specific tasks.

There are classes of systems that have both SMP and AMP features. This means that we have two or more cores running an SMP operating system, but the system has additional elements which do not operate as part of the SMP system. The SMP sub-system can be regarded as one element within the AMP system. Cache coherency is implemented between the SMP cores, but not necessarily between SMP cores and AMP elements within the system. In this way, independent subsystems can be implemented within the same multi-core processor.

It is entirely possible (and normal) to build AMP systems in which individual processors are running different operating systems (so-called Multi-OS systems).

The selection of software MP model is determined by the characteristics of the applications running in the system. In networking systems, for example, it may be convenient to provide a separation between control-plane (AMP) and data-plane (SMP) sections of the system. In other systems, it may be desirable to isolate those parts of the system which require hard real-time response from applications which simply require raw processor performance and to implement these on separate processors.



SMP Architectural Considerations

The ARM MPCore technology provides a number of features that reduce the overheads associated with multiprocessing software. To implement an SMP system, it is vital to have shared memory between the processors. To maintain the desired level of abstraction to application software, the hardware must take care of cache coherency problems for us. If data is modified by one process running on one processor and used by a process running on a different processor, we cannot require one task to clean the other processor's cache; nor can we require the data to be uncacheable. Instead, the processors must automatically maintain cache coherency for us. Similarly, we must have mechanisms by which cache maintenance operations (such as cleaning and invalidation of cache lines) can be passed between processors.

In addition, we need ways to mark areas of memory as being Shareable between processors (this was discussed in Chapter 8) to enforce particular orderings of memory transactions (discussed in Chapter 9 *Memory Ordering*), and to maintain consistent views of the memory map, including virtual to physical address translations.

23.1 Cache coherency

Cache coherency is vitally important in an SMP system. It means that changes to data held in one processor's cache are visible to the other processors, making it impossible for processors to see 'stale' copies of data (the old data from before it was changed by the first processor).

This activity is handled in ARM MPCore systems by a device known as the *Snoop Control Unit* (SCU). This device maintains coherency between the cores' L1 data caches. Since executable code changes much less frequently, this functionality is not extended to the Level 1 instruction caches. The coherency management is implemented using a MESI-based protocol, optimized to decrease the number of external memory accesses. In order for the coherency management to be active for a memory access, all of the following must be true:

- The SCU is enabled, through its control register. (The SCU has configurable access control, allowing restriction of which processors can configure it.)
- The core performing the access is configured to participate in the inner shareable domain (configured by the operating system at boot time, by setting the somewhat misleadingly named SMP bit in the CP15:ACTLR, Auxiliary Control Register).
- The MMU is enabled.
- The page being accessed is marked as "normal, shared" with a cache policy of
 "write-back, write-allocate". Device and Strongly Ordered memory, however, are not
 cacheable, and write-through caches behave just like uncached memory from the core's
 point of view.

Note that the SCU can only maintain coherency within the MP block. If there are additional processors or other bus masters in the system, explicit software synchronization is required when these share memory with the MP block. Alternatively, the Accelerated Coherency Port may be used (described in *Booting SMP systems* on page 23-10)

23.1.1 MESI protocol

There are a number of standard ways by which cache coherency schemes can operate. As mentioned in *Cache coherency*, ARM MP Processors use a modified version of the MESI protocol. Let's take a look at how that works and then describe some of the modifications made to it for performance reasons:

The SCU marks each line in the cache with one of the following attributes: M (Modified), E (Exclusive), S (Shared) or I (Invalid). These are described below:

- Modified: The most up-to-date version of the cache line is within this cache. No other
 copies of the memory location exist within other caches. The contents of the cache line
 are no longer coherent with main memory.
- *Exclusive*: The cache line is present in this cache and coherent with main memory. No other copies of the memory location exist within other caches.
- Shared: The cache line is present in this cache and coherent with main memory. Copies of it may also exist in other caches in the coherency scheme.
- *Invalid*: The cache line is invalid.

Now let's look at the standard implementation of the protocol. The rules are as follows:

A write can only be done if the cache line is in the Modified or Exclusive state. If it is in
the Shared state, all other cached copies must be invalidated first. A write moves the line
into Modified State

- A cache may discard a Shared line at any time, changing to the Invalid state. A Modified line is written back first.
- If a cache holds a line in the Modified state, reads from other caches in the system will get
 the updated data from the cache. This is conventionally done by first writing the data to
 main memory and then changing the cache line to the Shared state, before performing a
 read.
- A cache that has a line in the Exclusive state must move the line to Shared state when another cache reads that line.
- The Shared state may not be precise. If one cache discards a Shared line, another cache
 may not be aware that it could now move the line to Exclusive status.

ARM MP Cores also implement optimizations that can copy clean data and move dirty data directly between participating L1 caches, without having to access (and wait for) external memory.

These optimizations are made possible the by the use of duplicated Tag RAMs. These allow the SCU to track the contents of the L1 caches, without requiring direct access to them (which would slow the processor).

23.1.2 MOESI protocol

The Cortex-A5MP processor implements a slightly different coherency protocol. It uses the MOESI protocol, which introduces a fifth state for a shareable line in an L1 data cache. This is *Owned*, which describes a line that is dirty and in possibly more than one cache. A cache line in the owned state holds the most recent, correct copy of the data. Only one core can hold the data in the owned state. The other cores can hold the data in the shared state.

23.1.3 TLB and cache maintenance broadcast

An individual core can broadcast TLB and cache maintenance operations to other cores in the inner shareable coherency domain. This may be required whenever shared page tables are modified, for example. This behavior may need to be enabled by the programmer. For example, in the Cortex-A9 processor, this is controlled by the FW bit in the Auxiliary Control Register (ACTLR). Maintenance operations can only be broadcast and received when the core is configured to participate in the inner shareable domain (using the SMP bit in ACTLR). Only "inner shareable" operations are broadcast, for example:

- Invalidate TLB entry by virtual address.
- Clean/Invalidate data cache line by virtual address.
- Invalidate Instruction cache line by virtual address.

Maintenance broadcasting was not available in ARM11MPCore, requiring broadcasting of the above operations to be implemented in software.

Some care is needed with cache maintenance activity in multi-core systems which include a PL310 L2 cache (or similar). Cleaning and/or invalidating the L1 cache and L2 cache will not be a single atomic operation. A processor may therefore perform cache maintenance on a particular address in both L1 and L2 caches only as two discrete steps. If another processor were to access the affected address between those two actions, a coherency problem may occur. Such problems may be avoided by following two simple rules.

• When cleaning, always clean the innermost (L1) cache first and then clean the outer cache(s).

•	When invalidating, always invalidate the outermost cache first and the L1 cache last.

23.2 Handling interrupts in an SMP system

MPCore processors include an integrated interrupt controller, which is an implementation of the GIC architecture. This provides 32 private interrupts per core, of which the lower 16 are *Software Generated Interrupts* (SGI) that can be generated only through software operations, and the rest are *Private Peripheral Interrupts* (PPI). It also provides a configurable number of *Shared Peripheral Interrupts* (SPI) - up to 224 in current MPCore implementations). It supports interrupt prioritization, pre-emption and routing to different cores.

From a software perspective, the GIC has two major functional blocks:

- *The Distributor*, which is shared between all cores within the processor. This is used for configuring things like prioritization and routing, as well as providing global enabling/disabling of individual interrupts.
- *The CPU Interface*, which is each core's private channel for handling interrupts. This is where you find out which interrupt has been triggered and notify when you have completed processing an interrupt.

Within the Distributor you have series of configuration registers, the number depending on how many external interrupts are implemented:

- The *Interrupt Processor Targets Registers* configure which cores individual interrupts are routed to. They are ignored for private interrupts.
- The Interrupt Configuration Registers configure individual interrupt sources as edge or level sensitive.
- The *Interrupt Priority Registers* set priority values for individual interrupts. A lower value indicates a higher priority. The registers controlling the private interrupts (0-31) are banked, so that each core can have its own configuration for these.
- The Software Generated Interrupt (SGI) Register can assert a private software generated interrupt on any core, or a groups of cores. The priority of a software interrupt is determined by the priority configuration of the receiving core, not the one that sends the interrupt. The interrupt acknowledge register bits [12:10] will provide the ID of the processor which made the request. The SGI may be sent to all processors, all but self or to a target list.

Interrupts in a GIC have three possible states:

- *Inactive*: interrupt is not asserted
- *Pending*: interrupt line is asserted, but software has not yet acknowledged the interrupt
- Active: interrupt has been acknowledged and software is handling it.

Within the CPU Interfaces you have per-core instances of:

- The *Priority Mask Register* that prevents interrupts below a certain priority level from being delivered to a core. Interrupts of the lowest priority are always disabled.
- The *Binary Point Register* allows a configurable number of the least significant bits of the priority value to be ignored for pre-emption purposes. This allows interrupts to be configured such that groups of interrupts with similar levels of priority do not pre-empt each other, but are still handled in priority order if triggered simultaneously.
- The *Interrupt Acknowledge Register* returns the value of the highest priority pending interrupt and flags it as being Active. For a software generated interrupt, it also contains the ID of the core that generated it. If no interrupt is currently pending, a pre-defined "spurious" ID is returned.

• The End Of Interrupt Register is used to indicate that an interrupt handler has finished processing an interrupt. It does this by writing back the value previously read from the Interrupt Acknowledge Register. Until this is done, new signaling of that interrupt (and any interrupts of lower priority) will not be detected.

When the interrupt controller signals an interrupt to a core, the interrupt handling software acknowledges this by reading the Interrupt Acknowledge Register. This returns the ID of the highest priority pending interrupt, which is then made active. The interrupt controller then de-asserts the IRQ input to the core, which means that the interrupt service routine can now re-enable interrupts. This allows the arrival of a higher-priority interrupt to pre-empt processing of the current one. The interrupt is cleared by writing its ID to the End of Interrupt register.

In both AMP and SMP systems, it is likely that cores will need to trigger interrupts on other cores (or themselves) – a so called softirg.

These Inter-Processor Interrupts can be used for kernel synchronization operations, or for communicating between AMP processors. For operations requiring more information passed than a raised interrupt, you can use a shared buffer.

Before the processor can receive an interrupt, some initialization steps are required.

- Global Settings
 - Enable the distributor using the Distributor Control Register.
 - Enable and set priority of Shared Peripheral Interrupts using the Enable Set and Priority Level registers. The reset priority level of interrupts might be too low for them to be delivered.
- Individual Core Settings
 - Enable the CPU Interface using the CPU Interface Control Register.
 - Set Priority Mask Register (the reset value prevents all interrupts from being delivered).
 - Enable and set priority of Private Peripheral Interrupts and Software Generated
 Interrupts using the Enable Set and Priority Level registers. These operations are
 performed in the Distributor Priority Level Registers. These registers are banked
 providing a separate copy for each core.
 - Clear the I bit in CPSR.

23.3 Exclusive accesses

In an SMP system, data accesses frequently have to be restricted to one modifier at any particular time. This may be true of peripheral devices, but also for global variables and data structures accessed by more than one thread or process. Furthermore, library code which is used by multiple threads must be designed to ensure that concurrent access/execution is possible – it must be *reentrant*.

Protection of such shared resources is often through a method known as *mutual exclusion*. The section of code which is being executed by a core while accessing such a shared resource is known as the *critical section*.

In a single processor system, mutual exclusion can be achieved by disabling interrupts when inside critical sections. This is not sufficient in a multi-core system, as disabling interrupts on one core will not prevent others from entering the critical section. It is also not ideal since interrupts cannot be disabled from within user mode. (Of course, there are other problems with this technique, including reduced responsiveness to real-time events, particularly if the critical section is long.)

In a multi-core system, we may use a *spinlock* - effectively a shared flag with an atomic (indivisible) mechanism to test and set its value. We perform this operation in a tight loop to wait until another thread (or core) clears the flag. We require hardware assistance in the form of special assembly language instructions to implement this. In general, the software developer does not need to understand the low-level implementation detail, but instead become familiar with the lock and unlock calls available in their OS or threading library API. Nevertheless, in the next section, we will examine how this is implemented on the ARM Architecture.

Three assembly language instructions relating to exclusive access are provided in the ARM architecture (in ARMv6 onwards). Variants of these instructions which operate on byte, halfword, word or doubleword sized data are also provided.

- LDREX (Load exclusive) performs a load of memory, but also "tags" the physical address read as being for the exclusive access of that processor.
- STREX (Store exclusive) checks if the physical address to be written is tagged as exclusive access for that processor. If it is not, the store will not happen and a value of 1 is returned by the instruction. If the store completes, a value of 0 is returned
- CLREX (Clear exclusive) clears any tagged address value.

The instructions rely on the ability of the core and/or memory system to tag particular addresses as exclusively for the use of that core, using an "exclusive access monitor". The page table entry for a particular page has an attribute which says whether the memory is 'shared'. If the core reads from memory with an LDREX, the load happens and that physical address is 'tagged' as exclusive access for that processor. If any other processor writes to that address and the memory is marked as Shareable, the tag is cleared. If the memory is not Shareable then any attempt to write to the tagged address by the one that tagged it results in the tag being cleared. If the processor does a further LDREX to a different address, the tag for the previous LDREX address is cleared. Each processor is only permitted to tag one address.

STREX may be considered as a conditional store. The store is performed only if the physical address is still marked as exclusive access (this means. it was previously tagged by this processor and no other processor has since written to it). The STREX returns a status value showing if the store succeeded. STREX always clears the exclusive access tag.

The use of these instructions is not limited to multi-core systems. In fact, they are frequently employed in single processor systems, to implement synchronization operations between threads running on the same processor.

LDREX and STREX operations may be performed only to normal memory. If the memory is marked as "non-shareable", the hardware will assume that only this core can modify the exclusive location.

Let's take a very simple example (Example 23-1) of how the load and store exclusive operations can be used to implement a spinlock.

Example 23-1 Example spin lock implementation with LDREX/STREX

```
MOV R1, #0 @ the LOCK value
LDR R2, <spinlock_addr>
spin_lock:
LDREX R0, [R2] @ load value
CMP R0, R1 @ if not locked already
STREXNE R0, R1, [R2] @ try to claim the lock
CMPNE R0, #1 @ check if we succeeded
BEQ spin_lock @ retry if failed
```

In this code, we perform an LDREX (exclusive load) from the memory address which holds the lock value (address held in R2). This does two things. It returns the value of the lock into register R0. It also tags the address as being exclusively accessed. We then check to see if the value at the address is equal to 0 (the value we have chosen to represent that the lock is in a locked state). If it is not, we proceed to try to claim the lock. We execute the STREX (exclusive store) instruction. This first checks that the address is still marked as exclusive. If it is, this means that we check that no other thread on this processor, or on another, has touched the address in the time since the read was done and the address was tagged as exclusive. If this check succeeds then the memory location is updated and the exclusive access tag is cleared. In this case the value 0 is written, indicating that the resource is now locked. The register R0 is used to hold the value returned by the STREX instruction. If R0 is 1 then the STREX failed. The BEQ at the end covers both cases (that is, LDREX returned a value of 0 indicating the lock is taken or that STREX returned a 1 indicating that someone touched the lock since we read a non-zero value in the LDREX).

It should be clear from this that LDREX and STREX provide the necessary primitives to allow us to build complex synchronization objects. Let us now take a look at how the exclusive tagging actually works. In hardware, the processor includes a device named the *exclusive access monitor*. This monitor observes the processor. When it sees an exclusive load access performed by the processor, it records that fact. When it sees an exclusive store performed by the same processor, it checks that a previous exclusive load was performed and fails the exclusive store if this was not the case. The architecture allows individual implementations to determine the level of checking performed by the monitor. The processor can only tag one physical address at a time. An LDREX from a particular address should be followed shortly after by an STREX to the same location, before an LDREX from a different address is performed. This is because the local address monitor does not need to store the address of the exclusive tag (although it may do, if the hardware implementer decides to do this). The architecture allows the local monitor to treat any exclusive store as matching a previous LDREX address. For this reason, use of the CLREX instruction to clear an existing tag is required upon context switches.

Where exclusive accesses are used to synchronize with external masters outside the processor, or to regions marked as Sharable (but not coherency managed) even between cores in the same processor, it is necessary to implement a global access monitor within the hardware system. This acts as a wrapper to one or more memory slave devices and is independent of the individual cores. This is specific to a particular SoC and may or may not exist in any particular system. An LDREX/STREX sequence performed to a memory location which has no suitable exclusive access monitor will fail with the STREX instruction always returning 1.

Finally, let's look at the specific case of Linux – the arch/arm/include/asm/spinlock.h file, which includes two functions arch_spin_lock() and arch_spin_unlock(). The first of these contains the inline assembly sequence shown in Example 23-2.

Example 23-2 Linux Spinlock code

```
static inline void arch_spin_lock(arch_spinlock_t *lock )
   unsigned long tmp;
       asm_
           _ __volatile__(
          ldrex
                  %0, [%1]\n"
                  %0, #0\n"
          teq
  #ifdef CONFIG_CPU_32v6K
          wfene\n"
  #endif
          strexeq %0, %2, [%1]\n"
                  %0, #0\n"
          tegeg
                  1b"
          bne
          : "=&r" (tmp)
          : "r" (&lock->lock), "r" (1)
          : "cc");
           smp_mb();
}
```

As you can see, this is very similar to the example code earlier, a key difference being that Linux running on an MPCore may actually put a core which is waiting for a lock to become available into standby state, to save power. Of course, this relies on the other processor telling us when it has finished with the lock to wake this processor up, using the SEV instruction. More information on WFE and SEV is contained in Chapter 21 *Power Management*).

The smb_mb() macro at the end of the sequence is required to ensure that external observers see the lock acquisition before they see any modifications of the protected resource, and also to ensure that accesses to the region before the acquisition, have completed before the lock holder reads from it.

In *Linux use of barriers* on page 9-13 we introduced the Linux memory barrier functions, and mentioned that SMP versions of these are available. The smp_mb() macro will expand to a plain compiler barrier if the kernel is built without SMP support (CONFIG_SMP). If the kernel is built with SMP support, this will expand to the barrier of the required type for the core's shareability domain.

23.4 Booting SMP systems

Initialization of the external system may need to be synchronized between cores. Typically, only one of the cores in the system needs to run code which initializes the memory system and peripherals. Similarly, the SMP operating system initialization typically runs on only one core – the *primary core*. Once the system is fully booted, the remaining cores are brought online and this distinction between the primary core and the others (secondary cores) is lost.

If all of the cores come out of reset at the same time, they will normally all start executing from the same reset vector. The boot code will then read the processor ID to determine which core is the primary. The primary core will perform the initialization described above and then signal to the secondary ones that everything is ready. An alternative method is to hold the secondary cores in reset while the primary core does the initialization. This requires hardware support to co-ordinate the reset.

In an AMP system, the boot loader code will determine the suitable start address for the individual cores, based on their processor ID (as each processor will be running different code). Care may be needed to ensure correct boot order in the case where there are dependencies between the various applications running on different cores.

23.4.1 CPU ID

Booting provides a simple example of a situation where particular operations need to be performed only on a specific core. Other operations need to perform different actions dependent on the core on which they are executing.

The CP15:MPIDR Multiprocessor Affinity Register shown in Figure 23-1, allows kernel software to determine on which core within the system, it is running. This may be a processor ID within a specific MP instance and/or a Cluster ID value. The U bit indicates whether this is a Uni-Processor or MPCore, ID is the ID of the core performing the read (0, 1, 2 or 3) and Cluster ID field reflects the state of CLUSTERID configuration pins, which can be used to distinguish individual clusters in a system containing multiple MPCores.




Figure 23-1 Diagram of Multi-processor Affinity Register

23.4.2 SMP Boot in ARM Linux

The boot process for the primary processor is as described earlier in this book. While this happens, the secondary processors will be held in a standby state, using the WFI instruction. It will provide a startup address to the secondary processors and wake them using an inter-processor interrupt. Booting of the secondary processors is serialized, using the global variable pen_release. When an inter-processor interrupt (IPI) occurs, the secondary processors will check the value of pen_release against their own ID value using the MPIDR register.

Booting of the secondary processor will proceed in a similar way to the primary. It enables the MMU (setting the TTB register to the new page tables already created by the primary). It enables the interrupt controller interface to itself and calibrates the local timers. It sets a bit in cpu_online_map and calls cpu_idle(). The primary processor will see the setting of the appropriate bit in cpu_online_map and set pen_release to the next secondary processor.

23.5 Accelerator Coherency Port (ACP)

The Accelerator Coherency Port (ACP) is an optional feature of the Cortex-A9 and Cortex-A5 processors. It provides an AXI slave interface into the snoop control unit of the processor. (The AXI bus interface is defined in ARM's AMBA specification.)

This slave interface can be connected to an external uncached AXI master, such as a DMA engine, for example, and is able to initiate both read and write memory transfers to the ACP. It allows such a device to snoop the L1 caches of all cores, avoiding the need for synchronization through external memory. A cached device can also be connected, but this requires manual coherency management through software.

The behavior of accesses performed on the ACP is as follows:

- Addresses used by the ACP are physical addresses that can be snooped by the SCU to be fully coherent.
- ACP reads can hit in any core's L1 D-cache.
- Writes on the ACP invalidate any stale data in L1 and write through to L2.

The ACP allows an external device to see processor-coherent data without knowledge of where the data is in the memory hierarchy. Memory transfers are automatically coherent in the same way as happens between the processor's L1 D-caches.

Use of the ACP can both increase performance and save power, as there will be reduced traffic to external memory and faster execution.

Programmers writing device drivers which use ACP do not need to be concerned with coherency issues, as no cache cleaning or invalidation is required to ensure coherency. However, the use of memory barriers (DMB) or external cache synchronization operations may still be necessary, if a particular ordering must be enforced.

23.6 Private memory region

In the Cortex-A5, and Cortex-A9 MPCore processors, all of the internal peripherals are mapped to the private address space. This is an 8KB region location within the memory map at an address determined by the hardware implementation of the specific device used (this can be read using the CP15 Configuration Base Address Register).

The registers in this region are fixed in little-endian byte order, so some care is needed if the CPSR E bit is set when accessing it. Some locations within the region exist as banked versions, dependent on the processor ID. The private memory region is not accessible through the Accelerator Coherency Port. Figure 24.4 shows the layout of this private memory region.

Table 23-1 Private Memory Region layout

Base Address offset	Function
0x0000	Snoop Control Unit (SCU)
0x0100	Interrupt Controller CPU Interface
0x0200	Global Timer
0x0600	Local Timer/Watchdog
0x1000	Interrupt Controller Distributor

We looked at the SCU and interrupt control functions earlier in this chapter. In addition, each core in an ARM MPCore implements a standard timer and a watchdog, both private to that core.

These can be configured to trigger after a number of processor cycles, using a 32-bit start value and an 8-bit pre-scale. They can be operated using interrupts, or by periodic polling (supported with the Timer/Watchdog Interrupt Status Registers). They stop counting while the core is in debug state. The timer can be configured in "single-shot" or "auto-reload" mode. The watchdog can be operated in classic watchdog fashion, where it asserts the core reset signal (for that specific core) on timeout. Alternatively, it can be used as a second timer.

Revision 1 or later of the Cortex-A9 processor, and all versions of the Cortex-A5 processor also include a global timer, shared between all cores, but with banked comparator and auto-increment registers for each core. It is a single, incrementing 64-bit counter, accessible only through 32-bit accesses. It can be configured to trigger an interrupt when the comparator value is reached. The auto-increment feature causes the processor comparator register to be incremented after each match. This is typically used by the OS scheduler, to trigger the scheduler on each core, at different times.

Chapter 24 **Parallelizing Software**

In previous chapters, we described how an SMP system can allow us to run multiple threads efficiently and concurrently across multiple processors. In this case, the parallelization is, in effect, handled on our behalf by the OS Scheduler.

In many cases, however, this is insufficient and the programmer must take steps to rewrite code to take advantage of speed-ups available through parallelization. An obvious example is where a single application requires more performance than can be delivered by a single processor. More commonly, we may have the situation where an application simply requires much more performance than all of the others within a system, when it is said to be *dominant*. This prevents efficient energy usage, as we cannot perform optimal load-balancing. An unbalanced load distribution does not allow efficient dynamic voltage/frequency scaling.

The operating system cannot automatically parallelize an application. It is limited to treating that application as a single scheduling unit. In such cases, the application itself has to be split into multiple smaller tasks by the programmer. Of course, this means each of these tasks must be able to be independently scheduled by the OS, as separate threads. A thread is simply a part of a program that can be run independently and concurrently with other parts of a program. If the programmer breaks down an application into smaller execution entities which may be separately scheduled, the OS can spread the application across multiple cores.

24.1 Decomposition methods

There are a number of common methods to perform this decomposition.

The best approach to decomposition of an application into smaller tasks capable of parallel execution depends on the characteristics of the original application. Large data-processing algorithms can be broken down into smaller pieces by sub-division into a number of similar threads which execute in parallel on smaller portions of a dataset. This is known as *data decomposition*.

Consider the example of color-space conversion, from RGB to YUV. We start with an array of pixel data. The output is a similar array giving chrominance and luminance data for each pixel. Each output value is calculated by performing a small number of multiplies and adds. Crucially, the output Y, U and V values for each pixel depend only upon the input R, G and B values for that pixel. There is no dependency on the data values of other pixels. Therefore, the image may be divided into smaller blocks and we can perform the calculation using any number of instances of our code. This does not require any change to our original algorithm – simply changes to the amount of data supplied to each thread. We split the image into stripes (1/N arrays, where we have N threads) and each thread works on a stripe. The level of detail of the stripes may be an important consideration (it is clearly better for cacheability if each thread works on a contiguous block of pixels in array order). The code does not have to be modified to take care of scheduling – it is the operating system which takes care of it.

A different approach is that of *task decomposition*. Here, we identify areas of code which are independent of each other and capable of being executed concurrently. This is a little more difficult, as we need now to think about the discrete operations being carried out and the interactions between them. A simple example might be the start-up sequence of a program. One task might be to check that the user has a valid license for the software. Another task might be to display a start-up banner with a copyright message. These are independent tasks with no dependency on each other and can be performed in separate threads. Again, no change is required to the source code which carries out these tasks. We simply have to supply them to the OS kernel scheduler as separate execution threads.

Of course, not all algorithms are able to be handled through data or task decomposition. Instead, we must analyze the program with the aim of identifying functional blocks. These are independent pieces of code with defined inputs and outputs that have some scope to be parallelized. Such functional blocks often depend upon input from other blocks (they have a *serial dependency*), but do not have a corresponding dependency upon time (a *temporal dependency*). This is (in some respects) analogous to the hardware pipelining employed in the processor itself.

MPEG video encoder software provides a good example of this. Input data, in the form of an analog video signal is sampled and processed through a pipeline of discrete functional blocks. First, both inter-frame and intra-frame redundancies are removed. Then, quantization takes place to reduce the number of bits required to represent the video. After this, motion vector compensation takes place, then run length compression and finally the encoded sub-stream is stored.

At the same time that data from one frame is being run-length compressed and stored, we can also start to process the next frame. Within a frame, the motion vector compensation process can be parallelized. We can use multiple parallel threads to operate on a frame (an example of data decomposition).

When decomposing an application using these techniques, we must consider the overheads associated with task creation and management. An appropriate level of granularity is required for best performance. If we make our datasets too small, too big, or simply have too many datasets, we may reduce performance. In our example of color-space conversion, it would not be sensible to have a separate thread for each pixel, even though this is logically possible.

24.2 Threading models

Once an algorithm has been analyzed to determine potential changes which can be made for parallelization, the programmer must modify code to map the algorithm to smaller, threaded execution units. There are two widely-used threading models, the *workers' pool* model and the *fork-join* model. The latter simply creates ("spawns") a new thread whenever one is needed (that is, threads are created "on-demand.") The operating system then schedules the various threads across the available cores.

Each of the newly spawned threads is typically considered to be either a *detached* thread, or a *joinable* thread. A detached thread executes in the background and simply terminates once it has completed, without any message to the parent process. (Of course, communication to or from such processes may be implemented manually by the programmer, through the available signaling mechanisms, or using global variables). A joinable thread, in contrast, will communicate back to the main thread, at a point set by the programmer. The parent process may have to wait for all joinable threads to return before proceeding with the next execution step. This is referred to as a *synchronization point*.

In the fork-join model, individual threads have explicit start and end conditions. There is an overhead associated with managing their creation and destruction and latencies associated with the synchronization point. This means that threads must be sufficiently long-lived to justify these costs.

If we know that some execution threads will be repeatedly required to consume input data, we may instead use the workers pool threading model. Here, we create a pool of worker threads at the start of the application. The pool may consist of multiple instances of the same algorithm, where the distributor (also called producer or boss) will simply dispatch the task to the first available worker (consumer) thread. Alternatively, the worker pool may contain several different data processing operators and data-items will be tagged to show which worker should consume the data.

The number of worker threads can change dynamically to handle peaks in the workload. Each worker thread performs a task until it is finished, then interrupts the boss to be assigned another task. Alternatively, the boss can periodically poll workers to see whether one is ready to receive another task. The work queue model is similar. The boss places tasks in a queue, and workers check the queue and take tasks to perform. A further variant is to have multiple bosses, sharing the pool of workers. The boss threads place tasks onto a queue, from where they are taken by the worker threads.

In each of these models, it should be understood that the amount of work to be performed by a thread may be variable and unpredictable. Even for threads which operate on a fixed quantity of data, it may be the case that data dependencies cause different execution times for similar threads. There is always likely to be some synchronization overhead associated with the need for a parent thread to wait for all spawned threads to return (in the fork-join model) or for a pool of workers to complete data consumption before execution can be resumed.

24.3 Synchronization mechanisms

When porting software from a uniprocessor environment to run on multiple cores, there may be situations where we need to modify code to enforce a particular order of execution or to control parallel access to shared peripherals or global data. The Linux kernel (like other operating systems) provides a number of different synchronization primitives for this purpose. Understanding which of these is best suited for a particular case will give software performance benefits. Serialization and multiple threads contending for a resource can cause suboptimal use of the increased processing throughput provided by the multiple cores. This overhead is not present if software is written in a way which requires no synchronization, the ideal case. In all cases, minimizing the size of the critical section provides best performance.

24.3.1 Completions

Completions are a feature provided by the Linux kernel, which may be used to serialize task execution. They provide a lightweight mechanism with limited overhead that essentially provides a flag to signal completion of an event between two tasks. The task which is waiting may sleep until it receives the signal, using wait_for_completion (struct completion *comp) and the task that is sending the signal typically uses either complete (struct completion *comp), which will wake up one waiting process, or complete_all (struct completion *comp) which wakes all processes which are waiting for the event. Kernel version 2.6.11 added support for completions which can time out and for interruptible completions.

24.3.2 Spinlocks

A spinlock provides a simple binary locking mechanism, designed for protection of critical sections. It implements a busy-wait loop. A spinlock is a generic synchronization primitive that can be accessed by any number of threads. More than one thread might be spinning for obtaining the lock. However, only one thread may obtain the lock. The waiting task executes spin_lock (spinlock_t *lock) and the signaling task uses spin_unlock(spinlock_t *lock). Spinlocks do not sleep and disable pre-emption.

24.3.3 Semaphores

Semaphores are a widely used and understood method to control access to shared resources, and may also be used to achieve serialization of execution. They provide a counting locking mechanism, which can cope with multiple threads attempting to lock. They are designed for protection of critical sections and are useful when there is no fixed latency requirement. However, where there is a significant amount of contention for a semaphore, performance will be reduced. The Linux kernel provides a straightforward API with functions down (struct semaphore *sem) and up (struct semaphore *sem); to lower and raise the semaphore.

Unlike, spinlocks, which spin in a busy wait loop, semaphores have a queue of pending tasks. When a semaphore is locked, the task yields, so that some other tasks can run. Semaphores may be binary (in which case they are also mutexes) or counting.

24.3.4 Lock-free synchronization

The use of lock-free data structures, such as circular buffers, is widespread and can avoid the overheads associated with spinlocks or semaphores. The Linux kernel also provides two synchronization mechanisms which are lock-free, the *Read-Copy-Update* (RCU) and seqlocks. Neither of these mechanisms is normally used in device drivers.

If you have multiple readers and writers to a shared resource, using a mutex may not be very efficient. A mutex would prevent concurrent read access to the shared resource because only a single thread is allowed inside the critical section. Large numbers of readers might delay a writer

from being able to update the shared resource. RCUs can help in the case where the shared resource is mainly accessed by readers. Reader threads execute with little synchronization overhead. A thread which writes the shared resource has a much higher overhead, but is executed relatively infrequently. The writer thread must make a copy of the shared resource (access to shared resources must be done though pointers). When the update is complete, it publishes the new data structure, so that it is visible to all readers. The original copy is preserved until the next context switch on all processors. This guarantees that all ongoing read operations can complete. RCUs are more complex to use than standard mutexes and are typically used only when traditional solutions are not suitable. Examples include shared file buffers or networking routing tables and garbage collection.

Seqlocks are also intended to provide quick access to shared resources, without use of a lock. They are optimized for short critical sections. Readers are able to access the shared resource with no overhead, but must explicitly check and re-try if there is a conflict with a write. Writes, of course, still require exclusive access to the shared resource. They were originally developed to handle things like system time – a global variable which may be read by many processes and is written only by a timer-based interrupt (on a frequent basis, of course!) The timer write has a high priority and a hard deadline, in order to be accurate. Using a seqlock instead of a mutex allows many readers to share access, without locking out the writer from accessing the critical section.

24.4 Threading libraries

Now we have looked at how to make our target application be capable of concurrent execution, we must now consider actual source code modifications. This is normally done using a threading library, in conjunction with multi-threading support in the OS. When modifying existing code, we must take care to ensure that all shared resources are protected by proper synchronization. This includes any libraries used by the code, as these may not be reentrant. In some cases, there may actually be separate reentrant libraries for use in multi-threaded applications. A library which is designed to be used in multi-threaded applications is called *thread-safe*. If a library is not known to be thread-safe, then only one thread should be allowed to make calls to the library functions.

The most commonly used standard in this area is POSIX threads (PThreads), a subset of the wider POSIX standard. POSIX (IEEE Std .1003) is the Portable Operating System Interface, a collection of OS interface standards. Its goal is to assure interoperability and portability of code between systems. PThreads defines around 60 API calls for creating and managing threads. Pthreads libraries are available for Linux, Solaris, and Windows.

There are several other multi-threading frameworks, such as OpenMP, which may simplify multi-threaded development by providing high-level primitives, or even automatic multi-threading. OpenMP is a multi-platform, multi-language API that supports shared memory multi-processing through a set of libraries and compiler directives plus environment variables which affect run-time behavior.

PThreads provides a set of C primitives which allow us to create, terminate and cancel threads and to control thread synchronization and scheduling attributes. Let us examine, in general terms, how we can use PThreads to build multi-threaded software to run on our SMP system. We'll deal with the following types:

- *pthread t* thread identifier
- *pthread_mutex_t* mutex
- *sem t* semaphore

We need to modify our code to include the appropriate header files.

```
#include <pthread.h>
#include <semaphore.h>
```

We must link our code using the pthread library with the GCC switch -lpthread.

To create a thread, we must call pthread_create(), a library function which requires four arguments. The first of these is a pointer to a pthread_t, which is where we will store the thread identifier. The second argument is the attribute, which will normally be NULL, but can instead point to a structure which modifies the thread's attributes. The third argument is the function the new thread will start by executing. The thread will be terminated should this function return (and will return zero if the thread succeeded). The fourth argument is supplied to the thread in a format similar to the familiar command line argc/argv usage.

A thread may complete either by simply returning, or calling pthread_exit(). Both will terminate the thread. A thread can be "detached", using pthread_detach(). This frees up all of the resources the thread acquired, when it completes. An outside application can kill a thread using pthread_cancel() which takes the thread identifier as its argument. A thread can toggle whether or not it is allowed to be cancelled in this way using pthread_setcancelstate().

The library function pthread_join() allows us to make a thread stall and wait for completion of another thread. Take care, as so-called "zombie" threads can be created by joining a thread which has already completed. It is not possible to join a detached thread (one which has called pthread_detach()).

Mutexes are created with the pthread_mutex_init() function. The functions pthread_mutex_lock() and pthread_mutex_unlock() are used to lock or unlock a mutex. pthread_mutex_lock() simply blocks the thread until the mutex can be locked. pthread_mutex_trylock() checks whether the mutex can be claimed and returns an error if it cannot, rather than just blocking. A mutex can be deleted when no longer required with the pthread_mutex_destroy() function.

Semaphores are created in a similar way, using sem_init() — one key difference being that we must specify the initial value of the semaphore. sem_post() and sem_wait() are used to up and down the semaphore and sem_destroy() to delete it when it is no longer needed.

The GNU tools for ARM support full thread-local storage and the Native POSIX Thread library (NPTL), which enables efficient use of POSIX threads with the Linux kernel and is now a full part of the GNU C library. There is a one-to-one correspondence between threads created with pthread_create() and kernel tasks. This avoids the need for the user mode scheduler and the Linux kernel scheduler to pass information to avoid performance problems.

Example 24-1 provides a simple example of using the PThreads library.

Example 24-1 PThreads example code

```
void *thread(void *vargp);
int main(void)
{
   pthread_t tid;
   pthread_create(&tid, NULL, thread, NULL);
   /* Parallel execution area */
   pthread_join(tid, NULL);
   return 0;
}
/* thread routine */
void *thread(void *vargp)
{
   /* Parallel execution area */
   printf("Hello World from a POSIX thread!\n");
   return NULL;
}
```

24.4.1 Inter-thread communications

Semaphores can be used to signal to another thread. A simple example would be where one thread produces a buffer containing shared data. It could use a semaphore to indicate to another thread that the data may now be processed (that is, consumed).

For more complex signaling, a message passing protocol may be needed. Threads within a process use the same memory space, so an easy way to implement message passing is by posting in a previously agreed-upon mailbox and then incrementing a semaphore.

24.4.2 Threaded performance

There are a few general points to consider when writing a multi-threaded application:

• Each thread has its own stack space and care may be needed with the size of this if large numbers of threads are in use.

- Multiple threads contending for the same mutex or semaphore creates contention and wasted processor cycles. There is a large body of research on programming techniques to reduce this performance loss.
- There is an overhead associated with thread creation. Some applications avoid this by creating a thread pool at startup. These threads are used on demand and then returned to the thread pool for later re-use, rather than being closed completely.

24.4.3 Thread affinity

Thread affinity refers to the practice of assigning a thread to a particular core or cores. When the scheduler wants to run a particular thread, it will use only the selected core(s) even if others are idle (this can be quite a problem if too many threads have an affinity set to a specific processor). By default, threads are able to run on any core in an SMP system.

Chapter 25

Issues with Parallelizing Software

In this chapter, we will consider some of the problems and potential difficulties associated with making software concurrent.

Amdahl's Law defines the theoretical maximum speedup achievable by parallelizing an application. The maximum speedup is given by the formula:

Max speedup = 1/((1-P) + (P/N))

Where:

P = Parallelizable proportion of program.

N = Number of processors.

This is, of course, an abstract, academic view. In practice, this simply provides a theoretical maximum speedup, as there are a number of overheads associated with concurrency. Synchronization overheads occur when a thread must wait for another task or tasks before it can continue execution. If a single task is slow, the whole program must wait. In addition, we will have critical sections of code, where only a single task is able to run at a time. We may also have occasions when all tasks are contending for the same resource or where no other tasks can be scheduled to run by the OS.

25.1 Thread safety and reentrancy

Functions which can be used concurrently by more than one thread concurrently must be both thread-safe and reentrant. This is particularly important for device drivers and for library functions.

For a function to be reentrant, it must fulfill the following conditions:

- All data must be supplied by the caller.
- The function must not hold static or global data over successive calls.
- The function cannot return a pointer to static data.
- The function cannot itself call functions which are not reentrant.

For a function to be thread-safe, it must protect shared data with locks. (This means that the implementation needs to be changed by adding synchronization blocks to protect concurrent accesses to shared resources, from different threads.) Reentrancy is a stronger property, this means that not every thread-safe function is reentrant.

There are number of common library functions which are not reentrant. For example, the function ctime() returns a pointer to static data which is over-written on each call.

25.2 Performance issues

There are several MP-specific issues relating to performance of threads

- Bandwidth. The connection to external memory is shared between all processors within the MPCore. The individual cores run at speeds far higher than the external memory and so are potentially limited (in I/O intensive code) by the available bandwidth. This obviously is more likely in an MPCore. This is somewhat mitigated by support for outstanding reads and writes in MPCore implementations.
- Thread dependencies and priority inversion. The execution of a higher priority thread can be stalled by a lower priority thread holding a lock to some shared data.
- Cache contention. If multiple threads are running which share cache lines, there may be some cache line migration overheads. Concurrent access of the same shared data by multiple cache coherent cores would lead to frequent migration of the cache lines, containing that data, between the cores.

25.2.1 Bandwidth concerns

Bandwidth issues can be optimized in a number of ways. Clearly, the code itself must be optimized using the techniques described earlier, to minimize cache misses and therefore reduce the bandwidth utilization.

Another option is to pay attention to thread allocation. The kernel scheduler does not pay any attention to data usage by threads; instead it makes use of priority to decide which threads to run. The programmer may be able to provide hints which allow more efficient scheduling through the use of thread affinity.

25.2.2 Thread dependencies

In real systems we may have threads with higher or lower priority which both access a shared resource. This gives scope for some potential difficulties. The term *starvation* is used to describe the situation where a thread is unable to get access to a resource after repeated attempts to claim it

Priority inversion is said to occur when a lower priority task has a lock on a resource that a higher priority requires in order to be able to execute. In other words, a lower priority task prevents the higher priority task from executing. Priority inheritance resolves this by temporarily raising the priority of the task which has the lock to the highest level. This causes that task to execute as quickly as possible and relinquish the shared resource as soon as it can.

Operating systems (particularly real time operating systems) have ways to avoid such problems automatically. One method is not to allow lower-priority threads from directly accessing resources needed by higher-priority threads, they may need to use a higher-priority proxy thread to perform the operation. A similar approach is to temporarily increase the priority of the low-priority thread while it is holding the critical resource, ensuring that the scheduler will not pre-empt execution of that thread while in the critical selection.

A program that relies on threads executing in a particular sequence to work correctly may have a *race condition*. Single-core real-time systems often implicitly rely on tasks being executed in a priority based order. Tasks will then execute to completion, without pre-emption. Later tasks may rely on earlier tasks having completed. This can cause problems if such software is moved to a multi-core system without careful checking for such assumptions. A lower-priority task may run at the same time as a higher-priority task and the expected execution order of the original single-core system is no longer guaranteed. There are number of ways to resolve this. A simple approach is to set task affinity to make those tasks run on the same processor. This requires little change to the legacy code, but does break the symmetry of the system and remove

scope for load balancing. A better approach is to enforce serial execution through the use of the kernel synchronization mechanisms, which gives the programmer explicit control over the execution flow and better SMP performance, but does require the legacy code to be modified.

25.2.3 Cache trashing

In an SMP system, it is possible for tasks to migrate between the different processors in the system. The scheduler starts a task on a processor and it runs for a certain period and is then replaced by a different task. When that task is restarted at a later time by the scheduler and this could be on a different processor. This means that the task does not get the potential benefit of cache data already being present in the processor cache. Memory intensive tasks which quickly fill data cache might trash each others cached data. This has an impact on both performance (slower execution due to higher number of cache misses) and system energy usage (due to additional interaction with external memory). The ARM MPCore Hardware optimizations for direct data intervention and cache line migration do mitigate the effects of this. In addition, the OS scheduler may try to reduce the problem by aiming to keep tasks on the same processor. As we have seen, the programmer may also do this by setting processor affinity to threads and processes.

25.2.4 False sharing

This is a problem of systems with shared coherent caches and is effectively a form of involuntary memory contention. It can happen when a processor (or other block) regularly accesses data that is never changed by another processor and this data shares a cache line with data that will be altered by another processor. The MESI protocol may end up migrating data that is not truly shared between different parts of the memory system, costing clock cycles and power. Even though there is no actual coherency to be maintained, the MESI protocol requires each processor to invalidate the cache line in the other, forcing the cache line to be re-loaded on each write. However, the cache-to-cache migration capability of ARM MPCore processors limits the overhead. Therefore, programmers should avoid having processors operating on independent data that is stored within the same cache line and increasing the level of detail for inner loop parallelization.

25.2.5 Deadlock and livelock

When writing code that includes critical sections, it is important to be aware of common problems that can break correct execution of the program.

- Deadlock is the situation where two (or more) threads are each waiting for another thread to release a resource. Such threads are effectively blocked, waiting for a lock that can never be released.
- A *livelock* occurs when multiple threads are able to execute, without blocking indefinitely (the deadlock case), but the system as a whole is unable to proceed, due to a repeated pattern of resource contention.

Both deadlocks and livelocks can be avoided either by correct software design, or by use of lock-free software techniques.

25.3 Profiling in SMP systems

ARM MPCores contain additional performance counter functions, which allow counting of the following SMP cache events.

- Coherent linefill missed in all processors.
- Coherent linefill hit in other processor caches.

25.4 SMP Barriers

In Chapter 9, we looked at memory barrier instructions. That discussion included a number of comments about the implications of barriers in multi-core systems. In this section, we will look again at barriers, now that we have taken a much more detailed look at SMP operation.

Barriers are needed to enforce ordering of memory operations. Most programmers will not need to understand, or explicitly use memory barriers. This is because they are already included within kernel locking and scheduling primitives. Nevertheless, writers of device drivers or those seeking an understanding of kernel operation may find a detailed description useful.

Both the compiler and processor micro-architecture optimizations permit the order of instructions and associated memory operations to be changed. Sometimes, however, we wish to enforce a specified order of execution of memory operations. For example, we may write to a memory mapped peripheral register. This write may have side-effects elsewhere in the system. Memory operations which are in before or after this operation in our program may appear as if they can be re-ordered, as they operate on different locations. In some cases, however, we wish to ensure that all operations complete before this peripheral write completes. Or, we may want to make sure that the peripheral write completes before any further memory operations are started. Linux provides some functions to do this, as follows:

- We instruct the compiler that re-ordering is not permitted for a particular memory operation. This is done with the barrier() function call. This controls only the compiler code generation and optimization and has no effect on hardware re-ordering.
- We call a memory barrier function which maps to ARM processor instructions that
 perform the memory barrier operations described in Chapter 9. These enforce a particular
 hardware ordering. The available barriers are as follows (in a Linux kernel compiled with
 Cortex-A SMP support):
 - The read memory barrier rmb() function ensures that any read that appears before the barrier is completed before the execution of any read that appears after the barrier.
 - The write memory barrier wmb() function ensures that any write that appears before the barrier is completed before the execution of any write that appears after the barrier.
 - The memory barrier mb() function ensures that any memory access that appears before the barrier is completed before the execution of any memory access that appears after the barrier.
- There are corresponding SMP versions of these barriers, called smp_mb(), smp_rmb() and smp_wmb(). These are used to enforce ordering on Normal cacheable memory, between cores inside the same multi-core SMP processor. For example, each A9 core inside a multi-core Cortex-A9MPCore. They can be used with devices and they work even for normal non-cacheable memory.

For these memory barriers, it is almost always the case that a pair of barriers is required. Please refer to Chapter 9 for details on barrier usage (or see kernel/Documentation/memory-barriers.txt).

The programmer must not assume that smp_mb() is a superset of mb(). In a Linux kernel built without the CONFIG_SMP option, to run on a uniprocessor system, all of the smp_* memory barriers are treated simply as compiler barriers.

Chapter 26 **Security**

The term "security" is used in the context of computer systems to cover a wide variety of features. For the purposes of this chapter, we will use a narrower definition. A secure system means one which protects assets (resources which need protecting, for example passwords, or credit card details) and may prevent them from being copied or damaged or made unavailable (denial of service). Confidentiality is a key security concern for assets such as passwords and cryptographic keys. Defense against modification and proof of authenticity is vital for security software and on-chip secrets used for security. Examples of secure systems might include entry of Personal Identification Numbers (PIN) for such things as mobile payments, digital rights management, and e-Ticketing.

Security is harder to achieve in today's world of open systems where a wide range of software can be downloaded onto a platform. This gives the potential for malevolent or untrusted code to tamper with the system.

ARM processors include specific hardware extensions to allow construction of secure systems. Creating secure systems is outside the scope of this book. In the remainder of this chapter, we present the basic concepts behind ARM's security extensions (TrustZone). If your system is one which makes use of these extensions, you should be aware that this imposes some restrictions on the operating system and on unprivileged code (in other words, code which is not part of the secure system). TrustZone is of little or no use without memory system support.

It should, of course, be emphasized, that no security is absolute!

26.1 TrustZone hardware architecture

The TrustZone hardware architecture aims to provide resources that enable a system designer to build secure systems. It does this through a range of components and infrastructure additions. Low-level programmers need to have some awareness of the restrictions placed on the system by the TrustZone architecture, even if they are not intending to make use of the security features.

In essence, system security is achieved by dividing all of the device's hardware and software resources, so that they exist in either the Secure world for the security subsystem, or the Normal world for everything else. System hardware ensures that no Secure world resources can be accessed from the Normal world. A secure design places all sensitive resources in the Secure world, and has robust software running which can protect assets against a wide range of possible attacks.

Note that the use of the term "Non-Secure" is used in the ARM *Architecture Reference Manual* as a contrast to "Secure" state, but this does not imply that there is a security vulnerability associated with this state. We will refer to this simply as "Normal" operation here. The use of the word "world" is to emphasize the orthogonality between the secure world and other states the device is capable of.

The additions to the processor core enable a single physical processor core to act as two virtual processors, executing code from both the Normal world and the Secure world in a time-sliced fashion. The memory system is similarly divided. An additional bit, indicating whether the access is Secure or Non-Secure (the NS bit) is added to all memory system transactions, including cache tags and access to system memory and peripherals. This can be considered like an additional address bit, giving a 32-bit physical address space for the Secure world and a completely separate 32-bit physical address space for the Normal world.




Figure 26-1 Switching between normal and secure worlds

As the two virtual processors execute in a time-sliced fashion, context switching between them is done using an additional core mode (like the existing modes for IRQ, FIQ etc.). called Monitor mode. A limited set of mechanisms by which the physical processor can enter Monitor mode from the Normal world is provided. Entry to monitor can be through a dedicated instruction, the Secure Monitor Call (SMC) instruction, or by hardware exception mechanisms. IRQ, FIQ and external aborts may all be configured to cause the processor to switch into Monitor mode. In each case, this will appear as an exception to be dealt with by the Monitor mode exception handler. Figure 26-1 on page 26-2 provides a conceptual summary of this switching.

Figure 26-2 shows how, in many systems, FIQ is reserved for use by the secure world (it becomes, in effect, a non-maskable secure interrupt). An IRQ which occurs when in the Normal world is handled in the normal way, described in the chapters on exception handling. An FIQ which occurs while executing in the Normal world is vectored directly to Monitor mode. Monitor mode handles the transition to Secure world and transfers directly to the Secure world FIQ handler. If the FIQ occurs when in the Secure world, it is handled through the Secure vector table and routed directly to the Secure world handler. IRQs are typically disabled during execution in the Secure world.




Figure 26-2 Banked out registers

The software handler for Monitor mode is implementation specific, but will typically save the state of the current world and restore the state of the world being switched to, much like a normal context switch.

The NS-bit in the Secure Configuration Register (SCR) in CP15 indicates which world the processor is currently in. In Monitor mode, the processor is always executing in the Secure world, regardless of the value of the SCR NS-bit, which is used to signal which world you were previously in. The NS-bit also allows code running in Monitor mode to snoop security banked registers, to see what is in either world.

TrustZone hardware also effectively provides two virtual MMUs, one for each virtual processor. This allows each world to have a local set of translation tables, with the Secure world mappings hidden and protected from the Normal world. The page table descriptions include a NS bit, which is used to determine whether accesses are made to the secure or non-secure physical address space. Although the page table entry bit is still present, the Normal virtual processor hardware does not use this field, and memory accesses are always made with NS=1. The Secure virtual processor can therefore access either Secure or Normal memory. Cache and TLB hardware permits Normal and Secure entries to co-exist.

It is good practice for code which modifies page table entries and which does not care about TrustZone based security, to always set the page table NS-bit to zero. This means that it will be equally applicable when the code is executing in the Secure or Normal worlds.

The ability to direct aborts, IRQ and FIQ directly to the monitor, allows trusted software to route the interrupt request accordingly, which permits a design to provide secure interrupt sources immune from manipulation by the Normal world software. Similarly, the Monitor mode routing means that from the point of view of Normal world code, an interrupt that occurs during Secure world execution appears to occur in the last Normal world instruction that occurred before the Secure world was entered.

A typical implementation is to use FIQ for the Secure world and IRQ for the Normal world. Exceptions are configured to be taken by the current world (whether secure or non-secure), or to cause an entry to the monitor. The monitor has its own vector table. As a result of this, the processor has three sets of exception vector tables. It has a table for the Non-secure world, one for the Secure world, and one for monitor mode.

The hardware must also provide the illusion of two separate cores within CP15. Sensitive configuration CP15 registers can only be written by Secure world software. Other settings are normally banked in the hardware, or by the monitor mode software, so that each world sees its own version.

Implementations which use TrustZone will typically have a light-weight kernel (Trusted Execution Environment) which hosts services (for example, encryption) in the Secure world. A full OS runs in the Normal world and is able to access the secure services via SMC. In this way, the Normal world gets access to functions of the service, without any ability to see keys or other protected data.

26.1.1 Multiprocessor systems with security extensions

Each processor in a multi-core system has the programmers' model features described earlier. Any number of the processors in the cluster may be in the Secure world at any point in time, and processors are able to transition between the worlds independently of each other. The Snoop Control Unit is aware of security settings. Additional registers are provided to control whether Non-secure world code can modify SCU settings. Similarly, the generic interrupt controller which distributes prioritized interrupts across the Multi-processor cluster must also be modified to be aware of security concerns.

Theoretically, the Secure world OS on an SMP system could be as complicated as the Normal world OS. However, this is highly undesirable when aiming for security. In general, it is expected that a Secure world OS will actually only execute on one core of an SMP system (with security requests from the other cores being routed to this chosen core). This does provide some bottleneck issues. To some extent these will be balanced by the Normal world OS performing

load balancing against the core that it will see as "busy" for unknown reasons. Beyond that this limitation has to be seen as one of the compromises that may be reached to hit a particular target level of security.

26.1.2 Interaction of Normal and Secure worlds

If you are writing code in a system which contains some secure services, it may be useful to understand how these are used. As we have seen, a typical system will have a light-weight kernel, *Trusted Execution Environment* (TEE) hosting services (for example, encryption) in the Secure world. This interacts with a full OS in the Normal world, which can access the secure services using the SMC call. In this way, the Normal world is able to have access to functions of the service, without getting to see keys (for example).

Generally applications developers won't directly interact with TrustZone (or TEEs or Trusted Services). Instead, one makes use of a high level API (for example, it might be called reqPayment()) provided by a Normal world library. The library would be provided by the same vendor as the Trusted Service (for example, a credit card company), and would handle the low level interactions. Figure 26-3 shows this interaction and illustrates the flow from user application calling the API, which makes an appropriate OS call, which then passes to the TrustZone driver code, which passes execution into the TEE, through the secure monitor.




Figure 26-3 Interaction with TrustZone

It is common to share data between the Secure and Normal worlds. For example, in the Secure world you might have a signature checker. The Normal world can request that the Secure world verifies the signature of a downloaded update, using the SMC call. The Secure world needs access to the memory used by the Normal world to store the package. The Secure world can use the NS-bit in its page table descriptors to ensure that it used non-secure accesses to read the data. This is important because data relating to the package may already be in the caches, due to the accesses done by the Normal world. These accesses with addresses marked as non-secure. As mentioned previously the security attribute can be thought of as an additional address bit. If the core used secure access to try to read the package, it would not hit on data already in the cache.

If you are a Normal world programmer, in general, you can ignore something happening in the Secure world, as its operation is hidden from you. One side-effect is that interrupt latency may increase slightly, if an interrupt goes off in the Secure world, but this increase is small compared to the overall latency on a typical OS.

If you do need to access a secure application, you will need a driver like function to "talk" to the Secure world OS and Secure applications, but the details of creating that Secure world OS and applications are out of scope for this book. Programmers writing code for the Normal world only need to know the particular protocol for the secure application being called.

Finally, the TrustZone System also controls availability of debug provision. Separate hardware over full JTAG debug and trace control is separately configurable for Non-secure and Secure software worlds, so that no information about the Secure system leaks.

Chapter 27 **Debug**

Debugging is a key part of software development and is often considered to be the most time consuming (and therefore expensive) part of the process. Bugs can be difficult to detect, reproduce and fix and it can be difficult to predict how long it will take to resolve a defect. The cost of resolving problems grows significantly once the product is delivered to a customer. In many cases, when a product has a small time window for sales, if the product is late, it may miss the market opportunity. Therefore, the debug facilities provided by a system are a vital consideration for any developer.

Many embedded systems using ARM processors have limited input/output facilities. This means that traditional desktop debug methods (such as use of printf()) may not be appropriate. In such systems in the past, developers may have used expensive hardware tools like logic analyzers or oscilloscopes to observe the behavior of programs. The processors described in this book have caches and are part of a complex system-on-chip containing memory and many other blocks. There may be no processor signals which are visible off-chip and therefore no ability to monitor behavior by connecting up a logic analyzer (or similar). For this reason, ARM systems typically include dedicated hardware to provide wide-ranging control and observation facilities for debug.

27.1 ARM debug hardware

The Cortex-A series processors provide hardware features which allow debug tools to provide significant levels of control over processor activity and to non-invasively collect large amounts of data about program execution. We can sub-divide the hardware features into two broad classes, *invasive* and *non-invasive*.

Invasive debug provides facilities which allow us to stop programs and step through them line by line (either at the C source level, or stepping through assembly language instructions). This can be by means of an external device which connects to the processor using the chip JTAG pins, or (less commonly) by means of debug monitor code in system ROM. JTAG stands for Joint Test Action Group and refers to the IEEE-1149.1 specification, which was originally designed to standardize testing of electronic devices on boards, but is now widely re-used for processor debug connection. A JTAG connection typically has five pins – two inputs, plus a clock, a reset and an output.

The debugger gives the ability to control execution of the program, allowing us to run code to a certain point, halt the processor, step through code and resume execution. We can set breakpoints on specific instructions (causing the debugger to take control when the core reaches that instruction). These work using one of two different methods. Software breakpoints work by replacing the instruction with the opcode of the ARM BKPT instruction. Obviously, these can only be used on code which is stored in RAM, but have the advantage that they may be used in large numbers. The debug software must keep track of where it has placed software breakpoints and what opcodes were originally located at those addresses, so that it can put the correct code back when we wish to execute the breakpointed instruction. Hardware breakpoints use comparators built into the core and stop execution when execution reaches the specified address. These can be used anywhere in memory, as they do not require changes to code, but the hardware provides limited numbers of hardware breakpoint units (typically four in the Cortex-A family). Debug tools may support more complex breakpoints (for example stopping on any instruction in a range of addresses, or only when a specific sequence of events occurs or hardware is in a specific state). Data watchpoints give debugger control when a particular data address or address range is read or written. These may also be called data breakpoints.

Upon hitting a breakpoint, or when single-stepping, we can inspect and change the contents of ARM registers and of memory. A special case of changing memory is code download. Debug tools typically allow the user to change our code, recompile and then download the new image to the system.

27.2 ARM trace hardware

Non-invasive debug (often called "trace" in ARM documentation) allows observation of the processor behavior while it is executing. It is possible to record memory accesses performed (including address and data values) and generate a real-time trace of the program, seeing peripheral accesses, stack and heap accesses and changes to variables. For many real-time systems, it is not possible to use invasive debug methods. Consider, for example, an engine management system – while we may be able to stop the processor at a particular point, the engine will keep moving and we will not be able to do useful debug. Even in systems with less onerous real-time requirements, trace can be very useful.

Trace is typically provided by an external hardware block connected to the processor. This is known as an *Embedded Trace Macrocell* (ETM) or *Program Trace Macrocell* (PTM) and is an optional part of an ARM based system. System-on-chip designers may omit this block from their silicon to reduce costs. These blocks observe (but do not affect) the processor behavior and are able to monitor instruction execution and data accesses.

There are two main problems with capturing trace. The first is that with today's very high processor clock speeds, even a few seconds of operation can mean trillions of cycles of execution. Clearly, to look at this volume of information would be extremely difficult. The second, related problem is that today's processors could potentially perform one or more 64-bit cache accesses per cycle and to record both the data address and data values may require large bandwidth. This presents a problem in that typically, only a few pins may be provided on the chip and these outputs may be able to be switched at significantly lower rates than the processor can be clocked at. If the processor generates 100 bits of information every cycle at a speed of 1GHz, but the chip can only output four bits of trace at a speed of 200MHz, we clearly have a problem. To solve this latter problem, the trace macrocell will try to compress information to reduce the bandwidth needed. However, the main method to deal with these issues is to control the trace block so that only selected trace information is gathered. For example, we may trace only execution, without recording data values, or we may trace only data accesses to a particular peripheral or during execution of a particular function.

In addition, it is common to store trace information in an on-chip memory buffer (the *Embedded Trace Buffer*, (ETB)). This alleviates the problem of getting information off-chip at speed, but has an additional cost in terms of silicon area (and therefore price of the chip) and also provides a fixed limit on the amount of trace that can be captured.

The ETB stores the compressed trace information in a circular fashion, continuously capturing trace information until stopped. The size of the ETB varies between chip implementations, but a buffer of 8 or 16kB is typically enough to hold a few thousand lines of program trace.

When a program fails, if the trace buffer is enabled, you can see a portion of program history. With this program history, it is easier to walk back through your program to see what happened just before the point of failure. This is particularly useful for investigating intermittent and real-time failures, which can be difficult to identify through traditional debug methods that require stopping and starting the processor. The use of hardware tracing can significantly reduce the amount of time needed to find these failures, as the trace shows exactly what was executed, what the timing was and what data accesses occurred.

27.2.1 Coresight™

ARM's Coresight technology expands on the capabilities provided by the ETM. Again its presence and capabilities in a particular system are defined by the system designer. Coresight provides a number of extremely powerful debug facilities. It allows debug of multi-processor systems (both asymmetric and SMP) which can share debug access and trace pins, with full

control of which cores are being traced at which times. The embedded cross trigger mechanism allows tools to control multiple cores in a synchronized fashion, so that, for example when one core hits a breakpoint, all of the other cores will also be stopped.

Commercial debug tools can use trace data to provide features such as real-time views of processor registers, memory and peripherals, allowing the user to step forward and backward through the program execution. Profiling tools can use the data to show where the program is spending its time and what performance bottlenecks exist. Code coverage tools can use trace data to provide call graph exploration. Operating system aware debuggers can make use of trace (and in some cases additional code instrumentation) to provide high level system context information. Here, we list some of the available Coresight components and give a brief description of their purpose:

- Debug Access Port (DAP). The debug access port (DAP) is an optional part of an ARM Coresight system. Not every device will contain a DAP. It allows an external debugger to directly access the memory space of the system without having to put the core into debug state. To read or write memory without a DAP may need the debugger to stop the ARM and have the ARM execute load or store instructions. The DAP gives an external debug tool access to all of the JTAG scan chains in a system (and therefore to all debug and trace configuration registers of the available processors).
- Embedded Cross Trigger (ECT). The Embedded Cross Trigger block is a Coresight component which may optionally be included within in a Coresight system. Its purpose is to link together the debug capabilities of multiple devices in the system. For example, we may have two cores which run independently of each other. When we set a breakpoint on a program running on one core, it would be useful to be able to specify that when that core stops at the breakpoint, the other one should also be stopped (regardless of which instruction it is currently executing). The Cross Trigger Matrix and Interface within the ECT allow debug status and control information to be propagated between cores and trace macrocells.
- AHB Trace Macrocell. The AMBA AHB Trace Macrocell allows the debugger to have
 visibility of what is happening on the system memory bus. This information is not directly
 obtainable from the processor ETM, as the integer core is unable to determine whether
 data comes from a cache or external memory.
- *CoreSight Serial Wire*. CoreSight Serial Wire Debug gives a 2-pin connection using a Debug Access Port (DAP) which is equivalent in function to a 5-pin JTAG interface.
- System Trace Macrocell. This provides a way for multiple processors (and processes) to perform printf() style debugging. Software running on any master in the system is able to access STM channels, without needing to be aware of usage by others, using very simple fragments of code. This allows timestamped software instrumentation of both kernel and user space code. The timestamp information gives a delta with respect to previous events and can be extremely useful.
- Trace Memory Controller. As already discussed, adding additional pins to a packaged IC can significantly increase its cost. In situations where we have multiple cores (or other blocks capable of generating trace information) on a single device, it is likely that economics preclude the possibility of providing multiple trace ports. The CoreSight Trace Memory Controller may be used to combine multiple trace sources into a single bus. Controls are provided to allow prioritize and select between these multiple input sources. The trace information may exported off-chip using a dedciated trace port, through the JTAG or serial wire interface or by re-using I/O ports of the SoC. Trace information can be stored in an ETB or in system memory.

Programmers should consult documentation specific to the device they are using to determine what trace capabilities are present and which tools are available to make use of them.

27.3 Debug monitor

We have seen how the ARM architecture provides a wide range of features accessible to an external debugger. Many of these facilities may also be used by code running on the processor — a so called debug monitor, which is resident on the target system. Monitor systems can be inexpensive, as they may not need any additional hardware. However, they take up memory space in the system and can only be used if the target system itself is actually running. They are of little value on a system which does not at least boot correctly. The breakpoint and watchpoint hardware facilities of the core are available to a debug monitor. When Monitor mode debug is selected, breakpoint units may be programmed by code running on the ARM processor. If a BKPT instruction is executed, or a hardware breakpoint unit matches, the system behaves differently in Monitor mode. Instead of stopping the processor under control of an external hardware debugger, the processor instead takes an abort exception and this can recognize that the abort was generated by a debug event and call the monitor code.

27.4 Linux debug

Linux is a multi-tasking operating system in which each process has its own process address space, complete with private page table mappings. This can make debug of some kinds of problems quite tricky.

We can broadly define two different debug approaches used in Linux systems. For debug of kernel code, the traditional JTAG debugger is likely to be used, as this allows us to debug things like boot code or device drivers.

The ARM DS-5 is a professional software development solution for Linux-based and bare-metal embedded systems, covering all the stages in development, from boot code and kernel porting to application debug.

Linux programmers may already be familiar with GDB. Individual user mode applications are typically debugged using a GDB debug server running on the target, communicating with a host computer, usually through Etherrnet, or through JTAG. The kernel continues to operate normally while the debug session takes place. This method of debug does not provide access to the built-in hardware debug facilities. The target system is permanently in a running state. The server receives a connection request from the host debugger and then receives commands and provides data back to the host.

The host debugger sends a load request to the GDB server, which responds by starting a new process to run the application being debugged. Before execution begins, it uses the system call ptrace() to control the application process. All signals from this process are forwarded to the GDB server. Any signals sent to the application will go instead to the GDB server, which can deal with the signal and/or forward it to the application being debugged. To set a breakpoint, the GDB server inserts code which generates the **SIGTRAP** signal at the desired location in the code. When this is executed, the GDB server is called and can then perform classic debugger tasks such as examining call stack information, variables or register contents.

For kernel debug, a conventional external debugger may be used. The system is halted when a breakpoint is executed. This is the easiest way to examine problems such as device driver loading or incorrect operation or the kernel boot failure. Another common method is through printk() function calls. The strace tool shows information about user system calls. Kgdb is a source-level debugger for the Linux kernel, which works with gdb on a separate machine and allows inspection of stack traces and view of kernel state (such as PC value, timer contents, and memory. The device /dev/kmem allows run-time access to the kernel memory.

Of course, a Linux-aware JTAG debugger can be used to debug threads. It is usually possible only to halt all processes; one cannot halt an individual thread or process and leave others running. A breakpoint may be set either for all threads, or it may be set only on a specific thread. As the memory map depends on which process is active, software breakpoints can usually only be set when a particular process is mapped in.

Appendix A **Instruction Summary**

A summary of the instructions available in ARM/Thumb Assembly Language is given in this Appendix.

For most instructions, further explanation may be found in Chapter 6. The optional condition code field (denoted by cond below) is described in Section 6.1.2 *Conditional execution* on page 6-3. The format of the flexible operand2 used by data processing operations is described in Section 6.2.1 *Operand 2 and the barrel shifter* on page 6-7, while the various addressing mode options for loads and stores is given in *Addressing modes* on page 6-9.

This appendix is intended for quick reference. If more detail about the precise operation of an instruction is required, please refer to the ARM *Architecture Reference Manual*, or to the official ARM documentation (for example the Assembler Reference Guide) which may be found at, http://infocenter.arm.com/.

A.1 Instruction Summary

Instructions are listed in alphabetic order, with a description of the syntax, operands and behavior of the instruction. Not all usage restrictions are documented here, nor do we show the associated binary encoding or any detail of changes associated with older architecture versions.

A.1.1 ADC

ADC (Add with Carry) adds together the values in Rn and Operand2, with the carry flag.

Syntax

```
ADC{cond}{S} {Rd}, Rn, <0perand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.2 ADD

ADD adds together the values in Rn and Operand2 (or Rn and imm12).

Syntax

```
ADD{cond}{S} {Rd}, Rn, <0perand2>
ADD{cond}{Rd}, Rn, #imm12 (Only available in Thumb-2)
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

imm12 is in the range 0-4095.

A.1.3 ADR

ADR (Address) is an instruction which loads a program or register-relative address (short range). It generates an instruction which adds or subtracts a value to the PC (in the PC-relative case) or some other register for a label defined in a storage map.

ADR{cond} Rd, label

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

label is a PC or register-relative expression.

A.1.4 ADRL

ADRL (Address) is a pseudo- instruction which loads a program or register-relative address (short range). It always generates two instructions.

Syntax

ADRL{cond} Rd, label

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

label is a PC-relative expression. The offset between label and the current location has some restrictions.

The ADRL pseudo-instruction can generate a wider range of addresses than ADR.

A.1.5 AND

AND does a bitwise AND on the values in Rn and Operand2.

Syntax

AND{S}{cond} {Rd}, Rn, <Operand2>

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.6 ASR

ASR (Arithmetic Shift Right) shifts the value in Rm right, by the number of bit positions specified and copies the sign bit into vacated bit positions on the left. Allowed shift values are in the range 1-32. It may be considered to as giving the signed value of a register divided by a power of two.

```
ASR{S}{cond} Rd, Rm, Rs
ASR{S}{cond} Rd, Rm, #sh
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm is the register holding the operand to be shifted.

Rs is the register which holds a shift value to apply to the value in Rm. Only the least significant byte of the register is used.

sh is a shift amount, in the range 1-32.

A.1.7 B

B (Branch) transfers program execution to the address specified by label.

Syntax

```
B{cond} {.W} label
```

where:

cond is an optional condition code. See Section 6.1.2.

label is a pc-relative expression.

.W is an optional instruction width specifier to force the use of a 32-bit B instruction in Thumb-2.

A.1.8 BFC

BFC (Bit Field Clear) clears bits in a register. A number of bits specified by width are cleared in Rd, starting at 1sb. Other bits in Rd are unchanged.

Syntax

```
BFC{cond} Rd, #1sb, #width
```

where:

cond is an optional condition code. See Section 6.1.2

Rd is the destination register.

1sb specifies the least significant bit to be cleared.

width is the number of bits to be cleared.

A.1.9 BFI

BFI (Bit Field Insert) copies bits into a register. A number of bits in Rd specified by width, starting at 1sb, are replaced by bits from Rn, starting at bit[0]. Other bits in Rd are unchanged.

```
BFI{cond} Rd, Rn, #1sb, #width
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register which contains the bits to be copied.

1sb specifies the least significant bit in Rd to be written to.

width is the number of bits to be copied.

A.1.10 BIC

BIC (bit clear) does an AND operation on the bits in Rn, with the complements of the corresponding bits in the value of Operand2.

Syntax

```
BIC{S}{cond} {Rd}, Rn, <Operand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.11 BKPT

BKPT (Breakpoint) causes the processor to enter Debug state.

Syntax

BKPT #imm

where:

imm is an integer in the range 0-65535 (ARM) or 0-255 (Thumb). This integer is not used by the processor itself, but can be used by Debug tools.

A.1.12 BL

BL (Branch with Link) transfers program execution to the address specified by label and stores the address of the next instruction in the LR (R14) register.

Syntax

BL{cond} {.W} label

where:

cond is an optional condition code. See Section 6.1.2.

label is a pc-relative expression.

.W is an optional instruction width specifier to force the use of a 32-bit B instruction in Thumb-2.

A.1.13 BLX

BLX (Branch with Link and eXchange) transfers program execution to the address specified by label and stores the address of the next instruction in the LR (R14) register. BLX can change the processor state from ARM to Thumb, or from Thumb to ARM. BLX label always changes the processor state from Thumb to ARM, or ARM to Thumb. BLX Rm will set the state based on bit[0] of Rm:

- Rm bit[0]=0 ARM state
- Rm bit[0]=1 Thumb state

Syntax

```
BLX{cond} {.W} label
BLX{cond} Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

label is a PC-relative expression.

.W is an optional instruction width specifier to force the use of a 32-bit B instruction in Thumb-2.

Rm is a register which holds the address to branch to.

A.1.14 BX

BX (Branch and eXchange) transfers program execution to the address specified by label. BX can change the processor state from ARM to Thumb, or from Thumb to ARM. BX Rm will set the state based on bit[0] of Rm:

- Rm bit[0]=0 ARM state.
- Rm bit[0]=1 Thumb state.

Syntax

```
BX{cond} Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rm is a register which holds the address to branch to.

A.1.15 BXJ

BXJ (Branch and change to Jazelle State) causes a branch to the address contained in Rm and changes to Jazelle state.

BXJ{cond} Rm

where:

cond is an optional condition code. See Section 6.1.2.

Rm is a register which holds the address to branch to.

A.1.16 CBNZ

CBNZ (Compare and Branch if Nonzero) causes a branch if the value in Rn is not zero and does not change the PSR flags. There is no ARM or 32-bit Thumb versions of this instruction.

Syntax

CBNZ Rn, label

where:

label is a pc-relative expression.

Rn is a register which holds the operand.

A.1.17 CBZ

CBZ (Compare and Branch if Zero) causes a branch if the value in Rn is zero and does not change the PSR flags. There is no ARM or 32-bit Thumb versions of this instruction.

Syntax

CBZ Rn, label

where:

label is a PC-relative expression.

Rn is a register which holds the operand.

A.1.18 CDP

CDP (Coprocessor Data Processing operation) performs a coprocessor operation. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

CDP{cond} coproc, #opcode1, CRd, CRn, CRm{, #opcode2}

where:

cond is an optional condition code See Section 6.1.2.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

opcode1 is a 4-bit coprocessor-specific opcode.

opcode2 is an optional 3-bit coprocessor-specific opcode.

CRd, CRn, CRm are coprocessor registers.

A.1.19 CDP2

CDP2 (Coprocessor Data Processing operation) performs a coprocessor operation. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
CDP2{cond} coproc, #opcode1, CRd, CRn, CRm{, #opcode2}
```

where:

cond is an optional condition code See Section 6.1.2.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

opcode1 is a 4-bit coprocessor-specific opcode.

opcode2 is an optional 3-bit coprocessor-specific opcode.

CRd, CRn, CRm are coprocessor registers.

A.1.20 CHKA

CHKA (Check array) is a ThumbEE instruction. If the value in the first register is less than or equal to, the second, the IndexCheck handler is called. This instruction is only available in 16-bit ThumbEE and only when Thumb-2EE support is present.

Syntax

CHKA Rn, Rm

where:

Rn holds the size of the array.

Rm contains the array index.

A.1.21 CLREX

CLREX (Clear Exclusive) moves a local exclusive access monitor to its open-access state.

Syntax

CLREX{cond}

where:

cond is an optional condition code. See Section 6.1.2.

A.1.22 CLZ

CLZ (Count Leading Zeros) counts the number of leading zeros in the value in Rm and returns the result in Rd. The result returned is 32 if no bits are set in Rm, or 0 if bit [31] is set.

Syntax

CLZ{cond}Rd, Rm

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm contains the array index.

A.1.23 CMN

CMN (Compare Negative) performs a comparison by adding the value of Operand2 to the value in Rn. The condition flags are changed, based on the result, but the result itself is discarded.

Syntax

```
CMN{cond}Rn, <0perand2>
```

where:

cond is an optional condition code. See Section 6.1.2.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.24 CMP

CMP (Compare) performs a comparison by subtracting the value of Operand2 from the value in Rn. The condition flags are changed, based on the result, but the result itself is discarded.

Syntax

```
CMP{cond}Rn, <0perand2>
```

where:

cond is an optional condition code. See Section 6.1.2.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.25 CPS

CPS (Change Processor State) may be used to change the processor mode and/or to enable or disable individual exception types.

Syntax

```
CPS #mode
CPSIE iflags{, #mode}
CPSID iflags{, #mode}
```

where:

mode is the number of a mode for the processor to enter.

IE Interrupt or abort enable.

ID Interrupt or abort disable.

iflags specifies one or more of:

a imprecise abort

- i IRQ
- f FIQ.

A.1.26 DBG

DBG (Debug) is a hint operation, treated as a NOP by the processor, but may provide information to debug systems.

Syntax

```
DBG {cond} {option} where: cond is an optional condition code. See Section 6.1.2. option is in the range 0-15.
```

A.1.27 DMB

DMB (Data Memory Barrier) requires that all explicit memory accesses in program order before the DMB instruction are observed before any explicit memory accesses in program order after the DMB instruction. See Chapter 9 for detailed discussion.

Syntax

```
DMB {cond} {option}
where:
cond is an optional condition code. See Section 6.1.2.
option is covered in depth in Chapter 9.
```

A.1.28 DSB

DSB (Data Synchronization Barrier) requires that no further instruction executes until all explicit memory accesses, cache maintenance operations, branch prediction and TLB maintenance operations before this instruction complete. See Chapter 9 for detailed discussion.

Syntax

```
DSB {cond} {option} where: cond is an optional condition code. See Section 6.1.2. option is covered in depth in Chapter 9.
```

A.1.29 ENTERX

ENTERX causes a change from Thumb state to ThumbEE state, or has no effect in ThumbEE state. It is not available in the ARM instruction set.

Syntax

ENTERX

A.1.30 EOR

EOR performs an Exclusive OR operation on the values in Rn and Operand2.

Syntax

```
EOR{S}{cond} {Rd}, Rn, <Operand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.31 HB

HB (Handler Branch) branches to a specified handler (available in ThumbEE only).

Syntax

```
HB{L} #HandlerID
HB{L}P #imm, #HandlerID
```

where:

L indicates that the instruction saves a return address in the LR.

P means that the instruction passes the value of imm to the handler in R8.

imm is an immediate value in the range 0-31 (if L is present), otherwise in the range 0-7.

HandlerID is the index number of the handler to be called, in the range 0-31 (if P is specified), otherwise in the range 0-255.

A.1.32 ISB

ISB (Instruction Synchronization Barrier) flushes the processor pipeline and ensures that context altering operations (such as ASID or other CP15 changes, branch prediction or TLB maintenance activity) *before* the ISB, are visible to the instructions fetched *after* the ISB.

See Chapter 9 for detailed discussion of barriers.

Syntax

```
ISB {cond} {option}
```

where:

cond is an optional condition code. See Section 6.1.2.

option may be SY (full system), which is the default and so can be omitted.

A.1.33 IT

IT (If-then) makes up to four following instructions conditional (known as the IT block). The conditions may all be the same, or some can be the logical inverse of others. IT is a pseudo-instruction in ARM state.

Syntax

```
IT{x{y{z}}} {cond}
```

where:

cond is an optional condition code See Section 6.1.2 which specifies the condition for the first instruction in the IT block.

x, y and z specify the condition for the 2nd, 3rd and 4th instructions.

The condition switch for the second, third and fourth instruction in the IT block can be either:

- T (Then) Applies the condition cond to the instruction.
- E (Else) Applies the inverse condition of cond to the instruction.

A.1.34 LDC

LDC (Load Coprocessor Registers) reads a coprocessor register from memory (or multiple registers, if L is specified).

Syntax

```
LDC{L}{cond} coproc, CRd, [Rn]
LDC{L}{cond} coproc, CRd, [Rn, #{-}offset]{!}
LDC{L}{cond} coproc, CRd, [Rn], #{-}offset
LDC{L}{cond} coproc, CRd, label
```

where:

L specifies that more than one register may be transferred (called a long transfer). The length of the transfer is determined by the coprocessor, but may not be more than 16 words.

cond is an optional condition code. See Section 6.1.2.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRd is the coprocessor register to be stored.

Rn is the register holding the base address for the memory operation.

Offset is a multiple of 4, in the range 0-1020, to be added or subtracted from Rn. If ! is present, the address including the offset is written back into Rn.

label is a word-aligned PC-relative address label.

A.1.35 LDC2

LDC2 (Load Coprocessor Registers) reads a coprocessor register from memory (or multiple registers, if L is specified).

```
LDC2{L}{cond} coproc, CRd, [Rn]
LDC2{L}{cond} coproc, CRd, [Rn, #{-}offset]{!}
LDC2{L}{cond} coproc, CRd, [Rn], #{-}offset
LDC2{L}{cond} coproc, CRd, label
```

where:

L specifies that more than one register may be transferred (called a long transfer). The length of the transfer is determined by the coprocessor, but may not be more than 16 words.

cond is an optional condition code. See Section 6.1.2.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRd is the coprocessor register to be stored.

Rn is the register holding the base address for the memory operation.

Offset is a multiple of 4, in the range 0-1020, to be added or subtracted from Rn. If ! is present, the address including the offset is written back into Rn.

label is a word-aligned PC-relative address label.

A.1.36 LDM

LDM (Load Multiple registers) loads one or more registers from consecutive addresses in memory at an address specified in a base register.

Syntax

```
LDM{addr_mode}{cond} Rn{!},reglist{^}
```

where:

addr_mode is one of

- IA Increment address After each transfer. This is the default, and can be omitted.
- IB Increment address Before each transfer (ARM only).
- DA Decrement address After each transfer (ARM only).
- DB Decrement address Before each transfer.

It is also possible to use the corresponding stack oriented addressing modes (FD, ED, EA, FA). For example LDMFD is a synonym of LDMDB.

cond is an optional condition code. See Section 6.1.2.

Rn is the base register, giving the initial address for the transfer.

! if present, specifies that the final address is written back into Rn.

Reglist is a list of one or more registers to be stored, enclosed in braces. It can contain register ranges. It must be comma separated if it contains more than one register or register range.

^ if specified (in a mode other than User or System) means one of two possible special actions will be taken:

- data is transferred into the User mode registers instead of the current mode registers (in the case where Reglist does not contain the PC)
- if Reglist does contain the PC, the normal multiple register transfer happens and the SPSR is copied into the CPSR. This is used for returning from exception handlers.

A.1.37 LDR

LDR (Load Register) loads a value from memory to an ARM register, optionally updating the register used to give the address.

A variety of addressing options are provided. For full details of the available addressing modes, see *Addressing modes* on page 6-9.

Syntax

```
LDR{type}{T}{cond} Rt, [Rn {, #offset}]
LDR{type}{cond} Rt, [Rn, #offset]!
LDR{type}{T}{cond} Rt, [Rn], #offset
LDR{type}{cond} Rt, [Rn, +/-Rm {, shift}]
LDR{type}{cond} Rt, [Rn, +/-Rm {, shift}]!
LDR{type}{T}{cond} Rt, [Rn], +/-Rm {, shift}]!
```

where:

type can be any one of:

- B unsigned Byte. (Zero extend to 32 bits on loads.)
- SB signed Byte. (Sign extend to 32 bits.)
- H unsigned Halfword. (Zero extend to 32 bits on loads.)
- SH signed Halfword. (Sign extend to 32 bits.)

or omitted, for a Word load.

T specifies that memory is accessed as if the processor was in user mode (not available in all addressing modes).

cond is an optional condition code. See Section 6.1.2.

Rn is the register holding the base address for the memory operation.

! if present, specifies that the final address is written back into Rn.

Offset is a numeric value.

Rm is a register holding an offset value to be applied.

shift is the register holding the base address for the memory operation.

A.1.38 LDR (pseudo-instruction)

LDR (Load Register) pseudo-instruction loads a register with a 32-bit immediate value or an address. It generates either a MOV or MVN instruction (if possible), or a PC-relative LDR instruction that reads the constant from the literal pool.

Syntax

```
LDR{cond}{.W} Rt, =expr
```

```
LDR{cond}{.W} Rt, =label_expr
```

where:

cond is an optional condition code. See Section 6.1.2.

.W specifies that a 32-bit Thumb-2 instruction must be used.

Rt is the register to load.

expr is a numeric value.

label_expr is a label, optionally plus or minus a numeric value.

A.1.39 LDREX

LDREX (Load register exclusive). Performs a load from a location and marks it for exclusive access. Byte, halfword, word and doubleword variants are provided.

Syntax

```
LDREX{cond} Rt, [Rn {, #offset}]
LDREXB{cond} Rt, [Rn]
LDREXH{cond} Rt, [Rn]
LDREXD{cond} Rt, Rt2, [Rn]
```

where:

cond is an optional condition code. See Section 6.1.2.

Rt is the register to load.

Rt2 is the second register for doubleword loads.

Rn is the register holding the address.

offset is an optional value, allowed in Thumb-2 only.

A.1.40 LEAVEX

LEAVEX causes a change from ThumbEE state to Thumb state, or has no effect in Thumb state. It is not available in the ARM instruction set.

Syntax

LEAVEX

A.1.41 LSL

LSL (Logical Shift Left) shifts the value in Rm left by the specified number of bits, inserting zeros into the vacated bit positions.

Syntax

```
LSL{S}{cond} Rd, Rm, Rs
LSL{S}{cond} Rd, Rm, #sh
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2

Rd is the destination register.

Rm is the register holding the operand to be shifted.

Rs is the register which holds a shift value to apply to the value in Rm. Only the least significant byte of the register is used.

sh is a shift amount, in the range 0-31.

A.1.42 LSR

LSR (Logical Shift Right) shifts the value in Rm right by the specified number of bits, inserting zeros into the vacated bit positions.

Syntax

```
LSR{S}{cond} Rd, Rm, Rs
LSR{S}{cond} Rd, Rm, #sh
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm is the register holding the operand to be shifted.

Rs is the register which holds a shift value to apply to the value in Rm. Only the least significant byte of the register is used.

sh is a shift amount, in the range 0-31.

A.1.43 MCR

MCR (Move to Coprocessor from Register) writes a coprocessor register, from an ARM register. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MCR{cond} coproc, #opcode1, Rt, CRn, CRm{, #opcode2}
```

where:

cond is an optional condition code. See Section 6.1.2.

Rt is the ARM register to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

opcode1 is a 4-bit coprocessor-specific opcode.

opcode2 is an optional 3-bit coprocessor-specific opcode.

CRn, CRm are coprocessor registers.

A.1.44 MCR2

MCR2 (Move to Coprocessor from Register) writes a coprocessor register, from an ARM register. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MCR2{cond} coproc, #opcode1, Rt, CRn, CRm{, #opcode2}
```

where:

cond is an optional condition code. See Section 6.1.2.

Rt is the ARM register to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

opcode1 is a 4-bit coprocessor-specific opcode.

opcode2 is an optional 3-bit coprocessor-specific opcode.

CRn, CRm are coprocessor registers.

A.1.45 MCRR

MCRR (Move to Coprocessor from Registers) transfers a pair of ARM register to a coprocessor. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MCRR{cond} coproc, #opcode3, Rt, Rt2, CRm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rt and Rt2 are the ARM registers to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRm is a coprocessor register.

Opcode3 is an optional 4-bit coprocessor-specific opcode.

A.1.46 MCRR2

MCRR2 (Move to Coprocessor from Registers) transfers a pair of ARM register to a coprocessor. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MCRR2{cond} coproc, #opcode3, Rt, Rt2, CRm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rt and Rt2 are the ARM registers to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRm is a coprocessor register.

Opcode3 is an optional 4-bit coprocessor-specific opcode.

A.1.47 MLA

MLA (Multiply Accumulate) multiplies Rn and Rm, adds the value from Ra, and stores the least significant 32 bits of the result in Rd.

Syntax

```
MLA{S}{cond} {Rd}, Rn, Rm, Ra
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

Ra is the register holding the value to be added.

A.1.48 MLS

MLS (Multiply and Subtract) multiplies Rn and Rm, subtracts the result from Ra, and stores the least significant 32 bits of the final result in Rd.

Syntax

```
MLS{S}{cond} {Rd}, Rn, Rm, Ra
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

Ra is the register holding the value to be added.

A.1.49 MOV

MOV (Move) copies the value of Operand2 into Rd.

```
MOV{S}{cond} Rn, <Operand2>
MOV{cond} Rd, #imm16
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Operand2 is a flexible second operand. See Section 6.2.1.

imm16 is an immediate value in the range 0-65535.

A.1.50 MOVT

MOVT (Move Top) writes imm16 to Rd[31:16]. It does not affect Rd[15:0].

Syntax

```
MOVT{cond} Rd, #imm16
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Operand2 is a flexible second operand .See Section 6.2.1.

imm16 is an immediate value in the range 0-65535.

A.1.51 MOV32

MOV32 is a pseudo- instruction which loads a register with a 32-bit immediate value or address. It generates two instructions, a MOV, MOVT pair.

Syntax

MOV32 Rd, expr

where:

Rd is the destination register.

expr is a 32-bit constant, or address label.

A.1.52 MRC

MRC (Move to Register from Coprocessor) reads a coprocessor register to an ARM register. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MRC{cond} coproc, #opcode1, Rt, CRn, CRm{, #opcode2}
```

where:

cond is an optional condition code. See Section 6.1.2.

Rt is the ARM register to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

opcode1 is a 4-bit coprocessor-specific opcode.

opcode2 is an optional 3-bit coprocessor-specific opcode.

CRn, CRm are coprocessor registers.

A.1.53 MRC2

MRC2 (Move to Register from Coprocessor) reads a coprocessor register to an ARM register. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MRC2{cond} coproc, #opcode1, Rt, CRn, CRm{, #opcode2}
```

where:

cond is an optional condition code. See Section 6.1.2.

Rt is the ARM register to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

opcode1 is a 4-bit coprocessor-specific opcode.

opcode2 is an optional 3-bit coprocessor-specific opcode.

CRn, CRm are coprocessor registers.

A.1.54 MRRC

MRRC (Move to Registers from coprocessor) transfers a value from a coprocessor to a pair of ARM registers. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MRRC{cond} coproc, #opcode3, Rt, Rt2, CRm
```

where

cond is an optional condition code, See Section 6.1.2. CDP2 instructions may not specify a condition code in ARM state.

Rt and Rt2 are the ARM registers to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRm is a coprocessor register.

Opcode3 is an optional 4-bit coprocessor-specific opcode.

A.1.55 MRRC2

MRRC2 (Move to Registers from coprocessor) transfers a value from a coprocessor to a pair of ARM registers. The purpose of this instruction is defined by the coprocessor implementer.

Syntax

```
MRRC2{cond} coproc, #opcode3, Rt, Rt2, CRm
```

where:

cond is an optional condition code, See Section 6.1.2. CDP2 instructions may not specify a condition code in ARM state.

Rt and Rt2 are the ARM registers to be transferred.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRm is a coprocessor register.

Opcode3 is an optional 4-bit coprocessor-specific opcode.

A.1.56 MRS

MRS (Move Status register to General purpose register) can be used to read the CPSR/APSR, CP14 or CP15 coprocessor registers.

Syntax

```
MRS{cond} Rd, psr
MRS{cond} Rn, coproc_register
MRS{cond} APSR_nzcv, DBGDSCRint
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

psr is one of: APSR, CPSR or SPSR.

coproc_register is the name of a CP14 or CP15 readable register.

DBGDSCRint is the name of a CP14 register which can be copied to the APSR.

A.1.57 MSR

MSR (Move Status register or Coprocessor Register from General purpose register) can be used to write all or part of the CPSR/APSR or CP14 or CP15 registers.

Syntax

```
MSR{cond} APSR_flags, Rm
MSR{cond} coproc_register, Rn
MSR{cond} APSR_flags, #constant
MSR{cond} psr_fields, #constant
MSR{cond} psr_fields, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rm and Rn are the source registers.

APSR_flags may be one or more of nzcvq (ALU flags) and/or g (SIMD flags).

coproc_register is the name of a CP14 or CP15 readable register.

constant is an 8-bit pattern rotated by an even number of bits within a 32-bit word. (Not available in Thumb.)

psr is one of: APSR, CPSR or SPSR.

fields is one or more of:

- c control field mask byte, PSR[7:0]
- x extension field mask byte, PSR[15:8]
- s status field mask byte, PSR[23:16]
- f flags field mask byte, PSR[31:24].

A.1.58 MUL

MUL (Multiply) Multiplies Rn and Rm, and stores the least significant 32 bits of the result in Rd.

Syntax

```
MUL{S}{cond} {Rd}, Rn, Rm
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.59 MVN

MVN (Move Not) performs a bitwise NOT operation on the operand2 value, and places the result into Rd.

Syntax

```
MVN{S}{cond} Rn, <0perand2>
```

where

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.60 NOP

NOP(No Operation) does nothing.

Syntax

NOP{cond}

where:

NOP does not have to consume clock cycles. It may be removed by the processor pipeline. It is used for padding, to ensure following instructions align to a boundary.

A.1.61 ORN

ORN (OR NOT) does an OR operation on the bits in Rn with the complements of the corresponding bits in the value of Operand2.

Syntax

```
ORN{S}{cond} {Rd}, Rn, <Operand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.62 ORR

Performs an OR operation on the bits in Rn with the corresponding bits in the value of Operand2.

Syntax

```
ORR{S}{cond} {Rd}, Rn, <Operand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.63 PKHBT

PKHBT (Pack Halfword Bottom Top) combines bits[15:0] of Rn with bits[31:16] of the shifted value from Rm.

Syntax

```
PKHBT{cond} {Rd}, Rn, Rm{, LSL #leftshift}
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Rm is the register holding the second operand.

leftshift is a number in the range 0-31.

A.1.64 PKHTB

PKHTB (Pack Halfword Top Bottom) combines bits[31:16] of Rn with bits[15:0] of the shifted value from Rm.

Syntax

```
PKHTB {cond} {Rd}, Rn, Rm{, ASR #rightshift}
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Rm is the register holding the second operand.

rightshift is a number in the range 1-32.

A.1.65 PLD

PLD (Preload data) is a hint instruction which may cause data to be preloaded into the cache.

Syntax

```
PLD{cond} [Rn {, #offset}]
PLD{cond} [Rn, +/-Rm {, shift}]
PLD{cond} label
```

where:

cond is an optional condition code, See Section 6.1.2, allowed in Thumb-2 only, using a preceding IT instruction.

Rn is a base address.

offset is an immediate value, which defaults to 0 if not specified.

Rm contains an offset value and must not be PC (or SP, in Thumb state).

shift is an optional shift.

label is a PC-relative expression.

A.1.66 PLDW

PLDW (Preload data with intent to write) is a hint instruction which may cause data to be preloaded into the cache. It is available only in processors which implement multi-processing extensions.

Syntax

```
PLDW{cond} [Rn {, #offset}]
PLDW{cond} [Rn, +/-Rm {, shift}]
```

where:

cond is an optional condition code. See Section 6.1.2, allowed in Thumb-2 only, using a preceding IT instruction.

Rn is a base address.

offset is an immediate value, which defaults to 0 if not specified.

Rm contains an offset value and must not be PC (or SP, in Thumb state).

shift is an optional shift.

A.1.67 PLI

PLI (Preload instructions) is a hint instruction which may cause instructions to be preloaded into the cache.

Syntax

```
PLI{cond} [Rn {, #offset}]
PLI{cond} [Rn, +/-Rm {, shift}]
PLI{cond} label
```

where:

cond is an optional condition code, See Section 6.1.2, allowed in Thumb-2 only, using a preceding IT instruction.

Rn is a base address.

offset is an immediate value, which defaults to 0 if not specified.

Rm contains an offset value and must not be PC (or SP, in Thumb state).

shift is an optional shift.

label is a PC-relative expression.

A.1.68 POP

POP is used to pop registers off a full descending stack. POP is a synonym for LDMIA sp! reglist.

Syntax

```
POP {cond} reglist
```

where:

cond is an optional condition code. See Section 6.1.2.

reglist is a list of one or more registers, enclosed in braces.

A.1.69 PUSH

PUSH is used to push registers on to a full descending stack. PUSH is a synonym for STMDB sp! reglist.

Syntax

```
PUSH {cond} reglist
```

where:

cond is an optional condition code. See Section 6.1.2.

reglist is a list of one or more registers, enclosed in braces.

A.1.70 QADD

QADD (Saturating signed Add) does a signed addition and saturates the result to the signed range $-2^{31} \le x \le 2^{31}$ -1. If saturation occurs, the Q flag is set.

Syntax

```
QADD{cond} {Rd}, Rm, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the register holding the operands.

A.1.71 QADD8

QADD8 (Saturating signed bytewise Add) does a signed bytewise addition (4 adds) and saturates the results to the signed range $-2^7 \le x \le 2^7 - 1$. The Q flag is not affected by this instruction.

Syntax

```
QADD8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.72 QADD16

QADD16 (Saturating signed bytewise Add) does a signed halfword-wise addition (2 adds) and saturates the results to the signed range $-2^7 \le x \le 2^7-1$. The Q flag is not affected by this instruction.

Syntax

```
QADD16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.73 QASX

QASX (Saturating signed Add Subtract Exchange) exchanges halfwords of Rm, then adds the top halfwords and subtracts the bottom halfwords and saturates the results to the signed range $-2^{15} \le x \le 2^{15}-1$. The Q flag is not affected by this instruction.

Syntax

```
QASX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.74 QDADD

QADD (Saturating signed Add) does a signed doubling addition and saturates the result to the signed range $-2^{31} \le x \le 2^{31}-1$. If saturation occurs, the Q flag is set.

Syntax

```
QDADD{cond} {Rd}, Rm, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

The value in Rn is multiplied by 2, saturated and then added to the value in Rm. A second saturate operation is then performed.

A.1.75 QDSUB

QDSUB (Saturating signed doubling subtraction) does a signed doubling subtraction and saturates the result to the signed range $-2^{31} \le x \le 2^{31}-1$. If saturation occurs, the Q flag is set.

Syntax

```
QDSUB{cond} {Rd}, Rm, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

The value in Rn is multiplied by 2, saturated and then subtracted from the value in Rm. A second saturate operation is then performed.

A.1.76 QSAX

QSAX (Saturating signed Subtract Add Exchange) exchanges the halfwords of Rm, then subtracts the top halfwords and adds the bottom halfwords and saturates the results to the signed range $-2^{15} \le x \le 2^{15}-1$. The Q flag is not affected by this instruction.

Syntax

```
QSAX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.77 QSUB

QSUB (Saturating signed Subtraction) does a signed subtraction and saturates the result to the signed range $-2^{31} \le x \le 2^{31}-1$. If saturation occurs, the Q flag is set.

Syntax

```
QDSUB{cond} {Rd}, Rm, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

The value in Rn is subtracted from the value in Rm. A saturate operation is then performed.

A.1.78 QSUB8

QSUB8 (Saturating signed bytewise Subtract) does bytewise subtraction (4 subtracts), with saturation of the results to the signed range $-2^7 \le x \le 2^7-1$. The Q flag is not affected by this instruction.

Syntax

```
QSUB8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.79 QSUB16

QSUB16 (Saturating signed halfword Subtract) does halfword-wise subtraction (2 subtracts), with saturation of the results to the signed range $-2^{15} \le x \le 2^{15}-1$. The Q flag is not affected by this instruction.

Syntax

```
QSUB16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.80 RBIT

RBIT (Reverse bits) reverses the bit order in a 32-bit word.

Syntax

```
RBIT{cond}{Rd}, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the operand.

A.1.81 REV

REV (Reverse) converts 32-bit big-endian data into little-endian data , or 32-bit little-endian data into big-endian data.

Syntax

```
REV{cond}{Rd}, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the operand.

A.1.82 REV16

REV16 (Reverse byte order halfwords) converts 32-bit big-endian data into little-endian data, or 32-bit little-endian data into big-endian data.

Syntax

REV16{cond}{Rd}, Rn

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the operand.

A.1.83 REVSH

REVSH (Reverse byte order halfword, with sign extension) does a reverse byte order of the bottom halfword, and sign extends the result to 32 bits.

Syntax

```
REVSH{cond}{Rd}, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the operand.

A.1.84 RFE

RFE (Return from Exception) is used to return from an exception where the return state was saved with SRS. If ! is specified, the final address is written back into Rn.

Syntax

```
RFE{addr_mode}{cond} Rn{!}
```

where:

addr mode is one of

- IA Increment address After each transfer. This is the default, and can be omitted.
- IB Increment address Before each transfer (ARM only).
- DA Decrement address After each transfer (ARM only).
- DB Decrement address Before each transfer.

cond is an optional condition codes, See Section 6.1.2, and is allowed only in Thumb, using a preceding IT instruction.

Rn specifies the base register.

A.1.85 ROR

ROR (Rotate Right Register) rotates a value in a register by a specified number of bits. The bits that are rotated off the right end are inserted into the vacated bit positions on the left.

Syntax

```
ROR{S}{cond} Rd, Rm, Rs
ROR{S}{cond} Rd, Rm, #sh
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the operand.Rm is the register holding the operand to be shifted.

Rs is the register which holds a shift value to apply to the value in Rm. Only the least significant byte of the register is used.

sh is a shift amount, in the range 1-31.

A.1.86 RRX

RRX (Rotate Right with extend) performs a shift right one bit on a register value. The old carry flag is shifted into bit[31]. If the S suffix is present, the old bit[0] is placed in the carry flag.

Syntax

RRX{S}{cond} Rd, Rm

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm is the register holding the operand to be shifted.

A.1.87 RSB

RSB (Reverse Subtract) subtracts the value in Rn from the value of Operand2. This is useful because Operand2 has more options than Operand1 (which is always a register).

Syntax

```
RSB{S}{cond} {Rd}, Rn, <0perand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.88 RSC

RSC (Reverse Subtract with Carry) subtracts Rn from Operand2. If the carry flag is clear, the result is reduced by one.

Syntax

```
RSC{S}{cond} {Rd}, Rn, <0perand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.89 SADD8

SADD8 (Signed bytewise Add) does a signed bytewise addition (4 adds).

Syntax

```
SADD8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.90 SADD16

SADD16 (Signed bytewise Add) does a signed halfword-wise addition (2 adds).

Syntax

```
SADD16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.91 SASX

SASX (Signed Add Subtract Exchange) exchanges halfwords of Rm, then adds the top halfwords and subtracts the bottom halfwords.

Syntax

```
SASX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands

A.1.92 SBC

SBC (Subtract with Carry) subtracts the value of Operand2 from the value in Rn. If the carry flag is clear, the result is reduced by one.

Syntax

```
SBC{S}{cond} {Rd}, Rn, <0perand2>
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.93 SBFX

SBFX (Signed Bit Field Extract) writes adjacent bits from one register into the least significant bits of a second register and sign extends to 32 bits.

Syntax

```
SBFX{cond} Rd, Rn, #1sb, #width
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register which contains the bits to be extracted.

1sb specifies the least significant bit of the bitfield.

width is the width of the bitfield.

A.1.94 SDIV

SDIV (Signed divide). This instruction is not present in the ARMv7-A Architecture

A.1.95 SEL

SEL (Select) selects bytes from Rn or Rm, depending on the APSR GE flags.

If GE[0] is set, Rd[7:0] comes from Rn[7:0], else from Rm[7:0].

If GE[1] is set, Rd[15:8] comes from Rn[15:8], else from Rm[15:8].

If GE[2] is set, Rd[23:16] comes from Rn[23:16], else from Rm[23:16].

If GE[3] is set, Rd[31:24] comes from Rn[31:24], else from Rm[31:24].

Syntax

```
SEL{cond}(Rd),Rn,Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register which contains the bits to be extracted.

Rm is the register holding the second operand.

A.1.96 SETEND

SETEND (Set endianness) selects little-endian or big-endian memory access. See *Endianness* on page 14-2 for more details.

Syntax

SETEND LE SETEND BE

A.1.97 SEV

SEV(Set Event) causes an event to be signaled to all cores in an MPCore. See *Power and clocking* on page 21-2 for more detail.

Syntax

SEV {cond}

where:

cond is an optional condition code. See Section 6.1.2.

A.1.98 SHADD8

SHADD8 (Signed halving bytewise Add) does a signed bytewise addition (4 adds) and halves the results.

Syntax

```
SHADD8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.99 SHADD16

SHADD16 (Signed halving bytewise Add) does a signed halfword-wise addition (2 adds) and halves the results.

Syntax

```
SHADD16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.100 SHASX

SHASX (Signed Halving Add Subtract Exchange) exchanges halfwords of Rm, then adds the top halfwords and subtracts the bottom halfwords and halves the results.

Syntax

```
SHASX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.101 SHSAX

SHSAX (Signed Halving Subtract Add Exchange) exchanges halfwords of Rm, then subtracts the top halfwords and adds the bottom halfwords and halves the results.

Syntax

```
SHSAX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.102 SHSUB8

SHSUB8 (Signed halving bytewise subtraction) does a signed bytewise subtraction (4 subtracts) and halves the results.

Syntax

```
SHSUB8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands

A.1.103 SHSUB16

SHSUB16 (Signed halving halfword-wise subtract) does a signed halfword-wise subtraction (2 subtracts) and halves the result.

Syntax

```
SHSUB16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the register holding the operands.

A.1.104 SMC

SMC (Secure Monitor Call) is used by the ARM Security Extensions. This instruction was formerly called SMI. See Chapter 26 Security for more details.

Syntax

SMC{cond} #imm4

where:

cond is an optional condition code. See Section 6.1.2.

imm4 is an immediate value in the range 0-15, which is ignored by the processor, but may be used by the SMC exception handler.

A.1.105 SMLAxy

The SMLAxy (Signed Multiply Accumulate; $32 \le 32+16 \times 16$) instruction multiplies the 16-bit signed integers from the selected halves of Rn and Rm, adds the 32-bit result to the value from Ra, and writes the result in Rd.

Syntax

```
SMLA<x><y>{cond} Rd, Rn, Rm, Ra
```

where:

<x> and <y> may be either B or T. B means use the bottom half (bits [15:0]) of a register, T means use the top half (bits [31:16]) of a register. <x> specifies which half of Rn to use, <y> does the same for Rm.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

Ra is the register which holds the value to be added.

A.1.106 SMLAD

SMLAD (Dual Signed Multiply Accumulate; $32 \le 32 + 16 \times 16 + 16 \times 16$) multiplies the bottom halfword of Rn with the bottom halfword of Rm, and the top halfword of Rn with the top halfword of Rm. It then adds both products to the value in Ra and writes the sum to Rd.

Syntax

```
SMLAD{X}{cond} Rd, Rn, Rm, Ra
```

where:

{X} if present, means that the most and least significant halfwords of the second operand are swapped, before the multiplication.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

Ra is the register which holds the value to be added.

A.1.107 SMLAL

SMLAL (Signed Multiply Accumulate $64 \le 64 + 32 \times 32$) multiplies Rn and Rm (treated as signed integers) and adds the 64-bit result to the 64-bit signed integer contained in RdHi and RdLo.

Syntax 1 4 1

```
SMLAL{S}{cond} RdLo, RdHi, Rn, Rm
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.108 SMLALxy

SMLALxy (Signed Multiply Accumulate; $64 \le 64 + 16 \times 16$) multiplies the signed integer from the selected half of Rm by the signed integer from the selected half of Rn, and adds the 32-bit result to the 64-bit value in RdHi and RdLo.

Syntax

```
SMLAL<x><y>{cond} RdLo, RdHi, Rn, Rm
```

where:

<x> may be either B or T. B means use the bottom half (bits [15:0]) of Rn, T means use the top half (bits [31:16]) of Rn.

<y> may be either B or T. B means use the bottom half (bits [15:0]) of Rm, T means use the top half (bits [31:16]) of Rm.

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.109 SMLALD

SMLALD (Dual Signed Multiply Accumulate Long; $64 \le 64 + 16 \times 16 + 16 \times 16$) multiplies the bottom halfword of Rn with the bottom halfword of Rm, and the top halfword of Rn with the top halfword of Rm and adds both products to the value in RdLo, RdHi and stores the result in RdLo and RdHi.

Syntax

```
SMLALD{X}{cond} RdLo, RdHi Rn, Rm
```

where:

<x> may be either B or T. B means use the bottom half (bits [15:0]) of Rn, T means use the top half (bits [31:16]) of Rn

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.110 SMLAWy

SMLAW (Signed Multiply with Accumulate Wide; $32 \le 32 \times 16 + 32$) multiplies the signed integer from the selected half of Rm by the signed integer from Rn, adds the 32-bit result to the 32-bit value in Ra, and writes the result in Rd.

Syntax

```
SMLAW<y>{cond} Rd, Rn, Rm, Ra
```

where:

<y> may be either B or T. B means use the bottom half (bits [15:0]) of Rm, T means use the top half (bits [31:16]) of Rm.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

Ra is the register which holds the value to be added.

A.1.111 SMLSLD

SMLSLD (Dual Signed Multiply Subtract Accumulate Long; $64 \le 64 + 16 \times 16 - 16 \times 16$) multiplies Rn[15:0] with Rm[15:0] and Rn[31:16] with Rm[31:16]. It then subtracts the second product from the first, adds the difference to the value in RdLo, RdHi, and writes the result to RdLo, RdHi.

Syntax

```
SMLSLD{X}{cond} RdLo, RdHi Rn, Rm
```

where:

{X} if present, means that the most and least significant halfwords of the second operand are swapped, before the multiplication.

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers and hold the value to be accumulated.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.112 SMMLA

SMMLA (Signed top word Multiply with Accumulate; $32 \le \text{TopWord}(32 \times 32 + 32)$) multiplies Rn and Rm, adds Ra to the most significant 32 bits of the product, and writes the result in Rd.

Syntax

```
SMMLA{R}{cond} Rd, Rn, Rm, Ra
```

where:

R, if present means that 0x80000000 is added before extracting the most significant 32 bits. This rounds the result.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

Ra is the register holding the value to be added.

A.1.113 SMMLS

SMMLS (Signed top word Multiply with Subtract; $32 \le \text{TopWord}(32 \times 32 - 32)$) multiplies Rn and Rm, subtracts the product from the value in Ra shifted left by 32 bits, and stores the most significant 32 bits of the result in Rd.

Syntax

```
SMMLS{R}{cond} Rd, Rn, Rm, Ra
```

where:

R, if present means that 0x80000000 is added before extracting the most significant 32 bits. This rounds the result.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

Ra is the register holding the value to be added.

A.1.114 SMMUL

SMMUL (Signed top word Multiply; $32 \le \text{TopWord}(32 \times 32)$) multiplies Rn and Rm, and writes the most significant 32 bits of the 64-bit result to Rd.

Syntax

```
SMMUL{R}{cond} Rd, Rn, Rm
```

where:

R, if present means that 0x80000000 is added before extracting the most significant 32 bits. This rounds the result.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.115 SMUAD

SMUAD (Dual Signed Multiply and Add products) multiplies Rn[15:0] with Rm[15:0] and Rn[31:16] with Rm[31:16]. It then adds the products and stores the sum to Rd.

Syntax

```
SMUAD{X}{cond} Rd, Rn, Rm
```

where:

X, if present means that the most and least significant halfwords of the second operand are exchanged before the multiplications occur.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.116 SMUSD

SMUSD (Dual Signed Multiply and Subtract products) multiplies Rn[15:0] with Rm[15:0] and Rn[31:16] with Rm[31:16]. It then subtracts the products and stores the sum to Rd.

Syntax

```
SMUSD{X}{cond} Rd, Rn, Rm
```

where:

X, if present means that the most and least significant halfwords of the second operand are exchanged before the multiplications occur.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.117 SMULxy

The SMULxy (Signed Multiply ($32 \le 16 \times 16$) instruction multiplies the 16-bit signed integers from the selected halves of Rn and Rm, and places the 32-bit result in Rd.

Syntax

```
SMUL<x><y>{cond} {Rd}, Rn, Rm
```

where:

<x> and <y> may be either B or T. B means use the bottom half (bits [15:0]) of a register, T means use the top half (bits [31:16]) of a register. <x> specifies which half of Rn to use, <y> does the same for Rm.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.118 SMULL

The SMULL (signed multiply long; $64 \le 32 \times 32$) instruction multiplies Rn and Rm (treated as containing as two's complement signed integers) and places the least significant 32 bits of the result in RdLo, and the most significant 32 bits of the result in RdHi.

Syntax

```
SMULL{S}{cond} RdLo, RdHi, Rn, Rm
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.119 SMULWy

SMULWy (Signed Multiply Wide; $32 \le 32 \times 16$) multiplies the signed integer from the chosen half of Rm with the signed integer from Rn, and places the upper 32-bits of the 48-bit result in Rd.

Syntax

```
SMULW<y>{cond} {Rd}, Rn, Rm
```

where:

<y> is either B or T. B means use the bottom half (bits [15:0]) of Rm, T means use the top half (bits [31:16]) of Rm.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.120 SRS

SRS (Store Return State) stores the LR and the SPSR of the current mode, at the address contained in the SP of the mode specified by modenum. The optional! means that the SP value is updated. This is compatible with the normal use of the STM instruction for stack accesses.

Syntax

```
SRS{addr_mode}{cond} sp{!}, #modenum
```

where:

addr mode is one of:

- IA Increment address After each transfer. This is the default, and can be omitted.
- IB Increment address Before each transfer (ARM only).
- DA Decrement address After each transfer (ARM only).
- DB Decrement address Before each transfer.

It is also possible to use the corresponding stack oriented addressing modes (FD, ED, EA, FA).

cond is an optional condition code. See Section 6.1.2.

modenum gives the number of the mode whose SP is used.

A.1.121 SSAT

SSAT (Signed Saturate) performs a shift and saturates the result to the signed range $-2^{\text{sat-1}} \le x \le 2^{\text{sat-1}}$ -1. If saturation occurs, the Q flag is set.

Syntax

```
SSAT{ cond} Rd, #sat, Rm{, shift}
```

where:

<y> is either B or T. B means use the bottom half (bits [15:0]) of Rm, T means use the top half (bits [31:16]) of Rm.

cond is an optional condition code. See Section 6.1.2

Rd is the destination registers.

sat specifies the bit position to saturate to, in the range 1 to 32.

Rm is the register holding the second multiplicand.

shift is optional shift amount and can be either ASR #n where n is in the range (1-32 ARM state, 1-31 Thumb state) or LSL #n where n is in the range (0-31).

A.1.122 SSAT16

SSAT16(Signed Saturate, parallel halfwords) saturates each signed halfword to the signed range -2sat- $1 \le x \le 2$ sat-1 -1. If saturation occurs, the Q flag is set.

Syntax

```
SSAT16{cond} Rd, #sat, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination registers.

sat specifies the bit position to saturate to, in the range 1 to 32.

Rn is the register holding the operand.

A.1.123 SSAX

SSAX (Signed Subtract Add Exchange) exchanges halfwords of Rm, then subtracts the top halfwords and adds the bottom halfwords.

Syntax

```
SSAX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination registers.

Rm and Rn are the register holding the operands.

A.1.124 SSUB8

SSUB8 (Signed halving bytewise Subtraction) does a signed bytewise subtraction (4 subtracts).

Syntax

```
SSUB8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination registers.

Rm and Rn are the register holding the operands.

A.1.125 SSUB16

SSUB16 (Signed halfword-wise Subtract) does a signed halfword-wise subtraction (2 subtracts).

Syntax

```
SSUB16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination registers.

Rm and Rn are the register holding the operands.

A.1.126 STC

STC (Store Coprocessor Registers)writes a coprocessor register to memory (or multiple registers, if L is specified).

Syntax

```
STC{L}{cond} coproc, CRd, [Rn]
STC{L}{cond} coproc, CRd, [Rn, #{-}offset]{!}
STC{L}{cond} coproc, CRd, [Rn], #{-}offset
STC{L}{cond} coproc, CRd, label
```

where:

L specifies that more than one register may be transferred (called a long transfer). The length of the transfer is determined by the coprocessor, but may not be more than 16 words.

cond is an optional condition code. See Section 6.1.2.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRd is the coprocessor register to be stored.

Rn is the register holding the base address for the memory operation.

offset is a multiple of four, in the range 0-1020, to be added or subtracted from Rn. If ! is present, the address including the offset is written back into Rn.

label is a word-aligned PC-relative address label.

A.1.127 STC2

STC2 (Store Coprocessor registers) writes a coprocessor register to memory (or multiple registers, if L is specified).

Syntax

```
STC2{L}{cond} coproc, CRd, [Rn]
STC2{L}{cond} coproc, CRd, [Rn, #{-}offset]{!}
STC2{L}{cond} coproc, CRd, [Rn], #{-}offset
STC2{L}{cond} coproc, CRd, label
```

where:

L specifies that more than one register may be transferred (called a long transfer). The length of the transfer is determined by the coprocessor, but may not be more than 16 words.

cond is an optional condition code. See Section 6.1.2.

coproc is the name of the coprocessor the instruction is for. This is usually of the form pn, where n is an integer in the range 0 to 15.

CRd is the coprocessor register to be stored.

Rn is the register holding the base address for the memory operation.

offset is a multiple of four, in the range 0-1020, to be added or subtracted from Rn. If ! is present, the address including the offset is written back into Rn.

label is a word-aligned PC-relative address label.

A.1.128 STM

STM (Store Multiple registers) writes one or more registers to consecutive addresses in memory to an address specified in a base register.

Syntax

```
STM{addr_mode}{cond} Rn{!},reglist{^}
```

where:

addr_mode is one of

- IA Increment address After each transfer. This is the default, and can be omitted.
- IB Increment address Before each transfer (ARM only).
- DA Decrement address After each transfer (ARM only).
- DB Decrement address Before each transfer

It is also possible to use the corresponding stack oriented addressing modes (FD, ED, EA, FA). For example STMFD is a synonym of STMDB.

cond is an optional condition code. See Section 6.1.2.

Rn is the base register, giving the initial address for the transfer.

! if present, specifies that the final address is written back into Rn.

^ if specified (in ARM state and a mode other than User or System) means that data is transferred into or out of the User mode registers instead of the current mode registers.

reglist is a list of one or more registers to be stored, enclosed in braces. It can contain register ranges. It must be comma separated if it contains more than one register or register range.

A.1.129 STR

STR (Store Register) stores a value to memory from an ARM register, optionally updating the register used to give the address.

A variety of addressing options are provided. For full details of the available addressing modes, see *Addressing modes* on page 6-9.

Syntax

```
STR{type}{T}{cond} Rt, [Rn {, #offset}]
STR{type}{cond} Rt, [Rn, #offset]!
STR{type}{T}{cond} Rt, [Rn], #offset
STR{type}{cond} Rt, [Rn, +/-Rm {, shift}]
STR{type}{cond} Rt, [Rn, +/-Rm {, shift}]!
STR{type}{T}{cond} Rt, [Rn], +/-Rm {, shift}]!
```

where:

type can be any one of:

- B unsigned Byte (Zero extend to 32 bits on loads.)
- SB signed Byte (Sign extend to 32 bits.)
- H unsigned Halfword (Zero extend to 32 bits on loads.)
- SH signed Halfword (Sign extend to 32 bits.)

or omitted, for a Word load.

T specifies that memory is accessed as if the processor was in user mode (not available in all addressing modes).

cond is an optional condition code. See Section 6.1.2.

Rn is the register holding the base address for the memory operation.

! if present, specifies that the final address is written back into Rn.

offset is a numeric value.

Rm is a register holding an offset value to be applied.

shift is the register holding the base address for the memory operation.

A.1.130 STREX

STREX (Store register exclusive). Performs a store to a location marked for exclusive access, returning a status value if the store succeeded. Byte, halfword, word and doubleword variants are provided.

Syntax

```
STREX{cond} Rd, Rt, [Rn {, #offset}]
STREXB{cond} Rd, Rt, [Rn]
STREXH{cond} Rd, Rt, [Rn]
STREXD{cond} Rd, Rt, Rt2, [Rn]
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register for the return status.

Rt is the register to store.

Rt2 is the second register for doubleword stores.

Rn is the register holding the address.

offset is an optional value, allowed in Thumb-2 only.

A.1.131 SUB

SUB subtracts the value Operand2 from Rn (or subtracts imm12 from Rn).

Syntax

```
SUB{S}{cond} {Rd}, Rn, <Operand2>
SUB{cond}{Rd}, Rn, #imm12 (Only available in Thumb-2)
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

imm12 is in the range 0-4095.

A.1.132 SVC

SVC (SuperVisor Call) causes an SVC exception (was called SWI in older documentation).

Syntax

```
SVC{cond} #imm
```

where:

cond is an optional condition code. See Section 6.1.2.

imm is an integer in the range 0-0xFFFFFF (ARM) or 0-0xFF (Thumb). This integer is not used by the processor itself, but can be used by exception handler code.

A.1.133 SWP

SWP (Swap registers and memory) performs the following two actions. Data from memory is loaded into Rt. Rt2 is saved to memory, at the address given by Rn. Use of this instruction is deprecated and its use is disabled by default.

Syntax

```
SWP{B}{cond} Rt, Rt2, [Rn]
```

where:

B is an optional suffix. If specified, a byte is swapped. If not present, a word is specified.

Rt is the destination register.

Rt2 is the source register and can be the same as Rt.

Rn is the register holding the address and cannot be the same as Rt or Rt2.

A.1.134 SXT

SXT (Signed Extend) extracts the specified byte and extends to 32-bit.

Syntax

```
SXT<extend>{cond} {Rd}, Rm {,rotation}
```

where:

extend must be one of

- B16 Extends two 8-bit values to two 16-bit values.
- B Extends an 8-bit value to a 32-bit value.
- H Extends a 16-bit value to a 32-bit value.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm is the register which contains the value to be extended.

rotation can be one of ROR #8, ROR #16 or ROR #24 (or may be omitted).

A.1.135 SXTA

SXTA (Signed Extend and Add) extracts the specified byte, adds the value from Rn and extends to 32-bit.

Syntax

```
SXTA<extend>{cond} {Rd}, Rn, Rm {,rotation}
```

where:

extend must be one of

- B16 Extends two 8-bit values to two 16-bit values.
- B Extends an 8-bit value to a 32-bit value.

H Extends a 16-bit value to a 32-bit value.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the value to be added.

Rm is the register which contains the value to be extended.

rotation can be one of ROR #8, ROR #16 or ROR #24 (or may be omitted).

A.1.136 SYS

SYS (System coprocessor instruction) is used to execute special coprocessor instructions such as cache, branch predictor, and TLB operations. The instructions operate by writing to special write-only coprocessor registers.

Syntax

SYS{cond}instruction{,Rn}

where:

cond is an optional condition code. See Section 6.1.2.

instruction is a write-only system coprocessor register name.

Rn is the register holding the operand.

A.1.137 TBB

TBB (Table Branch Byte) causes a PC-relative forward branch using a table of single byte offsets. Rn provides a pointer to the table, and Rm supplies an index into the table. The branch length is twice the value of the byte returned from the table. The target of the branch table must be in the same execution state. There is no ARM or 16-bit Thumb version of this instruction.

Syntax

TBB [Rn, Rm]

where:

Rn is the base register which holds the address of the table of branch lengths.

Rm is a register which holds the index into the table.

A.1.138 TBH

TBH (Table Branch Byte) causes a PC-relative forward branch using a table of halfword offsets. Rn provides a pointer to the table, and Rm supplies an index into the table. The branch length is twice the value of the halfword returned from the table. The target of the branch table must be in the same execution state.

There is no ARM or 16-bit Thumb version of this instruction.

Syntax

TBH [Rn, Rm, LSL #1]

where:

Rn is the base register which holds the address of the table of branch lengths.

Rm is a register which holds the index into the table.

A.1.139 TEQ

TEQ (Test Equivalence) does a bitwise AND operation on the value in Rn and the value of Operand2. This is the same as an ANDS instruction, except that the result is discarded.

Syntax

TEQ{cond}Rn, <0perand2>

where:

cond is an optional condition code. See Section 6.1.2.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.140 TST

TST (Test) does an Exclusive OR operation on the value in Rn and the value of Operand2. This is the same as an EORS instruction, except that the result is discarded.

Syntax

TST{cond}Rn, <0perand2>

where:

cond is an optional condition code. See Section 6.1.2.

Rn is the register holding the first operand.

Operand2 is a flexible second operand. See Section 6.2.1.

A.1.141 UADD8

UADD8 (Unsigned bytewise Add) does an unsigned bytewise addition (4 adds).

Syntax

```
UADD8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.142 UADD16

UADD16 (Unsigned halfword-wise Add) does an unsigned halfword-wise addition (2 adds).

Syntax

```
UADD16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.143 UASX

UASX (Unsigned Add Subtract Exchange) exchanges halfwords of Rm, then adds the top halfwords and subtracts the bottom halfwords.

Syntax

```
UASX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.144 UBFX

UBFX (Unsigned Bit Field Extract) writes adjacent bits from one register into the least significant bits of a second register and zero extends to 32 bits.

Syntax

```
UBFX{cond} Rd, Rn, #1sb, #width
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register which contains the bits to be extracted.

1sb specifies the least significant bit of the bitfield.

width is the width of the bitfield.

A.1.145 UDIV

UDIV (Unsigned Divide). This instruction is not present in the ARMv7-A Architecture.

A.1.146 UHADD8

UHADD8 (Unigned Halving bytewise Add) does an unsigned bytewise addition (4 adds) and halves the results.

Syntax

```
UHADD8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.147 UHADD16

UHADD16 (Unsigned Halving halfword-wise Add) does an unsigned halfword-wise addition (2 adds) and halves the results.

Syntax

```
UHADD16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.148 UHASX

UHASX (Unsigned Halving Add Subtract Exchange) exchanges halfwords of Rm, then adds the top halfwords and subtracts the bottom halfwords and halves the results.

Syntax

```
UHASX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.149 UHSAX

UHSAX (Unsigned Halving Subtract Add Exchange) exchanges halfwords of Rm, then subtracts the top halfwords and adds the bottom halfwords and halves the results.

Syntax

```
UHSAX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.150 UHSUB8

UHSUB8 (Unsigned Halving bytewise Subtraction) does an unsigned bytewise subtraction (4 subtracts) and halves the results.

Syntax

```
UHSUB8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the register holding the operands.

A.1.151 UHSUB16

UHSUB16 (Unsigned Halving halfword-wise Subtract) does an unsigned halfword-wise subtraction (2 subtracts) and halves the result.

Syntax

```
UHSUB16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.152 UMAAL

UMAAL (Unsigned Multiply Accumulate Long; $64 \le 32 + 32 + 32 \times 32$) multiplies Rn and Rm (treated as unsigned integers) adds the two 32-bit values in RdHi and RdLo, and stores the 64-bit result to RdLo, RdHi.

Syntax

```
UMAAL{cond} RdLo, RdHi, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.153 UMLAL

UMLAL (Unsigned Multiply Accumulate $64 \le 64 + 32 \times 32$) multiplies Rn and Rm (treated as unsigned integers) and adds the 64-bit result to the 64-bit unsigned integer contained in RdHi and RdLo.

Syntax

```
UMLAL{S}{cond} RdLo, RdHi, Rn, Rm
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.154 UMULL

UMULL (Unsigned Multiply; $64 \le 32 \times 32$) multiplies Rn and Rm (treated as unsigned integers) and stores the least significant 32 bits of the result in RdLo, and the most significant 32 bits of the result in RdHi.

Syntax

```
UMULL{S}{cond} RdLo, RdHi, Rn, Rm
```

where:

S (if specified) means that the condition code flags will be updated depending upon the result of the instruction.

cond is an optional condition code. See Section 6.1.2.

RdLo and RdHi are the destination registers.

Rn is the register holding the first multiplicand.

Rm is the register holding the second multiplicand.

A.1.155 UND

UND is a pseudo-instruction which generates an instruction opcode defined as "undefined", which, if executed, will cause the Undef exception to occur.

Syntax

```
UND{cond}{.W} expr
```

where:

cond is an optional condition code. See Section 6.1.2.

.W forces generation of a 32-bit instruction in Thumb-2.

expr is a numeric value.

A.1.156 UQADD8

UQADD8 (Saturating Unsigned bytewise Add) does an unsigned bytewise addition (4 adds) and saturates the results to the unsigned range $0 \le x \le 2^8$ -1. The Q flag is not affected by this instruction.

Syntax

```
UQADD8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.157 UQADD16

UQADD16 (Saturating Unsigned halfword-wise Add) does an unsigned halfword-wise addition (2 adds) and saturates the results to the unsigned range $0 \le x \le 2^{16}$ -1. The Q flag is not affected by this instruction.

Syntax

```
UQADD16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the register holding the operands.

A.1.158 UQASX

UQASX (Saturating Unsigned Add Subtract Exchange) exchanges halfwords of Rm, then adds the top halfwords and subtracts the bottom halfwords and saturates the results to the unsigned range $0 \le x \le 2^{16}$ -1. The Q flag is not affected by this instruction.

Syntax

```
UQASX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.159 UQSAX

UQSAX (Saturating Unsigned Subtract Add Exchange) exchanges the halfwords of Rm, then subtracts the top halfwords and adds the bottom halfwords and saturates the results to the signed range $0 \le x \le 2^{16}$. The Q flag is not affected by this instruction.

Syntax

```
QSAX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.160 UQSUB8

UQSUB8 (Saturating Unsigned bytewise Subtract) does bytewise subtraction (4 subtracts), with saturation of the results to the unsigned range $0 \le x \le 28$ -1. The Q flag is not affected by this instruction.

Syntax

```
UQSUB8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.161 UQSUB16

UQSUB16 (Saturating Unsigned halfword Subtract) does halfword-wise subtraction (2 subtracts), with saturation of the results to the unsigned range $0 \le x \le 216$ -1. The Q flag is not affected by this instruction.

Syntax

```
UQSUB16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.162 USAD8

USAD8 (Unsigned Sum of Absolute Differences) finds the four differences between the unsigned values in corresponding bytes of Rn and Rm and adds the absolute values of the four differences, and stores the result in Rd.

Syntax

```
USAD8{cond} Rd, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Rm is the register holding the second operand.

A.1.163 USADA8

USADA8 (Unsigned Sum of Absolute Differences Accumulate) finds the four differences between the unsigned values in corresponding bytes of Rn and Rm and adds the absolute values of the four differences to the value in Ra, and stores the result in Rd.

See Sum of absolute differences on page 6-14 for more information.

Syntax

```
USADA8{cond} Rd, Rn, Rm, Ra
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the first operand.

Rm is the register holding the second operand.

Ra is the register which holds the accumulate value.

A.1.164 USAT

USAT (Unsigned Saturate) performs a shift and saturates the result to the signed range $0 \le x \le 2^{\text{sat}}$ -1. If saturation occurs, the Q flag is set.

Syntax

```
USAT{cond} Rd, #sat, Rm{, shift}
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

sat specifies the bit position to saturate to, in the range 0 to 3q.

Rm is the register holding the operand.

shift is optional shift amount and can be either ASR #n where n is in the range (1-32 ARM state, 1-31 Thumb state) or LSL #n where n is in the range (0-31).

A.1.165 USAT16

USAT16 (Unigned Saturate, parallel halfwords) saturates each unsigned halfword to the signed range $0 \le x \le 2^{sat}$ -1. If saturation occurs, the Q flag is set.

Syntax

```
USAT16{cond} Rd, #sat, Rn
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

sat specifies the bit position to saturate to, in the range 0 to 3q.

Rn is the register holding the operand.

A.1.166 USAX

USAX (Unsigned Subtract Add Exchange) exchanges halfwords of Rm, then subtracts the top halfwords and adds the bottom halfwords.

Syntax

```
USAX{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.167 USUB8

USUB8 (Unsigned bytewise Subtraction) does an unsigned bytewise subtraction (4 subtracts).

Syntax

```
USUB8{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.168 USUB16

USUB16 (Unsigned halfword-wise Subtract) does an unsigned halfword-wise subtraction (2 subtracts).

Syntax

```
USUB16{cond} {Rd}, Rn, Rm
```

where:

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm and Rn are the registers holding the operands.

A.1.169 UXT

UXT (Unsigned Extend) extracts the specified byte and zero extends to 32-bit.

Syntax

```
UXT<extend>{cond} {Rd}, Rm {,rotation}
```

where:

extend must be one of:

- B16 Extends two 8-bit values to two 16-bit values.
- B Extends an 8-bit value to a 32-bit value.
- H Extends a 16-bit value to a 32-bit value.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rm is the register which contains the value to be extended.

rotation can be one of ROR #8, ROR #16 or ROR #24 (or may be omitted).

A.1.170 UXTA

UXTA (Unigned Extend and Add) extracts the specified byte, adds the value from Rn and zero extends to 32-bit.

Syntax

```
UXTA<extend>{cond} {Rd}, Rn, Rm {,rotation}
```

where:

extend must be one of

- B16 Extends two 8-bit values to two 16-bit values.
- B Extends an 8-bit value to a 32-bit value.
- H Extends a 16-bit value to a 32-bit value.

cond is an optional condition code. See Section 6.1.2.

Rd is the destination register.

Rn is the register holding the value to be added.

Rm is the register which contains the value to be extended.

rotation can be one of ROR #8, ROR #16 or ROR #24 (or may be omitted).

A.1.171 WFE

WFE (Wait for Event). If the Event Register is not set, WFE suspends execution until one of the following events occurs:

- an IRQ interrupt (even when CPSR I-bit is set)
- an FIQ interrupt(even when CPSR F-bit is set)
- an Imprecise Data abort (not when masked by the CPSR A-bit)
- Debug Entry request, even when debug is disabled.
- an Event signaled by another processor using the SEV instruction.

If the Event Register is set, WFE clears it and returns immediately.

Syntax

```
WFE {cond}
```

where:

cond is an optional condition code. See Section 6.1.2.

A.1.172 WFI

WFI (Wait For Interrupt) suspends execution until one of the following events occurs:

- an IRQ interrupt (even when CPSR I-bit is set)
- an FIQ interrupt (even when CPSR F-bit is set)
- an Imprecise Data abort (not when masked by the CPSR A-bit)
- Debug Entry request, even when debug is disabled.

If the Event Register is set, WFE clears it and returns immediately.

Syntax

```
WFI {cond}
```

where:

cond is an optional condition code. See Section 6.1.2.

A.1.173 YIELD

YIELD indicates to the hardware that the current thread is performing a task that can be swapped out (for example, a spinlock). Hardware could use this hint to suspend and resume threads in a multithreading system.

Syntax

```
YIELD {cond}
```

where:

cond is an optional condition code. See Section 6.1.2.

Appendix B **NEON and VFP Instruction Summary**

This appendix provides a summary of the assembly language instructions available to the NEON and VFP programmer. It groups the instructions into the following classifications:

For each instruction, we provide a description of the syntax, operands and behavior. Not all usage restrictions are documented here, nor do we show the associated binary encoding. For most instructions, further explanation may be found in Chapter 19 and Chapter 20.

This appendix is intended for quick reference. If more detail about the precise operation of an instruction is required, please refer to the ARM *Architecture Reference Manual*, or to the official ARM documentation (for example the *Assembler Reference Guide*) which may be found at, http://infocenter.arm.com/

We divide the NEON and VFP instructions into a number of sections:

- *NEON general data processing instructions* on page B-6
- *NEON shift instructions* on page B-12
- *NEON logical and compare operations* on page B-16
- *NEON arithmetic instructions* on page B-22
- *NEON multiply instructions* on page B-31
- *NEON load and store element and structure instructions* on page B-34
- VFP instructions on page B-40
- *NEON and VFP pseudo-instructions* on page B-46.

Within each of these groups, instructions are listed alphabetically. Table B-1 shows an alphabetic listing of all NEON and VFP instructions, showing which section of this appendix describes them and which instruction sets support the instruction.

Table B-1 NEON and VFP instructions

Instruction	Section	Instruction set
V{Q}{R}SHL	B2	NEON
V{Q}ABS	B4	NEON
V{Q}ADD	B4	NEON
V{Q}MOVN	B1	NEON
V{Q}SUB	B4	NEON
V{R}ADDHN	B4	NEON
V{R}HADD	B4	NEON
V{R}SHR{N}	B2	NEON
V{R}SRA	B2	NEON
V{R}SUBHN	B4	NEON
VABA{L}	B4	NEON
VABD{L}	B4	NEON
VABS	В7	VFP
VACGE	В3	NEON
VACGT	В3	NEON
VACLE	В8	NEON
VACLT	В8	NEON
VADD	В7	VFP
VADDL	B4	NEON
VADDW	B4	NEON
VAND	В3	NEON
	В8	NEON
VBIC	В3	NEON
VBIF	В3	NEON
VBIT	В3	NEON
VBSL	В3	NEON
VCEQ	В3	NEON
VCGE	В3	NEON
VCGT	В3	NEON

Table B-1 NEON and VFP instructions (continued)

VCLE B3 NEON B8 NEON VCLS B4 NEON VCLT B3 NEON B8 NEON VCLZ B4 NEON VCMP B7 VFP VCNT B4 NEON VCVT B1 NEON VCVT B7 VFP VDUP B1 NEON VEOR B3 NEON VEXT B1 NEON VFP VFP VFMA B5 NEON B7 VFP VFMS B5 NEON B7 VFP VFNMS B7 VFP VFNMS B7 VFP VLD B8 NEON, VFP VLD B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 <	Instruction	Section	Instruction set
VCLT B4 NEON VCLT B3 NEON B8 NEON VCLZ B4 NEON VCMP B7 VFP VCNT B4 NEON VCVT B1 NEON B7 VFP VDIV B7 VFP VDIV B7 VFP VDIV B1 NEON VEOR B3 NEON VEAT B1 NEON VEMA B5 NEON B7 VFP VFMA B7 VFP VFNMS B7 VFP VFNMS B7 VFP VFNMS B7 VFP VFNMS B7 VFP VLD B8 NEON, VFP VLD B8 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VM	VCLE	В3	NEON
VCLT B3 NEON B8 NEON VCLZ B4 NEON VCMP B7 VFP VCNT B4 NEON VCVT B1 NEON B7 VFP VCVTT B7 VFP VDIV B7 VFP VDIV B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFMS B5 NEON B7 VFP VFNMS B7 VFP VFNMS B7 VFP VLD B8 NEON, VFP VLD B8 NEON, VFP VLD B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMLA B7 VFP VMLA B7 VFP VMLS B7 </td <td></td> <td>B8</td> <td>NEON</td>		B8	NEON
B8	VCLS	B4	NEON
VCLZ B4 NEON VCMP B7 VFP VCNT B4 NEON VCVT B1 NEON B7 VFP VCVTB B7 VFP VDIV B7 VFP VDIV B7 VFP VDIP B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFNMS B4 NEON VLD B8 NEON, VFP VLD B8 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMLA B7 VFP VMLA B7 VFP	VCLT	В3	NEON
VCMP B7 VFP VCNT B4 NEON VCVT B1 NEON B7 VFP VCVTB B7 VFP VCVTT B7 VFP VDUV B7 VFP VDUP B1 NEON VEOR B3 NEON VEYT B1 NEON VFMA B5 NEON B7 VFP VFNMS B7 VFP VFNMS B7 VFP VFNMS B7 VFP VFNMS B7 VFP VLD B8 NEON VLD B8 NEON, VFP VLD B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMLA B7 VFP VMLA B7 VFP VMLA B7 VFP		B8	NEON
VCNT B4 NEON VCVT B1 NEON B7 VFP VCVTB B7 VFP VCVTT B7 VFP VDIV B7 VFP VDIV B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFNMS B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLD B8 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA B7 VFP VMLS B7 VFP	VCLZ	B4	NEON
VCVT B1 NEON B7 VFP VCVTB B7 VFP VCVTT B7 VFP VDIV B7 VFP VDIV B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFNMS B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA B7 VFP VMLS B7 VFP	VCMP	В7	VFP
VCVTB B7 VFP VCVTT B7 VFP VDIV B7 VFP VDUP B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFNMS B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLD B8 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMLA B7 VFP VMLA B7 VFP VMLS B7 VFP	VCNT	B4	NEON
VCVTB B7 VFP VCVTT B7 VFP VDIV B7 VFP VDUP B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFNMS B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLD B8 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMLA B7 VFP VMLA B7 VFP VMLS B7 VFP	VCVT	B1	NEON
VCVTT B7 VFP VDIV B7 VFP VDUP B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFNMS B5 NEON B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLD B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP		В7	VFP
VDIV B7 VFP VDUP B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFNMS B5 NEON B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VCVTB	В7	VFP
VDUP B1 NEON VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFMS B5 NEON B7 VFP VFNMA B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VCVTT	В7	VFP
VEOR B3 NEON VEXT B1 NEON VFMA B5 NEON B7 VFP VFMS B5 NEON B7 VFP VFNMA B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA{L} B5 NEON VMLS B7 VFP	VDIV	В7	VFP
VEXT B1 NEON VFMA B5 NEON B7 VFP VFMS B5 NEON B7 VFP VFNMA B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA{L} B5 NEON VMLS B7 VFP	VDUP	B1	NEON
VFMA B5 NEON B7 VFP VFMS B5 NEON B7 VFP VFNMA B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VEOR	В3	NEON
B7 VFP VFMS B5 NEON B7 VFP VFNMA B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VEXT	B1	NEON
VFMS B5 NEON B7 VFP VFNMA B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VFMA	B5	NEON
B7 VFP VFNMA B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP		В7	VFP
VFNMA B7 VFP VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VFMS	B5	NEON
VFNMS B7 VFP VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP		B7	VFP
VHSUB B4 NEON VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VFNMA	В7	VFP
VLD B8 NEON, VFP VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VFNMS	В7	VFP
VLDM B6 NEON, VFP VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VHSUB	B4	NEON
VLDR B6 NEON, VFP VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VLD	В8	NEON, VFP
VMAX B4 NEON VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VLDM	В6	NEON, VFP
VMIN B4 NEON VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VLDR	В6	NEON, VFP
VMLA B7 VFP VMLA{L} B5 NEON VMLS B7 VFP	VMAX	B4	NEON
VMLA{L} B5 NEON VMLS B7 VFP	VMIN	B4	NEON
VMLS B7 VFP	VMLA	В7	VFP
	VMLA{L}	B5	NEON
VMLS{L} B5 NEON	VMLS	B7	VFP
	VMLS{L}	B5	NEON

Table B-1 NEON and VFP instructions (continued)

Instruction	Section	Instruction set
VMOV	B1	NEON
	В3	NEON
	B7	VFP
	В6	NEON, VFP
VMOV2	В8	NEON
VMOVL	B1	NEON
VMRS	В6	NEON, VFP
	В6	NEON, VFP
VMUL	В7	VFP
VMUL{L}	B5	NEON
VMVN	B1	NEON
	В3	NEON
VNEG	В7	VFP
VNMLA	В7	VFP
VNMLS	В7	VFP
VNMUL	В7	VFP
VORN	В3	NEON
	В8	NEON
VORR	В3	NEON
VPADAL	B4	NEON
VPADD{L}	B4	NEON
VPMAX	B4	NEON
VPMIN	B4	NEON
VPOP	B6	NEON, VFP
VPUSH	В6	NEON, VFP
VQ{R}DMULH	B5	NEON
VQ{R}SHR{U}N	B2	NEON
VQDMLAL	В5	NEON
VQDMLSL	B5	NEON
VQDMULL	B5	NEON
VQMOVUN	B1	NEON
VQSHL	B2	NEON
VQSHLU	B2	NEON

Table B-1 NEON and VFP instructions (continued)

Instruction	Section	Instruction set
VRECPE	B4	NEON
VRECPS	B4	NEON
VREV	B1	NEON
VRSQRTE	B4	NEON
VRSQRTS	B4	NEON
VSHL	B2	NEON
VSHLL	B2	NEON
VSLI	B2	NEON
VSQRT	В7	VFP
VSRI	B2	NEON
VST	В8	NEON, VFP
VSTM	В6	NEON, VFP
VSTR	В6	NEON, VFP
VSUB	В7	VFP
VSUBL	B4	NEON
VSUBW	B4	NEON
VSWP	B1	NEON
VTBL	B1	NEON
VTBX	B1	NEON
VTRN	B1	NEON
VTST	В3	NEON
VUZP	B1	NEON
VZIP	B1	NEON

B.1 NEON general data processing instructions

This section covers NEON data processing instructions, including those which extract or manipulate values in registers, perform type conversion or other operations.

B.1.1 VCVT (fixed-point or integer to floating-point)

VCVT (Vector Convert) converts each element in a vector and places the results in the destination vector. The possible conversions are:

- floating-point to integer
- integer to floating-point
- floating-point to fixed-point
- fixed-point to floating-point.

Integer or fixed-point to floating-point conversions use round to nearest.

Floating-point to integer or fixed-point conversions use round towards zero.

Syntax

```
VCVT{cond}.type Qd, Qm {, #fbits}
VCVT{cond}.type Dd, Dm {, #fbits}
```

This instruction must be unconditional.

where:

type specifies the data types for the elements of the vectors and can be:

- S32.F32 floating-point to signed integer or fixed-point
- U32.F32 floating-point to unsigned integer or fixed-point
- F32.S32 signed integer or fixed-point to floating-point
- F32.U32 unsigned integer or fixed-point to floating-point.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

fbits specifies the number of fraction bits in the fixed point number, in the range 0-32. If fbits is not present, the conversion is between floating-point and integer.

B.1.2 VCVT (between half-precision and single-precision floating-point)

VCVT (Vector Convert), with half-precision extension, converts each element in a vector and places the results in the destination vector. The conversion can be:

- from half-precision floating-point to single-precision floating-point (F32.F16)
- single-precision floating-point to half-precision floating-point (F16.F32)

This instruction is present only in NEON systems with the half-precision extension.

Syntax

```
VCVT{cond}.F32.F16 Qd, Dm
VCVT{cond}.F16.F32 Dd, Qm
```

where:

Qd and Dm specify the destination vector for the single-precision results and the half-precision operand vector.

Dd and Qm specify the destination vector for half-precision results and the single-precision operand vector.

B.1.3 VDUP

VDUP (Vector Duplicate) duplicates a scalar into every element of the destination vector. The source may be either a NEON scalar or an ARM register.

Syntax

```
VDUP{cond}.size Qd, Dm[x]
VDUP{cond}.size Dd, Dm[x]
VDUP{cond}.size Qd, Rm
VDUP{cond}.size Dd, Rm
```

where:

size is 8, 16, or 32.

Qd specifies the destination register for a quadword operation.

Dd specifies the destination register for a doubleword operation.

Dm[x] specifies the NEON scalar or Rm the ARM register.

B.1.4 VEXT

VEXT (Vector Extract) extracts 8-bit elements from the bottom end of the second operand vector and the top end of the first, concatenates them, and stores the result in the destination vector.

Syntax

```
\begin{tabular}{lll} VEXT\{cond\}.8 & \{Qd\}, & Qn, & Qm, & \#imm \\ VEXT\{cond\}.8 & \{Dd\}, & Dn, & Dm, & \#imm \\ \end{tabular}
```

This instruction must be unconditional.

where:

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

imm gives the number of 8-bit elements to extract from the bottom of the second operand vector, between 0-7 for doubleword operations, or 0-15 for quadword operations.

VEXT may also be written as a pseudo-instruction. In this case, a datatype of 16, 32, or 64 may be used and #imm refers to halfwords, words, or doublewords, with a corresponding reduction in the permitted range.

B.1.5 VMOV (immediate)

VMOV (Vector Bitwise Move) immediate, places an immediate value into every element of the destination register.

Syntax

```
VMOV{cond}.datatype Qd, #imm
VMOV{cond}.datatype Dd, #imm
```

This instruction must be unconditional.

where:

datatype is 18, 116, 132, 164, or F32.

Qd or Dd specify the NEON register for the result.

imm is an immediate value of the type specified by datatype, which is replicated to fill the destination register.

B.1.6 VMVN (immediate)

VMVN (Vector Bitwise NOT) immediate, places the bitwise inverse of an immediate integer value into every element of the destination register.

Syntax

```
VMVN{cond}.datatype Qd, #imm
VMVN{cond}.datatype Dd, #imm
```

This instruction must be unconditional.

where:

datatype is one of I8, I16, I32, I64, or F32.

Qd or Dd specify the NEON register for the result.

imm is an immediate value of the type specified by datatype, which is replicated to fill the destination register.

B.1.7 VMOVL, V{Q}MOVN, VQMOVUN

VMOVL (Vector Move Long) takes each element in a doubleword vector and sign or zero-extends them to twice their original length. The results are stored in a quadword vector.

VMOVN (Vector Move and Narrow) copies the least significant half of each element of a quadword vector into the corresponding element of a doubleword vector.

VQMOVN (Vector Saturating Move and Narrow) copies each element of the operand vector to the corresponding element of the destination. The result element is half the width of the operand element, and values are saturated to the result width.

VQMOVUN (Vector Saturating Move and Narrow, signed operand with Unsigned result) copies each element of the operand vector to the corresponding element of the destination. The result element is half the width of the operand element and values are saturated to the result width.

Syntax

```
VMOVL{cond}.datatype Qd, Dm
V{Q}MOVN{cond}.datatype Dd, Qm
VQMOVUN{cond}.datatype Dd, Qm
```

This instruction must be unconditional.

where:

Q specifies that the results are saturated.

datatype is one of:

- S8, S16, S32 for VMOVL
- U8, U16, U32 for VMOVL
- I16, I32, I64 for VMOVN
- F32.U32 unsigned integer or fixed-point to floating-point
- U16, U32, U64 for VQMOVN.

Qd and Dm specify the destination vector and the operand vector for VMOVL.

Dd and Qm specify the destination vector and the operand vector for V{Q}MOV{U}N.

B.1.8 VREV

VREV16 (Vector Reverse halfwords) reverses the order of 8-bit elements within each halfword of the vector and stores the result in the corresponding destination vector.

VREV32 (Vector Reverse words) reverses the order of 8-bit or 16-bit elements within each word of the vector, and stores the result in the corresponding destination vector.

VREV64 (Vector Reverse doublewords) reverses the order of 8-bit, 16-bit, or 32-bit elements within each doubleword of the vector, and stores the result in the destination vector.

Syntax

```
VREVn{cond}.size Qd, Qm
VREVn{cond}.size Dd, Dm
```

This instruction must be unconditional.

where:

n is one of 16, 32, or 64.

size is one of 8, 16, or 32, and must be less than n.

Qd and Qm specify the destination and operand registers for a quadword operation.

Dd and Dm specify the destination and operand registers for a doubleword operation.

B.1.9 VSWP

VSWP (Vector Swap) exchanges the contents of two vectors, which can be either doubleword or quadword.

Syntax

```
VSWP{cond}{.datatype} Qd, Qm
VSWP{cond}{.datatype} Dd, Dm
```

This instruction must be unconditional.

where:

Qd and Qm specify the vectors for a quadword operation.

Dd and Dm specify the vectors for a doubleword operation.

B.1.10 VTBL

VTBL (Vector Table Lookup) uses byte indexes in a control vector to look up byte values in a table and generate a new vector. Indexes which are out of range return 0.

Syntax

```
VTBL{cond}.8 Dd, list, Dm
```

This instruction must be unconditional.

where:

Dd specifies the destination vector.

Dm specifies the index vector.

list specifies the vectors containing the table. It is one of:

- {Dn}
- {Dn,D(n+1)}
- {Dn,D(n+1),D(n+2)}
- {Dn,D(n+1),D(n+2),D(n+3)}
- $\{Qn,Q(n+1)\}.$

All of the registers in 1ist must be in the range D0-D31 or Q0-Q15 and are not permitted to wrap around the end of the register bank.

B.1.11 VTBX

VTBX (Vector Table Extension)) uses byte indexes in a control vector to look up byte values in a table and generate a new vector, but leaves the destination element unchanged when an out of range index is used.

Syntax

```
VTBX{cond}.8 Dd, list, Dm
```

This instruction must be unconditional.

where:

Dd specifies the destination vector.

Dm specifies the index vector.

list specifies the vectors containing the table. It is one of:

- {Dn}
- {Dn,D(n+1)}
- {Dn,D(n+1),D(n+2)}
- {Dn,D(n+1),D(n+2),D(n+3)}
- $\{Qn,Q(n+1)\}.$

All of the registers in 1ist must be in the range D0-D31 or Q0-Q15 and are not permitted to wrap around the end of the register bank.

B.1.12 VTRN

VTRN (Vector Transpose) treats the elements of its operand vectors as elements of 2×2 matrices, and transposes them.

Syntax

```
VTRN{cond}.size Qd, Qm
VTRN{cond}.size Dd, Dm
```

This instruction must be unconditional.

where:

size is one of 8, 16, or 32.

Qd and Qm specify the vectors for a quadword operation.

Dd and Dm specify the vectors, for a doubleword operation.

B.1.13 VUZP

VUZP (Vector Unzip) de-interleaves the elements of two vectors.

Syntax

```
VUZP{cond}.size Qd, Qm
VUZP{cond}.size Dd, Dm
```

This instruction must be unconditional.

where:

size is one of 8, 16, or 32.

Qd and Qm specify the vectors for a quadword operation.

Dd and Dm specify the vectors, for a doubleword operation.

B.1.14 VZIP

VZIP (Vector Zip) interleaves the elements of two vectors.

Syntax

```
VZIP{cond}.size Qd, Qm
VZIP{cond}.size Dd, Dm
```

This instruction must be unconditional.

where:

size is one of 8, 16, or 32.

Qd and Qm specify the vectors for a quadword operation.

Dd and Dm specify the vectors, for a doubleword operation.

B.2 NEON shift instructions

This section covers NEON instructions which perform logical shift or insert operations.

B.2.1 VSHL, VQSHL, VQSHLU, and VSHLL (by immediate)

Vector Shift Left (by immediate) instructions take each element in a vector of integers, left shift them by an immediate value, and write the result to the destination vector. The instruction variants are:

- VSHL (Vector Shift Left) discards bits shifted out of the left of each element.
- VQSHL (Vector Saturating Shift Left) sets the sticky QC flag (FPSCR bit[27]) if saturation occurs.
- VQSHLU (Vector Saturating Shift Left Unsigned) sets the sticky QC flag (FPSCR bit[27]) if saturation occurs.
- VSHLL (Vector Shift Left Long) takes each element in a doubleword vector, left shifts them
 by an immediate value, and places the results in a quadword vector.

Syntax

```
V{Q}SHL{U}{cond}.datatype {Qd}, Qm, #imm
V{Q}SHL{U}{cond}.datatype {Qd}, Qm, #imm
VSHLL{cond}.datatype Qd, Dm, #imm
```

This instruction must be unconditional.

where:

Q indicates that results are saturated if they overflow.

U is only permitted if Q is also specified and indicates that the results are unsigned, even though the operands are signed.

datatype is one of:

- 18, I16, I32, I64 for VSHL
- S8, S16, S32 for VSHLL, VQSHL, or VQSHLU
- U8, U16, U32 for VSHLL or VQSHL
- S64 for VQSHL or VQSHLU
- U64 for VQSHL.

Qd and Qm are the destination and operand vectors for a quadword operation.

Dd and Dm are the destination and operand vectors for a doubleword operation.

Qd and Dm are the destination and operand vectors, for a long operation.

imm is the immediate value that sets the size of the shift and must be in the range:

- 1 to size(datatype) for VSHLL
- 1 to (size(datatype) 1) for VSHL, VQSHL, or VQSHLU.

A shift of 0 is permitted, but the code disassembles to VMOV or VMOVL.

B.2.2 V{Q}{R}SHL (by signed variable)

VSHL (Vector Shift Left by signed variable) shifts each element in a vector by a value from the least significant byte of the corresponding element of a second vector, and stores the results in the destination vector. If the shift value is positive, the operation is a left shift. Otherwise, it is a right shift. The results can be optionally saturated, rounded, or both. The sticky QC flag is set if saturation occurs.

Syntax

```
V{Q}{R}SHL{cond}.datatype {Qd}, Qm, Qn V{Q}{R}SHL{cond}.datatype {Dd}, Dm, Dn
```

This instruction must be unconditional.

where:

Q indicates that results are saturated if they overflow.

R indicates that each result is rounded. If R is not specified, each result is truncated.

datatype is one of S8, S16, S32, S64, U8, U16, U32, or U64.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.2.3 V{R}SHR{N}, V{R}SRA (by immediate)

V{R}SHR{N} (Vector Shift Right by immediate value) right shifts each element in a vector by an immediate value and stores the results in the destination vector. The results can be optionally rounded, or narrowed, or both.

V{R}SRA (Vector Shift Right by immediate value and Accumulate) right shifts each element in a vector by an immediate value, and accumulates the results into the destination vector. The results can be optionally rounded.

Syntax

```
V{R}SHR{cond}.datatype {Qd}, Qm, #imm
V{R}SHR{cond}.datatype {Dd}, Dm, #imm
V{R}SRA{cond}.datatype {Qd}, Qm, #imm
V{R}SRA{cond}.datatype {Dd}, Dm, #imm
V{R}SHRN{cond}.datatype Dd, Qm, #imm
```

This instruction must be unconditional.

where:

R indicates that the results are rounded. If R is not present, the results are truncated.

datatype is one of:

- S8, S16, S32, S64 for V{R}SHR or V{R}SRA
- U8, U16, U32, U64 for V{R}SHR or V{R}SRA
- I16, I32, I64 for V{R}SHRN.

Qd and Qm are the destination and operand vectors, for a quadword operation.

Dd and Dm are the destination and operand vectors for a doubleword operation.

Dd and Qm are the destination vector and the operand vector, for a narrow operation.

imm is the immediate value specifying the size of the shift, in the range 0 to (size(datatype) -1).

B.2.4 VQ{R}SHR{U}N (by immediate))

VQ{R}SHR{U}N (Vector Saturating Shift Right, Narrow, by immediate value, with optional Rounding) right shifts each element in a quadword vector of integers by an immediate value, and stores the results in a doubleword vector. The sticky QC flag (FPSCR bit[27]) is set if saturation occurs.

Syntax

```
VQ{R}SHR{U}N{cond}.datatype Dd, Qm, #imm
```

This instruction must be unconditional.

where:

R indicates that the results are rounded. If R is not present, the results are truncated.

U indicates that the results are unsigned, although the operands are signed.

datatype is one of:

- S16, S32, S64 for VQ{R}SHRN or VQ{R}SHRUN
- U16, U32, U64 for VQ{R}SHRN only.

Dd and Qm are the destination vector and the operand vector.

imm is the immediate value specifying the size of the shift, in the range 0 to (size(datatype) - 1).

B.2.5 VSLI

VSLI (Vector Shift Left and Insert) left shifts each element in a vector by an immediate value, and inserts the results in the destination vector. Bits shifted out of the left of each element are lost.

Syntax

```
VSLI{cond}.size {Qd}, Qm, #imm
VSLI{cond}.size {Dd}, Dm, #imm
```

This instruction must be unconditional.

where:

size is one of 8, 16, 32, or 64.

Qd and Qm are the destination and operand vectors for a quadword operation.

Dd and Dm are the destination and operand vectors for a doubleword operation.

Dd and Qm are the destination vector and the operand vector.

imm is the immediate value that sets the size of the shift, in the range 0 to (size - 1)

B.2.6 VSRI

VSRI (Vector Shift Right and Insert) right shifts each element in a vector by an immediate value, and inserts the results in the destination vector. Bits shifted out of the right of each element are lost.

Syntax

```
VSRI{cond}.size {Qd}, Qm, #imm VSRI{cond}.size {Dd}, Dm, #imm
```

This instruction must be unconditional.

where:

size is one of 8, 16, 32, or 64.

Qd and Qm are the destination and operand vectors for a quadword operation.

Dd and Dm are the destination and operand vectors for a doubleword operation.

imm is the immediate value that sets the size of the shift, in the range 1 to size.

B.3 NEON logical and compare operations

This section covers NEON instructions which perform bitwise boolean operations and comparisons.

B.3.1 VACGE and VACGT

Vector Absolute Compare takes the absolute value of each element in a vector, and compares it with the absolute value of the corresponding element in a second vector. If the condition is true, the corresponding element in the destination vector is set to all ones. If the condition is not true, it is set to all zeros.

Syntax

```
VACop{cond}.F32 {Qd}, Qn, Qm
VACop{cond}.F32 {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

op is either GE (Absolute Greater than or Equal) or GT (Absolute Greater Than).

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation. The result datatype is 132.

B.3.2 VAND (register)

VAND performs a bitwise logical AND operation between values in two registers, and places the results in the destination register.

Syntax

```
VAND{cond}{.datatype} {Qd}, Qn, Qm
VAND{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is an optional data type, which is ignored by the assembler.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.3 VBIC (immediate)

VBIC (Vector Bitwise Clear immediate) takes each element of the destination vector, does a bitwise AND Complement with an immediate value, and stores the result in the destination vector.

Syntax

```
VBIC{cond}.datatype Qd, #imm
VBIC{cond}.datatype Dd, #imm
```

This instruction must be unconditional.

where:

datatype is one of I8, I16, I32, or I64.

Qd or Dd is the NEON register for the source and result.

imm is the immediate value.

Immediate values can be specified as a pattern which the assembler repeats to fill the destination register. Alternatively, you can specify the entire value, provided it meets certain requirements. The allowed patterns for immediate value are 0x00XY or 0xXY00 for I16, or 0x000000XY, 0x0000XY00, 0x00XY00000 or 0xXY000000 for I32. If you choose I8 or I64 datatypes, the assembler produces the I16 or I32 equivalent.

B.3.4 VBIC (register)

VBIC (Vector Bitwise Clear) performs a bitwise logical AND complement operation between values in two registers, and places the results in the destination register.

Syntax

```
VBIC{cond}{.datatype} {Qd}, Qn, Qm
VBIC{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is an optional data type, which is ignored by the assembler.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.5 VBIF

VBIF (Vector Bitwise Insert if False) inserts each bit from the first operand into the destination, if the corresponding bit of the second operand is 0, otherwise it does not change the destination bit.

Syntax

```
VBIF{cond}{.datatype} {Qd}, Qn, Qm
VBIF{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is an optional data type, which is ignored by the assembler.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.6 VBIT

VBIT (Vector Bitwise Insert if True) inserts each bit from the first operand into the destination if the corresponding bit of the second operand is 1, otherwise it does not change the destination bit.

Syntax

```
VBIT{cond}{.datatype} {Qd}, Qn, Qm
VBIT{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is an optional data type, which is ignored by the assembler.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.7 VBSL

VBSL (Vector Bitwise Select) selects each destination bit from the first operand if the corresponding destination bit was 1 or from the second operand if the corresponding destination bit was 0.

Syntax

```
VBSL{cond}{.datatype} {Qd}, Qn, Qm
VBSL{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is an optional data type, which is ignored by the assembler.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.8 VCEQ, VCGE, VCGT, VCLE, and VCLT

Vector Compare takes each element in a vector and compares it with the corresponding element of a second vector (or zero). If the condition is true, the corresponding element in the destination vector is set to all ones. Otherwise, it is set to all zeros.

Syntax

```
VCop{cond}.datatype {Qd}, Qn, Qm
VCop{cond}.datatype {Dd}, Dn, Dm
VCop{cond}.datatype {Qd}, Qn, #0
VCop{cond}.datatype {Dd}, Dn, #0
```

This instruction must be unconditional.

where:

op is one of:

- EQ, Equal
- GE, Greater than or Equal
- GT, Greater Than
- LE, Less than or Equal (only if the second operand is #0)
- LT, Less Than (only if the second operand is #0).

datatype is one of:

- I8, I16, I32, or F32 for VCEQ
- S8, S16, S32, U8, U16, U32, or F32 for VCGE, VCGT, VCLE, or VCLT (except #0 form)
- S8, S16, S32, or F32 for VCGE, VCGT, VCLE, or VCLT (#0 form).

The result datatype is:

- I32 for operand datatypes I32, S32, U32, or F32
- I16 for operand datatypes I16, S16, or U16
- I8 for operand datatypes I8, S8, or U8.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation. #0 replaces Qm or Dm for comparisons with zero.

B.3.9 VEOR (register)

VEOR performs a bitwise logical exclusive OR operation between values in two registers, and places the results in the destination register.

Syntax

```
VEOR{cond}{.datatype} {Qd}, Qn, Qm
VEOR{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.10 VMOV (register)

VMOV, Vector Move (register) copies a value from a source register to a destination register.

Syntax

```
VMOV{cond}{.datatype} Qd, Qm
VMOV{cond}{.datatype} Dd, Dm
```

This instruction must be unconditional.

where:

Qd and Qm specify the destination vector and the source vector, for a quadword operation.

Dd and Dm specify the destination and source vector, for a doubleword operation.

B.3.11 VMVN (register)

VMVN, Vector Bitwise NOT (register) inverts the value of each bit from the source register and stores the result to the destination register.

Syntax

```
VMVN{cond}{.datatype} Qd, Qm
VMVN{cond}{.datatype} Dd, Dm
```

This instruction must be unconditional.

where:

Qd and Qm specify the destination vector and the source vector, for a quadword operation.

Dd and Dm specify the destination and source vector, for a doubleword operation.

B.3.12 VORN (register)

VORN performs a bitwise logical OR NOT operation between values in two registers, and places the results in the destination register.

Syntax

```
VORN{cond}{.datatype} {Qd}, Qn, Qm
VORN{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.13 VORR (immediate)

VORR (Bitwise OR immediate) takes each element of the destination vector, does a bitwise OR with an immediate value, and stores the result into the destination vector.

Syntax

```
VORR{cond}.datatype Qd, #imm
VORR{cond}.datatype Dd, #imm
```

This instruction must be unconditional.

where:

datatype is one of 18, 116, 132, or 164.

Qd or Dd is the NEON register for the source and result.

imm is the immediate value.

Immediate values may be specified as a pattern which the assembler repeats to fill the destination register. Alternatively, you can specify the entire value, provided it meets certain requirements. The allowed patterns for immediate value are 0x00XY or 0xXY00 for I16, or 0x000000XY, 0x000XY00, 0x00XY0000 or 0xXY000000 for I32. If you choose I8 or I64 datatypes, the assembler produces the I16 or I32 equivalent.

B.3.14 VORR (register)

VORR performs a bitwise logical OR operation between values in two registers, and places the results in the destination register.

Syntax

```
VORR{cond}{.datatype} {Qd}, Qn, Qm
VORR{cond}{.datatype} {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.3.15 VTST

VTST (Vector Test Bits) takes each element in a vector and does a bitwise AND with the corresponding element in a second vector. If the result is zero, the corresponding element in the destination vector is set to all zeros. Otherwise, it is set to all ones.

Syntax

```
VTST{cond}.size {Qd}, Qn, Qm
VTST{cond}.size {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

size is one of 8, 16, or 32.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

 $\,$ Dd, $\,$ Dn, and $\,$ Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.4 NEON arithmetic instructions

This section describe NEON instructions which perform arithmetic operations such as addition, subtraction, reciprocal calculation etc

B.4.1 VABA{L}

VABA (Vector Absolute Difference and Accumulate) subtracts the elements of one vector from the corresponding elements of another and accumulates the absolute values of the results into the elements of the destination vector. A Long version of this instructions is available.

Syntax

```
VABA{cond}.datatype {Qd}, Qn, Qm
VABA{cond}.datatype {Dd}, Dn, Dm
VABAL{cond}.datatype Qd, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is one of S8, S16, S32, U8, U16, or U32.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

Qd, Dn and Dm specify the destination, first operand and second operand vectors for a long operation.

B.4.2 VABD{L}

VABD (Vector Absolute Difference) subtracts the elements of one vector from the corresponding elements of another and places the absolute values of the results into the elements of the destination vector. A long version of the instruction is available.

Syntax

```
VABD{cond}.datatype {Qd}, Qn, Qm
VABD{cond}.datatype {Dd}, Dn, Dm
VABDL{cond}.datatype Qd, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is one of:

- S8, S16, S32, U8, U16, U32 or F32 for VABD
- S8, S16, S32, U8, U16, or U32 for VABDL.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

Qd, Dn, and Dm specify the destination, first operand and second operand vectors for a long operation.

B.4.3 V{Q}ABS

VABS (Vector Absolute) takes the absolute value of each element in a vector, and stores the results in the destination. The floating-point version only clears the sign bit. A saturating version of the instructions is available. The sticky QC flag is set if saturation occurs.

Syntax

```
V{Q}ABS{cond}.datatype Qd, Qm
V{Q}ABS{cond}.datatype Dd, Dm
```

This instruction must be unconditional.

where:

Q indicates that saturation is performed if any of the results overflow.

datatype is one of:

- S8, S16, S32 for VABS or VQABS
- F32 for VABS only.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.4 V{Q}ADD, VADDL, VADDW

VADD (Vector Add) adds corresponding elements in two vectors, and stores the results in the destination vector. VADD has long, wide and saturating variants.

Syntax

```
 V\{Q\} ADD\{cond\}. datatype \ \{Qd\}, \ Qn, \ Qm \ ; \ Saturating \ instruction \\ V\{Q\} ADD\{cond\}. datatype \ \{Dd\}, \ Dn, \ Dm \ ; \ Saturating \ instruction \\ VADDL\{cond\}. datatype \ Qd, \ Dn, \ Dm \ ; \ Long \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\ VADDW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Pm \ ; \ Wall \ \{Qd\}, \ Qn, \ Pm \ ; \ Wall \ \{Qd\}, \ Qn, \ Pm \ ; \ Wall \ \{Qd\}, \ Qn, \ Pm \ ; \ Wall \ YADDW\{cond\}, \ Wall \ YADDW\{c
```

This instruction must be unconditional.

where:

Q indicates that saturation is performed if any of the results overflow.

datatype is one of:

- I8, I16, I32, I64, F32 for VADD
- S8, S16, S32 for VQADD, VADDL or VADDW
- U8, U16, U32 for VQADD, VADDL or VADDW
- S64, U64 for VQADD.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

Qd, Dn, and Dm specify the destination, first operand and second operand vectors for a long operation.

B.4.5 V{R}ADDHN

V{R}ADDHN (Vector Add and Narrow, selecting High half) adds corresponding elements in two vectors, selects the most significant halves of the results, and stores them in the destination vector.

Syntax

```
V{R}ADDHN{cond}.datatype Dd, Qn, Qm
```

This instruction must be unconditional.

where:

R specifies that each result is rounded. If R is not specified, each result is truncated.

datatype is one of I16, I32, or I64.

Dd, Qn, and Qm are the destination vector, the first operand vector, and the second operand vector.

B.4.6 VCLS

VCLS (Vector Count Leading Sign Bits) counts the number of consecutive bits following the topmost bit that are the same as that bit, in each element in a vector, and stores the results in a destination vector.

Syntax

```
VCLS{cond}.datatype Qd, Qm
VCLS{cond}.datatype Dd, Dm
```

This instruction must be unconditional.

where:

datatype is one of S8, S16, or S32.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.7 VCLZ

VCLZ (Vector Count Leading Zeros) counts the number of consecutive zeros, starting from the top bit, in each element in a vector, and stores the results in a destination vector.

Syntax

```
VCLZ{cond}.datatype Qd, Qm
VCLZ{cond}.datatype Dd, Dm
```

This instruction must be unconditional.

where:

datatype is one of S8, S16, or S32.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.8 VCNT

VCNT (Vector Count Set Bits) counts the number of bits that are one in each element in a vector, and stores the results in a destination vector.

Syntax

```
VCNT{cond}.datatype Qd, Qm
VCNT{cond}.datatype Dd, Dm
```

This instruction must be unconditional.

where:

datatype must be I8.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.9 V{R}HADD

VHADD (Vector Halving Add) adds corresponding elements in two vectors, shifts each result right one bit and stores the results in the destination vector. Results can be either rounded or truncated.

Syntax

```
V{R}HADD{cond}.datatype {Qd}, Qn, Qm
V{R}HADD{cond}.datatype {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

R specifies that each result is rounded. If R is not specified, each result is truncated.

datatype is one of S8, S16, S32, U8, U16, or U32.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.4.10 VHSUB

VHSUB (Vector Halving Subtract) subtracts the elements of one vector from the corresponding elements of another vector, shifts each result right one bit, and stores the result in the destination vector. Results are always truncated.

Syntax

```
VHSUB{cond}.datatype {Qd}, Qn, Qm
VHSUB{cond}.datatype {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is one of S8, S16, S32, U8, U16, or U32.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.4.11 VMAX and VMIN

VMAX (Vector Maximum) compares corresponding elements in two vectors, and writes the larger of them into the corresponding element in the destination vector.

VMIN (Vector Minimum) compares corresponding elements in two vectors, and writes the smaller value into the corresponding element in the destination vector.

Syntax

```
VMAX{cond}.datatype Qd, Qn, Qm
VMAX{cond}.datatype Dd, Dn, Dm
VMIN{cond}.datatype Qd, Qn, Qm
VMIN{cond}.datatype Dd, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is one of S8, S16, S32, U8, U16, U32, or F32.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.4.12 V{Q}NEG

VNEG (Vector Negate) negates each element in a vector, and places the results in a second vector. The floating-point version only inverts the sign bit. A saturating version of the instruction is available. The sticky QC flag is set if saturation occurs.

Syntax

```
V{Q}NEG{cond}.datatype Qd, Qm
V{Q}NEG{cond}.datatype Dd, Dm
```

where:

Q indicates that saturation is performed if any of the results overflow.

datatype is one of:

- S8, S16, S32 for VNEG, or VQNEG
- F32 or F64 for VNEG.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.13 VPADD{L}, VPADAL

VPADD (Vector Pairwise Add) adds adjacent pairs of elements of two vectors, and stores the results in the destination vector.

VPADDL (Vector Pairwise Add Long) adds adjacent pairs of elements of a vector, sign or zero extends the results to twice their original width and stores the results in the destination vector.

VPADAL (Vector Pairwise Add and Accumulate Long) adds adjacent pairs of elements of a vector, and accumulates the results into the elements of the destination vector.

Syntax

```
VPADD{cond}.datatype {Dd}, Dn, Dm
VPopL{cond}.datatype Qd, Qm
VPopL{cond}.datatype Dd, Dm
```

This instruction must be unconditional.

where:

op is either ADD or ADA.

datatype is one of:

- I8, I16, I32, F32 for VPADD
- S8, S16, S32 for VPADDL or VPADAL
- U8, U16, U32 for VPADDL or VPADAL.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a VPADD.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.14 VPMAX and VPMIN

VPMAX (Vector Pairwise Maximum) compares adjacent pairs of elements in two vectors and writes the larger of each pair into the corresponding element in the destination vector.

VPMIN (Vector Pairwise Minimum) compares adjacent pairs of elements in two vectors, and writes the smaller of each pair into the corresponding element in the destination vector. Operands and results must be doubleword vectors for the latter two pairwise operations.

Syntax

```
VPMAX{cond}.datatype Dd, Dn, Dm
VPMIN{cond}.datatype Dd, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is one of S8, S16, S32, U8, U16, U32, or F32.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

B.4.15 VRECPE

VRECPE (Vector Reciprocal Estimate) finds an approximate reciprocal of each element in a vector, and stores the results in a destination vector.

Syntax

```
VRECPE{cond}.datatype Qd, Qm
VRECPE{cond}.datatype Dd, Dm
```

This instruction must be unconditional.

where:

datatype is either U32 or F32.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.16 VRECPS

VRECPS (Vector Reciprocal Step) multiplies the elements of one vector by the corresponding elements of another, subtracts each of the results from 2.0, and stores the final results into the elements of the destination. This instruction is used as part of the Newton-Raphson iteration algorithm.

Syntax

```
VRECPS{cond}.F32 {Qd}, Qn, Qm
VRECPS{cond}.F32 {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

datatype is either U32 or F32.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.17 VRSQRTE

VRSQRTE (Vector Reciprocal Square Root Estimate) finds an approximate reciprocal square root of each element in a vector and stores the results in a destination vector.

Syntax

```
VRSQRTE{cond}.datatype Qd, Qm
VRSQRTE{cond}.datatype Dd, Dm
```

This instruction must be unconditional.

where:

datatype is either U32 or F32.

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.18 VRSQRTS

VRSQRTS (Vector Reciprocal Square Root Step) multiplies the elements of one vector by the corresponding elements of another, subtracts each of the results from 3.0, divides these results by 2.0, and places the final results into the elements of the destination. This instruction is used as part of the Newton-Raphson iteration algorithm.

Syntax

```
VSQRTS{cond}.F32 {Qd}, Qn, Qm
VSQRTS{cond}.F32 {Dd}, Dn, Dm
```

This instruction must be unconditional.

where:

Qd and Qm specify the destination and operand vectors for a quadword operation.

Dd and Dm specify the destination and operand vectors for a doubleword operation.

B.4.19 V{Q}SUB, VSUBL and VSUBW

VSUB (Vector Subtract) subtracts the elements of one vector from the corresponding elements of another vector and stores the results in the destination vector. VSUB has Long, Wide and Saturating variants.

Syntax

```
 V\{Q\}SUB\{cond\}. datatype \ \{Qd\}, \ Qn, \ Qm \ ; \ Saturating \ instruction \\ V\{Q\}SUB\{cond\}. datatype \ \{Dd\}, \ Dn, \ Dm \ ; \ Saturating \ instruction \\ VSUBL\{cond\}. datatype \ Qd, \ Dn, \ Dm \ ; \ Long \ instruction \\ VSUBW\{cond\}. datatype \ \{Qd\}, \ Qn, \ Dm \ ; \ Wide \ instruction \\
```

This instruction must be unconditional.

where:

Q specifies that saturation should be performed if any of the results overflow.

datatype is one of:

- 18, I16, I32, I64, F32 for VSUB
- S8, S16, S32 for VQSUB, VSUBL, or VSUBW
- U8, U16, U32 for VQSUB, VSUBL, or VSUBW
- S64, U64 for VQSUB.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

Qd, Dn, and Dm specify the destination, first operand and second operand vectors for a long operation.

B.4.20 V{R}SUBHN

V{R}SUBHN (Vector Subtract and Narrow, selecting High Half) subtracts the elements of one vector from the corresponding elements of another vector, selects the most significant halves of the results and stores them in the destination vector. Results can be either rounded or truncated for both operations.

Syntax

V{R}SUBHN{cond}.datatype Dd, Qn, Qm

This instruction must be unconditional.

where:

R specifies that each result is rounded. If R is not specified, each result is truncated.

datatype is one of I16, I32, or I64.

Dd, Qn, and Qm are the destination vector, the first operand vector, and the second operand vector.

B.5 NEON multiply instructions

This section describe NEON instructions which perform multiplication or multiply-accumulate.

B.5.1 VFMA, VFMS

VFMA (Vector Fused Multiply Accumulate) multiplies corresponding elements in two vectors, and accumulates the results into the destination vector.

VFMS (Vector Fused Multiply Subtract) multiplies corresponding elements in two operand vectors, subtracts the products from the corresponding elements of the destination vector, and stores the final results in the destination vector. The result of the multiply is not rounded before performing the accumulate or subtract operation.

Syntax

```
Vop{cond}.F32 {Qd}, Qn, Qm
Vop{cond}.F32 {Dd}, Dn, Dm
Vop{cond}.F64 {Dd}, Dn, Dm
Vop{cond}.F32 {Sd}, Sn, Sm
```

where:

op is one of FMA or FMS.

Sd, Sn, and Sm are the destination and operand vectors for word operation.

Dd, Dn, and Dm are the destination and operand vectors for doubleword operation.

Qd, Qn, and Qm are the destination and operand vectors for quadword operation.

B.5.2 VMUL{L}, VMLA{L}, and VMLS{L}

VMUL (Vector Multiply) multiplies corresponding elements in two vectors and stores the results in the destination vector.

VMLA (Vector Multiply Accumulate) multiplies corresponding elements in two vectors and accumulates the results into the elements of the destination vector.

VMLS (Vector Multiply Subtract) multiplies elements in two vectors, subtracts the results from corresponding elements of the destination vector, and stores the results in the destination vector.

Syntax

```
Vop{cond}.datatype {Qd}, Qn, Qm
Vop{cond}.datatype {Dd}, Dn, Dm
VopL{cond}.datatype Qd, Dn, Dm
```

This instruction must be unconditional.

where:

op is one of:

- MUL, Multiply
- MLA, Multiply Accumulate
- MLS, Multiply Subtract.

datatype is one of:

• 18, 116, 132, F32 for VMUL, VMLA, or VMLS

- S8, S16, S32 for VMULL, VMLAL, or VMLSL
- U8, U16, U32 for VMULL, VMLAL, or VMLSL
- P8 for VMUL or VMULL.

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

Qd, Dn, and Dm specify the destination, first operand and second operand vectors for a long operation.

B.5.3 VMUL{L}, VMLA{L}, and VMLS{L} (by scalar)

VMUL (Vector Multiply by scalar) multiplies each element in a vector by a scalar and stores the results in the destination vector.

VMLA (Vector Multiply Accumulate) multiplies each element in a vector by a scalar and accumulates the results into the corresponding elements of the destination vector.

VMLS (Vector Multiply Subtract) multiplies each element in a vector by a scalar and subtracts the results from the corresponding elements of the destination vector and stores the final results in the destination vector.

Syntax

```
Vop{cond}.datatype {Qd}, Qn, Dm[x]
Vop{cond}.datatype {Dd}, Dn, Dm[x]
VopL{cond}.datatype Qd, Dn, Dm[x]
```

This instruction must be unconditional.

where:

op is one of:

- MUL, Multiply
- MLA, Multiply Accumulate
- MLS, Multiply Subtract.

datatype is one of:

- I16, I32, F32 for VMUL, VMLA, or VMLS
- S16, S32 for VMULL, VMLAL, or VMLSL
- U16, U32 for VMULL, VMLAL, or VMLSL

Qd, Qn, and Qm specify the destination, first operand and second operand registers for a quadword operation.

Dd, Dn, and Dm specify the destination, first operand and second operand registers for a doubleword operation.

Qd, Dn, and Dm specify the destination, first operand and second operand vectors for a long operation.

Dm[x] is the scalar holding the second operand.

B.5.4 VQ{R}DMULH (by vector or by scalar)

Vector Saturating Doubling Multiply Returning High Half instructions multiply their operands and double the result. They return only the high half of the results. If any of the results overflow, they are saturated and the sticky QC flag is set.

Syntax

```
VQ{R}DMULH{cond}.datatype {Qd}, Qn, Qm
VQ{R}DMULH{cond}.datatype {Dd}, Dn, Dm
VQ{R}DMULH{cond}.datatype {Qd}, Qn, Dm[x]
VQ{R}DMULH{cond}.datatype {Dd}, Dn, Dm[x]
```

This instruction must be unconditional.

where:

R specifies that each result is rounded. If R is not specified, each result is truncated.

datatype is either S16 or S32.

Qd and Qn are the destination and first operand vector, for a quadword operation.

Dd and Dn are the destination and first operand vector for a doubleword operation.

Qm or Dm specifies the vector holding the second operand, for a by vector operation.

Dm[x] is the scalar holding the second operand for a by scalar operation.

B.5.5 VQDMULL, VQDMLAL, and VQDMLSL (by vector or by scalar)

Vector Saturating Doubling Multiply Long instructions multiply their operands and double the results. The instruction variants are:

- VQDMULL stores the results in the destination register.
- VQDMLAL adds the results to the values in the destination register.
- VQDMLSL subtracts the results from the values in the destination register.

If any of the results overflow, they are saturated and the sticky QC flag is set.

Syntax

```
VQDopL{cond}.datatype Qd, Dn, Dm
VQDopL{cond}.datatype Qd, Dn, Dm[x]
```

This instruction must be unconditional.

where:

op is one of:

- MUL, Multiply
- MLA, Multiply Accumulate
- MLS, Multiply Subtract.

datatype is either \$16 or \$32.

Qd and Dn are the destination vector and the first operand vector.

Dm is the vector holding the second operand in the case of a by vector operation.

Dm[x] is the scalar holding the second operand for a by scalar operation.

B.6 NEON load and store element and structure instructions

This section describe NEON instructions which load or store data to or from memory or ARM integer registers.

B.6.1 VLDn and VSTn (single n-element structure to one lane)

VLDn (Vector Load single n-element structure to one lane) loads an n-element structure from memory into one or more NEON registers. Elements of the register that are not loaded remain unchanged.

VSTn (Vector Store single n-element structure to one lane) stores an n-element structure to memory from one or more NEON registers.

Syntax

```
Vopn{cond}.datatype list, [Rn{@align}]{!}
Vopn{cond}.datatype list, [Rn{@align}], Rm
```

This instruction must be unconditional.

where:

op is either LD or ST.

n is one of 1, 2, 3, or 4.

cond is an optional conditional code. (See *Conditional execution* on page 6-3)

datatype is one of 8, 16 or 32.

The following table shows the permitted options.

Table B-2 Permitted combinations of parameters

n	datatype	list	align	alignment
1	8	$\{Dd[x]\}$	-	Standard only
	16	$\{Dd[x]\}$	@16	2-byte
	32	$\{Dd[x]\}$	@32	4-byte
2	8	$\{Dd[x], D(d+1)[x]\}$	@16	2-byte
	16	$\{Dd[x], D(d+1)[x]\}$	@32	4-byte
		$\{Dd[x], D(d+2)[x]\}$	@32	4-byte
	32	$\{Dd[x], D(d+1)[x]\}$	@64	8-byte
		$\{Dd[x], D(d+2)[x]\}$	@64	8-byte
3	8	{Dd[x], D(d+1)[x], D(d+2)[x]}	-	Standard only
	16 or 32	{Dd[x], D(d+1)[x], D(d+2)[x]}	-	Standard only
		{Dd[x], D(d+2)[x], D(d+4)[x]}	-	Standard only
4	8	{Dd[x], D(d+1)[x], D(d+2)[x], D(d+3)[x]}	@32	4-byte
	16	{Dd[x], D(d+1)[x], D(d+2)[x], D(d+3)[x]}	@64	8-byte

Table B-2 Permitted combinations of parameters (continued)

n	datatype	list	align	alignment
		{Dd[x], D(d+2)[x], D(d+4)[x], D(d+6)[x]}	@64	8-byte
	32	{Dd[x], D(d+1)[x], D(d+2)[x], D(d+3)[x]}	@64 or @128	8-byte or 16-byte
		{Dd[x], D(d+2)[x], D(d+4)[x], D(d+6)[x]}	@64 or @128	8-byte or 16-byte

list is a list of NEON registers in the range D0-D31, subject to the limitations given in the table.

Rn is the ARM register containing the base address (cannot be PC). If ! is present, Rn is updated to (Rn + the number of bytes transferred by the instruction). The update occurs after all the loads or stores have been performed.

Rm is an ARM register containing an offset from the base address. If Rm is present, then Rm is updated to (Rn + Rm) after the memory accesses have been performed. Rm cannot be SP or PC.

B.6.2 VLDn (single n-element structure to all lanes)

VDLn (Vector Load single n-element structure to all lanes) loads multiple copies of an n-element structure from memory into one or more NEON registers.

Syntax

```
VLDn{cond}.datatype list, [Rn{@align}]{!}
VLDn{cond}.datatype list, [Rn{@align}], Rm
```

where:

n is one of 1, 2, 3, or 4.

cond is an optional conditional code. (See Conditional execution on page 6-3)

datatype is one of 8, 16 or 32.

The following table shows the permitted options:

Table B-3 Permitted combinations of parameters

n	datatype	list	align	alignment
1	8	{Dd[]}	-	Standard only
		{Dd[],D(d+1)[]}	-	Standard only
	16	{Dd[]}	@16	2-byte
		{Dd[],D(d+1)[]}	@16	2-byte
	32	{Dd[]}	@32	4-byte
		{Dd[],D(d+1)[]}	@32	4-byte
2	8	{Dd[], D(d+1)[]}	@8	byte
		{Dd[], D(d+2)[]}	@8	byte
	16	{Dd[], D(d+1)[]}	@16	2-byte
		{Dd[], D(d+2)[]}	@16	2-byte

Table B-3 Permitted combinations of parameters (continued)

n	datatype	list	align	alignment
	32	{Dd[], D(d+1)[]}	@32	4-byte
		{Dd[], D(d+2)[]}	@32	4-byte
3	8, 16, or 32	{Dd[], D(d+1)[], D(d+2)[]}	-	Standard only
		{Dd[], D(d+2)[], D(d+4)[]}	-	Standard only
4	8	{Dd[], D(d+1)[], D(d+2)[], D(d+3)[]}	@32	4-byte
		{Dd[], D(d+2)[], D(d+4)[], D(d+6)[]}	@32	4-byte
	16	{Dd[], D(d+1)[], D(d+2)[], D(d+3)[]}	@64	8-byte
		{Dd[], D(d+2)[], D(d+4)[], D(d+6)[]}	@64	8-byte
	32	{Dd[], D(d+1)[], D(d+2)[], D(d+3)[]}	@64 or @128	8-byte or 16-byte
		{Dd[], D(d+2)[], D(d+4)[], D(d+6)[]}	@64 or @128	8-byte or 16-byte

list is a list of NEON registers in the range D0-D31, subject to the limitations given in the table.

Rn is the ARM register containing the base address. Rn cannot be PC. If ! is specified, Rn is updated to (Rn + the number of bytes transferred by the instruction). The update occurs after the memory accesses are performed.

Rm is an ARM register containing an offset from the base address. If Rm is present, Rm is updated to (Rn + Rm) after the address is used to access memory. Rm cannot be SP or PC.

B.6.3 VLDn and VSTn (multiple n-element structures)

VLDn (Vector Load multiple n-element structures) loads multiple n-element structures from memory into one or more NEON registers, with de-interleaving (unless n == 1). Every element of each register is loaded.

VSTn (Vector Store multiple n-element structures) writes multiple n-element structures to memory from one or more NEON registers, with interleaving (unless n == 1). Every element of each register is stored.

Syntax

datatype is one of 8, 16 or 32.

```
Vopn{cond}.datatype list, [Rn{@align}]{!}
Vopn{cond}.datatype list, [Rn{@align}], Rm
where:

op is either LD or ST.

n is one of 1, 2, 3, or 4.

cond is an optional conditional code. (See Conditional execution on page 6-3)
```

The following table shows the permitted options:

Table B-4 Permitted combinations of parameters

n	datatype	list	align	alignment
1	8, 16, 32, or 64	{Dd}	@64	8-byte
		{Dd, D(d+1)}	@64 or @128	8-byte or 16-byte
		{Dd, D(d+1), D(d+2)}	@64	8-byte
		{Dd, D(d+1), D(d+2), D(d+3)}	@64, @128, or @256	8-byte, 16-byte, or 32-byte
2	8, 16, or 32	{Dd, D(d+1)}	@64, @128	8-byte or 16-byte
		{Dd, D(d+2)}	@64, @128	8-byte or 16-byte
		{Dd, D(d+1), D(d+2), D(d+3)}	@64, @128, or @256	8-byte, 16-byte, or 32-byte
3	8, 16, or 32	{Dd, D(d+1), D(d+2)}	@64	8-byte
		{Dd, D(d+2), D(d+4)}	@64	8-byte
4	8, 16, or 32	{Dd, D(d+1), D(d+2), D(d+3)}	@64, @128, or @256	8-byte, 16-byte, or 32-byte
		{Dd, D(d+2), D(d+4), D(d+6)}	@64, @128, or @256	8-byte, 16-byte, or 32-byte

list is a list of NEON registers in the range D0-D31, subject to the limitations given in the table.

Rn is the ARM register containing the base address. Rn cannot be PC. If ! is specified, Rn is updated to (Rn + the number of bytes transferred by the instruction). The update occurs after the memory accesses are performed.

Rm is an ARM register containing an offset from the base address. If Rm is present, Rm is updated to (Rn + Rm) after the address is used to access memory. Rm cannot be SP or PC.

B.6.4 VLDR and VSTR

VLDR loads a single extension register from memory, using an address from an ARM core register, with an optional offset..

VSTR saves the contents of a NEON or VFP register to memory.

One word is transferred if Fd is a VFP single-precision register, otherwise two words are transferred.

This instruction is present in both NEON and VFP instruction sets.

Syntax

```
VLDR{cond}{.size} Fd, [Rn{, #offset}]
VSTR{cond}{.size} Fd, [Rn{, #offset}]
VLDR{cond}{.size} Fd, label
VSTR{cond}{.size} Fd, label
```

where:

size is an optional data size specifier, which is 32 if Fd is an S register, or 64 otherwise.

Fd is the extension register to be loaded or saved. For a NEON instruction, it must be a D register. For a VFP instruction, it can be either a D or S register.

Rn is the ARM register holding the base address for the transfer.

offset is an optional numeric expression. It must be a multiple of 4, within the range -1020 to +1020. The value is added to the base address to form the address used for the transfer. Label is a PC-relative expression and must align to a word boundary within ± 1 KB of the current instruction.

B.6.5 VLDM, VSTM, VPOP, and VPUSH

NEON/VFP register load multiple (VLDM), store multiple (VSTM), pop from stack (VPOP), push onto stack (VPUSH).

These instructions are present in both NEON and VFP instruction sets.

Syntax

```
VLDMmode{cond} Rn{!}, Registers
VSTMmode{cond} Rn{!}, Registers
VPOP{cond} Registers
VPUSH{cond} Registers
```

where:

mode is one of:

- IA (Increment address after each transfer). This is the default, and can be omitted.
- DB (Decrement address before each transfer)
- EA (Empty Ascending stack operation). This is the same as DB for loads and IA for saves.
- FD (Full Descending stack operation). This is the same as IA for loads, and DB for saves.

Rn is the ARM register holding the base address for the transfer. If ! is specified, the updated base address must be written back to Rn. If ! is not specified, the mode must be IA.

Registers is a list of one or more consecutive NEON or VFP registers enclosed in braces, { }. The list can be comma-separated, or in range format. S, D, or Q registers can be specified, but they must not be mixed. The number of registers must not exceed 16 D registers, or 8 Q registers.

VPOP is equivalent to VLDM sp! and VPUSH is equivalent to VSTMDB sp!.

B.6.6 VMOV (between two ARM registers and an extension register)

Transfer contents between two ARM registers and a 64-bit NEON or VFP register, or two consecutive 32-bit VFP registers.

This instruction is present in both NEON and VFP instruction sets.

Syntax

```
VMOV{cond} Dm, Rd, Rn
VMOV{cond} Rd, Rn, Dm
VMOV{cond} Sm, Sm1, Rd, Rn
VMOV{cond} Rd, Rn, Sm, Sm1
```

where:

Dm is a 64-bit extension register.

Sm is a VFP 32-bit register and Sm1 is the next consecutive VFP 32-bit register after Sm.

Rd and Rn are the ARM registers.

B.6.7 VMOV (between an ARM register and a NEON scalar)

Transfer contents between an ARM register and a NEON scalar.

This instruction is present in both NEON and VFP instruction sets.

Syntax

```
VMOV{cond}{.size} Dn[x], Rd
VMOV{cond}{.datatype} Rd, Dn[x]
```

where:

size can be 8, 16, or 32(default) for NEON, or 32 for VFP.

datatype can be U8, S8, U16, S16, or 32 (default). For VFP instructions, datatype must be 32 or omitted.

Dn[x] is the NEON scalar.

Rd is the ARM register.

B.6.8 VMRS and VMSR (between an ARM register and a NEON or VFP system register)

VMRS transfers the contents of NEON or VFP system register FPSCR into Rd.

VMSR transfers the contents of Rd into a NEON or VFP system register, FPSCR.

These instructions are present in both NEON and VFP instruction sets.

Syntax

```
VMRS{cond} Rd, extsysreg
VMSR{cond} extsysreg, Rd
```

where:

extsysreg specifies a NEON and VFP system register, one of:

- FPSCR
- FPSID
- FPEXC.

Rd is the ARM register. Rd can be APSR_nzcv, if extsysreg is FPSCR. Here, the floating-point status flags are transferred into the corresponding flags in the ARM APSR.

These instructions stall the ARM until all current NEON or VFP operations complete.

B.7 VFP instructions

This section describes VFP floating-point instructions.

B.7.1 VABS

Floating-point absolute value (VABS). This instruction can be scalar, vector, or mixed. VABS takes the contents of the specified register, clears the sign bit and stores the result.

Syntax

```
VABS{cond}.F32 Sd, Sm
VABS{cond}.F64 Dd, Dm
```

where:

Sd and Sm are the single-precision registers for the result and operand.

Dd and Dm are the double-precision registers for the result and operand.

B.7.2 VADD

VADD adds the values in the operand registers and places the result in the destination register.

Syntax

```
VADD{cond}.F32 {Sd}, Sn, Sm
VADD{cond}.F64 {Dd}, Dn, Dm
```

where:

Sd, Sn, and Sm are the single-precision registers for the result and operands.

Dd, Dn, and Dm are the double-precision registers for the result and operands.

B.7.3 VCMP (Floating-point compare)

VCMP subtracts the value in the second operand register (or 0 if the second operand is #0) from the value in the first operand register and sets the VFP condition flags depending on the result. VCMP is always scalar.

Syntax

```
VCMP{cond}.F32 Sd, Sm
VCMP{cond}.F32 Sd, #0
VCMP{cond}.F64 Dd, Dm
VCMP{cond}.F64 Dd, #0
```

where:

Sd and Sm are the single-precision registers holding the operands.

Dd and Dm are the double-precision registers holding the operands.

B.7.4 VCVT (between single-precision and double-precision)

VCVT converts the single-precision value in Sm to double-precision and stores the result in Dd, or converts the double-precision value in Dm to single-precision, storing the result in Sd. VCVT is always scalar.

Syntax

```
VCVT{cond}.F64.F32 Dd, Sm
VCVT{cond}.F32.F64 Sd, Dm
```

where:

Dd is a double-precision register for the result, with Sm a single-precision register which holds the operand.

Sd is a single-precision register for the result with Dm a double-precision register holding the operand.

B.7.5 VCVT (between floating-point and integer)

VCVT forms which convert from floating-point to integer or from integer to floating-point. VCVT is always scalar.

Syntax

```
VCVT{R}{cond}.type.F64 Sd, Dm
VCVT{R}{cond}.type.F32 Sd, Sm
VCVT{cond}.F64.type Dd, Sm
VCVT{cond}.F32.type Sd, Sm
```

where:

R makes the operation use the rounding mode specified by the FPSCR. If R is not specified, VCVT rounds towards zero.

type is either U32 (unsigned 32-bit integer) or S32 (signed 32-bit integer).

Sd is a single-precision register for the result.

Dd is a double-precision register for the result.

Sm is a single-precision register holding the operand.

Dm is a double-precision register holding the operand.

B.7.6 VCVT (between floating-point and fixed-point)

Convert between floating-point and fixed-point numbers. In all cases the fixed-point number is contained in the least significant 16 or 32 bits of the register. VCVT is always scalar.

Syntax

```
VCVT{cond}.type.F64 Dd, Dd, #fbits
VCVT{cond}.type.F32 Sd, Sd, #fbits
VCVT{cond}.F64.type Dd, Dd, #fbits
VCVT{cond}.F32.type Sd, Sd, #fbits
```

where:

type can be any one of:

- \$16, 16-bit signed fixed-point number
- U16, 16-bit unsigned fixed-point number
- S32, 32-bit signed fixed-point number
- U32, 32-bit unsigned fixed-point number.

Sd is a single-precision register for the operand and result.

Dd is a double-precision register for the operand and result.

fbits is the number of fraction bits in the fixed-point number, in the range 0-16 (if type is S16 or U16), or 1-32 (if type is S32 or U32).

B.7.7 VCVTB, VCVTT (half-precision extension)

These instructions convert between half-precision and single-precision floating-point numbers:

- VCVTB uses the lower half (bits[15:0]) of the single word register to obtain or store the half-precision value.
- VCVTT uses the upper half (bits[31:16]) of the single word register to obtain or store the half-precision value.

VCVTB and VCVTT are always scalar.

Syntax

```
VCVTB{cond}.type Sd, Sm
VCVTT{cond}.type Sd, Sm
```

where:

type is either F32.F16 (convert from half-precision to single-precision) or F16.F32 (convert from single-precision to half-precision).

Sd is a single word register for the result.

Sm is a single word register for the operand.

B.7.8 VDIV

VDIV divides the value in the first operand register by the value in the second operand register, and places the result in the destination register. The instructions can be scalar, vector, or mixed.

Syntax

```
VDIV{cond}.F32 {Sd}, Sn, Sm
VDIV{cond}.F64 {Dd}, Dn, Dm
```

where:

Sd, Sn, and Sm are the single-precision registers for the result and operands.

Dd, Dn, and Dm are the double-precision registers for the result and operands.

B.7.9 VFMA, VFMS, VFNMA, VFNMS (Fused floating-point multiply accumulate and fused floating-point multiply subtract with optional negation)

VFMA multiplies the operand registers, adds the value from the destination register and stores the final result in the destination register. The result of the multiply is not rounded before the accumulation.

VFMS multiplies the values in the operand registers, subtracts the product from the destination register value and places the final result in the destination register. The result of the multiply is not rounded before the subtraction.

These instructions are always scalar.

Syntax

```
VF{N}op{cond}.F64 {Dd}, Dn, Dm
VF{N}op{cond}.F32 {Sd}, Sn, Sm
```

where:

op is either MA or MS.

N negates the final result.

Sd, Sn, and Sm are the single-precision registers for the result and operands.

Dd, Dn, and Dm are the double-precision registers for the result and operands.

Qd, Qn, and Qm are the double-precision registers for the result and operands.

B.7.10 VMOV

VMOV puts a floating-point immediate value into a single-precision or double-precision register, or copies one register into another register. This instruction is always scalar.

Syntax

```
VMOV{cond}.F32 Sd, #imm
VMOV{cond}.F64 Dd, #imm
VMOV{cond}.F32 Sd, Sm
VMOV{cond}.F64 Dd, Dm
```

where:

Sd is the single-precision destination register.

Dd is the double-precision destination register.

imm is the floating-point immediate value.

Sm is the single-precision source register.

Dm is the double-precision source register.

B.7.11 VMOV (between one ARM register and single precision VFP)

Transfer contents between a single-precision floating-point register and an ARM register.

Syntax

```
VMOV{cond} Rd, Sn
VMOV{cond} Sn, Rd
```

where:

Sn is the VFP single-precision register.

Rd is the ARM register.

B.7.12 VMUL, VMLA, VMLS, VNMUL, VNMLA, and VNMLS (Floating-point multiply and multiply accumulate, with optional negation)

VMUL multiplies the values in the operand registers and stores the result in the destination register.

VMLA multiplies the values in the operand registers, adds the value from the destination register, and stores the final result in the destination register.

VMLS multiplies the values in the operand registers, subtracts the result from the value in the destination register, and stores the final result in the destination register.

The final result is negated if the N option is used.

These instructions can be scalar, vector, or mixed.

Syntax

```
V{N}MUL{cond}.F32 {Sd,} Sn, Sm
V{N}MUL{cond}.F64 {Dd,} Dn, Dm
V{N}MLA{cond}.F32 Sd, Sn, Sm
V{N}MLA{cond}.F64 Dd, Dn, Dm
V{N}MLS{cond}.F32 Sd, Sn, Sm
V{N}MLS{cond}.F34 Dd, Dn, Dm
```

where:

N negates the final result.

Sd, Sn, and Sm are the single-precision registers for the result and operands.

Dd, Dn, and Dm are the double-precision registers for the result and operands.

B.7.13 VNEG

Floating-point negate (VNEG). This instruction can be scalar, vector, or mixed. VNEG takes the contents of the specified register, inverts the sign bit and stores the result.

Syntax

```
VNEG{cond}.F32 Sd, Sm
VNEG{cond}.F64 Dd, Dm
```

where:

Sd and Sm are the single-precision registers for the result and operand.

Dd and Dm are the double-precision registers for the result and operand.

B.7.14 VSQRT

Floating point square root (VSQRT) takes the square root of the contents of Sm or Dm, and places the result in Sd or Dd. It can be scalar, vector, or mixed.

Syntax

```
VSQRT{cond}.F32 Sd, Sm
VSQRT{cond}.F64 Dd, Dm
```

where:

Sd and Sm are the single-precision registers for the result and operand.

Dd and Dm are the double-precision registers for the result and operand.

B.7.15 VSUB

VSUB subtracts the value in the second operand register from the value in the first operand register, and places the result in the destination register. The instructions can be scalar, vector, or mixed.

Syntax

```
VSUB{cond}.F32 {Sd}, Sn, Sm
VSUB{cond}.F64 {Dd}, Dn, Dm
```

where:

Sd, Sn, and Sm are the single-precision registers for the result and operands.

Dd, Dn, and Dm are the double-precision registers for the result and operands.

B.8 NEON and VFP pseudo-instructions

This section describe pseudo-instructions which will be translated by the assembler to a real machine instruction.

B.8.1 VACLE and VACLT

Vector Absolute Compare takes the absolute value of each element in a vector, and compares with the absolute value of the corresponding element of a second vector. If the condition is true, the corresponding element in the destination vector is set to all ones. If false, it is set to all zeros. This produces the corresponding VACGE and VACGT instructions, with the operands reversed.

Syntax

```
VACop{cond}.datatype {Qd}, Qn, Qm
VACop{cond}.datatype {Dd}, Dn, Dm
```

where:

op is either LE (Absolute Less than or Equal) or LT (Absolute Less Than).

datatype must be F32.

Qd or Dd is the NEON register for the result. The result datatype is always I32.

Qn or Dn is the NEON register holding the first operand,

Qm or Dm is the NEON register which holds the second operand.

B.8.2 VAND (immediate)

VAND (bitwise AND immediate) takes each element of the destination vector, does a bitwise AND with an immediate value, and stores the result into the destination.

Syntax

```
VAND{cond}.datatype Qd, #imm
VAND{cond}.datatype Dd, #imm
```

where:

datatype is one of I8, I16, I32, or I64.

Qd or Dd is the NEON register for the result.

imm is the immediate value.

If datatype is I16, the immediate value must have one of the following forms:

- 0xFFXY
- 0xXYFF.

If datatype is 132, the immediate value must have one of the following forms:

- 0xFFFFFXY
- 0xFFFFXYFF
- 0xFFXYFFFF
- 0xXYFFFFFF.

B.8.3 VCLE and VCLT

Vector Compare takes the value of each element in a vector, and compares it with the value of the corresponding element of a second vector. If the condition is true, the corresponding element in the destination vector is set to all ones. If false, it is set to all zeros. These pseudo-instructions produce the corresponding VCGE and VCGT instructions, with the operands reversed.

Syntax

```
VCop{cond}.datatype {Qd}, Qn, Qm
VCop{cond}.datatype {Dd}, Dn, Dm
```

where:

op is either LE (Less than or Equal) or LT (Less Than).

datatype is one of S8, S16, S32, U8, U16, U32, or F32.

Qd or Dd is the NEON register for the result. The result datatype is as follows:

- I32 for operand datatypes I32, S32, U32, or F32
- I16 for operand datatypes I16, S16, or U16
- I8 for operand datatypes I8, S8, or U8
- U32 32-bit unsigned fixed-point number.

Qn or Dn is the NEON register holding the first operand.

Qm or Dm is the NEON register which holds the second operand.

B.8.4 VLDR pseudo-instruction

The VLDR pseudo-instruction loads a constant value into every element of a 64-bit NEON vector (or a VFP single-precision or double-precision register).

Syntax

```
VLDR{cond}.datatype Dd,=constant
VLDR{cond}.datatype Sd,=constant
```

where:

datatype is one of In, Sn, Un (where n is one of 8, 16, 32, or 64) or F32 for NEON. For VFP code, use either F32 or F64.

Dd or Sd is the register to be loaded.

constant is an immediate value of the appropriate type for datatype. If an instruction is available that can generate the constant directly, the assembler uses it. Otherwise, it generates a doubleword literal pool entry containing the constant and use a VLDR instruction to load the constant.

B.8.5 VLDR and VSTR (post-increment and pre-decrement)

The VLDR and VSTR pseudo-instructions load or store extension registers with post-increment and pre-decrement.

Syntax

```
op{cond}{.size} Fd, [Rn], #offset ; post-increment
op{cond}{.size} Fd, [Rn, #-offset]! ; pre-decrement
```

where:

op is either VLDR or VSTR.

size is 32 if Fd is an S register, or 64 if Fd is a D register. For a NEON instruction, it must be a doubleword (Dd) register. For a VFP instruction, it can be a double precision (Dd) or single precision (Sd) register.

Rn is the ARM register that sets the base address for the transfer.

The post-increment instruction increments the base address in the register by the offset value, after the transfer. The pre-decrement instruction decrements the base address in the register by the offset value, and then does the transfer using the new address in the register. These pseudo-instructions assemble to VLDM or VSTM instructions.

B.8.6 VMOV2

The VMOV2 pseudo-instruction generates an immediate value and places it in every element of a NEON vector, without a load from a literal pool. It always generates two instructions typically a VMOV or VMVN followed by a VBIC or VORR. VMOV2 can generate any 16-bit immediate value, and a restricted range of 32-bit and 64-bit immediate values.

Syntax

```
VMOV2{cond}.datatype Qd, #constant
VMOV2{cond}.datatype Dd, #constant
```

where:

datatype is one of:

- 18, I16, I32, or I64
- S8, S16, S32, or S64
- U8, U16, U32, or U64
- F32.

Qd or Dd is the extension register to be loaded.

constant is an immediate value of the appropriate type for datatype.

B.8.7 VORN (immediate)

VORN (Bitwise OR NOT immediate) takes each element of the destination vector, does a bitwise OR Complement with an immediate value and stores the result into the destination vector.

Syntax

```
VORN{cond}.datatype Qd, #imm
VORN{cond}.datatype Dd, #imm
```

where:

datatype is one of 18, 116, 132, or 164.

Qd or Dd is the NEON register for the result.

imm is the immediate value.

If datatype is I16, the immediate value must have one of the following forms:

0xFFXY

0xXYFF.

If datatype is I32, the immediate value must have one of the following forms:

- 0xFFFFFFXY
- 0xFFFFXYFF
- 0xFFXYFFFF
- 0xXYFFFFFF.

Appendix C **Building ARM Linux**

The objective of this appendix is to enable the reader to build an ARM Linux System. Though the process for doing this will vary slightly for different processor cores and platforms, most of the steps will be very similar to those outlined here.

A working Linux system has two primary components, namely the kernel and the Linux filesystem. The kernel is the core of the operating system and acts as a resource manager. It is loaded into primary memory by the boot-loader and then executed during the boot process, as described in Chapter 13. The Linux filesystem, on the other hand, provides a structured view of secondary memory (such as disk drives) to the kernel. It also contains other useful tools and utilities, for example, command line interfaces or shells, graphic interfaces (such as X-windows), text editors (such as vi, emacs, gedit) and also advanced applications like browsers or office suites. Linux also allows filesystems to reside in primary memory (typically RAM) instead of the disk. These are commonly referred to as *ramfs*. However, this book will not cover ramfs in great detail. We will first cover the steps for building the kernel and then the filesystem and then see how these fit together to get the system running. At the end of this appendix, we cover troubleshooting and common problems.

C.1 Building the Linux kernel

In this section we explain the steps required to build the kernel for an ARM based platform (called the *target* platform). This should enable anyone without prior knowledge or experience to build a Linux kernel, but it is far from a complete guide to all features, configurations and combinations. We assume that the reader has some experience in using Linux, C compilers and has a machine (either x86 or ARM based) running a Linux distribution like Ubuntu (for other distributions some of the steps of the build procedure might differ slightly). This machine may be referred to as the build platform. If this machine is ARM based, the build platform need not be exactly the same as the target platform (the machine for which the kernel is being built). Before going into the details of building the kernel, it is worthwhile to know the structure of the Linux kernel.

The Linux kernel can be viewed as consisting two parts, as shown in Figure C-1. One part is architecture independent and consists of components like process schedulers, system call interfaces and high-level network subsystems. The other part is closely related to the hardware platform for which the kernel is being built. This consists of board support packages (BSP) and drivers corresponding to a specific hardware platform. The fact that BSPs and drivers vary between different hardware platforms means that while building a kernel one has be sure of having the correct set of BSPs and drivers for the platform at hand. This will be further clarified during the steps for building a Linux kernel later in this appendix.




Figure C-1 Simplified layered block diagram of the Linux Kernel

The source tree for the latest Linux kernel can be found at, http://www.kernel.org/. There are two ways to get the kernel source code. The first is to download the compressed tar file. The exact name of this file will naturally depend upon the version of the kernel selected. Here we will use 2.6.34, for which the file we need is named linux-2.6.34.tar.bz2. This file needs to be uncompressed using a command similar to the following.

```
tar -jxvf linux-2.6.34.tar.bz2
```

The other option for obtaining the kernel source is to obtain the source tree using GIT (git) commands. Linux uses the GIT code versioning system, which can be installed using a command similar to the one below for Ubuntu.

```
sudo apt-get install git-core
```

Obviously, a working internet connection is required for the above steps and those which follow.

The Linux source tree can be cloned with a command similar to the following:

```
git clone
git://git.kernel.org/pub/scm/linux/kernel/git/torvalds/linux-2.6.git
```

This command will fetch the latest Linux kernel sources from the official repository maintained by Linus Torvalds. This might then be modified to reflect a particular tag or stable kernel version using a command like the one below.

```
git checkout -b v2.6.33 v2.6.33
```

Another reason for adhering to a particular version of the kernel is that the kernel might require some additional components or drivers for a particular hardware platform. These are often available as patches to a particular kernel version from the hardware platform vendor. For many of the platforms from ARM the patches can be found at, http://www.arm.com/linux in the Linux OS Downloads tab. For many other hardware platforms they are either available on the manufacturer's website or are already integrated into the kernel source tree.

Kernel patches can again be of two kinds: normal code patches or git patches. The patches need to be applied to the correct version of the source tree before building the kernel. For normal code patches a command line similar to the following can be used depending on the directory/folder level from which it is applied.

```
patch -p1 < patch-file-name
```

For git patches, we proceed in two stages. First, to check if the patches can be applied cleanly before actually applying them, we use the following command.

```
git apply --check patch-file-name
```

At this point, it may be necessary to use the --rejects options, which allows some changes to be applied manually, if the standard apply fails.

Before proceeding, it is advisable to check that the correct ARM GNU toolchain is installed on the machine being used for building the ARM Linux kernel. If you are attempting to build the ARM Linux kernel on an x86 platform, then you will need to use a cross-compilation toolchain. If not already installed, this can be obtained from, http://www.codesourcery.com/. The cross compilation toolchain consists of the GNU C compiler (GCC), glibc libraries and so on, which are necessary for building the kernel. If the compilation is being done on a native ARM platform these tools can be obtained using a command like the following (example for Ubuntu).

```
sudo apt-get install gcc
```

Once the source tree is in place, the kernel needs to be configured to match the hardware platform and also choose desired kernel features. The Linux kernel's build infrastructure uses KConfig for hierarchically selecting or omitting different components and features of the kernel. The possible configurations for the kernel are specified in the form of KConfig configuration files. Each of the components or features corresponds to different parts of the Linux source tree. Thus the config files also are arranged in the form of a hierarchical tree with a root or primary configuration file. The template root or primary configuration file for ARM based platforms can

be usually found in the Linux source tree (assuming linux-2.6 to be the source root) at the location: linux-2.6/arch/arm/configs/. The "config" file templates usually conform to the naming format: hardware_platforms_defconfig.

The standard method is to use a command like:

```
make ARCH=arm realview_defconfig
```

which does the copying of the default config file to .config and setting the defaults.

Another possible way to configure the Linux kernel is to copy the template corresponding to the hardware platform at hand to the source root and renaming it as .config. For example if we are using the nVidia Tegra Harmony board we would choose the file

tegra_harmony_gnu_linux_defconfig and copy it to source root, say /linux-2.6/, and rename it to .config. In order to reach the desired kernel configuration from the template .config file, the file can either be edited using a standard text editor or one of the tools mentioned below can be used for the purpose. Editing the .config file by hand would require some expertise in kernel configuration and is therefore not recommended for beginners.

There are two possible tools for configuring the kernel. The first uses a text based interface based on ncurses (a library for creating text user interfaces independent of the platform). It can be invoked using the command:

```
make ARCH=arm menuconfig
```

This gives a configuration screen for selecting/omitting features of the kernel as shown in Figure C-2.




Figure C-2 Kernel Configuration screen using make menuconfig

The other alternative is to use a graphical configuration tool which uses a Qt (GUI library) based environment and can be invoked using the command below:

make ARCH=arm xconfig

Figure C-3 shows the Kernel Configuration screen from this tool.





Figure C-3 Kernel Configuration screen using make xconfig

Once the kernel is configured correctly then it can be built using a simple make command as below, though this may differ slightly depending on the boot-loader used which is explained below.

make ARCH=arm CROSS_COMPILE=arm-none-linux-gnueabi-

The output of the compilation would be in the form of a compressed kernel zImage. This can usually be found in the path <source root>/arch/arm/boot as a file named zImage.



If the hardware platform uses the U-Boot boot-loader, the kernel image will need to be converted into a form accepted by U-boot. For example, in Ubuntu the uboot-mkimage package can be installed followed by the command below, instead of the simple make, to create an "ubootified" image.

make ARCH=arm CROSS_COMPILE=arm-none-linux-gnueabi-uImage

The built kernel image would be found as the file named uImage, again in the path <source root>/arch/arm/boot.

Now that the kernel is built, the filesystem needs to be created in order to have a working ARM Linux system. The next section deals with creating the filesystem followed by a section on how to use the kernel and filesystem.

C.2 Creating the Linux filesystem

Creating a filesystem for an ARM platform is relatively straightforward, using a Ubuntu distribution. The procedure described here does not actually compile the filesystem, rather it downloads pre-built packages through the internet to create the filesystem. A full compilation of the filesystem would take many hours of compilation time and is non-trivial from a technical standpoint.

For carrying out the process of putting together the filesystem the rootstock package needs to be installed, which can be done using the command below:

```
sudo apt-get install rootstock
```

Once the package is installed, navigate to the directory to be used for creating and saving the filesystem. The filesystem can be created in the form of a compressed tar-ball using the command below.

sudo rootstock --fqdn ubuntu --login ubuntu --password ubuntu --imagesize 3G --seed ubuntu-desktop

In this case, the system would be based on the ubuntu-desktop seed which includes a desktop windowing system. Other "seeds" could be used instead, for example xubuntu-desktop (for a smaller, more lightweight desktop system) or build-essential (for a text based interface).

Note	
This step might take a signif connection.	icant amount on time, depending on the speed of Internet

The following steps describe the process of preparing a disk drive and transferring the filesystem to it. This disk would then be used as the root filesystem on the ARM platform. The term disk drive is used here in a loose sense and refers to a variety of secondary storage devices, for example, hard-disks, compact-flash drives, or USB drives. After plugging in the disk drive to the computer which was used to create the filesystem, the following command can be used to check the connected drives

sudo fdisk	-1
——Note	

The disk drive being used for storing the root filesystem of the ARM platform will be formatted by the following steps. The process of formatting the disk will destroy any data that might exist on the disk. Therefore the user needs to ensure that the disk does not contain any useful data prior to formatting, as this data will be permanently erased.

The disk drive to be used needs to be identified correctly in the list given by the command above (for example, /dev/sdb). Assuming that /dev/sdb is the correct device / disk drive, the following command is needed to partition the drive correctly.

```
sudo fdisk /dev/sdb
```

On entering the above command, the fdisk prompt will be displayed. Now a sequence of fdisk command needs to be entered which are in the form of single characters. Type "m" to display the help for the possible set of fdisk commands. Use "d" to delete any existing partitions on the disk. You can then create a new partition using "n". The character "w" is used to write the changes to the disk and exit. You can check that the partition has been written correctly by starting fdisk again using the above command, followed by a "p" for printing the partition table.

Once the partition table has been written correctly, the disk partition that has been created can be formatted. Usually the first partition created on the disk identified by (for example) /dev/sdb is denoted as /dev/sdb1. The command for formatting this partition as an ext-3 filesystem is as below.

sudo mkfs.ext3 /dev/sdb1

Now, the previously created tar-ball for the ARM Linux filesystem needs to be decompressed into this disk partition. To do this, the disk partition needs to be 'mounted' which either can be done manually with the mount command, or automatically by unplugging and re-plugging the drive. In the automatic mounting case, the disk is usually mounted at the location /media/<disk_directory>. Navigate to the directory at which the disk is mounted and uncompress the file-stem tarball into it using the command below:

sudo tar -zxvf <path_to_tarred_file_system/file.tgz>

Now that both the kernel and filesystem have been created, the two need to be brought together to have a working ARM Linux system.

——Note ———
It is also possible to have a root filesystem in the primary memory, called RAMDISK. However,
this alternative will not be discussed here and is left to advanced users.

C.3 Putting It together

The steps for creating the kernel and the filesystem are generic and common to many different boards/platforms. However, the steps for having the kernel programmed onto the platform may vary between boards. For most boards, the kernel needs to be transferred to some form of secondary memory that either exists on the board or is connected to it. For example, on ARM Versatile boards, the kernel needs to be copied on to a flash device on the board. There may be two different kinds of procedures for doing this depending on the board.

The first is to copy the kernel on to an SD (Secure Digital) card memory, which can then be plugged into the board and copied to flash using boot-monitor commands. The other mechanism, if supported by the board, is to copy the kernel on to a flash memory on the board, using an USB cable, from another computer. Refer to the user manual for the board being used for the best possible way of doing this. The internet is also a very useful source of information for many different boards.

Now that the kernel is on the board, ensure that the root filesystem which had been created earlier is connected correctly to the target board. The boot procedure is almost ready to be initiated to have the system running. When an ARM system is powered on, the boot-monitor invokes the boot-loader. The boot-loader is then responsible for loading the kernel during the boot process. In some systems the boot-monitor and boot-loader are merged into a single entity.

The U-Boot boot-loader is popular on many ARM platforms. It is free and open-source. Other than U-Boot, there are also other boot-loaders which might be proprietary for certain ARM platforms. In order to interact with the boot-loader, it might be necessary to connect a serial interface between the board/platform and a personal computer running a serial terminal. Again, refer to the board's user manual for more details.

The boot-loader can pass a set of parameters to the kernel during the boot process. These are known as *bootargs* (an abbreviation for boot arguments). Actually, the bootloader passes parameters to the Kernel using ATAGS. One of these atags contains the Kernel command line, which is what bootargs refers to here. These parameters are used by the kernel for some initialization configurations. An example command for setting up the bootargs on ARM Versatile boards is shown below. This needs to be entered at the U-Boot prompt.

setenv bootargs root=/dev/sda1 mem=512M@0x20000000 ip=dhcp console=ttyAMA0 clcd=xvga rootwait

The 'bootargs' in this case specifies the following:

- The root-filesystem is in /dev/sda1.
- The memory region to be used by the operating system in the form of a size (512MB) and
 a starting address location. This isn't required if the bootloade passes the correct
 ATAG MEM atag.
- The IP address (for example, 192.168.0.7) or the mechanism for obtaining it (in this case DHCP).
- The display interface details.
- The delay required before trying to mount the root filesystem which may be needed for devices to be recognized (for example, USB disks).

The command above may be followed by a saveenv command in U-Boot, to save the changes into flash and make them permanent. In order to obtain a list of possible U-Boot commands type help at the U-Boot prompt. Type help <command> at the U-Boot prompt, to get more details regarding a particular command.

The boot-loader also needs a boot-command to start the boot process automatically. In the simplest case the bootcmd can be set as follows, where 0x41000000 is the location where the kernel is stored for example in flash memory.

setenv bootcmd bootm 0x41000000

If the kernel image exists at a different location, or on the network, a cp or tftp command can precede the bootm command. U-Boot commands on the same line need to be separated by a ";", for example:

setenv bootcmd cp 0x65000000 0x41000000 0x8000000; bootm 0x41000000

Again, a saveenv command would be required, to ensure that changes are saved to secondary storage. Now that the bootcmd is in place, the system needs to be restarted such that the "bootcmd" is used automatically and the system should start running. The sequence of boot-commands can also be entered manually at the U-Boot prompt, to try different options without saving them permanently.

C.4 Troubleshooting

Here are some commonly encountered problems while creating ARM Linux systems, and some hints to their diagnosis and cure.

- The kernel does not compile or make menuconfig fails.
 - Check if the ARM GNU compiler and toolchain has been correctly installed. An easy way of checking this is to see if a classic "Hello World" program can be cross-compiled for ARM. However, this simple program will not run on the x86 machine on which it is built, since it compiled for ARM. If it does run then the wrong toolchain has been used. Also check whether any libraries (for example, curses) are missing.
- The kernel gets built but does not execute at all on the target system.
 Ensure that the kernel has been built for the ARM architecture and not for x86.
 Sometimes, if the toolchain has not been configured correctly, the kernel gets built for the x86 system on which it is being compiled.
- The kernel starts executing on the target system but crashes half way through (a kernel panic error).
 - Check if the Board-Support-Packages (BSP) used correspond to the hardware platform being used. Ensure that the .config file used and the code-patches match the right hardware version.
- The kernel boots up but complains that it cannot find the root filesystem.

This could be due to a number of reasons; the check list is as follows:

- Ensure that the disk drive containing the root filesystem in connected correctly and there are no additional disks / drives connected to the board. This is necessary since if there are multiple disk drives connected to board and the board does not necessarily detect them in any particular order then board might assume one of the other drives to be the root filesystem and since it is not, the system will fail.
- The bootargs have not been setup correctly to point to the correct location of the root filesystem. Refer to the board documentation to check what the concerned disk drive will be detected as during boot-up.
- The disk drive has not been correctly partitioned or formatted. This occurs commonly when the disk-drive is either left as a FAT32 filesystem instead of a Linux partition such as EXT-2 or EXT-3. It is also observed when the partition-table has not been created correctly or has become corrupted due to some unsafe operation.
- The error message could also indicate that some critical system file is missing or corrupted. Sometimes a filesystem check using the fsck command can help in such a situation. Alternately the filesystem would need to be recreated.
- When the hardware platform is switched on it shows no output on screen.
 - Try to connect to connect a serial interface to the hardware platform/board. Often ARM development boards do not come with any prior configurations. If possible, look at the boot-monitor and boot-loader messages through a serial interface. Kernel debug messages can also be received through the channel if early_prtinks were enabled during the kernel build.