# MIPS assembly programming:

### Today's lecture

- Exam Structure
- Review the Datapath
  - Trace a couple of instructions
- Assembly programming
  - Register names
  - Arrays
  - Pseudo-instructions (including pseudo-branches)
  - If/else


### **Exam Structure**

3 main capabilities that you need to demonstrate:

- 1. Combinational Design (e.g., key pad
- 2. Sequential Design (e.g., score keeper)
- 3. Processor Datapath and Control (e.g., Lab 6)
  (all of these will be available for the 2<sup>nd</sup> chance exam)

#### In addition there will be a number of short answer questions

- Covering topics selected from all of the lectures
- (e.g., multiple choice, true/false, short answer)
  - The web problems are good examples of these questions.



Α	0
В	1
С	2
D	3

FOR-

OPCODE / FUNCT

NAME, MNEMONIC

MAT

OPERATION (in Verilog)


(Hex)

Load Word

lw

R[rt] = M[R[rs] + SignExtImm] (2)

 $23_{\text{hex}}$ 



Α	0
В	1
С	2
D	3

FOR-

OPCODE / FUNCT

NAME, MNEMONIC


MAT

OPERATION (in Verilog)

(Hex)

Load Upper Imm.

lui  $I R[rt] = \{imm, 16'b0\}$ 



Α	0
В	1
С	2
D	3

FOR-

OPCODE / FUNCT

NAME, MNEMONIC

MAT

OPERATION (in Verilog)


(Hex)

Add

add

 $R \quad R[rd] = R[rs] + R[rt]$ 

(1)  $0/20_{\text{hex}}$  6



FOR-

OPCODE / FUNCT

NAME, MNEMONIC

MAT

OPERATION (in Verilog)

(Hex)

Store Word

SW

 $I \quad M[R[rs]+SignExtImm] = R[rt]$  (2)

(2)  $2b_{\text{hex}}$ 

# What you will need to learn for exam 2

- You must become "fluent" in MIPS assembly:
  - Translate from C to MIPS and MIPS to C

#### Example problem from a 232 mid-term:

Question 3: Write a recursive function (30 points)

Here is a function pow that takes two arguments (n and m, both 32-bit numbers) and returns n<sup>m</sup> (i.e., n raised to the m<sup>th</sup> power).

```
int
pow(int n, int m) {
  if (m == 1)
    return n;
  return n * pow(n, m-1);
}
```

Translate this into a MIPS assembly language function.

### MIPS register names

- In hardware, all the registers are equivalent:
  - Except register \$0, which is always zero
- In software, we'll use them for different purposes.
  - So we give them meaningful names
- For temporary values, we'll use the \$t registers

If you have no reason for picking another register, then you should probably be using a \$t register.

### Review: arithmetic expressions

Complex arithmetic expressions may require multiple operations at the instruction set level.

$$t0 = (t1 + t2) \times (t3 - t4)$$

```
add $t0, $t1, $t2  # $t0 contains $t1 + $t2

sub $t5, $t3, $t4  # Temporary value $t5 = $t3 - $t4

mul $t0, $t0, $t5  # $t0 contains the final product
```

# Computing with memory

- So, to compute with memory-based data, you must:
  - 1. Load the data from memory to the register file.
  - 2. Do the computation, leaving the result in a register.
  - 3. Store that value back to memory if needed.
- For example, let's say that you wanted to do the same addition, but the values were in memory. How can we do the following using MIPS assembly language?

```
char A[4] = {1, 2, 3, 4};
int result;

result = A[0] + A[1] + A[2] + A[3];
```

### Allocating memory in the data segment

- Data define outside of functions is called global data
  - These variables can be accessed from any function
- This data is place in the program's global data segment
  - Allocated to memory addresses at compile time.
  - Amount of space allocated is based on variable type.

```
.data // indicates the beginning of data segment
.word // allocates space for 4-byte variable
.byte // allocates space for 1-byte variable
.asciiz // allocates space for an ASCII string
.space // allocates a defined amount of space.
```

### Review: Loading and storing bytes

The MIPS "load byte" instruction to transfers one byte of data from main memory to a register.

```
1b $t0, 20($a0) $a0 $t0 = Memory[$a0 + 20]
```

The "store byte" instruction sb transfers the lowest byte of data from a register into main memory.


```
$b $t0, 20($a0) # Memory[$a0 + 20] = $t0
```

# Review: Loading and storing words

You can also load or store 32-bit quantities—a complete word instead of just a byte—with the lw and sw instructions.


```
lw $t0, 20($a0)  # $t0 = Memory[$a0 + 20]
sw $t0, 20($a0)  # Memory[$a0 + 20] = $t0
```

- Most programming languages support several 32-bit data types.
  - Integers
  - Single-precision floating-point numbers
  - Memory addresses, or pointers
- Unless otherwise stated, we'll assume words are the basic unit of data.



# Review: Memory alignment


 Since memory is byte-addressable, a 32-bit word actually occupies four contiguous locations (bytes) of main memory.




- The MIPS architecture requires words to be aligned in memory; 32-bit words must start at an address that is divisible by 4.
  - 0, 4, 8 and 12 are valid word addresses.
  - 1, 2, 3, 5, 6, 7, 9, 10 and 11 are *not* valid word addresses.
  - Unaligned memory accesses result in a bus error, which you may have unfortunately seen before.

### **Arrays**

- Arrays are just groups of variables contiguous in memory
  - Contiguous = laid out one after another in memory.





### An array of words

- Remember to be careful with memory addresses when accessing words.
- For instance, assume an array of words begins at address 2000.
  - The first array element is at address 2000.
  - The second word is at address 2004, not 2001.
- Revisiting the earlier example, if \$a0 contains 2000, then

accesses the 0th word of the array, but

would access the 2nd word of the array, at address 2008.

### Pseudo-instructions

- MIPS assemblers support pseudo-instructions that give the illusion of a more expressive instruction set, but are actually translated into one or more simpler, "real" instructions.
- In addition to the la (load address) we saw in section, you can use the li and move pseudo-instructions:

They are probably clearer than their corresponding MIPS instructions:

```
addi $a0, $0, 2000  # Initialize $a0 to 2000
add $a1, $t0, $0  # Copy $t0 into $a1
```

- We'll see lots more pseudo-instructions this semester.
  - A complete list of instructions is given in <u>Appendix A</u> of the text.
  - Unless otherwise stated, you can always use pseudo-instructions in your assignments and on exams.

### Pseudo-branches (motivation)

Do you remember how much of a pain it to implement:

```
if (x < 10) {

bge $+4, 10, 5klp

...

sklp.
```

Need a slt and a beq.... (or is it a bne?)

```
slti $t0, $t4, 10  # immediate version of slt

____ $t0, $zero, skip_if_body # beq(a) or bne(b)?
_____
```

This is extremely error prone; bad design for humans

### Pseudo-branches

The MIPS processor only supports two branch instructions, beq and bne, but to simplify your life the assembler provides the following other branches:

```
blt $t0, $t1, L1 // Branch if $t0 < $t1
ble $t0, $t1, L2 // Branch if $t0 <= $t1
bgt $t0, $t1, L3 // Branch if $t0 > $t1
bge $t0, $t1, L4 // Branch if $t0 >= $t1
```

There are also immediate versions of these branches, where the second source is a constant instead of a register.

# Implementing pseudo-branches

Most pseudo-branches are implemented using slt. For example, a branch-if-less-than instruction blt \$a0, \$a1, Label is translated into the following.

```
slt $at, $a0, $a1  // $at = 1 if $a0 < $a1 bne $at, $0, Label  // Branch if $at != 0
```

- All of the pseudo-branches need a register to save the result of slt, even though it's not needed afterwards.
  - MIPS assemblers use register \$1, or \$at, for temporary storage.
  - You should probably avoid using \$at in your own programs, as it may be overwritten by assembler-generated code.

# Translating an if-then-else statements

- If there is an else clause, it is the target of the conditional branch
  - And the then clause needs a jump over the else clause

```
// increase the magnitude of v0 by one
if (v0 < 0)
    v0 --;
else
    v0 ++;
v1 = v0;</pre>
E:
L:
```

Dealing with else-if code is similar, but the target of the first branch will be another if statement.

# Translating an if-then-else statements

- If there is an else clause, it is the target of the conditional branch
  - And the then clause needs a jump over the else clause

```
// increase the magnitude of v0 by one
if (v0 < 0)
    v0 --;
    v0 ++;
v1 = v0;</pre>
bge $v0, $0, E
    sub $v0, $v0, 1
    j L
E: add $v0, $v0, 1
L: move $v1, $v0
```

- Dealing with else-if code is similar, but the target of the first branch will be another if statement.
  - Drawing the control-flow graph can help you out.

### Case/Switch Statement

Many high-level languages support multi-way branches, e.g.

```
switch (two_bits) {
  case 0: break;
  case 1: /* fall through */
  case 2: count ++; break;
  case 3: count += 2; break;
}
```

We could just translate the code to if, thens, and elses:

```
if ((two_bits == 1) || (two_bits == 2)) {
    count ++;
} else if (two_bits == 3) {
October 6, 2612**Int += 2; More MIPS instructions 24
```

### Case/Switch Statement

```
switch (two_bits) {
  case 0:    break;
  case 1:    /* fall through */
  case 2:    count ++;    break;
  case 3:    count += 2;    break;
}
```

#### Alternatively, we can:

- 1. Create an array of jump targets
- 2. Load the entry indexed by the variable two\_bits
- 3. Jump to that address using the jump register, or jr, instruction

October 6, 2012

More MIPS instructions

25

This is much easier to show than to tell.