



WHAT'S NEW

CUPTI contains a number of changes and new features as part of the CUDA Toolkit 5.5 release.

- ▶ Applications that use CUDA Dynamic Parallelism can now be profiled using CUPTI. Device-side kernel launches are reported using a new activity kind.
- Device attributes such as power usage, clocks, thermals, etc. are now reported via a new activity kind.
- A new activity buffer API uses callbacks to request and return buffers of activity records. The existing cuptiActivityEnqueueBuffer and cuptiActivityDequeueBuffer functions are still supported but are deprecated and will be removed in a future release.
- ► The Event API supports kernel replay so that any number of events can be collected during a single run of the application.
- A new metric API cuptiMetricGetValue2 allows metric values to be calculated for any device, even if that device is not available on the system.
- ► CUDA peer-to-peer memory copies are reported explicitly via the activity API. In previous releases these memory copies were only partially reported.

TABLE OF CONTENTS

Chapter 1. Introduction	1
1.1. CUPTI Compatibility and Requirements	1
1.2. CUPTI Initialization	1
1.3. CUPTI Activity API	2
1.4. CUPTI Callback API	3
1.4.1. Driver and Runtime API Callbacks	4
1.4.2. Resource Callbacks	5
1.4.3. Synchronization Callbacks	5
1.4.4. NVIDIA Tools Extension Callbacks	5
1.5. CUPTI Event API	7
1.5.1. Collecting Kernel Execution Events	8
1.5.2. Sampling Events	9
1.6. CUPTI Metric API	9
1.6.1. Metric Reference - Compute Capability 1.x	11
1.6.2. Metric Reference - Compute Capability 2.x	11
1.6.3. Metric Reference - Compute Capability 3.x	17
1.7. Samples	23
Chapter 2. Modules	24
2.1. CUPTI Version	24
cuptiGetVersion	24
CUPTI_API_VERSION	25
2.2. CUPTI Result Codes	25
CUptiResult	25
cuptiGetResultString	27
2.3. CUPTI Activity API	27
CUpti_Activity	28
CUpti_ActivityAPI	28
CUpti_ActivityBranch	28
CUpti_ActivityCdpKernel	28
CUpti_ActivityContext	28
CUpti_ActivityDevice	28
CUpti_ActivityEnvironment	28
CUpti_ActivityEvent	28
CUpti_ActivityEventInstance	28
CUpti_ActivityGlobalAccess	28
CUpti_ActivityKernel	28
CUpti_ActivityKernel2	28
CUpti_ActivityMarker	28
CUpti_ActivityMarkerData	29
CUpti_ActivityMemcpy	29

CUpti_ActivityMemcpy2	.29
CUpti_ActivityMemset	.29
CUpti_ActivityMetric	. 29
CUpti_ActivityMetricInstance	. 29
CUpti_ActivityName	. 30
CUpti_ActivityObjectKindId	. 30
CUpti_ActivityOverhead	. 30
CUpti_ActivityPreemption	. 30
CUpti_ActivitySourceLocator	. 30
CUpti_ActivityAttribute	.30
CUpti_ActivityComputeApiKind	
CUpti_ActivityEnvironmentKind	. 31
CUpti_ActivityFlag	. 31
CUpti_ActivityKind	.32
CUpti_ActivityMemcpyKind	
CUpti_ActivityMemoryKind	. 36
CUpti_ActivityObjectKind	
CUpti_ActivityOverheadKind	
CUpti_ActivityPreemptionKind	
CUpti_EnvironmentClocksThrottleReason	
CUpti_BuffersCallbackCompleteFunc	
CUpti_BuffersCallbackRequestFunc	. 38
cuptiActivityDequeueBuffer	
cuptiActivityDisable	. 40
cuptiActivityDisableContext	40
cuptiActivityEnable	
cuptiActivityEnableContext	. 41
cuptiActivityEnqueueBuffer	. 42
cuptiActivityFlush	.44
cuptiActivityFlushAll	. 45
cuptiActivityGetAttribute	. 45
cuptiActivityGetNextRecord	
cuptiActivityGetNumDroppedRecords	
cuptiActivityQueryBuffer	. 48
cuptiActivityRegisterCallbacks	
cuptiActivitySetAttribute	. 49
cuptiGetDeviceId	
cuptiGetStreamId	
cuptiGetTimestamp	
CUPTI_CORRELATION_ID_UNKNOWN	
CUPTI_GRID_ID_UNKNOWN	
CUPTI_SOURCE_LOCATOR_ID_UNKNOWN	. 52
CUPTI TIMESTAMP UNKNOWN	. 52

2.	4. CUPTI Callback API	.52
	CUpti_CallbackData	53
	CUpti_NvtxData	53
	CUpti_ResourceData	.53
	CUpti_SynchronizeData	53
	CUpti_ApiCallbackSite	53
	CUpti_CallbackDomain	. 53
	CUpti_CallbackIdResource	. 54
	CUpti_CallbackIdSync	54
	CUpti_CallbackFunc	55
	CUpti_CallbackId	.55
	CUpti_DomainTable	
	CUpti_SubscriberHandle	
	cuptiEnableAllDomains	.55
	cuptiEnableCallback	
	cuptiEnableDomain	. 57
	cuptiGetCallbackName	
	cuptiGetCallbackState	59
	cuptiSubscribe	
	cuptiSupportedDomains	.61
	cuptiUnsubscribe	
2.	5. CUPTI Event API	
	CUpti_EventGroupSet	
	CUpti_EventGroupSets	62
	CUpti_DeviceAttribute	
	CUpti_DeviceAttributeDeviceClass	
	CUpti_EventAttribute	63
	CUpti_EventCategory	.63
	CUpti_EventCollectionMethod	64
	CUpti_EventCollectionMode	.64
	CUpti_EventDomainAttribute	65
	CUpti_EventGroupAttribute	. 65
	CUpti_ReadEventFlags.	66
	CUpti_EventDomainID	. 66
	CUpti_EventGroup	66
	CUpti_EventID	. 66
	cuptiDeviceEnumEventDomains	67
	cuptiDeviceGetAttribute	
	cuptiDeviceGetEventDomainAttribute	
	cuptiDeviceGetNumEventDomains	70
	cuptiDeviceGetTimestamp	70
	cuptiDisableKernelReplayMode	71
	cuptiFnableKernelReplayMode	. 71

	cuptiEnumEventDomains	72
	cuptiEventDomainEnumEvents	.73
	cuptiEventDomainGetAttribute	.73
	cuptiEventDomainGetNumEvents	75
	cuptiEventGetAttribute	.75
	cuptiEventGetIdFromName	.76
	cuptiEventGroupAddEvent	77
	cuptiEventGroupCreate	78
	cuptiEventGroupDestroy	79
	cuptiEventGroupDisable	80
	cuptiEventGroupEnable	.80
	cuptiEventGroupGetAttribute	
	cuptiEventGroupReadAllEvents	82
	cuptiEventGroupReadEvent	
	cuptiEventGroupRemoveAllEvents	85
	cuptiEventGroupRemoveEvent	.86
	cuptiEventGroupResetAllEvents	
	cuptiEventGroupSetAttribute	87
	cuptiEventGroupSetDisable	
	cuptiEventGroupSetEnable	89
	cuptiEventGroupSetsCreate	90
	cuptiEventGroupSetsDestroy	91
	cuptiGetNumEventDomains	
	cuptiSetEventCollectionMode	92
	CUPTI_EVENT_OVERFLOW	92
2.	6. CUPTI Metric API	93
	CUpti_MetricValue	93
	CUpti_MetricAttribute	93
	CUpti_MetricCategory	.93
	CUpti_MetricEvaluationMode	94
	CUpti_MetricPropertyDeviceClass	94
	CUpti_MetricPropertyID	94
	CUpti_MetricValueKind	.95
	CUpti_MetricValueUtilizationLevel	. 95
	CUpti_MetricID	96
	cuptiDeviceEnumMetrics	.96
	cuptiDeviceGetNumMetrics	97
	cuptiEnumMetrics	. 97
	cuptiGetNumMetrics	.98
	cuptiMetricCreateEventGroupSets	98
	cuptiMetricEnumEvents	99
	cuptiMetricEnumProperties1	00
	cuntiMatricCotAttributo	101

cuptiMetricGetIdFromName	102
cuptiMetricGetNumEvents	102
cuptiMetricGetNumProperties	103
cuptiMetricGetValue	103
cuptiMetricGetValue2	105
Chapter 3. Data Structures	108
CUpti_Activity	110
kind	110
CUpti_ActivityAPI	110
cbid	110
correlationId	110
end	111
kind	111
processId	111
returnValue	111
start	111
threadId	111
CUpti_ActivityBranch	112
correlationId	112
diverged	112
executed	112
kind	112
pcOffset	112
sourceLocatorId	112
threadsExecuted	113
CUpti_ActivityCdpKernel	113
blockX	113
blockY	113
blockZ	113
completed	113
contextId	113
correlationId	114
deviceld	114
dynamicSharedMemory	114
end	114
executed	114
gridld	114
gridX	115
gridY	115
gridZ	115
kind	115
localMemoryPerThread	115
local Memory Total	115

	name	115
	parentBlockX	116
	parentBlockY	116
	parentBlockZ	116
	parentGridId	116
	queued	116
	registersPerThread	116
	requested	116
	sharedMemoryConfig	.117
	start	117
	staticSharedMemory	117
	streamld	117
	submitted	.117
Cl	Jpti_ActivityContext	117
	computeApiKind	118
	contextld	118
	deviceld	118
	kind	118
Cι	Jpti_ActivityDevice	118
	computeCapabilityMajor	118
	computeCapabilityMinor	119
	constantMemorySize	119
	coreClockRate	119
	flags	119
	globalMemoryBandwidth	119
	globalMemorySize	119
	id	.119
	kind	120
	l2CacheSize	120
	maxBlockDimX	120
	maxBlockDimY	120
	maxBlockDimZ	120
	maxBlocksPerMultiprocessor	120
	maxGridDimX	120
	maxGridDimY	121
	maxGridDimZ	.121
	maxIPC	121
	maxRegistersPerBlock	.121
	maxSharedMemoryPerBlock	.121
	maxThreadsPerBlock	121
	maxWarpsPerMultiprocessor	121
	name	122
	numMemcpyEngines	122

	numMultiprocessors	122
	numThreadsPerWarp	122
CU	pti_ActivityEnvironment	122
	clocksThrottleReasons	122
	cooling	123
	deviceld	123
	environmentKind	123
	fanSpeed	123
	gpuTemperature	123
	kind	123
	memoryClock	123
	pcieLinkGen	124
	pcieLinkWidth	124
	power	124
	power	124
	powerLimit	124
:	smClock	124
:	speed	124
	temperature	125
	timestamp	125
CU	pti_ActivityEvent	125
	correlationId	125
	domain	125
	id	125
	kind	126
	value	
	pti_ActivityEventInstance	
	correlationId	
	domain	126
	id	
	instance	127
	kind	127
	pad	
,	value	127
	pti_ActivityGlobalAccess	
	correlationId	
	executed	
	flags	128
	kind	
	I2_transactions	
	pcOffset	
	sourceLocatorld	
	threadsExecuted	

CUpti_ActivityKernel	128
blockX	129
blockY	129
blockZ	129
cacheConfigExecuted	129
cacheConfigRequested	129
contextId	129
correlationId	130
deviceld	130
dynamicSharedMemory	
end	130
gridX	130
gridY	130
gridZ	130
kind	131
localMemoryPerThread	131
localMemoryTotal	131
name	131
pad	131
registersPerThread	131
reserved0	131
runtimeCorrelationId	132
start	132
staticSharedMemory	132
streamld	132
CUpti_ActivityKernel2	132
blockX	132
blockY	133
blockZ	133
completed	133
contextld	133
correlationId	133
deviceld	133
dynamicSharedMemory	133
end	134
executed	134
gridld	
gridX	
gridY	
gridZ	
kind	
localMemoryPerThread	
localMemoryTotal	

name	135
registersPerThread	135
requested	135
reserved0	135
sharedMemoryConfig	135
start	136
staticSharedMemory	136
streamld	136
CUpti_ActivityMarker	136
flags	136
id	136
kind	137
name	137
objectId	137
objectKind	137
timestamp	137
CUpti_ActivityMarkerData	137
category	138
color	138
flags	138
id	138
kind	138
payload	138
payloadKind	139
CUpti_ActivityMemcpy	139
bytes	139
contextld	139
copyKind	139
correlationId	139
deviceld	140
dstKind	140
end	140
flags	140
kind	140
reserved0	140
runtimeCorrelationId	141
srcKind	141
start	141
streamld	141
CUpti_ActivityMemcpy2	141
bytes	
contextId	
copyKind	

correlationId	. 142
deviceIddeviceId	. 142
dstContextId	142
dstDeviceId	. 142
dstKind	. 143
end	143
flagsflags	. 143
kind	. 143
pad	143
reserved0	. 143
srcContextId	.144
srcDeviceId	. 144
srcKind	. 144
start	. 144
streamld	. 144
CUpti_ActivityMemset	. 144
bytes	145
contextld	145
correlationId	. 145
deviceld	. 145
end	145
kind	. 145
reserved0	. 145
runtimeCorrelationId	146
start	. 146
streamld	. 146
value	146
CUpti_ActivityMetric	.146
correlationId	. 146
flagsflags	. 147
id	.147
kind	
pad	147
value	147
CUpti_ActivityMetricInstance	
correlationId	
flags	
id	.148
instance	. 148
kind	
pad	
value	
Clinti ActivityNamo	1/0

kind	149
name	149
objectId	149
objectKindobjectKind	149
CUpti_ActivityObjectKindId	149
dcs	150
pt	150
CUpti_ActivityOverhead	150
end	150
kind	150
objectId	151
objectKind	151
overheadKind	151
start	151
CUpti_ActivityPreemption	151
blockX	151
blockY	152
blockZ	152
gridld	152
kind	152
pad	152
preemptionKind	152
timestamp	
CUpti_ActivitySourceLocator	
fileName	
id	153
kind	153
lineNumber	153
CUpti_CallbackData	153
callbackSite	154
context	154
contextUid	154
correlationData	154
correlationId	154
functionName	155
functionParams	155
functionReturnValue	
symbolName	
CUpti_EventGroupSet	
eventGroups.	
numEventGroups	
CUpti_EventGroupSets	
numSats	156

sets	156
CUpti_MetricValue	156
CUpti_NvtxData	157
functionName	
functionParams	157
CUpti_ResourceData	157
context	
resourceDescriptor	
stream	
CUpti_SynchronizeData	158
context	
stream	158
Chapter 4. Data Fields	

LIST OF TABLES

Table 1	Capability 1	1.x Metrics	11
Table 2	Capability 2	2.x Metrics	12
Table 3	Capability 3	3.x Metrics	17

Chapter 1. INTRODUCTION

The *CUDA Profiling Tools Interface* (CUPTI) enables the creation of profiling and tracing tools that target CUDA applications. CUPTI provides four APIs: *the Activity API*, the *Callback API*, the *Event API*, and the *Metric API*. Using these APIs, you can develop profiling tools that give insight into the CPU and GPU behavior of CUDA applications. CUPTI is delivered as a dynamic library on all platforms supported by CUDA.

1.1. CUPTI Compatibility and Requirements

New versions of the CUDA driver are backwards compatible with older versions of CUPTI. For example, a developer using a profiling tool based on CUPTI 4.1 can update to a more recently released CUDA driver. However, new versions of CUPTI are not backwards compatible with older versions of the CUDA driver. For example, a developer using a profiling tool based on CUPTI 4.1 must have a version of the CUDA driver released with CUDA Toolkit 4.1 (or later) installed as well. CUPTI calls will fail with CUPTI_ERROR_NOT_INITIALIZED if the CUDA driver version is not compatible with the CUPTI version.

1.2. CUPTI Initialization

CUPTI initialization occurs lazily the first time you invoke any CUPTI function. For the Event, Metric, and Callback APIs there are no requirements on when this initialization must occur (i.e. you can invoke the first CUPTI function at any point). For correct operation, the Activity API does require that CUPTI be initialized before any CUDA driver or runtime API is invoked. See the CUPTI Activity API section for more information on CUPTI initialization requirements for the activity API.

1.3. CUPTI Activity API

The CUPTI Activity API allows you to asynchronously collect a trace of an application's CPU and GPU CUDA activity. The following terminology is used by the activity API.

Activity Record

CPU and GPU activity is reported in C data structures called activity records. There is a different C structure type for each activity kind (e.g. CUpti_ActivityMemcpy). Records are generically referred to using the CUpti_Activity type. This type contains only a kind field that indicates the kind of the activity record. Using this kind, the object can be cast from the generic CUpti_Activity type to the specific type representing the activity. See the printActivity function in the activity_trace_async sample for an example.

Activity Buffer

An activity buffer is used to transfer one or more activity records from CUPTI to the client. CUPTI fills activity buffers with activity records as the corresponding activities occur on the CPU and GPU. The CUPTI client is responsible for providing empty activity buffers as necessary to ensure that no records are dropped.

This section describes the new asynchronous buffering API implemented by cuptiActivityRegisterCallbacks, cuptiActivityFlush, and cuptiActivityFlushAll. The old buffering API implemented by cuptiActivityEnqueueBuffer and cuptiActivityDequeueBuffer is still supported but is deprecated and will be removed in a future release (see the API documentation for information on these functions).

To ensure that all activity records are collected, CUPTI must be initialized before any CUDA driver or runtime API is invoked. Initialization can be done by enabling one or more activity kinds using cuptiActivityEnable or cuptiActivityEnableContext, as shown in the initTrace function of the activity_trace_async sample. Some activity kinds cannot be directly enabled, see the API documentation for for CUpti_ActivityKind for details. Functions cuptiActivityEnable and cuptiActivityEnableContext will return CUPTI_ERROR_NOT_COMPATIBLE if the requested activity kind cannot be enabled.

The new activity buffer API uses callbacks to request and return buffers of activity records. The use the asynchronous buffering API you must first register two callbacks using cuptiActivityRegisterCallbacks. One of these callbacks will be invoked whenever CUPTI needs an empty activity buffer. The other callback is used to deliver a buffer containing one or more activity records to the client. To minimize profiling overhead the client should return as quickly as possible from these callbacks. Functions cuptiActivityFlush and cuptiActivityFlushAll can be used to force CUPTI to deliver any activity buffers that contain completed activity records. Functions cuptiActivityGetAttribute and cuptiActivitySetAttribute can be used

to read and write attributes that control how the buffering API behaves. See the API documentation for more information.

The activity_trace_async sample shows how to use the activity buffer API to collect a trace of CPU and GPU activity for a simple application.

1.4. CUPTI Callback API

The CUPTI Callback API allows you to register a callback into your own code. Your callback will be invoked when the application being profiled calls a CUDA runtime or driver function, or when certain events occur in the CUDA driver. The following terminology is used by the callback API.

Callback Domain

Callbacks are grouped into domains to make it easier to associate your callback functions with groups of related CUDA functions or events. There are currently four callback domains, as defined by CUpti_CallbackDomain: a domain for CUDA runtime functions, a domain for CUDA driver functions, a domain for CUDA resource tracking, and a domain for CUDA synchronization notification.

Callback ID

Each callback is given a unique ID within the corresponding callback domain so that you can identify it within your callback function. The CUDA driver API IDs are defined in <code>cupti_driver_cbid.h</code> and the CUDA runtime API IDs are defined in <code>cupti_runtime_cbid.h</code>. Both of these headers are included for you when you include <code>cupti.h</code>. The CUDA resource callback IDs are defined by <code>CUpti_CallbackIdResource</code> and the CUDA synchronization callback IDs are defined by <code>CUpti_CallbackIdSync</code>.

Callback Function

Your callback function must be of type <code>CUpti_CallbackFunc</code>. This function type has two arguments that specify the callback domain and ID so that you know why the callback is occurring. The type also has a <code>cbdata</code> argument that is used to pass data specific to the callback.

Subscriber

A subscriber is used to associate each of your callback functions with one or more CUDA API functions. There can be at most one subscriber initialized with cuptiSubscribe() at any time. Before initializing a new subscriber, the existing subscriber must be finalized with cuptiUnsubscribe().

Each callback domain is described in detail below. Unless explicitly stated, it is not supported to call any CUDA runtime or driver API from within a callback function. Doing so may cause the application to hang.

1.4.1. Driver and Runtime API Callbacks

Using the callback API with the CUPTI_CB_DOMAIN_DRIVER_API or CUPTI_CB_DOMAIN_RUNTIME_API domains, you can associate a callback function with one or more CUDA API functions. When those CUDA functions are invoked in the application, your callback function is invoked as well. For these domains, the cbdata argument to your callback function will be of the type CUpti CallbackData.

It is legal to call cudaThreadSynchronize(), cudaDeviceSynchronize(), cudaStreamSynchronize(), cuCtxSynchronize(), and cuStreamSynchronize() from within a driver or runtime API callback function.

The following code shows a typical sequence used to associate a callback function with one or more CUDA API functions. To simplify the presentation error checking code has been removed.

First, cuptiSubscribe is used to initialize a subscriber with the my_callback callback function. Next, cuptiEnableDomain is used to associate that callback with all the CUDA runtime API functions. Using this code sequence will cause my_callback to be called twice each time any of the CUDA runtime API functions are invoked, once on entry to the CUDA function and once just before exit from the CUDA function. CUPTI callback API functions cuptiEnableCallback and cuptiEnableAllDomains can also be used to associate CUDA API functions with a callback (see reference below for more information).

The following code shows a typical callback function.

In your callback function, you use the <code>CUpti_CallbackDomain</code> and <code>CUpti_CallbackID</code> parameters to determine which <code>CUDA</code> API function invocation is causing this callback. In the example above, we are checking for the <code>CUDA</code> runtime <code>cudaMemcpy</code> function. The <code>cbdata</code> parameter holds a structure of useful information that can be used within the callback. In this case we use the <code>callbackSite</code> member of the structure to detect that the callback is occurring on entry to <code>cudaMemcpy</code>, and we use the <code>functionParams</code> member to access the parameters that were passed to <code>cudaMemcpy</code>. To access the parameters we first cast <code>functionParams</code> to a structure type corresponding to the <code>cudaMemcpy</code> function. These parameter structures are contained in <code>generated_cuda_runtime_api_meta.h</code>, <code>generated_cuda_meta.h</code>, and a number of other files. When possible these files are included for you by <code>cupti.h</code>.

The **callback_event** and **callback_timestamp** samples described on the samples page both show how to use the callback API for the driver and runtime API domains.

1.4.2. Resource Callbacks

Using the callback API with the CUPTI_CB_DOMAIN_RESOURCE domain, you can associate a callback function with some CUDA resource creation and destruction events. For example, when a CUDA context is created, your callback function will be invoked with a callback ID equal to CUPTI_CBID_RESOURCE_CONTEXT_CREATED. For this domain, the cbdata argument to your callback function will be of the type CUpti ResourceData.

1.4.3. Synchronization Callbacks

Using the callback API with the CUPTI_CB_DOMAIN_SYNCHRONIZE domain, you can associate a callback function with CUDA context and stream synchronizations. For example, when a CUDA context is synchronized, your callback function will be invoked with a callback ID equal to CUPTI_CBID_SYNCHRONIZE_CONTEXT_SYNCHRONIZED. For this domain, the cbdata argument to your callback function will be of the type CUpti SynchronizeData.

1.4.4. NVIDIA Tools Extension Callbacks

Using the callback API with the CUPTI_CB_DOMAIN_NVTX domain, you can associate a callback function with NVIDIA Tools Extension (NVTX) API functions. When an NVTX function is invoked in the application, your callback function is invoked as well. For these domains, the cbdata argument to your callback function will be of the type CUpti NvtxData.

The NVTX library has its own convention for discovering the profiling library that will provide the implementation of the NVTX callbacks. To receive callbacks you must set the NVTX environment variables appropriately so that when the application calls an NVTX

function, your profiling library recieve the callbacks. The following code sequence shows a typical initialization sequence to enable NVTX callbacks and activity records.

```
/* Set env so CUPTI-based profiling library loads on first nvtx call. */
char *inj32_path = "/path/to/32-bit/version/of/cupti/based/profiling/library";
char *inj64_path = "/path/to/64-bit/version/of/cupti/based/profiling/library";
setenv("NVTX_INJECTION32_PATH", inj32_path, 1);
setenv("NVTX_INJECTION64_PATH", inj64_path, 1);
```

The following code shows a typical sequence used to associate a callback function with one or more NVTX functions. To simplify the presentation error checking code has been removed.

First, cuptiSubscribe is used to initialize a subscriber with the my_callback callback function. Next, cuptiEnableDomain is used to associate that callback with all the NVTX functions. Using this code sequence will cause my_callback to be called once each time any of the NVTX functions are invoked. CUPTI callback API functions cuptiEnableCallback and cuptiEnableAllDomains can also be used to associate NVTX API functions with a callback (see reference below for more information).

The following code shows a typical callback function.

In your callback function, you use the <code>CUpti_CallbackDomain</code> and <code>CUpti_CallbackID</code> parameters to determine which NVTX API function invocation is causing this callback. In the example above, we are checking for the <code>nvtxNameOsThreadA</code> function. The <code>cbdata</code> parameter holds a structure of useful information that can be used within the callback. In this case, we use the <code>functionParams</code> member to access the parameters that were passed to <code>nvtxNameOsThreadA</code>. To access the parameters we first cast <code>functionParams</code> to a structure type corresponding to the <code>nvtxNameOsThreadA</code> function. These parameter structures are contained in <code>generated nvtx meta.h</code>.

1.5. CUPTI Event API

The CUPTI Event API allows you to query, configure, start, stop, and read the event counters on a CUDA-enabled device. The following terminology is used by the event API.

Event

An event is a countable activity, action, or occurrence on a device.

Event ID

Each event is assigned a unique identifier. A named event will represent the same activity, action, or occurrence on all device types. But the named event may have different IDs on different device families. Use <code>cuptiEventGetIdFromName</code> to get the ID for a named event on a particular device.

Event Category

Each event is placed in one of the categories defined by CUpti_EventCategory. The category indicates the general type of activity, action, or occurrence measured by the event.

Event Domain

A device exposes one or more event domains. Each event domain represents a group of related events available on that device. A device may have multiple instances of a domain, indicating that the device can simultaneously record multiple instances of each event within that domain.

Event Group

An event group is a collection of events that are managed together. The number and type of events that can be added to an event group are subject to device-specific limits. At any given time, a device may be configured to count events from a limited number of event groups. All events in an event group must belong to the same event domain.

Event Group Set

An event group set is a collection of event groups that can be enabled at the same time. Event group sets are created by <code>cuptiEventGroupSetsCreate</code> and <code>cuptiMetricCreateEventGroupSets</code>.

You can determine the events available on a device using the cuptiDeviceEnumEventDomains and cuptiEventDomainEnumEvents functions. The cupti_query sample described on the samples page shows how to use these functions. You can also enumerate all the CUPTI events available on any device using the cuptiEnumEventDomains function.

Configuring and reading event counts requires the following steps. First, select your event collection mode. If you want to count events that occur during the execution of a kernel, use <code>cuptiSetEventCollectionMode</code> to set mode <code>CUPTI_EVENT_COLLECTION_MODE_KERNEL</code>. If you want to continuously sample the event counts, use mode <code>CUPTI_EVENT_COLLECTION_MODE_CONTINUOUS</code>.

Next determine the names of the events that you want to count, and then use the <code>cuptiEventGroupCreate</code>, <code>cuptiEventGetIdFromName</code>, and <code>cuptiEventGroupAddEvent</code> functions to create and initialize an event group with those events. If you are unable to add all the events to a single event group then you will need to create multiple event groups. Alternatively, you can use the <code>cuptiEventGroupSetsCreate</code> function to automatically create the event group(s) required for a set of events.

To begin counting a set of events, enable the event group or groups that contain those events by using the <code>cuptiEventGroupEnable</code> function. If your events are contained in multiple event groups you may be unable to enable all of the event groups at the same time, due to device limitations. In this case, you can gather the events across multiple executions of the application or you can enable kernel replay. If you enable kernel replay using <code>cuptiEnableKernelReplayMode</code> you will be able to enabled any number of event groups and all the contained events will be collect.

Use the cuptiEventGroupReadEvent and/or cuptiEventGroupReadAllEvents functions to read the event values. When you are done collecting events, use the cuptiEventGroupDisable function to stop counting of the events contained in an event group. The callback_event sample described on the samples page shows how to use these functions to create, enable, and disable event groups, and how to read event counts.

1.5.1. Collecting Kernel Execution Events

A common use of the event API is to count a set of events during the execution of a kernel (as demonstrated by the **callback_event** sample). The following code shows a typical callback used for this purpose. Assume that the callback was enabled only for a kernel launch using the CUDA runtime (i.e. by cuptiEnableCallback(1, subscriber, CUPTI_CB_DOMAIN_RUNTIME_API, CUPTI_RUNTIME_TRACE_CBID_cudaLaunch_v3020). To simplify the presentation error checking code has been removed.

Two synchronization points are used to ensure that events are counted only for the execution of the kernel. If the application contains other threads that launch kernels, then additional thread-level synchronization must also be introduced to ensure that those threads do not launch kernels while the callback is collecting events. When the cudaLaunch API is entered (that is, before the kernel is actually launched on the device), cudaThreadSynchronize is used to wait until the GPU is idle. The event collection mode is set to CUPTI_EVENT_COLLECTION_MODE_KERNEL so that the event counters are automatically started and stopped just before and after the kernel executes. Then event collection is enabled with cuptiEventGroupEnable.

When the cudaLaunch API is exited (that is, after the kernel is queued for execution on the GPU) another cudaThreadSynchronize is used to cause the CPU thread to wait for the kernel to finish execution. Finally, the event counts are read with cuptiEventGroupReadEvent.

1.5.2. Sampling Events

The event API can also be used to sample event values while a kernel or kernels are executing (as demonstrated by the **event_sampling** sample). The sample shows one possible way to perform the sampling. The event collection mode is set to CUPTI_EVENT_COLLECTION_MODE_CONTINUOUS so that the event counters run continuously. Two threads are used in **event_sampling**: one thread schedules the kernels and memcpys that perform the computation, while another thread wakes periodically to sample an event counter. In this sample there is no correlation of the event samples with what is happening on the GPU. To get some coarse correlation, you can use <code>cuptiDeviceGetTimestamp</code> to collect the GPU timestamp at the time of the sample and also at other interesting points in your application.

1.6. CUPTI Metric API

The CUPTI Metric API allows you to collect application metrics calculated from one or more event values. The following terminology is used by the metric API.

Metric

An characteristic of an application that is calculated from one or more event values.

Metric ID

Each metric is assigned a unique identifier. A named metric will represent the same characteristic on all device types. But the named metric may have different IDs on different device families. Use <code>cuptiMetricGetIdFromName</code> to get the ID for a named metric on a particular device.

Metric Category

Each metric is placed in one of the categories defined by CUpti_MetricCategory. The category indicates the general type of the characteristic measured by the metric.

Metric Property

Each metric is calculated from input values. These input values can be events or properties of the device or system. The available properties are defined by CUpti MetricPropertyID.

Metric Value

Each metric has a value that represents one of the kinds defined by CUpti_MetricValueKind. For each value kind, there is a corresponding member of the CUpti MetricValue union that is used to hold the metric's value.

The tables included in this section list the metrics available for each device, as determined by the device's compute capability. You can also determine the metrics available on a device using the <code>cuptiDeviceEnumMetrics</code> function. The <code>cupti_query</code> sample described on the samples page shows how to use this function. You can also enumerate all the CUPTI metrics available on any device using the <code>cuptiEnumMetrics</code> function.

CUPTI provides two functions for calculating a metric value. cuptiMetricGetValue2 can be used to calculate a metric value when the device is not available. All required event values and metric properties must be provided by the caller. cuptiMetricGetValue can be used to calculate a metric value when the device is available (as a CUdevice object). All required event values must be provided by the caller but CUPTI will determine the appropriate property values from the CUdevice object.

Configuring and calculating metric values requires the following steps. First, determine the name of the metric that you want to collect, and then use the <code>cuptiMetricGetIdFromName</code> to get the metric ID. Use <code>cuptiMetricEnumEvents</code> to get the events required to calculate the metric and follow instructions in the CUPTI Event API section to create the event groups for those events. Alternatively, you can use the <code>cuptiMetricCreateEventGroupSets</code> function to automatically create the event group(s) required for metric's events.

If you are using cuptiMetricGetValue2 the you must also collect the required metric property values using cuptiMetricEnumProperties.

Collect event counts as described in the CUPTI Event API section, and then use either cuptiMetricGetValue or cuptiMetricGetValue2 to calculate the metric value from the collected event and property values. The **callback_metric** sample described on the samples page shows how to use the functions to calculate event values and calculate a metric using cuptiMetricGetValue. Note that, as shown in the example, you should collect event counts from all domain instances and normalize the counts to get the most accurate metric values. It is necessary to normalize the event counts because the number of event counter instances varies by device and by the event being counted.

For example, a device might have 8 multiprocessors but only have event counters for 4 of the multiprocessors, and might have 3 memory units and only have events counters for one memory unit. When calculating a metric that requires a multiprocessor event and a memory unit event, the 4 multiprocessor counters should be summed and multiplied by 2 to normalize the event count across the entire device. Similarly, the one memory unit counter should be multiplied by 3 to normalize the event count across the entire device. The normalized values can then be passed to cuptiMetricGetValue or cuptiMetricGetValue2 to calculate the metric value.

As described, the normalization assumes the kernel executes a sufficient number of blocks to completely load the device. If the kernel has only a small number of blocks, normalizing across the entire device may skew the result.

1.6.1. Metric Reference - Compute Capability 1.x

Devices with compute capability less than 2.0 implement the metrics shown in the following table. A scope value of single-context indicates that the metric can only be accurately collected when a single context (CUDA or graphic) is executing on the GPU. A scope value of multi-context indicates that the metric can be accurately collected when multiple contexts are executing on the GPU.

Table 1 Capability 1.x Metrics

Metric Name	Description	Scope
branch_efficiency	Ratio of non-divergent branches to total branches	Single-context
gld_efficiency	Ratio of requested global memory load transactions to actual global memory load transactions	Single-context
gst_efficiency	Ratio of requested global memory store transactions to actual global memory store transactions	Single-context
gld_requested_throughput	Requested global memory load throughput	Single-context
gst_requested_throughput	Requested global memory store throughput	Single-context

1.6.2. Metric Reference - Compute Capability 2.x

Devices with compute capability between 2.0, inclusive, and 3.0 implement the metrics shown in the following table. A scope value of single-context indicates that the metric can only be accurately collected when a single context (CUDA or graphic) is executing on the GPU. A scope value of multi-context indicates that the metric can be accurately collected when multiple contexts are executing on the GPU.

Table 2 Capability 2.x Metrics

Metric Name	Description	Scope
sm_efficiency	The percentage of time at least one warp is active on a multiprocessor averaged over all multiprocessors on the GPU	Single-context
sm_efficiency_instance	The percentage of time at least one warp is active on a specific multiprocessor	Single-context
achieved_occupancy	Ratio of the average active warps per active cycle to the maximum number of warps supported on a multiprocessor	Multi-context
issue_slot_utilization	Percentage of issue slots that issued at least one instruction, averaged across all cycles	Multi-context
inst_executed	The number of instructions executed	Multi-context
inst_issued	The number of instructions issued	Multi-context
issue_slots	The number of issue slots used	Multi-context
executed_ipc	Instructions executed per cycle	Multi-context
issued_ipc	Instructions issued per cycle	Multi-context
ipc_instance	Instructions executed per cycle for a single multiprocessor	Multi-context
inst_per_warp	Average number of instructions executed by each warp	Multi-context
cf_issued	Number of issued control-flow instructions	Multi-context
cf_executed	Number of executed control-flow instructions	Multi-context
ldst_issued	Number of issued load and store instructions	Multi-context
ldst_executed	Number of executed load and store instructions	Multi-context
branch_efficiency	Ratio of non-divergent branches to total branches	Multi-context
warp_execution_efficiency	Ratio of the average active threads per warp to the maximum number of threads per warp supported on a multiprocessor	Multi-context
inst_replay_overhead	Average number of replays for each instruction executed	Multi-context

Metric Name	Description	Scope
shared_replay_overhead	Average number of replays due to shared memory conflicts for each instruction executed	Single-context
global_cache_replay_overhead	Average number of replays due to global memory cache misses for each instruction executed	Single-context
local_replay_overhead	Average number of replays due to local memory accesses for each instruction executed	Single-context
gld_efficiency	Ratio of requested global memory load throughput to required global memory load throughput	Single-context
gst_efficiency	Ratio of requested global memory store throughput to required global memory store throughput	Single-context
gld_transactions	Number of global memory load transactions	Single-context
gst_transactions	Number of global memory store transactions	Single-context
gld_transactions_per_request	Average number of global memory load transactions performed for each global memory load	Single-context
gst_transactions_per_request	Average number of global memory store transactions performed for each global memory store	Single-context
gld_throughput	Global memory load throughput	Single-context
gst_throughput	Global memory store throughput	Single-context
gld_requested_throughput	Requested global memory load throughput	Multi-context
gst_requested_throughput	Requested global memory store throughput	Multi-context
local_load_transactions	Number of local memory load transactions	Single-context
local_store_transactions	Number of local memory store transactions	Single-context
local_load_transactions_per_ request	Average number of local memory load transactions performed for each local memory load	Single-context

Metric Name	Description	Scope
local_store_transactions_per_ request	Average number of local memory store transactions performed for each local memory store	Single-context
local_load_throughput	Local memory load throughput	Single-context
local_store_throughput	Local memory store throughput	Single-context
shared_load_transactions	Number of shared memory load transactions	Single-context
shared_store_transactions	Number of shared memory store transactions	Single-context
shared_load_transactions_per_ request	Average number of shared memory load transactions performed for each shared memory load	Single-context
shared_store_transactions_per_ request	Average number of shared memory store transactions performed for each shared memory store	Single-context
shared_load_throughput	Shared memory load throughput	Single-context
shared_store_throughput	Shared memory store throughput	Single-context
shared_efficiency	Ratio of requested shared memory throughput to required shared memory throughput	Single-context
dram_read_transactions	Device memory read transactions	Single-context
dram_write_transactions	Device memory write transactions	Single-context
dram_read_throughput	Device memory read throughput	Single-context
dram_write_throughput	Device memory write throughput	Single-context
sysmem_read_transactions	System memory read transactions	Single-context
sysmem_write_transactions	System memory write transactions	Single-context
sysmem_read_throughput	System memory read throughput	Single-context
sysmem_write_throughput	System memory write throughput	Single-context
l1_cache_global_hit_rate	Hit rate in L1 cache for global loads	Single-context
l1_cache_local_hit_rate	Hit rate in L1 cache for local loads and stores	Single-context
tex_cache_hit_rate	Texture cache hit rate	Single-context
tex_cache_transactions	Texture cache read transactions	Single-context
tex_cache_throughput	Texture cache throughput	Single-context

Metric Name	Description	Scope
l2_read_transactions	Memory read transactions seen at L2 cache for all read requests	Single-context
l2_write_transactions	Memory write transactions seen at L2 cache for all write requests	Single-context
l2_read_throughput	Memory read throughput seen at L2 cache for all read requests	Single-context
l2_write_throughput	Memory write throughput seen at L2 cache for all write requests	Single-context
l2_l1_read_hit_rate	Hit rate at L2 cache for all read requests from L1 cache	Sinlge-context
l2_l1_read_throughput	Memory read throughput seen at L2 cache for read requests from L1 cache	Single-context
l2_texture_read_hit_rate	Hit rate at L2 cache for all read requests from texture cache	Single-context
l2_texure_read_throughput	Memory read throughput seen at L2 cache for read requests from the texture cache	Sinlge-context
local_memory_overhead	Ratio of local memory traffic to total memory traffic between the L1 and L2 caches	Single-context
l1_shared_utilization	The utilization level of the L1/shared memory relative to peak utilization	Single-context
l2_utilization	The utilization level of the L2 cache relative to the peak utilization	Single-context
tex_utilization	The utilization level of the texture cache relative to the peak utilization	Single-context
dram_utilization	The utilization level of the device memory relative to the peak utilization	Single-context
sysmem_utilization	The utilization level of the system memory relative to the peak utilization	Single-context
ldst_fu_utilization	The utilization level of the multiprocessor function units that execute load and store instructions	Multi-context
int_fu_utilization	The utilization level of the multiprocessor function units that execute integer instructions	Multi-context

Metric Name	Description	Scope
cf_fu_utilization	The utilization level of the multiprocessor function units that execute control-flow instructions	Multi-context
tex_fu_utilization	The utilization level of the multiprocessor function units that execute texture instructions	Multi-context
tex_fu_utilization	The utilization level of the multiprocessor function units that execute floating point instructions	Multi-context
fpspec_fu_utilization	The utilization level of the multiprocessor function units that execute special floating point instructions	Multi-context
misc_fu_utilization	The utilization level of the multiprocessor function units that execute miscellaneous instructions	Multi-context
flops_sp	Single-precision floating point operations executed	Multi-context
flops_sp_add	Single-precision floating point add operations executed	Multi-context
flops_sp_mul	Single-precision floating point multiply operations executed	Multi-context
flops_sp_fma	Single-precision floating point multiply- accumulate operations executed	Multi-context
flops_dp	Double-precision floating point operations executed	Multi-context
flops_dp_add	Double-precision floating point add operations executed	Multi-context
flops_dp_mul	Double-precision floating point multiply operations executed	Multi-context
flops_dp_fma	Double-precision floating point multiply- accumulate operations executed	Multi-context
flops_sp_special	Single-precision floating point special operations executed	Multi-context

Metric Name	Description	Scope
stall_inst_fetch	Percentage of stalls occurring because the next assembly instruction has not yet been fetched	Multi-context
stall_exec_dependency	Percentage of stalls occurring because an input required by the instruction is not yet available	Multi-context
stall_data_request	Percentage of stalls occurring because a memory operation cannot be performed due to the required resources not being available or fully utilized, or because too many requests of a given type are outstanding	Multi-context
stall_sync	Percentage of stalls occurring because the warp is blocked at asyncthreads() call	Multi-context
stall_texture	Percentage of stalls occurring because the texture sub-system is fully utilized or has too many outstanding requests	Multi-context
stall_other	Percentage of stalls occurring due to miscellaneous reasons	Multi-context

1.6.3. Metric Reference - Compute Capability 3.x

Devices with compute capability greater than or equal to 3.0 implement the metrics shown in the following table. A scope value of single-context indicates that the metric can only be accurately collected when a single context (CUDA or graphic) is executing on the GPU. A scope value of multi-context indicates that the metric can be accurately collected when multiple contexts are executing on the GPU.

Table 3 Capability 3.x Metrics

Metric Name	Description	Scope
sm_efficiency	The percentage of time at least one warp is active on a multiprocessor averaged over all multiprocessors on the GPU	Single-context
sm_efficiency_instance	The percentage of time at least one warp is active on a specific multiprocessor	Single-context
achieved_occupancy	Ratio of the average active warps per active cycle to the maximum number of warps supported on a multiprocessor	Multi-context

Metric Name	Description	Scope
issue_slot_utilization	Percentage of issue slots that issued at least one instruction, averaged across all cycles	Multi-context
inst_executed	The number of instructions executed	Multi-context
inst_issued	The number of instructions issued	Multi-context
issue_slots	The number of issue slots used	Multi-context
executed_ipc	Instructions executed per cycle	Multi-context
issued_ipc	Instructions issued per cycle	Multi-context
ipc_instance	Instructions executed per cycle for a single multiprocessor	Multi-context
inst_per_warp	Average number of instructions executed by each warp	Multi-context
cf_issued	Number of issued control-flow instructions	Multi-context
cf_executed	Number of executed control-flow instructions	Multi-context
ldst_issued	Number of issued load and store instructions	Multi-context
ldst_executed	Number of executed load and store instructions	Multi-context
branch_efficiency	Ratio of non-divergent branches to total branches	Multi-context
warp_execution_efficiency	Ratio of the average active threads per warp to the maximum number of threads per warp supported on a multiprocessor	Multi-context
warp_nonpred_execution_efficiency	Ratio of the average active threads per warp executing non-predicated instructions to the maximum number of threads per warp supported on a multiprocessor	Multi-context
inst_replay_overhead	Average number of replays for each instruction executed	Multi-context
shared_replay_overhead	Average number of replays due to shared memory conflicts for each instruction executed	Single-context
global_cache_replay_overhead	Average number of replays due to global memory cache misses for each instruction executed	Single-context

Metric Name	Description	Scope
local_replay_overhead	Average number of replays due to local memory accesses for each instruction executed	Single-context
gld_efficiency	Ratio of requested global memory load throughput to required global memory load throughput	Single-context
gst_efficiency	Ratio of requested global memory store throughput to required global memory store throughput	Single-context
gld_transactions	Number of global memory load transactions	Single-context
gst_transactions	Number of global memory store transactions	Single-context
gld_transactions_per_request	Average number of global memory load transactions performed for each global memory load	Single-context
gst_transactions_per_request	Average number of global memory store transactions performed for each global memory store	Single-context
gld_throughput	Global memory load throughput	Single-context
gst_throughput	Global memory store throughput	Single-context
gld_requested_throughput	Requested global memory load throughput	Multi-context
gst_requested_throughput	Requested global memory store throughput	Multi-context
local_load_transactions	Number of local memory load transactions	Single-context
local_store_transactions	Number of local memory store transactions	Single-context
local_load_transactions_per_ request	Average number of local memory load transactions performed for each local memory load	Single-context
local_store_transactions_per_ request	Average number of local memory store transactions performed for each local memory store	Single-context
local_load_throughput	Local memory load throughput	Single-context
local_store_throughput	Local memory store throughput	Single-context
shared_load_transactions	Number of shared memory load transactions	Single-context
shared_store_transactions	Number of shared memory store transactions	Single-context

Metric Name	Description	Scope
shared_load_transactions_per_ request	Average number of shared memory load transactions performed for each shared memory load	Single-context
shared_store_transactions_per_ request	Average number of shared memory store transactions performed for each shared memory store	Single-context
shared_load_throughput	Shared memory load throughput	Single-context
shared_store_throughput	Shared memory store throughput	Single-context
shared_efficiency	Ratio of requested shared memory throughput to required shared memory throughput	Single-context
dram_read_transactions	Device memory read transactions	Single-context
dram_write_transactions	Device memory write transactions	Single-context
dram_read_throughput	Device memory read throughput	Single-context
dram_write_throughput	Device memory write throughput	Single-context
sysmem_read_transactions	System memory read transactions	Single-context
sysmem_write_transactions	System memory write transactions	Single-context
sysmem_read_throughput	System memory read throughput	Single-context
sysmem_write_throughput	System memory write throughput	Single-context
l1_cache_global_hit_rate	Hit rate in L1 cache for global loads	Single-context
l1_cache_local_hit_rate	Hit rate in L1 cache for local loads and stores	Single-context
tex_cache_hit_rate	Texture cache hit rate	Single-context
tex_cache_transactions	Texture cache read transactions	Single-context
tex_cache_throughput	Texture cache throughput	Single-context
l2_read_transactions	Memory read transactions seen at L2 cache for all read requests	Single-context
l2_write_transactions	Memory write transactions seen at L2 cache for all write requests	Single-context
l2_read_throughput	Memory read throughput seen at L2 cache for all read requests	Single-context
l2_write_throughput	Memory write throughput seen at L2 cache for all write requests	Single-context

Metric Name	Description	Scope
l2_l1_read_hit_rate	Hit rate at L2 cache for all read requests from L1 cache	Sinlge-context
l2_l1_read_throughput	Memory read throughput seen at L2 cache for read requests from L1 cache	Single-context
l2_texture_read_hit_rate	Hit rate at L2 cache for all read requests from texture cache	Single-context
l2_texure_read_throughput	Memory read throughput seen at L2 cache for read requests from the texture cache	Sinlge-context
local_memory_overhead	Ratio of local memory traffic to total memory traffic between the L1 and L2 caches	Single-context
l1_shared_utilization	The utilization level of the L1/shared memory relative to peak utilization	Single-context
l2_utilization	The utilization level of the L2 cache relative to the peak utilization	Single-context
tex_utilization	The utilization level of the texture cache relative to the peak utilization	Single-context
dram_utilization	The utilization level of the device memory relative to the peak utilization	Single-context
sysmem_utilization	The utilization level of the system memory relative to the peak utilization	Single-context
ldst_fu_utilization	The utilization level of the multiprocessor function units that execute load and store instructions	Multi-context
int_fu_utilization	The utilization level of the multiprocessor function units that execute integer instructions	Multi-context
cf_fu_utilization	The utilization level of the multiprocessor function units that execute control-flow instructions	Multi-context
tex_fu_utilization	The utilization level of the multiprocessor function units that execute texture instructions	Multi-context
tex_fu_utilization	The utilization level of the multiprocessor function units that execute floating point instructions	Multi-context

Metric Name	Description	Scope
fpspec_fu_utilization	The utilization level of the multiprocessor function units that execute special floating point instructions	Multi-context
misc_fu_utilization	The utilization level of the multiprocessor function units that execute miscellaneous instructions	Multi-context
flops_sp	Single-precision floating point operations executed	Multi-context
flops_sp_add	Single-precision floating point add operations executed	Multi-context
flops_sp_mul	Single-precision floating point multiply operations executed	Multi-context
flops_sp_fma	Single-precision floating point multiply- accumulate operations executed	Multi-context
flops_dp	Double-precision floating point operations executed	Multi-context
flops_dp_add	Double-precision floating point add operations executed	Multi-context
flops_dp_mul	Double-precision floating point multiply operations executed	Multi-context
flops_dp_fma	Double-precision floating point multiply- accumulate operations executed	Multi-context
flops_sp_special	Single-precision floating point special operations executed	Multi-context
stall_inst_fetch	Percentage of stalls occurring because the next assembly instruction has not yet been fetched	Multi-context
stall_exec_dependency	Percentage of stalls occurring because an input required by the instruction is not yet available	Multi-context
stall_data_request	Percentage of stalls occurring because a memory operation cannot be performed due to the required resources not being available or fully utilized, or because too many requests of a given type are outstanding	Multi-context

Metric Name	Description	Scope
stall_sync	Percentage of stalls occurring because the warp is blocked at asyncthreads() call	Multi-context
stall_texture	Percentage of stalls occurring because the texture sub-system is fully utilized or has too many outstanding requests	Multi-context
stall_other	Percentage of stalls occurring due to miscellaneous reasons	Multi-context

1.7. Samples

The CUPTI installation includes several samples that demonstrate the use of the CUPTI APIs. The samples are:

activity_trace_async

This sample shows how to collect a trace of CPU and GPU activity using the new asynchronous activity buffer APIs.

callback_event

This sample shows how to use both the callback and event APIs to record the events that occur during the execution of a simple kernel. The sample shows the required ordering for synchronization, and for event group enabling, disabling and reading.

callback_metric

This sample shows how to use both the callback and metric APIs to record the metric's events during the execution of a simple kernel, and then use those events to calculate the metric value.

callback_timestamp

This sample shows how to use the callback API to record a trace of API start and stop times.

cupti_query

This sample shows how to query CUDA-enabled devices for their event domains, events, and metrics.

event_sampling

This sample shows how to use the event API to sample events using a separate host thread.

Chapter 2. MODULES

Here is a list of all modules:

- CUPTI Version
- CUPTI Result Codes
- ► CUPTI Activity API
- ► CUPTI Callback API
- ► CUPTI Event API
- ► CUPTI Metric API

2.1. CUPTI Version

Function and macro to determine the CUPTI version.

CUptiResult cuptiGetVersion (uint32_t *version)

Get the CUPTI API version.

Parameters

version

Returns the version

Returns

► CUPTI_SUCCESS

on success

CUPTI_ERROR_INVALID_PARAMETER

if version is NULL

Description

Return the API version in *version.

See also:

CUPTI API VERSION

#define CUPTI_API_VERSION 4

The API version for this implementation of CUPTI.

The API version for this implementation of CUPTI. This define along with cuptiGetVersion can be used to dynamically detect if the version of CUPTI compiled against matches the version of the loaded CUPTI library.

v1 : CUDAToolsSDK 4.0 v2 : CUDAToolsSDK 4.1 v3 : CUDA Toolkit 5.0 v4 : CUDA Toolkit 5.5

2.2. CUPTI Result Codes

Error and result codes returned by CUPTI functions.

enum CUptiResult

CUPTI result codes.

Error and result codes returned by CUPTI functions.

Values

CUPTI SUCCESS = 0

No error.

CUPTI_ERROR_INVALID_PARAMETER = 1

One or more of the parameters is invalid.

CUPTI_ERROR_INVALID_DEVICE = 2

The device does not correspond to a valid CUDA device.

CUPTI_ERROR_INVALID_CONTEXT = 3

The context is NULL or not valid.

CUPTI_ERROR_INVALID_EVENT_DOMAIN_ID = 4

The event domain id is invalid.

CUPTI_ERROR_INVALID_EVENT_ID = 5

The event id is invalid.

CUPTI_ERROR_INVALID_EVENT_NAME = 6

The event name is invalid.

CUPTI_ERROR_INVALID_OPERATION = 7

The current operation cannot be performed due to dependency on other factors.

CUPTI ERROR OUT OF MEMORY = 8

Unable to allocate enough memory to perform the requested operation.

CUPTI_ERROR_HARDWARE = 9

An error occurred on the performance monitoring hardware.

CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT = 10

The output buffer size is not sufficient to return all requested data.

CUPTI_ERROR_API_NOT_IMPLEMENTED = 11

API is not implemented.

CUPTI_ERROR_MAX_LIMIT_REACHED = 12

The maximum limit is reached.

CUPTI_ERROR_NOT_READY = 13

The object is not yet ready to perform the requested operation.

CUPTI_ERROR_NOT_COMPATIBLE = 14

The current operation is not compatible with the current state of the object

CUPTI_ERROR_NOT_INITIALIZED = 15

CUPTI is unable to initialize its connection to the CUDA driver.

CUPTI_ERROR_INVALID_METRIC_ID = 16

The metric id is invalid.

CUPTI_ERROR_INVALID_METRIC_NAME = 17

The metric name is invalid.

CUPTI_ERROR_QUEUE_EMPTY = 18

The queue is empty.

CUPTI ERROR INVALID HANDLE = 19

Invalid handle (internal?).

CUPTI_ERROR_INVALID_STREAM = 20

Invalid stream.

CUPTI_ERROR_INVALID_KIND = 21

Invalid kind.

CUPTI_ERROR_INVALID_EVENT_VALUE = 22

Invalid event value.

CUPTI_ERROR_DISABLED = 23

CUPTI is disabled due to conflicts with other enabled profilers

CUPTI_ERROR_INVALID_MODULE = 24

Invalid module.

CUPTI_ERROR_INVALID_METRIC_VALUE = 25

Invalid metric value.

CUPTI_ERROR_HARDWARE_BUSY = 26

The performance monitoring hardware is in use by other client.

CUPTI_ERROR_UNKNOWN = 999

An unknown internal error has occurred.

CUPTI_ERROR_FORCE_INT = 0x7ffffffff

CUptiResult cuptiGetResultString (CUptiResult result, const char **str)

Get the descriptive string for a CUptiResult.

Parameters

result

The result to get the string for

str

Returns the string

Returns

CUPTI_SUCCESS

on success

CUPTI_ERROR_INVALID_PARAMETER

if str is NULL or result is not a valid CUptiResult

Description

Return the descriptive string for a CUptiResult in *str.



Thread-safety: this function is thread safe.

2.3. CUPTI Activity API

Functions, types, and enums that implement the CUPTI Activity API.

struct CUpti_Activity

The base activity record.

struct CUpti_ActivityAPI

The activity record for a driver or runtime API invocation.

struct CUpti_ActivityBranch

The activity record for source level result branch.

struct CUpti_ActivityCdpKernel

The activity record for CDP (CUDA Dynamic Parallelism) kernel.

struct CUpti_ActivityContext

The activity record for a context.

struct CUpti_ActivityDevice

The activity record for a device.

struct CUpti_ActivityEnvironment

The activity record for CUPTI environmental data.

struct CUpti_ActivityEvent

The activity record for a CUPTI event.

struct CUpti_ActivityEventInstance

The activity record for a CUPTI event with instance information.

struct CUpti_ActivityGlobalAccess

The activity record for source-level global access.

struct CUpti_ActivityKernel

The activity record for kernel. (deprecated).

struct CUpti_ActivityKernel2

The activity record for a kernel (CUDA 5.5 onwards).

struct CUpti_ActivityMarker

The activity record providing a marker which is an instantaneous point in time.

struct CUpti_ActivityMarkerData

The activity record providing detailed information for a marker.

struct CUpti_ActivityMemcpy

The activity record for memory copies.

struct CUpti_ActivityMemcpy2

The activity record for peer-to-peer memory copies.

struct CUpti_ActivityMemset

The activity record for memset.

struct CUpti_ActivityMetric

The activity record for a CUPTI metric.

struct CUpti_ActivityMetricInstance

The activity record for a CUPTI metric with instance information. This activity record represents a CUPTI metric value for a specific metric domain instance (CUPTI_ACTIVITY_KIND_METRIC_INSTANCE). This activity record kind is not produced by the activity API but is included for completeness and ease-of-use. Profile frameworks built on top of CUPTI that collect metric data may choose to use this type to store the collected metric data. This activity record should be used when metric domain instance information needs to be associated with the metric.

struct CUpti_ActivityName

The activity record providing a name.

union CUpti_ActivityObjectKindId

Identifiers for object kinds as specified by CUpti_ActivityObjectKind.

struct CUpti_ActivityOverhead

The activity record for CUPTI and driver overheads.

struct CUpti_ActivityPreemption

The activity record for a preemption of a CDP kernel.

struct CUpti_ActivitySourceLocator

The activity record for source locator.

enum CUpti_ActivityAttribute

Activity attributes.

These attributes are used to control the behavior of the activity API.

Values

CUPTI_ACTIVITY_ATTR_DEVICE_BUFFER_SIZE = 0

The device memory reserved for storing profiling data for non-CDP operations for each stream. The value is a size_t.Larger buffers require less flush operations but consume more device memory. Small buffers might increase the risk of missing timestamps for concurrent kernel records in the asynchronous buffer handling mode if too many kernels are launched/replayed between context synchronizations. This value only applies to new allocations. Set this value before initializing CUDA or before creating a stream to ensure it is considered for the following allocations. Note: The actual amount of device memory per stream reserved by CUPTI might be larger.

CUPTI_ACTIVITY_ATTR_DEVICE_BUFFER_SIZE_CDP = 1

The device memory reserved for storing profiling data for CDP operations for each stream. The value is a size_t.Larger buffers require less flush operations but consume more device memory. This value only applies to new allocations.Set this value before initializing CUDA or before creating a stream to ensure it is considered for the following allocations.Note: The actual amount of device memory per stream reserved by CUPTI might be larger.

CUPTI_ACTIVITY_ATTR_DEVICE_BUFFER_POOL_LIMIT = 2

The maximum number of device memory buffers stored for reuse by CUPTI. The value is a size_t.Buffers can be reused by streams of the same context. Increasing this value reduces the profiling overhead when the application creates and destroys many

streams. Setting this value will not modify the number of memory buffers currently stored. Set this value before initializing CUDA to ensure the limit is not exceeded.

enum CUpti_ActivityComputeApiKind

The kind of a compute API.

Values

CUPTI_ACTIVITY_COMPUTE_API_UNKNOWN = 0

The compute API is not known.

CUPTI_ACTIVITY_COMPUTE_API_CUDA = 1

The compute APIs are for CUDA.

CUPTI_ACTIVITY_COMPUTE_API_FORCE_INT = 0x7fffffff

enum CUpti_ActivityEnvironmentKind

The kind of environment data. Used to indicate what type of data is being reported by an environment activity record.

Values

CUPTI_ACTIVITY_ENVIRONMENT_UNKNOWN = 0

Unknown data.

CUPTI_ACTIVITY_ENVIRONMENT_SPEED = 1

The environment data is related to speed.

CUPTI_ACTIVITY_ENVIRONMENT_TEMPERATURE = 2

The environment data is related to temperature.

CUPTI_ACTIVITY_ENVIRONMENT_POWER = 3

The environment data is related to power.

CUPTI_ACTIVITY_ENVIRONMENT_COOLING = 4

The environment data is related to cooling.

CUPTI_ACTIVITY_ENVIRONMENT_COUNT

CUPTI_ACTIVITY_ENVIRONMENT_KIND_FORCE_INT = 0x7fffffff

enum CUpti_ActivityFlag

Flags associated with activity records.

Activity record flags. Flags can be combined by bitwise OR to associated multiple flags with an activity record. Each flag is specific to a certain activity kind, as noted below.

Values

CUPTI_ACTIVITY_FLAG_NONE = 0

Indicates the activity record has no flags.

CUPTI_ACTIVITY_FLAG_DEVICE_CONCURRENT_KERNELS = 1<<0

Indicates the activity represents a device that supports concurrent kernel execution. Valid for CUPTI_ACTIVITY_KIND_DEVICE.

CUPTI_ACTIVITY_FLAG_MEMCPY_ASYNC = 1<<0

Indicates the activity represents an asynchronous memcpy operation. Valid for CUPTI_ACTIVITY_KIND_MEMCPY.

CUPTI_ACTIVITY_FLAG_MARKER_INSTANTANEOUS = 1<<0

Indicates the activity represents an instantaneous marker. Valid for CUPTI_ACTIVITY_KIND_MARKER.

CUPTI_ACTIVITY_FLAG_MARKER_START = 1<<1

Indicates the activity represents a region start marker. Valid for CUPTI_ACTIVITY_KIND_MARKER.

CUPTI_ACTIVITY_FLAG_MARKER_END = 1<<2

Indicates the activity represents a region end marker. Valid for CUPTI ACTIVITY KIND MARKER.

CUPTI_ACTIVITY_FLAG_MARKER_COLOR_NONE = 1<<0

Indicates the activity represents a marker that does not specify a color. Valid for CUPTI_ACTIVITY_KIND_MARKER_DATA.

CUPTI_ACTIVITY_FLAG_MARKER_COLOR_ARGB = 1<<1

Indicates the activity represents a marker that specifies a color in alpha-red-green-blue format. Valid for CUPTI_ACTIVITY_KIND_MARKER_DATA.

CUPTI_ACTIVITY_FLAG_GLOBAL_ACCESS_KIND_SIZE_MASK = 0xFF<<0

The number of bytes requested by each thread Valid for CUpti_ActivityGlobalAccess.

CUPTI_ACTIVITY_FLAG_GLOBAL_ACCESS_KIND_LOAD = 1<<8

If bit in this flag is set, the access was load, else it is a store access. Valid for CUpti_ActivityGlobalAccess.

CUPTI_ACTIVITY_FLAG_GLOBAL_ACCESS_KIND_CACHED = 1<<9

If this bit in flag is set, the load access was cached else it is uncached. Valid for CUpti_ActivityGlobalAccess.

CUPTI_ACTIVITY_FLAG_METRIC_OVERFLOWED = 1<<0

If this bit in flag is set, the metric value overflowed. Valid for CUpti_ActivityMetric.

CUPTI_ACTIVITY_FLAG_METRIC_VALUE_INVALID = 1<<1

If this bit in flag is set, the metric value couldn't be calculated. This occurs when a value(s) required to calculate the metric is missing. Valid for CUpti_ActivityMetric.

CUPTI_ACTIVITY_FLAG_FORCE_INT = 0x7fffffff

enum CUpti_ActivityKind

The kinds of activity records.

Each activity record kind represents information about a GPU or an activity occurring on a CPU or GPU. Each kind is associated with a activity record structure that holds the information associated with the kind.

See also:

CUpti_Activity

CUpti_ActivityAPI

CUpti_ActivityContext

CUpti_ActivityDevice

CUpti_ActivityEvent

CUpti_ActivityEventInstance

CUpti_ActivityKernel

CUpti_ActivityKernel2

CUpti_ActivityCdpKernel

CUpti_ActivityPreemption

CUpti_ActivityMemcpy

CUpti_ActivityMemcpy2

CUpti_ActivityMemset

CUpti_ActivityMetric

CUpti_ActivityMetricInstance

CUpti_ActivityName

CUpti_ActivityMarker

CUpti_ActivityMarkerData

CUpti_ActivitySourceLocator

CUpti_ActivityGlobalAccess

CUpti_ActivityBranch

CUpti_ActivityOverhead

CUpti_ActivityEnvironment

Values

CUPTI_ACTIVITY_KIND_INVALID = 0

The activity record is invalid.

CUPTI_ACTIVITY_KIND_MEMCPY = 1

A host<->host, host<->device, or device<->device memory copy. The corresponding activity record structure is CUpti_ActivityMemcpy.

CUPTI_ACTIVITY_KIND_MEMSET = 2

A memory set executing on the GPU. The corresponding activity record structure is CUpti_ActivityMemset.

CUPTI_ACTIVITY_KIND_KERNEL = 3

A kernel executing on the GPU. The corresponding activity record structure is CUpti_ActivityKernel2.

CUPTI_ACTIVITY_KIND_DRIVER = 4

A CUDA driver API function execution. The corresponding activity record structure is CUpti_ActivityAPI.

CUPTI_ACTIVITY_KIND_RUNTIME = 5

A CUDA runtime API function execution. The corresponding activity record structure is CUpti_ActivityAPI.

CUPTI_ACTIVITY_KIND_EVENT = 6

An event value. The corresponding activity record structure is CUpti_ActivityEvent.

CUPTI_ACTIVITY_KIND_METRIC = 7

A metric value. The corresponding activity record structure is CUpti_ActivityMetric.

CUPTI_ACTIVITY_KIND_DEVICE = 8

Information about a device. The corresponding activity record structure is CUpti_ActivityDevice.

CUPTI_ACTIVITY_KIND_CONTEXT = 9

Information about a context. The corresponding activity record structure is CUpti_ActivityContext.

CUPTI_ACTIVITY_KIND_CONCURRENT_KERNEL = 10

A (potentially concurrent) kernel executing on the GPU. The corresponding activity record structure is CUpti_ActivityKernel2.

CUPTI_ACTIVITY_KIND_NAME = 11

Thread, device, context, etc. name. The corresponding activity record structure is CUpti_ActivityName.

CUPTI_ACTIVITY_KIND_MARKER = 12

Instantaneous, start, or end marker.

CUPTI_ACTIVITY_KIND_MARKER_DATA = 13

Extended, optional, data about a marker.

CUPTI_ACTIVITY_KIND_SOURCE_LOCATOR = 14

Source information about source level result. The corresponding activity record structure is CUpti_ActivitySourceLocator.

CUPTI_ACTIVITY_KIND_GLOBAL_ACCESS = 15

Results for source-level global access. The corresponding activity record structure is CUpti_ActivityGlobalAccess.

CUPTI_ACTIVITY_KIND_BRANCH = 16

Results for source-level branch. The corresponding activity record structure is CUpti_ActivityBranch.

CUPTI_ACTIVITY_KIND_OVERHEAD = 17

Overhead activity records. The corresponding activity record structure is CUpti_ActivityOverhead.

CUPTI_ACTIVITY_KIND_CDP_KERNEL = 18

A CDP (CUDA Dynamic Parallel) kernel executing on the GPU. The corresponding activity record structure is CUpti_ActivityCdpKernel. This activity can not be directly

enabled or disabled. It is enabled and disabled through concurrent kernel activity CUPTI_ACTIVITY_KIND_CONCURRENT_KERNEL

CUPTI_ACTIVITY_KIND_PREEMPTION = 19

Preemption activity record indicating a preemption of a CDP (CUDA Dynamic Parallel) kernel executing on the GPU. The corresponding activity record structure is CUpti ActivityPreemption.

CUPTI_ACTIVITY_KIND_ENVIRONMENT = 20

Environment activity records indicating power, clock, thermal, etc. levels of the GPU. The corresponding activity record structure is CUpti_ActivityEnvironment.

CUPTI_ACTIVITY_KIND_EVENT_INSTANCE = 21

An event value associated with a specific event domain instance. The corresponding activity record structure is CUpti_ActivityEventInstance.

CUPTI_ACTIVITY_KIND_MEMCPY2 = 22

A peer to peer memory copy. The corresponding activity record structure is CUpti_ActivityMemcpy2.

CUPTI_ACTIVITY_KIND_METRIC_INSTANCE = 23

A metric value associated with a specific metric domain instance. The corresponding activity record structure is CUpti_ActivityMetricInstance.

CUPTI_ACTIVITY_KIND_FORCE_INT = 0x7fffffff

enum CUpti_ActivityMemcpyKind

The kind of a memory copy, indicating the source and destination targets of the copy.

Each kind represents the source and destination targets of a memory copy. Targets are host, device, and array.

Values

CUPTI_ACTIVITY_MEMCPY_KIND_UNKNOWN = 0

The memory copy kind is not known.

CUPTI_ACTIVITY_MEMCPY_KIND_HTOD = 1

A host to device memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_DTOH = 2

A device to host memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_HTOA = 3

A host to device array memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_ATOH = 4

A device array to host memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_ATOA = 5

A device array to device array memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_ATOD = 6

A device array to device memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_DTOA = 7

A device to device array memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_DTOD = 8

A device to device memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_HTOH = 9

A host to host memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_PTOP = 10

A peer to peer memory copy.

CUPTI_ACTIVITY_MEMCPY_KIND_FORCE_INT = 0x7fffffff

enum CUpti_ActivityMemoryKind

The kinds of memory accessed by a memory copy.

Each kind represents the type of the source or destination memory accessed by a memory copy.

Values

CUPTI_ACTIVITY_MEMORY_KIND_UNKNOWN = 0

The source or destination memory kind is unknown.

CUPTI_ACTIVITY_MEMORY_KIND_PAGEABLE = 1

The source or destination memory is pageable.

CUPTI_ACTIVITY_MEMORY_KIND_PINNED = 2

The source or destination memory is pinned.

CUPTI_ACTIVITY_MEMORY_KIND_DEVICE = 3

The source or destination memory is on the device.

CUPTI_ACTIVITY_MEMORY_KIND_ARRAY = 4

The source or destination memory is an array.

CUPTI_ACTIVITY_MEMORY_KIND_FORCE_INT = 0x7fffffff

enum CUpti_ActivityObjectKind

The kinds of activity objects.

See also:

CUpti_ActivityObjectKindId

Values

CUPTI_ACTIVITY_OBJECT_UNKNOWN = 0

The object kind is not known.

CUPTI_ACTIVITY_OBJECT_PROCESS = 1

A process.

CUPTI_ACTIVITY_OBJECT_THREAD = 2

A thread.

CUPTI_ACTIVITY_OBJECT_DEVICE = 3

A device.

CUPTI ACTIVITY OBJECT CONTEXT = 4

A context.

CUPTI_ACTIVITY_OBJECT_STREAM = 5

A stream.

CUPTI_ACTIVITY_OBJECT_FORCE_INT = 0x7fffffff

enum CUpti_ActivityOverheadKind

The kinds of activity overhead.

Values

CUPTI_ACTIVITY_OVERHEAD_UNKNOWN = 0

The overhead kind is not known.

CUPTI_ACTIVITY_OVERHEAD_DRIVER_COMPILER = 1

Compiler(JIT) overhead.

CUPTI_ACTIVITY_OVERHEAD_CUPTI_BUFFER_FLUSH = 1<<16

Activity buffer flush overhead.

CUPTI_ACTIVITY_OVERHEAD_CUPTI_INSTRUMENTATION = 2<<16

CUPTI instrumentation overhead.

CUPTI_ACTIVITY_OVERHEAD_CUPTI_RESOURCE = 3<<16

CUPTI resource creation and destruction overhead.

CUPTI_ACTIVITY_OVERHEAD_FORCE_INT = 0x7fffffff

enum CUpti_ActivityPreemptionKind

The kind of a preemption activity.

Values

CUPTI_ACTIVITY_PREEMPTION_KIND_UNKNOWN = 0

The preemption kind is not known.

CUPTI_ACTIVITY_PREEMPTION_KIND_SAVE = 1

Preemption to save CDP block.

CUPTI_ACTIVITY_PREEMPTION_KIND_RESTORE = 2

Preemption to restore CDP block.

CUPTI_ACTIVITY_PREEMPTION_KIND_FORCE_INT = 0x7fffffff

enum CUpti_EnvironmentClocksThrottleReason

Reasons for clock throttling.

The possible reasons that a clock can be throttled. There can be more than one reason that a clock is being throttled so these types can be combined by bitwise OR. These are used in the clocksThrottleReason field in the Environment Activity Record.

Values

CUPTI_CLOCKS_THROTTLE_REASON_GPU_IDLE = 0x00000001

Nothing is running on the GPU and the clocks are dropping to idle state.

CUPTI_CLOCKS_THROTTLE_REASON_USER_DEFINED_CLOCKS = 0x00000002

The GPU clocks are limited by a user specified limit.

CUPTI_CLOCKS_THROTTLE_REASON_SW_POWER_CAP = 0x00000004

A software power scaling algorithm is reducing the clocks below requested clocks.

CUPTI_CLOCKS_THROTTLE_REASON_HW_SLOWDOWN = 0x00000008

Hardware slowdown to reduce the clock by a factor of two or more is engaged. This is an indicator of one of the following: 1) Temperature is too high, 2) External power brake assertion is being triggered (e.g. by the system power supply), 3) Change in power state.

CUPTI_CLOCKS_THROTTLE_REASON_UNKNOWN = 0x80000000

Some unspecified factor is reducing the clocks.

CUPTI_CLOCKS_THROTTLE_REASON_UNSUPPORTED = 0x40000000

Throttle reason is not supported for this GPU.

CUPTI_CLOCKS_THROTTLE_REASON_NONE = 0x000000000

No clock throttling.

CUPTI_CLOCKS_THROTTLE_REASON_FORCE_INT = 0x7fffffff

typedef (*CUpti_BuffersCallbackCompleteFunc) (CUcontext context, uint32_t streamId, uint8_t* buffer, size_t size, size_t validSize)

Function type for callback used by CUPTI to return a buffer of activity records.

This callback function returns to the CUPTI client a buffer containing activity records. The buffer contains <code>validSize</code> bytes of activity records which should be read using cuptiActivityGetNextRecord. The number of dropped records can be read using cuptiActivityGetNumDroppedRecords. After this call CUPTI relinquished ownership of the buffer and will not use it anymore. The client may return the buffer to CUPTI using the CUpti_BuffersCallbackRequestFunc callback.

typedef (*CUpti_BuffersCallbackRequestFunc) (uint8_t* *buffer, size_t* size, size_t* maxNumRecords)

Function type for callback used by CUPTI to request an empty buffer for storing activity records.

This callback function signals the CUPTI client that an activity buffer is needed by CUPTI. The activity buffer is used by CUPTI to store activity records. The callback function can decline the request by setting *buffer to NULL. In this case CUPTI may drop activity records.

CUptiResult cuptiActivityDequeueBuffer (CUcontext context, uint32_t streamId, uint8_t **buffer, size_t *validBufferSizeBytes)

Dequeue a buffer containing activity records.

Parameters

context

The context, or NULL to dequeue from the global queue

streamId

The stream ID

buffer

Returns the dequeued buffer

validBufferSizeBytes

Returns the number of bytes in the buffer that contain activity records

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_OPERATION

if preceeded by a successful call to cuptiActivityRegisterCallbacks

CUPTI_ERROR_INVALID_PARAMETER

if buffer or validBufferSizeBytes are NULL

CUPTI_ERROR_QUEUE_EMPTY

the queue is empty, buffer returns NULL and validBufferSizeBytes returns 0

Description

Remove the buffer from the head of the specified queue. See cuptiActivityEnqueueBuffer() for description of queues. Calling this function transfers ownership of the buffer from CUPTI. CUPTI will no add any activity records to the buffer after it is dequeued.

DEPRECATED This method is deprecated and will be removed in a future release. The new asynchronous API implemented by cuptiActivityRegisterCallbacks(), cuptiActivityFlush(), and cuptiActivityFlushAll() should be adopted.

CUptiResult cuptiActivityDisable (CUpti_ActivityKind kind)

Disable collection of a specific kind of activity record.

Parameters

kind

The kind of activity record to stop collecting

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_KIND

if the activity kind is not supported

Description

Disable collection of a specific kind of activity record. Multiple kinds can be disabled by calling this function multiple times. By default all activity kinds are disabled for collection.

CUptiResult cuptiActivityDisableContext (CUcontext context, CUpti_ActivityKind kind)

Disable collection of a specific kind of activity record for a context.

Parameters

context

The context for which activity is to be disabled

kind

The kind of activity record to stop collecting

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- ► CUPTI_ERROR_INVALID_KIND

if the activity kind is not supported

Description

Disable collection of a specific kind of activity record for a context. This setting done by this API will supersede the global settings for activity records. Multiple kinds can be enabled by calling this function multiple times.

CUptiResult cuptiActivityEnable (CUpti_ActivityKind kind)

Enable collection of a specific kind of activity record.

Parameters

kind

The kind of activity record to collect

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_NOT_COMPATIBLE
 - if the activity kind cannot be enabled
- CUPTI_ERROR_INVALID_KIND

if the activity kind is not supported

Description

Enable collection of a specific kind of activity record. Multiple kinds can be enabled by calling this function multiple times. By default all activity kinds are disabled for collection.

CUptiResult cuptiActivityEnableContext (CUcontext context, CUpti_ActivityKind kind)

Enable collection of a specific kind of activity record for a context.

Parameters

context

The context for which activity is to be enabled

kind

The kind of activity record to collect

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_NOT_COMPATIBLE
 - if the activity kind cannot be enabled
- CUPTI_ERROR_INVALID_KIND

if the activity kind is not supported

Description

Enable collection of a specific kind of activity record for a context. This setting done by this API will supersede the global settings for activity records enabled by cuptiActivityEnable. Multiple kinds can be enabled by calling this function multiple times.

CUptiResult cuptiActivityEnqueueBuffer (CUcontext context, uint32_t streamId, uint8_t *buffer, size_t bufferSizeBytes)

Queue a buffer for activity record collection.

Parameters

context

The context, or NULL to enqueue on the global queue

streamId

The stream ID

buffer

The pointer to user supplied buffer for storing activity records. The buffer must be at least 8 byte aligned, and the size of the buffer must be at least 1024 bytes.

bufferSizeBytes

The size of the buffer, in bytes. The size of the buffer must be at least 1024 bytes.

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_OPERATION

if preceeded by a successful call to cuptiActivityRegisterCallbacks

CUPTI_ERROR_INVALID_PARAMETER

if buffer is NULL, does not have alignment of at least 8 bytes, or is not at least 1024 bytes in size

Description

Queue a buffer for activity record collection. Calling this function transfers ownership of the buffer to CUPTI. The buffer should not be accessed or modified until ownership is regained by calling cuptiActivityDequeueBuffer().

There are three types of queues:

Global Queue: The global queue collects all activity records that are not associated with a valid context. All device and API activity records are collected in the global queue. A buffer is enqueued in the global queue by specifying context == NULL.

Context Queue: Each context queue collects activity records associated with that context that are not associated with a specific stream or that are associated with the default stream. A buffer is enqueued in a context queue by specifying the context and a streamId of 0.

Stream Queue: Each stream queue collects memcpy, memset, and kernel activity records associated with the stream. A buffer is enqueued in a stream queue by specifying a context and a non-zero stream ID.

Multiple buffers can be enqueued on each queue, and buffers can be enqueue on multiple queues.

When a new activity record needs to be recorded, CUPTI searches for a non-empty queue to hold the record in this order: 1) the appropriate stream queue, 2) the appropriate context queue. If the search does not find any queue with a buffer then the activity record is dropped. If the search finds a queue containing a buffer, but that buffer is full, then the activity record is dropped and the dropped record count for the queue is incremented. If the search finds a queue containing a buffer with space available to hold the record, then the record is recorded in the buffer.

At a minimum, one or more buffers must be queued in the global queue and context queue at all times to avoid dropping activity records. Global queue will not store any activity records for gpu activity(kernel, memcpy, memset). It is also necessary to enqueue at least one buffer in the context queue of each context as it is created. The stream queues are optional and can be used to reduce or eliminate application perturbations caused by the need to process or save the activity records returned in the buffers. For example, if a stream queue is used, that queue can be flushed when the stream is synchronized.

DEPRECATED This method is deprecated and will be removed in a future release. The new asynchronous API implemented by cuptiActivityRegisterCallbacks(), cuptiActivityFlush(), and cuptiActivityFlushAll() should be adopted.

CUptiResult cuptiActivityFlush (CUcontext context, uint32_t streamId, uint32_t flag)

Wait for all activity records are delivered via the completion callback.

Parameters

context

A valid CUcontext or NULL.

streamId

The stream ID.

flag

Reserved, must be 0.

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_CUPTI_ERROR_INVALID_OPERATION
 if not preceded by a successful call to cuptiActivityRegisterCallbacks
- CUPTI_ERROR_UNKNOWN

an internal error occurred

Description

This function does not return until all activity records associated with the specified context/stream are returned to the CUPTI client using the callback registered in cuptiActivityRegisterCallbacks. To ensure that all activity records are complete, the requested stream(s), if any, are synchronized.

If context is NULL, the global activity records (i.e. those not associated with a particular stream) are flushed (in this case no streams are synchonized). If context is a valid CUcontext and streamId is 0, the buffers of all streams of this context are flushed. Otherwise, the buffers of the specified stream in this context is flushed.

Before calling this function, the buffer handling callback api must be activated by calling cuptiActivityRegisterCallbacks.

CUptiResult cuptiActivityFlushAll (uint32_t flag)

Wait for all activity records are delivered via the completion callback.

Parameters

flag

Reserved, must be 0.

Returns

- CUPTI_SUCCESS
- CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_OPERATION

if not preceded by a successful call to cuptiActivityRegisterCallbacks

CUPTI ERROR UNKNOWN

an internal error occurred

Description

This function does not return until all activity records associated with all contexts/ streams (and the global buffers not associated with any stream) are returned to the CUPTI client using the callback registered in cuptiActivityRegisterCallbacks. To ensure that all activity records are complete, the requested stream(s), if any, are synchronized.

Before calling this function, the buffer handling callback api must be activated by calling cuptiActivityRegisterCallbacks.

CUptiResult cuptiActivityGetAttribute (CUpti_ActivityAttribute attr, size_t *valueSize, void *value)

Read an activity API attribute.

Parameters

attr

The attribute to read

valueSize

Size of buffer pointed by the value, and returns the number of bytes written to value value

Returns the value of the attribute

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_PARAMETER

if valueSize or value is NULL, or if attr is not an activity attribute

► CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

Indicates that the value buffer is too small to hold the attribute value.

Description

Read an activity API attribute and return it in *value.

CUptiResult cuptiActivityGetNextRecord (uint8_t *buffer, size_t validBufferSizeBytes, CUpti_Activity **record)

Iterate over the activity records in a buffer.

Parameters

buffer

The buffer containing activity records

validBufferSizeBytes

The number of valid bytes in the buffer.

record

Inputs the previous record returned by cuptiActivityGetNextRecord and returns the next activity record from the buffer. If input value is NULL, returns the first activity record in the buffer. Records of kind CUPTI_ACTIVITY_KIND_CONCURRENT_KERNEL may contain invalid (0) timestamps, indicating that no timing information could be collected for lack of device memory.

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI ERROR MAX LIMIT REACHED

if no more records in the buffer

► CUPTI ERROR INVALID PARAMETER

if buffer is NULL.

Description

This is a helper function to iterate over the activity records in a buffer. A buffer of activity records is typically obtained by using the cuptiActivityDequeueBuffer() function or by receiving a CUpti_BuffersCallbackCompleteFunc callback.

An example of typical usage:

```
CUpti_Activity *record = NULL;
CUptiResult status = CUPTI_SUCCESS;
do {
    status = cuptiActivityGetNextRecord(buffer, validSize, &record);
    if(status == CUPTI_SUCCESS) {
        // Use record here...
}
else if (status == CUPTI_ERROR_MAX_LIMIT_REACHED)
        break;
else {
        goto Error;
}
while (1);
```

CUptiResult cuptiActivityGetNumDroppedRecords (CUcontext context, uint32_t streamId, size_t *dropped)

Get the number of activity records that were dropped of insufficient buffer space.

Parameters

context

The context, or NULL to get dropped count from global queue

streamId

The stream ID

dropped

The number of records that were dropped since the last call to this function.

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_PARAMETERif dropped is NULL

Description

Get the number of records that were dropped because of insufficient buffer space. The dropped count includes records that could not be recorded because CUPTI did not have activity buffer space available for the record (because the CUpti_BuffersCallbackRequestFunc callback did not return an empty buffer of sufficient size) and also CDP records that could not be record because the device-size buffer was

full (size is controlled by the CUPTI_ACTIVITY_ATTR_DEVICE_BUFFER_SIZE_CDP attribute). The dropped count maintained for the queue is reset to zero when this function is called.

CUptiResult cuptiActivityQueryBuffer (CUcontext context, uint32_t streamId, size_t *validBufferSizeBytes)

Query the status of the buffer at the head of a queue.

Parameters

context

The context, or NULL to query the global queue

streamId

The stream ID

validBufferSizeBytes

Returns the number of bytes in the buffer that contain activity records

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_PARAMETER

if buffer or validBufferSizeBytes are NULL

CUPTI_ERROR_MAX_LIMIT_REACHED

if buffer is full

CUPTI_ERROR_QUEUE_EMPTY

the queue is empty, validBufferSizeBytes returns 0

Description

Query the status of buffer at the head in the queue. See cuptiActivityEnqueueBuffer() for description of queues. Calling this function does not transfer ownership of the buffer.

CUptiResult cuptiActivityRegisterCallbacks (CUpti_BuffersCallbackRequestFunc funcBufferRequested,

CUpti_BuffersCallbackCompleteFuncfuncBufferCompleted)

Registers callback functions with CUPTI for activity buffer handling.

Parameters

funcBufferRequested

callback which is invoked when an empty buffer is requested by CUPTI

funcBufferCompleted

callback which is invoked when a buffer containing activity records is available from CUPTI

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_INVALID_PARAMETER

if either funcBufferRequested or funcBufferCompleted is NULL

Description

This function registers two callback functions to be used in asynchronous buffer handling. If registered, activity record buffers are handled using asynchronous requested/completed callbacks from CUPTI.

Registering these callbacks prevents the client from using CUPTI's blocking enqueue/dequeue functions.

CUptiResult cuptiActivitySetAttribute (CUpti_ActivityAttribute attr, size_t *valueSize, void *value)

Write an activity API attribute.

Parameters

attr

The attribute to write

valueSize

The size, in bytes, of the value

value

The attribute value to write

Returns

CUPTI SUCCESS

- CUPTI_ERROR_NOT_INITIALIZED
- ► CUPTI_ERROR_INVALID_PARAMETER

if valueSize or value is NULL, or if attr is not an activity attribute

CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

Indicates that the value buffer is too small to hold the attribute value.

Description

Write an activity API attribute.

CUptiResult cuptiGetDeviceId (CUcontext context, uint32_t *deviceId)

Get the ID of a device.

Parameters

context

The context, or NULL to indicate the current context.

deviceId

Returns the ID of the device that is current for the calling thread.

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE

if unable to get device ID

► CUPTI ERROR INVALID PARAMETER

if deviceId is NULL

Description

If context is NULL, returns the ID of the device that contains the currently active context. If context is non-NULL, returns the ID of the device which contains that context. Operates in a similar manner to cudaGetDevice() or cuCtxGetDevice() but may be called from within callback functions.

CUptiResult cuptiGetStreamId (CUcontext context, CUstream stream, uint32_t *streamId)

Get the ID of a stream.

Parameters

context

If non-NULL then the stream is checked to ensure that it belongs to this context. Typically this parameter should be null.

stream

The stream

streamId

Returns a context-unique ID for the stream

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_STREAM

if unable to get stream ID, or if context is non-NULL and stream does not belong to the context

► CUPTI_ERROR_INVALID_PARAMETER

if streamId is NULL

Description

Get the ID of a stream. The stream ID is unique within a context (i.e. all streams within a context will have unique stream IDs).

See also:

cuptiActivityEnqueueBuffer cuptiActivityDequeueBuffer

CUptiResult cuptiGetTimestamp (uint64_t *timestamp)

Get the CUPTI timestamp.

Parameters

timestamp

Returns the CUPTI timestamp

Returns

- CUPTI_SUCCESS
- ► CUPTI_ERROR_INVALID_PARAMETER if timestamp is NULL

Description

Returns a timestamp normalized to correspond with the start and end timestamps reported in the CUPTI activity records. The timestamp is reported in nanoseconds.

#define CUPTI_CORRELATION_ID_UNKNOWN 0

An invalid/unknown correlation ID. A correlation ID of this value indicates that there is no correlation for the activity record.

#define CUPTI_GRID_ID_UNKNOWN 0LL

An invalid/unknown grid ID.

#define CUPTI_SOURCE_LOCATOR_ID_UNKNOWN 0

The source-locator ID that indicates an unknown source location. There is not an actual CUpti_ActivitySourceLocator object corresponding to this value.

#define CUPTI_TIMESTAMP_UNKNOWN OLL

An invalid/unknown timestamp for a start, end, queued, submitted, or completed time.

2.4. CUPTI Callback API

Functions, types, and enums that implement the CUPTI Callback API.

struct CUpti_CallbackData

Data passed into a runtime or driver API callback function.

struct CUpti_NvtxData

Data passed into a NVTX callback function.

struct CUpti_ResourceData

Data passed into a resource callback function.

struct CUpti_SynchronizeData

Data passed into a synchronize callback function.

enum CUpti_ApiCallbackSite

Specifies the point in an API call that a callback is issued.

Specifies the point in an API call that a callback is issued. This value is communicated to the callback function via CUpti_CallbackData::callbackSite.

Values

$CUPTI_API_ENTER = 0$

The callback is at the entry of the API call.

$CUPTI_API_EXIT = 1$

The callback is at the exit of the API call.

CUPTI_API_CBSITE_FORCE_INT = 0x7fffffff

enum CUpti_CallbackDomain

Callback domains.

Callback domains. Each domain represents callback points for a group of related API functions or CUDA driver activity.

Values

CUPTI_CB_DOMAIN_INVALID = 0

Invalid domain.

CUPTI_CB_DOMAIN_DRIVER_API = 1

Domain containing callback points for all driver API functions.

CUPTI_CB_DOMAIN_RUNTIME_API = 2

Domain containing callback points for all runtime API functions.

CUPTI_CB_DOMAIN_RESOURCE = 3

Domain containing callback points for CUDA resource tracking.

CUPTI_CB_DOMAIN_SYNCHRONIZE = 4

Domain containing callback points for CUDA synchronization.

CUPTI_CB_DOMAIN_NVTX = 5

Domain containing callback points for NVTX API functions.

CUPTI_CB_DOMAIN_SIZE = 6

CUPTI_CB_DOMAIN_FORCE_INT = 0x7fffffff

enum CUpti_CallbackIdResource

Callback IDs for resource domain.

Callback IDs for resource domain, CUPTI_CB_DOMAIN_RESOURCE. This value is communicated to the callback function via the cbid parameter.

Values

CUPTI_CBID_RESOURCE_INVALID = 0

Invalid resource callback ID.

CUPTI_CBID_RESOURCE_CONTEXT_CREATED = 1

A new context has been created.

CUPTI_CBID_RESOURCE_CONTEXT_DESTROY_STARTING = 2

A context is about to be destroyed.

CUPTI_CBID_RESOURCE_STREAM_CREATED = 3

A new stream has been created.

CUPTI_CBID_RESOURCE_STREAM_DESTROY_STARTING = 4

A stream is about to be destroyed.

CUPTI_CBID_RESOURCE_CU_INIT_FINISHED = 5

The driver has finished initializing.

CUPTI_CBID_RESOURCE_SIZE

CUPTI_CBID_RESOURCE_FORCE_INT = 0x7fffffff

enum CUpti_CallbackIdSync

Callback IDs for synchronization domain.

Callback IDs for synchronization domain, CUPTI_CB_DOMAIN_SYNCHRONIZE. This value is communicated to the callback function via the cbid parameter.

Values

CUPTI_CBID_SYNCHRONIZE_INVALID = 0

Invalid synchronize callback ID.

CUPTI_CBID_SYNCHRONIZE_STREAM_SYNCHRONIZED = 1

Stream synchronization has completed for the stream.

CUPTI_CBID_SYNCHRONIZE_CONTEXT_SYNCHRONIZED = 2

Context synchronization has completed for the context.

CUPTI_CBID_SYNCHRONIZE_SIZE

CUPTI_CBID_SYNCHRONIZE_FORCE_INT = 0x7fffffff

typedef (*CUpti_CallbackFunc) (void* userdata, CUpti_CallbackDomain domain, CUpti_CallbackId cbid, const void* cbdata)

Function type for a callback.

Function type for a callback. The type of the data passed to the callback in cbdata depends on the domain. If domain is CUPTI_CB_DOMAIN_DRIVER_API or CUPTI_CB_DOMAIN_RUNTIME_API the type of cbdata will be CUpti_CallbackData. If domain is CUPTI_CB_DOMAIN_RESOURCE the type of cbdata will be CUpti_ResourceData. If domain is CUPTI_CB_DOMAIN_SYNCHRONIZE the type of cbdata will be CUpti_SynchronizeData. If domain is CUPTI_CB_DOMAIN_NVTX the type of cbdata will be CUpti_NvtxData.

typedef uint32_t CUpti_CallbackId

An ID for a driver API, runtime API, resource or synchronization callback.

An ID for a driver API, runtime API, resource or synchronization callback. Within a driver API callback this should be interpreted as a CUpti_driver_api_trace_cbid value (these values are defined in cupti_driver_cbid.h). Within a runtime API callback this should be interpreted as a CUpti_runtime_api_trace_cbid value (these values are defined in cupti_runtime_cbid.h). Within a resource API callback this should be interpreted as a CUpti_CallbackIdResource value. Within a synchronize API callback this should be interpreted as a CUpti_CallbackIdSync value.

typedef CUpti_DomainTable

Pointer to an array of callback domains.

typedef struct CUpti_Subscriber_st *CUpti_SubscriberHandle

A callback subscriber.

CUptiResult cuptiEnableAllDomains (uint32_t enable, CUpti_SubscriberHandle subscriber)

Enable or disable all callbacks in all domains.

Parameters

enable

New enable state for all callbacks in all domain. Zero disables all callbacks, non-zero enables all callbacks.

subscriber

- Handle to callback subscription

Returns

CUPTI_SUCCESS

on success

CUPTI_ERROR_NOT_INITIALIZED

if unable to initialized CUPTI

► CUPTI_ERROR_INVALID_PARAMETER

if subscriber is invalid

Description

Enable or disable all callbacks in all domains.



Thread-safety: a subscriber must serialize access to cuptiGetCallbackState, cuptiEnableCallback, cuptiEnableDomain, and cuptiEnableAllDomains. For example, if cuptiGetCallbackState(sub, d, *) and cuptiEnableAllDomains(sub) are called concurrently, the results are undefined.

CUptiResult cuptiEnableCallback (uint32_t enable, CUpti_SubscriberHandle subscriber, CUpti_CallbackDomain domain, CUpti_CallbackId cbid)

Enable or disabled callbacks for a specific domain and callback ID.

Parameters

enable

New enable state for the callback. Zero disables the callback, non-zero enables the callback.

subscriber

- Handle to callback subscription

domain

The domain of the callback

cbid

The ID of the callback

Returns

CUPTI_SUCCESS

on success

CUPTI_ERROR_NOT_INITIALIZED

if unable to initialized CUPTI

CUPTI_ERROR_INVALID_PARAMETER

if subscriber, domain or cbid is invalid.

Description

Enable or disabled callbacks for a subscriber for a specific domain and callback ID.



Thread-safety: a subscriber must serialize access to cuptiGetCallbackState, cuptiEnableCallback, cuptiEnableDomain, and cuptiEnableAllDomains. For example, if cuptiGetCallbackState(sub, d, c) and cuptiEnableCallback(sub, d, c) are called concurrently, the results are undefined.

CUptiResult cuptiEnableDomain (uint32_t enable, CUpti_SubscriberHandle subscriber, CUpti_CallbackDomain domain)

Enable or disabled all callbacks for a specific domain.

Parameters

enable

New enable state for all callbacks in the domain. Zero disables all callbacks, non-zero enables all callbacks.

subscriber

- Handle to callback subscription

domain

The domain of the callback

Returns

CUPTI SUCCESS

on success

CUPTI_ERROR_NOT_INITIALIZED

if unable to initialized CUPTI

CUPTI_ERROR_INVALID_PARAMETER

if subscriber or domain is invalid

Description

Enable or disabled all callbacks for a specific domain.



Thread-safety: a subscriber must serialize access to cuptiGetCallbackState, cuptiEnableCallback, cuptiEnableDomain, and cuptiEnableAllDomains. For example, if cuptiGetCallbackEnabled(sub, d, *) and cuptiEnableDomain(sub, d) are called concurrently, the results are undefined.

CUptiResult cuptiGetCallbackName (CUpti_CallbackDomain domain, uint32_t cbid, const char **name)

Get the name of a callback for a specific domain and callback ID.

Parameters

domain

The domain of the callback

cbid

The ID of the callback

name

Returns pointer to the name string on success, NULL otherwise

Returns

CUPTI_SUCCESS

on success

CUPTI_ERROR_INVALID_PARAMETER

if name is NULL, or if domain or cbid is invalid.

Description

Returns a pointer to the name c_string in **name.



Names are available only for the DRIVER and RUNTIME domains.

CUptiResult cuptiGetCallbackState (uint32_t *enable, CUpti_SubscriberHandle subscriber, CUpti_CallbackId cbid)

Get the current enabled/disabled state of a callback for a specific domain and function ID.

Parameters

enable

Returns non-zero if callback enabled, zero if not enabled

subscriber

Handle to the initialize subscriber

domain

The domain of the callback

cbid

The ID of the callback

Returns

CUPTI_SUCCESS

on success

CUPTI ERROR NOT INITIALIZED

if unable to initialized CUPTI

► CUPTI_ERROR_INVALID_PARAMETER

if enabled is NULL, or if subscriber, domain or cbid is invalid.

Description

Returns non-zero in *enable if the callback for a domain and callback ID is enabled, and zero if not enabled.



Thread-safety: a subscriber must serialize access to cuptiGetCallbackState, cuptiEnableCallback, cuptiEnableDomain, and cuptiEnableAllDomains. For example, if cuptiGetCallbackState(sub, d, c) and cuptiEnableCallback(sub, d, c) are called concurrently, the results are undefined.

CUptiResult cuptiSubscribe (CUpti_SubscriberHandle *subscriber, CUpti_CallbackFunc callback, void *userdata)

Initialize a callback subscriber with a callback function and user data.

Parameters

subscriber

Returns handle to initialize subscriber

callback

The callback function

userdata

A pointer to user data. This data will be passed to the callback function via the userdata paramater.

Returns

CUPTI_SUCCESS

on success

CUPTI_ERROR_NOT_INITIALIZED

if unable to initialize CUPTI

CUPTI_ERROR_MAX_LIMIT_REACHED

if there is already a CUPTI subscriber

CUPTI_ERROR_INVALID_PARAMETER

if subscriber is NULL

Description

Initializes a callback subscriber with a callback function and (optionally) a pointer to user data. The returned subscriber handle can be used to enable and disable the callback for specific domains and callback IDs.



- Only a single subscriber can be registered at a time.
- This function does not enable any callbacks.
- Thread-safety: this function is thread safe.

CUptiResult cuptiSupportedDomains (size_t *domainCount, CUpti_DomainTable *domainTable)

Get the available callback domains.

Parameters

domainCount

Returns number of callback domains

domainTable

Returns pointer to array of available callback domains

Returns

► CUPTI_SUCCESS

on success

CUPTI_ERROR_NOT_INITIALIZED

if unable to initialize CUPTI

► CUPTI_ERROR_INVALID_PARAMETER

if domainCount or domainTable are NULL

Description

Returns in *domainTable an array of size *domainCount of all the available callback domains.



Thread-safety: this function is thread safe.

CUptiResult cuptiUnsubscribe (CUpti_SubscriberHandle subscriber)

Unregister a callback subscriber.

Parameters

subscriber

Handle to the initialize subscriber

Returns

CUPTI SUCCESS

on success

CUPTI_ERROR_NOT_INITIALIZED

if unable to initialized CUPTI

► CUPTI_ERROR_INVALID_PARAMETER

if subscriber is NULL or not initialized

Description

Removes a callback subscriber so that no future callbacks will be issued to that subscriber.



Thread-safety: this function is thread safe.

2.5. CUPTI Event API

Functions, types, and enums that implement the CUPTI Event API.

struct CUpti_EventGroupSet

A set of event groups.

struct CUpti_EventGroupSets

A set of event group sets.

enum CUpti_DeviceAttribute

Device attributes.

CUPTI device attributes. These attributes can be read using cuptiDeviceGetAttribute.

Values

CUPTI_DEVICE_ATTR_MAX_EVENT_ID = 1

Number of event IDs for a device. Value is a uint32_t.

CUPTI_DEVICE_ATTR_MAX_EVENT_DOMAIN_ID = 2

Number of event domain IDs for a device. Value is a uint32_t.

CUPTI_DEVICE_ATTR_GLOBAL_MEMORY_BANDWIDTH = 3

Get global memory bandwidth in Kbytes/sec. Value is a uint64_t.

CUPTI_DEVICE_ATTR_INSTRUCTION_PER_CYCLE = 4

Get theoretical maximum number of instructions per cycle. Value is a uint32_t.

CUPTI_DEVICE_ATTR_INSTRUCTION_THROUGHPUT_SINGLE_PRECISION = 5

Get theoretical maximum number of single precision instructions that can be executed per second. Value is a uint64_t.

CUPTI_DEVICE_ATTR_MAX_FRAME_BUFFERS = 6

Get number of frame buffers for device. Value is a uint64_t.

CUPTI DEVICE ATTR PCIE LINK RATE = 7

Get PCIE link rate in Mega bits/sec for device. Return 0 if bus-type is non-PCIE. Value is a uint64_t.

CUPTI_DEVICE_ATTR_PCIE_LINK_WIDTH = 8

Get PCIE link width for device. Return 0 if bus-type is non-PCIE. Value is a uint64_t.

CUPTI_DEVICE_ATTR_PCIE_GEN = 9

Get PCIE generation for device. Return 0 if bus-type is non-PCIE. Value is a uint64_t.

CUPTI_DEVICE_ATTR_DEVICE_CLASS = 10

Get the class for the device. Value is a CUpti_DeviceAttributeDeviceClass.

CUPTI_DEVICE_ATTR_FORCE_INT = 0x7fffffff

enum CUpti_DeviceAttributeDeviceClass

Device class.

Enumeration of device classes for device attribute CUPTI_DEVICE_ATTR_DEVICE_CLASS.

Values

CUPTI_DEVICE_ATTR_DEVICE_CLASS_TESLA = 0 CUPTI_DEVICE_ATTR_DEVICE_CLASS_QUADRO = 1 CUPTI_DEVICE_ATTR_DEVICE_CLASS_GEFORCE = 2

enum CUpti_EventAttribute

Event attributes.

Event attributes. These attributes can be read using cuptiEventGetAttribute.

Values

$CUPTI_EVENT_ATTR_NAME = 0$

Event name. Value is a null terminated const c-string.

CUPTI_EVENT_ATTR_SHORT_DESCRIPTION = 1

Short description of event. Value is a null terminated const c-string.

CUPTI_EVENT_ATTR_LONG_DESCRIPTION = 2

Long description of event. Value is a null terminated const c-string.

CUPTI_EVENT_ATTR_CATEGORY = 3

Category of event. Value is CUpti_EventCategory.

CUPTI_EVENT_ATTR_FORCE_INT = 0x7fffffff

enum CUpti_EventCategory

An event category.

Each event is assigned to a category that represents the general type of the event. A event's category is accessed using cuptiEventGetAttribute and the CUPTI_EVENT_ATTR_CATEGORY attribute.

Values

CUPTI_EVENT_CATEGORY_INSTRUCTION = 0

An instruction related event.

CUPTI_EVENT_CATEGORY_MEMORY = 1

A memory related event.

CUPTI_EVENT_CATEGORY_CACHE = 2

A cache related event.

CUPTI_EVENT_CATEGORY_PROFILE_TRIGGER = 3

A profile-trigger event.

CUPTI_EVENT_CATEGORY_FORCE_INT = 0x7fffffff

enum CUpti_EventCollectionMethod

The collection method used for an event.

The collection method indicates how an event is collected.

Values

CUPTI_EVENT_COLLECTION_METHOD_PM = 0

Event is collected using a hardware global performance monitor.

CUPTI_EVENT_COLLECTION_METHOD_SM = 1

Event is collected using a hardware SM performance monitor.

CUPTI_EVENT_COLLECTION_METHOD_INSTRUMENTED = 2

Event is collected using software instrumentation.

CUPTI_EVENT_COLLECTION_METHOD_FORCE_INT = 0x7fffffff

enum CUpti_EventCollectionMode

Event collection modes.

The event collection mode determines the period over which the events within the enabled event groups will be collected.

Values

CUPTI_EVENT_COLLECTION_MODE_CONTINUOUS = 0

Events are collected for the entire duration between the cuptiEventGroupEnable and cuptiEventGroupDisable calls. This is the default mode. For devices with compute capability less than 2.0, event values are reset when a kernel is launched. For all other devices event values are only reset when the events are read.

CUPTI_EVENT_COLLECTION_MODE_KERNEL = 1

Events are collected only for the durations of kernel executions that occur between the cuptiEventGroupEnable and cuptiEventGroupDisable calls. Event collection begins when a kernel execution begins, and stops when kernel execution completes. Event values are reset to zero when each kernel execution begins. If multiple kernel executions occur between the cuptiEventGroupEnable and cuptiEventGroupDisable

calls then the event values must be read after each kernel launch if those events need to be associated with the specific kernel launch.

CUPTI_EVENT_COLLECTION_MODE_FORCE_INT = 0x7fffffff

enum CUpti_EventDomainAttribute

Event domain attributes.

Event domain attributes. Except where noted, all the attributes can be read using either cuptiDeviceGetEventDomainAttribute or cuptiEventDomainGetAttribute.

Values

CUPTI_EVENT_DOMAIN_ATTR_NAME = 0

Event domain name. Value is a null terminated const c-string.

CUPTI_EVENT_DOMAIN_ATTR_INSTANCE_COUNT = 1

Number of instances of the domain for which event counts will be collected.

The domain may have additional instances that cannot be profiled (see

CUPTI_EVENT_DOMAIN_ATTR_TOTAL_INSTANCE_COUNT). Can be read only with cuptiDeviceGetEventDomainAttribute. Value is a uint32_t.

CUPTI_EVENT_DOMAIN_ATTR_TOTAL_INSTANCE_COUNT = 3

Total number of instances of the domain, including instances that cannot be profiled. Use CUPTI_EVENT_DOMAIN_ATTR_INSTANCE_COUNT to get the number of instances that can be profiled. Can be read only with cuptiDeviceGetEventDomainAttribute. Value is a uint32 t.

CUPTI_EVENT_DOMAIN_ATTR_COLLECTION_METHOD = 4

Collection method used for events contained in the event domain. Value is a CUpti_EventCollectionMethod.

CUPTI_EVENT_DOMAIN_ATTR_FORCE_INT = 0x7fffffff

enum CUpti_EventGroupAttribute

Event group attributes.

Event group attributes. These attributes can be read using cuptiEventGroupGetAttribute. Attributes marked [rw] can also be written using cuptiEventGroupSetAttribute.

Values

CUPTI_EVENT_GROUP_ATTR_EVENT_DOMAIN_ID = 0

The domain to which the event group is bound. This attribute is set when the first event is added to the group. Value is a CUpti_EventDomainID.

CUPTI_EVENT_GROUP_ATTR_PROFILE_ALL_DOMAIN_INSTANCES = 1

[rw] Profile all the instances of the domain for this eventgroup. This feature can be used to get load balancing across all instances of a domain. Value is an integer.

CUPTI_EVENT_GROUP_ATTR_USER_DATA = 2

[rw] Reserved for user data.

CUPTI_EVENT_GROUP_ATTR_NUM_EVENTS = 3

Number of events in the group. Value is a uint32_t.

CUPTI_EVENT_GROUP_ATTR_EVENTS = 4

Enumerates events in the group. Value is a pointer to buffer of size sizeof(CUpti_EventID) * num_of_events in the eventgroup. num_of_events can be queried using CUPTI_EVENT_GROUP_ATTR_NUM_EVENTS.

CUPTI_EVENT_GROUP_ATTR_INSTANCE_COUNT = 5

Number of instances of the domain bound to this event group that will be counted. Value is a uint32 t.

CUPTI_EVENT_GROUP_ATTR_FORCE_INT = 0x7fffffff

enum CUpti_ReadEventFlags

 $Flags\ for\ cupti Event Group Read Event\ an\ cupti Event Group Read All Events.$

Flags for cuptiEventGroupReadEvent an cuptiEventGroupReadAllEvents.

Values

CUPTI_EVENT_READ_FLAG_NONE = 0
No flags.
CUPTI_EVENT_READ_FLAG_FORCE_INT = 0x7fffffff

typedef uint32_t CUpti_EventDomainID

ID for an event domain.

ID for an event domain. An event domain represents a group of related events. A device may have multiple instances of a domain, indicating that the device can simultaneously record multiple instances of each event within that domain.

typedef void *CUpti_EventGroup

A group of events.

An event group is a collection of events that are managed together. All events in an event group must belong to the same domain.

typedef uint32_t CUpti_EventID

ID for an event.

An event represents a countable activity, action, or occurrence on the device.

CUptiResult cuptiDeviceEnumEventDomains (CUdevice device, size_t *arraySizeBytes, CUpti_EventDomainID *domainArray)

Get the event domains for a device.

Parameters

device

The CUDA device

arraySizeBytes

The size of domainArray in bytes, and returns the number of bytes written to domainArray

domainArray

Returns the IDs of the event domains for the device

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE
- CUPTI ERROR INVALID PARAMETER

if arraySizeBytes or domainArray are NULL

Description

Returns the event domains IDs in domainArray for a device. The size of the domainArray buffer is given by *arraySizeBytes. The size of the domainArray buffer must be at least numdomains * sizeof(CUpti_EventDomainID) or else all domains will not be returned. The value returned in *arraySizeBytes contains the number of bytes returned in domainArray.



Thread-safety: this function is thread safe.

CUptiResult cuptiDeviceGetAttribute (CUdevice device, CUpti_DeviceAttribute attrib, size_t *valueSize, void *value)

Read a device attribute.

Parameters

device

The CUDA device

attrib

The attribute to read

valueSize

Size of buffer pointed by the value, and returns the number of bytes written to value value

Returns the value of the attribute

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI ERROR INVALID DEVICE
- CUPTI_ERROR_INVALID_PARAMETER

if valueSize or value is NULL, or if attrib is not a device attribute

► CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

For non-c-string attribute values, indicates that the value buffer is too small to hold the attribute value.

Description

Read a device attribute and return it in *value.



Thread-safety: this function is thread safe.

CUptiResult cuptiDeviceGetEventDomainAttribute (CUdevice device, CUpti_EventDomainID eventDomain,

CUpti_EventDomainAttribute attrib, size_t *valueSize, void *value)

Read an event domain attribute.

Parameters

device

The CUDA device

eventDomain

ID of the event domain

attrib

The event domain attribute to read

valueSize

The size of the value buffer in bytes, and returns the number of bytes written to value

value

Returns the attribute's value

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE
- CUPTI_ERROR_INVALID_EVENT_DOMAIN_ID
- CUPTI ERROR INVALID PARAMETER

if valueSize or value is NULL, or if attrib is not an event domain attribute

► CUPTI ERROR PARAMETER SIZE NOT SUFFICIENT

For non-c-string attribute values, indicates that the value buffer is too small to hold the attribute value.

Description

Returns an event domain attribute in *value. The size of the value buffer is given by *valueSize. The value returned in *valueSize contains the number of bytes returned in value.

If the attribute value is a c-string that is longer than *valueSize, then only the first *valueSize characters will be returned and there will be no terminating null byte.



Thread-safety: this function is thread safe.

CUptiResult cuptiDeviceGetNumEventDomains (CUdevice device, uint32_t *numDomains)

Get the number of domains for a device.

Parameters

device

The CUDA device

numDomains

Returns the number of domains

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE
- ► CUPTI_ERROR_INVALID_PARAMETER

if numDomains is NULL

Description

Returns the number of domains in numDomains for a device.



Thread-safety: this function is thread safe.

CUptiResult cuptiDeviceGetTimestamp (CUcontext context, uint64_t *timestamp)

Read a device timestamp.

Parameters

context

A context on the device from which to get the timestamp

timestamp

Returns the device timestamp

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED

- CUPTI_ERROR_INVALID_CONTEXT
- CUPTI_ERROR_INVALID_PARAMETERis timestamp is NULL

Description

Returns the device timestamp in *timestamp. The timestamp is reported in nanoseconds and indicates the time since the device was last reset.



Thread-safety: this function is thread safe.

CUptiResult cuptiDisableKernelReplayMode (CUcontext context)

Disable kernel replay mode.

Parameters

context

The context

Returns

► CUPTI_SUCCESS

Description

Set profiling mode for the context to non-replay (default) mode. Event collection mode will be set to CUPTI_EVENT_COLLECTION_MODE_CONTINUOUS. All previously enabled event groups and event group sets will be disabled.



Thread-safety: this function is thread safe.

CUptiResult cuptiEnableKernelReplayMode (CUcontext context)

Enable kernel replay mode.

Parameters

context

The context

Returns

CUPTI_SUCCESS

Description

Set profiling mode for the context to replay mode. In this mode, any number of events can be collected in one run of the kernel. The event collection mode will automatically switch to CUPTI_EVENT_COLLECTION_MODE_KERNEL. In this mode, cuptiSetEventCollectionMode will return CUPTI_ERROR_INVALID_OPERATION.



- Kernels might take longer to run if many events are enabled.
- ► Thread-safety: this function is thread safe.

CUptiResult cuptiEnumEventDomains (size_t *arraySizeBytes, CUpti_EventDomainID *domainArray)

Get the event domains available on any device.

Parameters

arraySizeBytes

The size of domainArray in bytes, and returns the number of bytes written to domainArray

domainArray

Returns all the event domains

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_INVALID_PARAMETER

if arraySizeBytes or domainArray are NULL

Description

Returns all the event domains available on any CUDA-capable device. Event domain IDs are returned in domainArray. The size of the domainArray buffer is given by *arraySizeBytes. The size of the domainArray buffer must be at least numDomains * sizeof(CUpti_EventDomainID) or all domains will not be returned. The value returned in *arraySizeBytes contains the number of bytes returned in domainArray.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventDomainEnumEvents (CUpti_EventDomainID eventDomain, size_t *arraySizeBytes, CUpti_EventID *eventArray)

Get the events in a domain.

Parameters

eventDomain

ID of the event domain

arraySizeBytes

The size of eventArray in bytes, and returns the number of bytes written to eventArray

eventArray

Returns the IDs of the events in the domain

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_EVENT_DOMAIN_ID
- CUPTI ERROR INVALID PARAMETER

if arraySizeBytes or eventArray are NULL

Description

Returns the event IDs in eventArray for a domain. The size of the eventArray buffer is given by *arraySizeBytes. The size of the eventArray buffer must be at least numdomainevents * sizeof(CUpti_EventID) or else all events will not be returned. The value returned in *arraySizeBytes contains the number of bytes returned in eventArray.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventDomainGetAttribute (CUpti_EventDomainID eventDomain,

CUpti_EventDomainAttribute attrib, size_t *valueSize, void *value)

Read an event domain attribute.

Parameters

eventDomain

ID of the event domain

attrib

The event domain attribute to read

valueSize

The size of the value buffer in bytes, and returns the number of bytes written to value

value

Returns the attribute's value

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_EVENT_DOMAIN_ID
- CUPTI_ERROR_INVALID_PARAMETER

if valueSize or value is NULL, or if attrib is not an event domain attribute

► CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

For non-c-string attribute values, indicates that the value buffer is too small to hold the attribute value.

Description

Returns an event domain attribute in *value. The size of the value buffer is given by *valueSize. The value returned in *valueSize contains the number of bytes returned in value.

If the attribute value is a c-string that is longer than *valueSize, then only the first *valueSize characters will be returned and there will be no terminating null byte.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventDomainGetNumEvents (CUpti_EventDomainID eventDomain, uint32_t *numEvents)

Get number of events in a domain.

Parameters

eventDomain

ID of the event domain

numEvents

Returns the number of events in the domain

Returns

- ► CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_EVENT_DOMAIN_ID
- ► CUPTI ERROR INVALID PARAMETER

if numEvents is NULL

Description

Returns the number of events in numEvents for a domain.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGetAttribute (CUpti_EventID event, CUpti_EventAttribute attrib, size_t *valueSize, void *value)

Get an event attribute.

Parameters

event

ID of the event

attrib

The event attribute to read

valueSize

The size of the value buffer in bytes, and returns the number of bytes written to value

value

Returns the attribute's value

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI ERROR INVALID EVENT ID
- CUPTI_ERROR_INVALID_PARAMETER

if valueSize or value is NULL, or if attrib is not an event attribute

► CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

For non-c-string attribute values, indicates that the value buffer is too small to hold the attribute value.

Description

Returns an event attribute in *value. The size of the value buffer is given by *valueSize. The value returned in *valueSize contains the number of bytes returned in value.

If the attribute value is a c-string that is longer than *valueSize, then only the first *valueSize characters will be returned and there will be no terminating null byte.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGetIdFromName (CUdevice device, const char *eventName, CUpti_EventID *event)

Find an event by name.

Parameters

device

The CUDA device

eventName

The name of the event to find

event

Returns the ID of the found event or undefined if unable to find the event

Returns

- CUPTI_SUCCESS
- CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE
- ► CUPTI_ERROR_INVALID_EVENT_NAME

if unable to find an event with name eventName. In this case *event is undefined

CUPTI ERROR INVALID PARAMETER

if eventName or event are NULL

Description

Find an event by name and return the event ID in *event.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupAddEvent (CUpti_EventGroup eventGroup, CUpti_EventID event)

Add an event to an event group.

Parameters

eventGroup

The event group

event

The event to add to the group

Returns

- CUPTI_SUCCESS
- CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_EVENT_ID
- CUPTI_ERROR_OUT_OF_MEMORY
- ► CUPTI_ERROR_INVALID_OPERATION
 - if eventGroup is enabled
- CUPTI_ERROR_NOT_COMPATIBLE

if event belongs to a different event domain than the events already in eventGroup, or if a device limitation prevents event from being collected at the same time as the events already in eventGroup

CUPTI_ERROR_MAX_LIMIT_REACHED

if eventGroup is full

CUPTI_ERROR_INVALID_PARAMETER

if eventGroup is NULL

Description

Add an event to an event group. The event add can fail for a number of reasons:

- ▶ The event group is enabled
- ► The event does not belong to the same event domain as the events that are already in the event group
- Device limitations on the events that can belong to the same group
- The event group is full



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupCreate (CUcontext context, CUpti_EventGroup *eventGroup, uint32_t flags)

Create a new event group for a context.

Parameters

context

The context for the event group

eventGroup

Returns the new event group

flags

Reserved - must be zero

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI ERROR INVALID CONTEXT
- CUPTI_ERROR_OUT_OF_MEMORY
- CUPTI_ERROR_INVALID_PARAMETER

if eventGroup is NULL

Description

Creates a new event group for context and returns the new group in *eventGroup.



- flags are reserved for future use and should be set to zero.
- Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupDestroy (CUpti_EventGroup eventGroup)

Destroy an event group.

Parameters

eventGroup

The event group to destroy

Returns

- ► CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_OPERATION
 - if the event group is enabled
- ► CUPTI_ERROR_INVALID_PARAMETER

if eventGroup is NULL

Description

Destroy an eventGroup and free its resources. An event group cannot be destroyed if it is enabled.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupDisable (CUpti_EventGroup eventGroup)

Disable an event group.

Parameters

eventGroup

The event group

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- ► CUPTI_ERROR_HARDWARE
- CUPTI_ERROR_INVALID_PARAMETER

if eventGroup is NULL

Description

Disable an event group. Disabling an event group stops collection of events contained in the group.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupEnable (CUpti_EventGroup eventGroup)

Enable an event group.

Parameters

eventGroup

The event group

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_HARDWARE
- CUPTI_ERROR_NOT_READY

if eventGroup does not contain any events

► CUPTI_ERROR_NOT_COMPATIBLE

if eventGroup cannot be enabled due to other already enabled event groups

► CUPTI_ERROR_INVALID_PARAMETER

if eventGroup is NULL

CUPTI_ERROR_HARDWARE_BUSY

if another client is profiling and hardware is busy

Description

Enable an event group. Enabling an event group zeros the value of all the events in the group and then starts collection of those events.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupGetAttribute (CUpti_EventGroup eventGroup, CUpti_EventGroupAttribute attrib, size_t *valueSize, void *value)

Read an event group attribute.

Parameters

eventGroup

The event group

attrib

The attribute to read

valueSize

Size of buffer pointed by the value, and returns the number of bytes written to value value

Returns the value of the attribute

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_PARAMETER

if valueSize or value is NULL, or if attrib is not an eventgroup attribute

CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

For non-c-string attribute values, indicates that the value buffer is too small to hold the attribute value.

Description

Read an event group attribute and return it in *value.



Thread-safety: this function is thread safe but client must guard against simultaneous destruction or modification of eventGroup (for example, client must guard against simultaneous calls to cuptiEventGroupDestroy, cuptiEventGroupAddEvent, etc.), and must guard against simultaneous destruction of the context in which eventGroup was created (for example, client must guard against simultaneous calls to cudaDeviceReset, cuCtxDestroy, etc.).

CUptiResult cuptiEventGroupReadAllEvents
(CUpti_EventGroup eventGroup, CUpti_ReadEventFlags
flags, size_t *eventValueBufferSizeBytes, uint64_t
*eventValueBuffer, size_t *eventIdArraySizeBytes,
CUpti_EventID *eventIdArray, size_t *numEventIdsRead)

Read the values for all the events in an event group.

Parameters

eventGroup

The event group

flags

Flags controlling the reading mode

eventValueBufferSizeBytes

The size of eventValueBuffer in bytes, and returns the number of bytes written to eventValueBuffer

eventValueBuffer

Returns the event values

eventIdArraySizeBytes

The size of eventIdArray in bytes, and returns the number of bytes written to eventIdArray

eventIdArray

Returns the IDs of the events in the same order as the values return in eventValueBuffer.

numEventIdsRead

Returns the number of event IDs returned in eventIdArray

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- ► CUPTI ERROR HARDWARE
- CUPTI_ERROR_INVALID_OPERATION
- if eventGroup is disabled
- CUPTI ERROR INVALID PARAMETER

if eventGroup, eventValueBufferSizeBytes, eventValueBuffer, eventIdArraySizeBytes, eventIdArray or numEventIdsRead is NULL

Description

Read the values for all the events in an event group. The event values are returned in the eventValueBuffer buffer. eventValueBufferSizeBytes indicates the size of eventValueBuffer. The buffer must be at least (sizeof(uint64) * number of events in group) if CUPTI_EVENT_GROUP_ATTR_PROFILE_ALL_DOMAIN_INSTANCES is not set on the group containing the events. The buffer must be at least (sizeof(uint64) * number of domain instances * number of events in group) if CUPTI_EVENT_GROUP_ATTR_PROFILE_ALL_DOMAIN_INSTANCES is set on the group.

The data format returned in eventValueBuffer is:

- domain instance 0: event0 event1 ... eventN
- domain instance 1: event0 event1 ... eventN
- domain instance M: event0 event1 ... eventN

The event order in eventValueBuffer is returned in eventIdArray. The size of eventIdArray is specified in eventIdArraySizeBytes. The size should be at least (sizeof(CUpti_EventID) * number of events in group).

If any instance of any event counter overflows, the value returned for that event instance will be CUPTI_EVENT_OVERFLOW.

The only allowed value for flags is CUPTI_EVENT_READ_FLAG_NONE.

Reading events from a disabled event group is not allowed. After being read, an event's value is reset to zero.



Thread-safety: this function is thread safe but client must guard against simultaneous destruction or modification of eventGroup (for example, client must guard against simultaneous calls to cuptiEventGroupDestroy, cuptiEventGroupAddEvent, etc.), and must guard against simultaneous destruction of the context in which



eventGroup was created (for example, client must guard against simultaneous calls to cudaDeviceReset, cuCtxDestroy, etc.). If cuptiEventGroupResetAllEvents is called simultaneously with this function, then returned event values are undefined.

CUptiResult cuptiEventGroupReadEvent (CUpti_EventGroup eventGroup, CUpti_ReadEventFlags flags, CUpti_EventID event, size_t *eventValueBufferSizeBytes, uint64_t *eventValueBuffer)

Read the value for an event in an event group.

Parameters

eventGroup

The event group

flags

Flags controlling the reading mode

event

The event to read

eventValueBufferSizeBytes

The size of eventValueBuffer in bytes, and returns the number of bytes written to eventValueBuffer

eventValueBuffer

Returns the event value(s)

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_EVENT_ID
- CUPTI_ERROR_HARDWARE
- CUPTI_ERROR_INVALID_OPERATION

if eventGroup is disabled

► CUPTI_ERROR_INVALID_PARAMETER

 $if\ event \ Group,\ event \ Value \ Buffer \ Size Bytes\ or\ event \ Value \ Buffer\ is\ NULL$

Description

Read the value for an event in an event group. The event value is returned in the eventValueBuffer buffer. eventValueBufferSizeBytes indicates the size of the eventValueBuffer buffer. The buffer must be at least sizeof(uint64) if CUPTI_EVENT_GROUP_ATTR_PROFILE_ALL_DOMAIN_INSTANCES is not set on the group containing the event. The buffer must be at least (sizeof(uint64) * number of domain instances) if CUPTI_EVENT_GROUP_ATTR_PROFILE_ALL_DOMAIN_INSTANCES is set on the group.

If any instance of an event counter overflows, the value returned for that event instance will be CUPTI_EVENT_OVERFLOW.

The only allowed value for flags is CUPTI_EVENT_READ_FLAG_NONE.

Reading an event from a disabled event group is not allowed. After being read, an event's value is reset to zero.



Thread-safety: this function is thread safe but client must guard against simultaneous destruction or modification of eventGroup (for example, client must guard against simultaneous calls to cuptiEventGroupDestroy, cuptiEventGroupAddEvent, etc.), and must guard against simultaneous destruction of the context in which eventGroup was created (for example, client must guard against simultaneous calls to cudaDeviceReset, cuCtxDestroy, etc.). If cuptiEventGroupResetAllEvents is called simultaneously with this function, then returned event values are undefined.

CUptiResult cuptiEventGroupRemoveAllEvents (CUpti_EventGroup eventGroup)

Remove all events from an event group.

Parameters

eventGroup

The event group

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_OPERATION if eventGroup is enabled
- CUPTI_ERROR_INVALID_PARAMETER

if eventGroup is NULL

Description

Remove all events from an event group. Events cannot be removed if the event group is enabled



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupRemoveEvent (CUpti_EventGroup eventGroup, CUpti_EventID event)

Remove an event from an event group.

Parameters

eventGroup

The event group

event

The event to remove from the group

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_EVENT_ID
- CUPTI_ERROR_INVALID_OPERATION

if eventGroup is enabled

► CUPTI_ERROR_INVALID_PARAMETER

if eventGroup is NULL

Description

Remove event from the an event group. The event cannot be removed if the event group is enabled.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupResetAllEvents (CUpti_EventGroup eventGroup)

Zero all the event counts in an event group.

Parameters

eventGroup

The event group

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- ► CUPTI_ERROR_HARDWARE
- CUPTI_ERROR_INVALID_PARAMETERif eventGroup is NULL

Description

Zero all the event counts in an event group.



Thread-safety: this function is thread safe but client must guard against simultaneous destruction or modification of eventGroup (for example, client must guard against simultaneous calls to cuptiEventGroupDestroy, cuptiEventGroupAddEvent, etc.), and must guard against simultaneous destruction of the context in which eventGroup was created (for example, client must guard against simultaneous calls to cudaDeviceReset, cuCtxDestroy, etc.).

CUptiResult cuptiEventGroupSetAttribute (CUpti_EventGroup eventGroup, CUpti_EventGroupAttribute attrib, size_t valueSize, void *value)

Write an event group attribute.

Parameters

eventGroup

The event group

attrib

The attribute to write

valueSize

The size, in bytes, of the value

value

The attribute value to write

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- ► CUPTI_ERROR_INVALID_PARAMETER

if valueSize or value is NULL, or if attrib is not an event group attribute, or if attrib is not a writable attribute

► CUPTI ERROR PARAMETER SIZE NOT SUFFICIENT

Indicates that the value buffer is too small to hold the attribute value.

Description

Write an event group attribute.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupSetDisable (CUpti_EventGroupSet *eventGroupSet)

Disable an event group set.

Parameters

eventGroupSet

The pointer to the event group set

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_HARDWARE
- ► CUPTI_ERROR_INVALID_PARAMETER

if eventGroupSet is NULL

Description

Disable a set of event groups. Disabling a set of event groups stops collection of events contained in the groups.



- Thread-safety: this function is thread safe.
- If this call fails, some of the event groups in the set may be disabled and other event groups may remain enabled.

CUptiResult cuptiEventGroupSetEnable (CUpti_EventGroupSet *eventGroupSet)

Enable an event group set.

Parameters

eventGroupSet

The pointer to the event group set

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_HARDWARE
- CUPTI_ERROR_NOT_READY

if eventGroup does not contain any events

► CUPTI_ERROR_NOT_COMPATIBLE

if eventGroup cannot be enabled due to other already enabled event groups

CUPTI_ERROR_INVALID_PARAMETER

if eventGroupSet is NULL

CUPTI_ERROR_HARDWARE_BUSY

if other client is profiling and hardware is busy

Description

Enable a set of event groups. Enabling a set of event groups zeros the value of all the events in all the groups and then starts collection of those events.



Thread-safety: this function is thread safe.

CUptiResult cuptiEventGroupSetsCreate (CUcontext context, size_t eventIdArraySizeBytes, CUpti_EventID *eventIdArray, CUpti_EventGroupSets **eventGroupPasses)

For a set of events, get the grouping that indicates the number of passes and the event groups necessary to collect the events.

Parameters

context

The context for event collection

eventIdArraySizeBytes

Size of eventIdArray in bytes

eventIdArray

Array of event IDs that need to be grouped

eventGroupPasses

Returns a CUpti_EventGroupSets object that indicates the number of passes required to collect the events and the events to collect on each pass

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_CONTEXT
- CUPTI_ERROR_INVALID_EVENT_ID
- CUPTI_ERROR_INVALID_PARAMETER

if eventIdArray or eventGroupPasses is NULL

Description

The number of events that can be collected simultaneously varies by device and by the type of the events. When events can be collected simultaneously, they may need to be grouped into multiple event groups because they are from different event domains. This function takes a set of events and determines how many passes are required to collect all those events, and which events can be collected simultaneously in each pass.

The CUpti_EventGroupSets returned in eventGroupPasses indicates how many passes are required to collect the events with the numSets field. Within each event group set, the sets array indicates the event groups that should be collected on each pass.



Thread-safety: this function is thread safe, but client must guard against another thread simultaneously destroying context.

CUptiResult cuptiEventGroupSetsDestroy (CUpti_EventGroupSets *eventGroupSets)

Destroy a CUpti_EventGroupSets object.

Parameters

eventGroupSets

The object to destroy

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_OPERATION

if any of the event groups contained in the sets is enabled

CUPTI_ERROR_INVALID_PARAMETER

if eventGroupSets is NULL

Description

Destroy a CUpti_EventGroupSets object.



Thread-safety: this function is thread safe.

CUptiResult cuptiGetNumEventDomains (uint32_t *numDomains)

Get the number of event domains available on any device.

Parameters

numDomains

Returns the number of domains

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_INVALID_PARAMETER

if numDomains is NULL

Description

Returns the total number of event domains available on any CUDA-capable device.



Thread-safety: this function is thread safe.

CUptiResult cuptiSetEventCollectionMode (CUcontext context, CUpti_EventCollectionMode mode)

Set the event collection mode.

Parameters

context

The context

mode

The event collection mode

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_CONTEXT
- CUPTI_ERROR_INVALID_OPERATION

if called when replay mode is enabled

Description

Set the event collection mode for a context. The mode controls the event collection behavior of all events in event groups created in the context. This API is invalid in kernel replay mode.



Thread-safety: this function is thread safe.

#define CUPTI_EVENT_OVERFLOW ((uint64_t)0xFFFFFFFFFFFFFFULL)

The overflow value for a CUPTI event.

The CUPTI event value that indicates an overflow.

2.6. CUPTI Metric API

Functions, types, and enums that implement the CUPTI Metric API.

union CUpti_MetricValue

A metric value.

enum CUpti_MetricAttribute

Metric attributes.

Metric attributes describe properties of a metric. These attributes can be read using cuptiMetricGetAttribute.

Values

CUPTI_METRIC_ATTR_NAME = 0

Metric name. Value is a null terminated const c-string.

CUPTI_METRIC_ATTR_SHORT_DESCRIPTION = 1

Short description of metric. Value is a null terminated const c-string.

CUPTI_METRIC_ATTR_LONG_DESCRIPTION = 2

Long description of metric. Value is a null terminated const c-string.

CUPTI_METRIC_ATTR_CATEGORY = 3

Category of the metric. Value is of type CUpti_MetricCategory.

CUPTI_METRIC_ATTR_VALUE_KIND = 4

Value type of the metric. Value is of type CUpti_MetricValueKind.

CUPTI_METRIC_ATTR_EVALUATION_MODE = 5

Metric evaluation mode. Value is of type CUpti MetricEvaluationMode.

CUPTI_METRIC_ATTR_FORCE_INT = 0x7fffffff

enum CUpti_MetricCategory

A metric category.

Each metric is assigned to a category that represents the general type of the metric. A metric's category is accessed using cuptiMetricGetAttribute and the CUPTI_METRIC_ATTR_CATEGORY attribute.

Values

CUPTI_METRIC_CATEGORY_MEMORY = 0

A memory related metric.

CUPTI_METRIC_CATEGORY_INSTRUCTION = 1

An instruction related metric.

CUPTI_METRIC_CATEGORY_MULTIPROCESSOR = 2

A multiprocessor related metric.

CUPTI_METRIC_CATEGORY_CACHE = 3

A cache related metric.

CUPTI_METRIC_CATEGORY_TEXTURE = 4

A texture related metric.

CUPTI_METRIC_CATEGORY_FORCE_INT = 0x7fffffff

enum CUpti_MetricEvaluationMode

A metric evaluation mode.

A metric can be evaluated per hardware instance to know the load balancing across instances of a domain or the metric can be evaluated in aggregate mode when the events involved in metric evaluation are from different event domains. It might be possible to evaluate some metrics in both modes for convenience. A metric's evaluation mode is accessed using CUpti_MetricEvaluationMode and the CUPTI_METRIC_ATTR_EVALUATION_MODE attribute.

Values

CUPTI_METRIC_EVALUATION_MODE_PER_INSTANCE = 1

If this bit is set, the metric can be profiled for each instance of the domain. The event values passed to cuptiMetricGetValue can contain values for one instance of the domain. And cuptiMetricGetValue can be called for each instance.

CUPTI_METRIC_EVALUATION_MODE_AGGREGATE = 1<<1

If this bit is set, the metric can be profiled over all instances. The event values passed to cuptiMetricGetValue can be aggregated values of events for all instances of the domain.

CUPTI_METRIC_EVALUATION_MODE_FORCE_INT = 0x7fffffff

enum CUpti_MetricPropertyDeviceClass

Device class.

Enumeration of device classes for metric property CUPTI_METRIC_PROPERTY_DEVICE_CLASS.

Values

CUPTI_METRIC_PROPERTY_DEVICE_CLASS_TESLA = 0 CUPTI_METRIC_PROPERTY_DEVICE_CLASS_QUADRO = 1 CUPTI_METRIC_PROPERTY_DEVICE_CLASS_GEFORCE = 2

enum CUpti_MetricPropertyID

Metric device properties.

Metric device properties describe device properties which are needed for a metric. Some of these properties can be collected using cuDeviceGetAttribute.

Values

CUPTI_METRIC_PROPERTY_MULTIPROCESSOR_COUNT
CUPTI_METRIC_PROPERTY_WARPS_PER_MULTIPROCESSOR
CUPTI_METRIC_PROPERTY_KERNEL_GPU_TIME
CUPTI_METRIC_PROPERTY_CLOCK_RATE
CUPTI_METRIC_PROPERTY_FRAME_BUFFER_COUNT
CUPTI_METRIC_PROPERTY_GLOBAL_MEMORY_BANDWIDTH
CUPTI_METRIC_PROPERTY_PCIE_LINK_RATE
CUPTI_METRIC_PROPERTY_PCIE_LINK_WIDTH
CUPTI_METRIC_PROPERTY_PCIE_GEN

enum CUpti_MetricValueKind

CUPTI_METRIC_PROPERTY_DEVICE_CLASS

Kinds of metric values.

Metric values can be one of several different kinds. Corresponding to each kind is a member of the CUpti_MetricValue union. The metric value returned by cuptiMetricGetValue should be accessed using the appropriate member of that union based on its value kind.

Values

CUPTI_METRIC_VALUE_KIND_DOUBLE = 0

The metric value is a 64-bit double.

CUPTI_METRIC_VALUE_KIND_UINT64 = 1

The metric value is a 64-bit unsigned integer.

CUPTI_METRIC_VALUE_KIND_PERCENT = 2

The metric value is a percentage represented by a 64-bit double. For example, 57.5% is represented by the value 57.5.

CUPTI_METRIC_VALUE_KIND_THROUGHPUT = 3

The metric value is a throughput represented by a 64-bit integer. The unit for throughput values is bytes/second.

CUPTI_METRIC_VALUE_KIND_INT64 = 4

The metric value is a 64-bit signed integer.

CUPTI_METRIC_VALUE_KIND_UTILIZATION_LEVEL = 5

The metric value is a utilization level, as represented by

CUpti MetricValueUtilizationLevel.

CUPTI_METRIC_VALUE_KIND_FORCE_INT = 0x7fffffff

enum CUpti_MetricValueUtilizationLevel

Enumeration of utilization levels for metrics values of kind CUPTI_METRIC_VALUE_KIND_UTILIZATION_LEVEL. Utilization values can vary from IDLE (0) to MAX (10) but the enumeration only provides specific names for a few values.

Values

CUPTI_METRIC_VALUE_UTILIZATION_IDLE = 0
CUPTI_METRIC_VALUE_UTILIZATION_LOW = 2
CUPTI_METRIC_VALUE_UTILIZATION_MID = 5
CUPTI_METRIC_VALUE_UTILIZATION_HIGH = 8
CUPTI_METRIC_VALUE_UTILIZATION_MAX = 10
CUPTI_METRIC_VALUE_UTILIZATION_FORCE_INT = 0x7fffffff

typedef uint32_t CUpti_MetricID

ID for a metric.

A metric provides a measure of some aspect of the device.

CUptiResult cuptiDeviceEnumMetrics (CUdevice device, size_t *arraySizeBytes, CUpti_MetricID *metricArray)

Get the metrics for a device.

Parameters

device

The CUDA device

arraySizeBytes

The size of metricArray in bytes, and returns the number of bytes written to metricArray

metricArray

Returns the IDs of the metrics for the device

Returns

- CUPTI_SUCCESS
- CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE
- CUPTI_ERROR_INVALID_PARAMETER

if arraySizeBytes or metricArray are NULL

Description

Returns the metric IDs in metricArray for a device. The size of the metricArray buffer is given by *arraySizeBytes. The size of the metricArray buffer must be at least numMetrics * sizeof(CUpti_MetricID) or else all metric IDs will not be returned. The value returned in *arraySizeBytes contains the number of bytes returned in metricArray.

CUptiResult cuptiDeviceGetNumMetrics (CUdevice device, uint32_t *numMetrics)

Get the number of metrics for a device.

Parameters

device

The CUDA device

numMetrics

Returns the number of metrics available for the device

Returns

- ► CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE
- ► CUPTI_ERROR_INVALID_PARAMETER

if numMetrics is NULL

Description

Returns the number of metrics available for a device.

CUptiResult cuptiEnumMetrics (size_t *arraySizeBytes, CUpti_MetricID *metricArray)

Get all the metrics available on any device.

Parameters

arraySizeBytes

The size of metricArray in bytes, and returns the number of bytes written to metricArray

metricArray

Returns the IDs of the metrics

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_INVALID_PARAMETER

if arraySizeBytes or metricArray are NULL

Description

Returns the metric IDs in metricArray for all CUDA-capable devices. The size of the metricArray buffer is given by *arraySizeBytes. The size of the metricArray buffer must be at least numMetrics * sizeof(CUpti_MetricID) or all metric IDs will not be returned. The value returned in *arraySizeBytes contains the number of bytes returned in metricArray.

CUptiResult cuptiGetNumMetrics (uint32_t *numMetrics)

Get the total number of metrics available on any device.

Parameters

numMetrics

Returns the number of metrics

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_INVALID_PARAMETER

if numMetrics is NULL

Description

Returns the total number of metrics available on any CUDA-capable devices.

CUptiResult cuptiMetricCreateEventGroupSets (CUcontext context, size_t metricIdArraySizeBytes, CUpti_MetricID *metricIdArray, CUpti_EventGroupSets **eventGroupPasses)

For a set of metrics, get the grouping that indicates the number of passes and the event groups necessary to collect the events required for those metrics.

Parameters

context

The context for event collection

metricIdArraySizeBytes

Size of the metricIdArray in bytes

metricIdArray

Array of metric IDs

eventGroupPasses

Returns a CUpti_EventGroupSets object that indicates the number of passes required to collect the events and the events to collect on each pass

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_CONTEXT
- CUPTI ERROR INVALID METRIC ID
- CUPTI_ERROR_INVALID_PARAMETER

if metricIdArray or eventGroupPasses is NULL

Description

For a set of metrics, get the grouping that indicates the number of passes and the event groups necessary to collect the events required for those metrics.

See also:

cuptiEventGroupSetsCreate for details on event group set creation.

CUptiResult cuptiMetricEnumEvents (CUpti_MetricID metric, size_t *eventIdArraySizeBytes, CUpti_EventID *eventIdArray)

Get the events required to calculating a metric.

Parameters

metric

ID of the metric

eventIdArraySizeBytes

The size of eventIdArray in bytes, and returns the number of bytes written to eventIdArray

eventIdArray

Returns the IDs of the events required to calculate metric

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_METRIC_ID

CUPTI_ERROR_INVALID_PARAMETER

if eventIdArraySizeBytes or eventIdArray are NULL.

Description

Gets the event IDs in eventIdArray required to calculate a metric. The size of the eventIdArray buffer is given by *eventIdArraySizeBytes and must be at least numEvents * sizeof(CUpti_EventID) or all events will not be returned. The value returned in *eventIdArraySizeBytes contains the number of bytes returned in eventIdArray.

CUptiResult cuptiMetricEnumProperties (CUpti_MetricID metric, size_t *propldArraySizeBytes, CUpti_MetricPropertyID *propldArray)

Get the properties required to calculating a metric.

Parameters

metric

ID of the metric

propIdArraySizeBytes

The size of propIdArray in bytes, and returns the number of bytes written to propIdArray

propIdArray

Returns the IDs of the properties required to calculate metric

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_METRIC_ID
- CUPTI_ERROR_INVALID_PARAMETER

if propIdArraySizeBytes or propIdArray are NULL.

Description

Gets the property IDs in propldArray required to calculate a metric. The size of the propldArray buffer is given by *propldArraySizeBytes and must be at least numProp * sizeof(CUpti_DeviceAttribute) or all properties will not be returned. The value returned in *propldArraySizeBytes contains the number of bytes returned in propldArray.

CUptiResult cuptiMetricGetAttribute (CUpti_MetricID metric, CUpti_MetricAttribute attrib, size_t *valueSize, void *value)

Get a metric attribute.

Parameters

metric

ID of the metric

attrib

The metric attribute to read

valueSize

The size of the value buffer in bytes, and returns the number of bytes written to value

value

Returns the attribute's value

Returns

- ► CUPTI_SUCCESS
- CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_METRIC_ID
- CUPTI ERROR INVALID PARAMETER

if valueSize or value is NULL, or if attrib is not a metric attribute

► CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

For non-c-string attribute values, indicates that the value buffer is too small to hold the attribute value.

Description

Returns a metric attribute in *value. The size of the value buffer is given by *valueSize. The value returned in *valueSize contains the number of bytes returned in value.

If the attribute value is a c-string that is longer than *valueSize, then only the first *valueSize characters will be returned and there will be no terminating null byte.

CUptiResult cuptiMetricGetIdFromName (CUdevice device, const char *metricName, CUpti_MetricID *metric)

Find an metric by name.

Parameters

device

The CUDA device

metricName

The name of metric to find

metric

Returns the ID of the found metric or undefined if unable to find the metric

Returns

- CUPTI SUCCESS
- ► CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_DEVICE
- CUPTI_ERROR_INVALID_METRIC_NAME

if unable to find a metric with name metricName. In this case *metric is undefined

CUPTI ERROR INVALID PARAMETER

if metricName or metric are NULL.

Description

Find a metric by name and return the metric ID in *metric.

CUptiResult cuptiMetricGetNumEvents (CUpti_MetricID metric, uint32_t *numEvents)

Get number of events required to calculate a metric.

Parameters

metric

ID of the metric

numEvents

Returns the number of events required for the metric

Returns

- ► CUPTI_SUCCESS
- CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_METRIC_ID
- ► CUPTI_ERROR_INVALID_PARAMETER
 if numEvents is NULL

Description

Returns the number of events in numEvents that are required to calculate a metric.

CUptiResult cuptiMetricGetNumProperties (CUpti_MetricID metric, uint32_t *numProp)

Get number of properties required to calculate a metric.

Parameters

metric

ID of the metric

numProp

Returns the number of properties required for the metric

Returns

- ► CUPTI_SUCCESS
- CUPTI ERROR NOT INITIALIZED
- CUPTI_ERROR_INVALID_METRIC_ID
- ► CUPTI_ERROR_INVALID_PARAMETER if numProp is NULL

Description

Returns the number of properties in numProp that are required to calculate a metric.

CUptiResult cuptiMetricGetValue (CUdevice device, CUpti_MetricID metric, size_t eventIdArraySizeBytes, CUpti_EventID *eventIdArray, size_t eventValueArraySizeBytes, uint64_t

*eventValueArray, uint64_t timeDuration, CUpti_MetricValue *metricValue)

Calculate the value for a metric.

Parameters

device

The CUDA device that the metric is being calculated for

metric

The metric ID

eventIdArraySizeBytes

The size of eventIdArray in bytes

eventIdArray

The event IDs required to calculate metric

eventValueArraySizeBytes

The size of eventValueArray in bytes

eventValueArray

The normalized event values required to calculate metric. The values must be order to match the order of events in eventIdArray

timeDuration

The duration over which the events were collected, in ns

metricValue

Returns the value for the metric

Returns

- CUPTI_SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI ERROR INVALID METRIC ID
- CUPTI_ERROR_INVALID_OPERATION
- CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

if the eventIdArray does not contain all the events needed for metric

CUPTI ERROR INVALID EVENT VALUE

if any of the event values required for the metric is CUPTI_EVENT_OVERFLOW

CUPTI_ERROR_INVALID_METRIC_VALUE

if the computed metric value cannot be represented in the metric's value type. For example, if the metric value type is unsigned and the computed metric value is negative

CUPTI_ERROR_INVALID_PARAMETER

if metricValue, eventIdArray or eventValueArray is NULL

Description

Use the events collected for a metric to calculate the metric value. Metric value evaluation depends on the evaluation mode CUpti_MetricEvaluationMode that the metric supports. If a metric has evaluation mode as CUPTI_METRIC_EVALUATION_MODE_PER_INSTANCE, then it assumes that the input event value is for one domain instance. If a metric has evaluation mode as CUPTI_METRIC_EVALUATION_MODE_AGGREGATE, it assumes that input event values are normalized to represent all domain instances on a device. For the most accurate metric collection, the events required for the metric should be collected for all profiled domain instances. For example, to collect all instances of an event, set the CUPTI_EVENT_GROUP_ATTR_PROFILE_ALL_DOMAIN_INSTANCES attribute on the group containing the event to 1. The normalized value for the event is then: (sum event values * totalInstanceCount) / instanceCount, where sum event values is the summation of the event values across all profiled domain instances, totalInstanceCount is obtained from querying CUPTI_EVENT_DOMAIN_ATTR_TOTAL_INSTANCE_COUNT and instanceCount is obtained from querying CUPTI_EVENT_GROUP_ATTR_INSTANCE_COUNT (or CUPTI_EVENT_DOMAIN_ATTR_INSTANCE_COUNT).

CUptiResult cuptiMetricGetValue2 (CUpti_MetricID metric, size_t eventIdArraySizeBytes, CUpti_EventID *eventIdArray, size_t eventValueArraySizeBytes, uint64_t *eventValueArray, size_t propIdArraySizeBytes, CUpti_MetricPropertyID *propIdArray, size_t propValueArraySizeBytes, uint64_t *propValueArray, CUpti_MetricValue *metricValue)

Calculate the value for a metric.

Parameters

metric

The metric ID

eventIdArraySizeBytes

The size of eventIdArray in bytes

eventIdArray

The event IDs required to calculate metric

eventValueArraySizeBytes

The size of eventValueArray in bytes

eventValueArray

The normalized event values required to calculate metric. The values must be order to match the order of events in eventIdArray

propIdArraySizeBytes

The size of propIdArray in bytes

propIdArray

The metric property IDs required to calculate metric

propValueArraySizeBytes

The size of propValueArray in bytes

propValueArray

The metric property values required to calculate metric. The values must be order to match the order of metric properties in propldArray

metricValue

Returns the value for the metric

Returns

- CUPTI SUCCESS
- CUPTI_ERROR_NOT_INITIALIZED
- CUPTI_ERROR_INVALID_METRIC_ID
- CUPTI_ERROR_INVALID_OPERATION
- CUPTI_ERROR_PARAMETER_SIZE_NOT_SUFFICIENT

if the eventIdArray does not contain all the events needed for metric

CUPTI_ERROR_INVALID_EVENT_VALUE

if any of the event values required for the metric is CUPTI_EVENT_OVERFLOW

► CUPTI_ERROR_NOT_COMPATIBLE

if the computed metric value cannot be represented in the metric's value type. For example, if the metric value type is unsigned and the computed metric value is negative

CUPTI_ERROR_INVALID_PARAMETER

if metricValue, eventIdArray or eventValueArray is NULL

Description

Use the events and properties collected for a metric to calculate the metric value. Metric value evaluation depends on the evaluation mode CUpti_MetricEvaluationMode that the metric supports. If a metric has evaluation mode as CUPTI_METRIC_EVALUATION_MODE_PER_INSTANCE, then it assumes that the input event value is for one domain instance. If a metric has evaluation mode as CUPTI_METRIC_EVALUATION_MODE_AGGREGATE, it assumes that input event values are normalized to represent all domain instances on a device. For the most accurate metric collection, the events required for the metric should be collected for all profiled domain instances. For example, to collect all instances of an event,

set the CUPTI_EVENT_GROUP_ATTR_PROFILE_ALL_DOMAIN_INSTANCES attribute on the group containing the event to 1. The normalized value for the event is then: (sum_event_values * totalInstanceCount) / instanceCount, where sum_event_values is the summation of the event values across all profiled domain instances, totalInstanceCount is obtained from querying CUPTI_EVENT_DOMAIN_ATTR_TOTAL_INSTANCE_COUNT and instanceCount is obtained from querying CUPTI_EVENT_GROUP_ATTR_INSTANCE_COUNT (or CUPTI_EVENT_DOMAIN_ATTR_INSTANCE_COUNT).

Chapter 3. DATA STRUCTURES

Here are the data structures with brief descriptions:

CUpti_Activity

The base activity record

CUpti_ActivityAPI

The activity record for a driver or runtime API invocation

CUpti_ActivityBranch

The activity record for source level result branch

CUpti_ActivityCdpKernel

The activity record for CDP (CUDA Dynamic Parallelism) kernel

CUpti_ActivityContext

The activity record for a context

CUpti_ActivityDevice

The activity record for a device

CUpti_ActivityEnvironment

The activity record for CUPTI environmental data

CUpti_ActivityEvent

The activity record for a CUPTI event

CUpti_ActivityEventInstance

The activity record for a CUPTI event with instance information

CUpti_ActivityGlobalAccess

The activity record for source-level global access

CUpti_ActivityKernel

The activity record for kernel. (deprecated)

CUpti_ActivityKernel2

The activity record for a kernel (CUDA 5.5 onwards)

CUpti_ActivityMarker

The activity record providing a marker which is an instantaneous point in time

CUpti_ActivityMarkerData

The activity record providing detailed information for a marker

CUpti_ActivityMemcpy

The activity record for memory copies

CUpti_ActivityMemcpy2

The activity record for peer-to-peer memory copies

CUpti_ActivityMemset

The activity record for memset

CUpti_ActivityMetric

The activity record for a CUPTI metric

CUpti_ActivityMetricInstance

The activity record for a CUPTI metric with instance information. This activity record represents a CUPTI metric value for a specific metric domain instance (CUPTI_ACTIVITY_KIND_METRIC_INSTANCE). This activity record kind is not produced by the activity API but is included for completeness and ease-of-use. Profile frameworks built on top of CUPTI that collect metric data may choose to use this type to store the collected metric data. This activity record should be used when metric domain instance information needs to be associated with the metric

CUpti_ActivityName

The activity record providing a name

CUpti_ActivityObjectKindId

Identifiers for object kinds as specified by CUpti_ActivityObjectKind

CUpti_ActivityOverhead

The activity record for CUPTI and driver overheads

CUpti_ActivityPreemption

The activity record for a preemption of a CDP kernel

CUpti_ActivitySourceLocator

The activity record for source locator

CUpti_CallbackData

Data passed into a runtime or driver API callback function

CUpti_EventGroupSet

A set of event groups

CUpti_EventGroupSets

A set of event group sets

CUpti_MetricValue

A metric value

CUpti_NvtxData

Data passed into a NVTX callback function

CUpti_ResourceData

Data passed into a resource callback function

CUpti_SynchronizeData

Data passed into a synchronize callback function

3.1. CUpti_Activity Struct Reference

The base activity record.

The activity API uses a CUpti_Activity as a generic representation for any activity. The 'kind' field is used to determine the specific activity kind, and from that the CUpti_Activity object can be cast to the specific activity record type appropriate for that kind.

Note that all activity record types are padded and aligned to ensure that each member of the record is naturally aligned.

See also:

CUpti_ActivityKind

CUpti_ActivityKind CUpti_Activity::kind

Description

The kind of this activity.

3.2. CUpti_ActivityAPI Struct Reference

The activity record for a driver or runtime API invocation.

This activity record represents an invocation of a driver or runtime API (CUPTI_ACTIVITY_KIND_DRIVER and CUPTI_ACTIVITY_KIND_RUNTIME).

CUpti_CallbackId CUpti_ActivityAPI::cbid

Description

The ID of the driver or runtime function.

uint32_t CUpti_ActivityAPI::correlationId

Description

The correlation ID of the driver or runtime CUDA function. Each function invocation is assigned a unique correlation ID that is identical to the correlation ID in the memcpy, memset, or kernel activity record that is associated with this function.

uint64_t CUpti_ActivityAPI::end

Description

The end timestamp for the function, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the function.

CUpti_ActivityKind CUpti_ActivityAPI::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_DRIVER or CUPTI_ACTIVITY_KIND_RUNTIME.

uint32_t CUpti_ActivityAPI::processId

Description

The ID of the process where the driver or runtime CUDA function is executing.

uint32_t CUpti_ActivityAPI::returnValue

Description

The return value for the function. For a CUDA driver function with will be a CUresult value, and for a CUDA runtime function this will be a cudaError_t value.

uint64_t CUpti_ActivityAPI::start

Description

The start timestamp for the function, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the function.

uint32_t CUpti_ActivityAPI::threadId

Description

The ID of the thread where the driver or runtime CUDA function is executing.

3.3. CUpti_ActivityBranch Struct Reference

The activity record for source level result branch.

This activity record the locations of the branches in the source (CUPTI_ACTIVITY_KIND_BRANCH).

uint32_t CUpti_ActivityBranch::correlationId

Description

The correlation ID of the kernel to which this result is associated.

uint32_t CUpti_ActivityBranch::diverged

Description

Number of times this branch diverged

uint32_t CUpti_ActivityBranch::executed

Description

The number of times this branch was executed

CUpti_ActivityKind CUpti_ActivityBranch::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_BRANCH.

uint32_t CUpti_ActivityBranch::pcOffset

Description

The pc offset for the branch.

uint32_t CUpti_ActivityBranch::sourceLocatorId

Description

The ID for source locator.

uint64_t CUpti_ActivityBranch::threadsExecuted

Description

This increments each time when this instruction is executed by number of threads that executed this instruction

3.4. CUpti_ActivityCdpKernel Struct Reference

The activity record for CDP (CUDA Dynamic Parallelism) kernel.

This activity record represents a CDP kernel execution.

int32_t CUpti_ActivityCdpKernel::blockX

Description

The X-dimension block size for the kernel.

int32_t CUpti_ActivityCdpKernel::blockY

Description

The Y-dimension block size for the kernel.

int32_t CUpti_ActivityCdpKernel::blockZ

Description

The Z-dimension grid size for the kernel.

uint64_t CUpti_ActivityCdpKernel::completed

Description

The timestamp when kernel is marked as completed, in ns. A value of CUPTI_TIMESTAMP_UNKNOWN indicates that the completion time is unknown.

uint32_t CUpti_ActivityCdpKernel::contextId

Description

The ID of the context where the kernel is executing.

uint32_t CUpti_ActivityCdpKernel::correlationId

Description

The correlation ID of the kernel. Each kernel execution is assigned a unique correlation ID that is identical to the correlation ID in the driver API activity record that launched the kernel.

uint32_t CUpti_ActivityCdpKernel::deviceId

Description

The ID of the device where the kernel is executing.

int32_t

CUpti_ActivityCdpKernel::dynamicSharedMemory

Description

The dynamic shared memory reserved for the kernel, in bytes.

uint64_t CUpti_ActivityCdpKernel::end

Description

The end timestamp for the kernel execution, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the kernel.

uint8_t CUpti_ActivityCdpKernel::executed

Description

The cache configuration used for the kernel. The value is one of the CUfunc_cache enumeration values from cuda.h.

int64_t CUpti_ActivityCdpKernel::gridId

Description

The grid ID of the kernel. Each kernel execution is assigned a unique grid ID.

int32_t CUpti_ActivityCdpKernel::gridX

Description

The X-dimension grid size for the kernel.

int32_t CUpti_ActivityCdpKernel::gridY

Description

The Y-dimension grid size for the kernel.

int32_t CUpti_ActivityCdpKernel::gridZ

Description

The Z-dimension grid size for the kernel.

CUpti_ActivityKind CUpti_ActivityCdpKernel::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_CDP_KERNEL

uint32 t

CUpti_ActivityCdpKernel::localMemoryPerThread

Description

The amount of local memory reserved for each thread, in bytes.

uint32_t CUpti_ActivityCdpKernel::localMemoryTotal

Description

The total amount of local memory reserved for the kernel, in bytes.

const char *CUpti_ActivityCdpKernel::name

Description

The name of the kernel. This name is shared across all activity records representing the same kernel, and so should not be modified.

uint32_t CUpti_ActivityCdpKernel::parentBlockX

Description

The X-dimension of the parent block.

uint32_t CUpti_ActivityCdpKernel::parentBlockY

Description

The Y-dimension of the parent block.

uint32_t CUpti_ActivityCdpKernel::parentBlockZ

Description

The Z-dimension of the parent block.

int64_t CUpti_ActivityCdpKernel::parentGridId

Description

The grid ID of the parent kernel.

uint64_t CUpti_ActivityCdpKernel::queued

Description

The timestamp when kernel is queued up, in ns. A value of CUPTI_TIMESTAMP_UNKNOWN indicates that the queued time is unknown.

uint16_t CUpti_ActivityCdpKernel::registersPerThread

Description

The number of registers required for each thread executing the kernel.

uint8_t CUpti_ActivityCdpKernel::requested

Description

The cache configuration requested by the kernel. The value is one of the CUfunc_cache enumeration values from cuda.h.

uint8_t CUpti_ActivityCdpKernel::sharedMemoryConfig

Description

The shared memory configuration used for the kernel. The value is one of the CUshared configuration values from cuda.h.

uint64_t CUpti_ActivityCdpKernel::start

Description

The start timestamp for the kernel execution, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the kernel.

int32_t CUpti_ActivityCdpKernel::staticSharedMemory

Description

The static shared memory allocated for the kernel, in bytes.

uint32_t CUpti_ActivityCdpKernel::streamId

Description

The ID of the stream where the kernel is executing.

uint64_t CUpti_ActivityCdpKernel::submitted

Description

The timestamp when kernel is submitted to the gpu, in ns. A value of CUPTI_TIMESTAMP_UNKNOWN indicates that the submission time is unknown.

3.5. CUpti_ActivityContext Struct Reference

The activity record for a context.

This activity record represents information about a context (CUPTI_ACTIVITY_KIND_CONTEXT).

CUpti_ActivityComputeApiKind CUpti_ActivityContext::computeApiKind

Description

The compute API kind.

See also:

CUpti_ActivityComputeApiKind

uint32_t CUpti_ActivityContext::contextId

Description

The context ID.

uint32_t CUpti_ActivityContext::deviceId

Description

The device ID.

CUpti_ActivityKind CUpti_ActivityContext::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_CONTEXT.

3.6. CUpti_ActivityDevice Struct Reference

The activity record for a device.

This activity record represents information about a GPU device (CUPTI_ACTIVITY_KIND_DEVICE).

uint32_t CUpti_ActivityDevice::computeCapabilityMajor

Description

Compute capability for the device, major number.

uint32_t CUpti_ActivityDevice::computeCapabilityMinor

Description

Compute capability for the device, minor number.

uint32_t CUpti_ActivityDevice::constantMemorySize

Description

The amount of constant memory on the device, in bytes.

uint32_t CUpti_ActivityDevice::coreClockRate

Description

The core clock rate of the device, in kHz.

CUpti_ActivityFlag CUpti_ActivityDevice::flags

Description

The flags associated with the device.

See also:

CUpti_ActivityFlag

uint64_t CUpti_ActivityDevice::globalMemoryBandwidth

Description

The global memory bandwidth available on the device, in kBytes/sec.

uint64_t CUpti_ActivityDevice::globalMemorySize

Description

The amount of global memory on the device, in bytes.

uint32_t CUpti_ActivityDevice::id

Description

The device ID.

CUpti_ActivityKind CUpti_ActivityDevice::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_DEVICE.

uint32_t CUpti_ActivityDevice::l2CacheSize

Description

The size of the L2 cache on the device, in bytes.

uint32_t CUpti_ActivityDevice::maxBlockDimX

Description

Maximum allowed X dimension for a block.

uint32_t CUpti_ActivityDevice::maxBlockDimY

Description

Maximum allowed Y dimension for a block.

uint32_t CUpti_ActivityDevice::maxBlockDimZ

Description

Maximum allowed Z dimension for a block.

uint32_t

CUpti_ActivityDevice::maxBlocksPerMultiprocessor

Description

Maximum number of blocks that can be present on a multiprocessor at any given time.

uint32_t CUpti_ActivityDevice::maxGridDimX

Description

Maximum allowed X dimension for a grid.

uint32_t CUpti_ActivityDevice::maxGridDimY

Description

Maximum allowed Y dimension for a grid.

uint32_t CUpti_ActivityDevice::maxGridDimZ

Description

Maximum allowed Z dimension for a grid.

uint32_t CUpti_ActivityDevice::maxIPC

Description

The maximum "instructions per cycle" possible on each device multiprocessor.

uint32_t CUpti_ActivityDevice::maxRegistersPerBlock

Description

Maximum number of registers that can be allocated to a block.

uint32_t

CUpti_ActivityDevice::maxSharedMemoryPerBlock

Description

Maximum amount of shared memory that can be assigned to a block, in bytes.

uint32_t CUpti_ActivityDevice::maxThreadsPerBlock

Description

Maximum number of threads allowed in a block.

uint32_t

CUpti_ActivityDevice::maxWarpsPerMultiprocessor

Description

Maximum number of warps that can be present on a multiprocessor at any given time.

const char *CUpti_ActivityDevice::name

Description

The device name. This name is shared across all activity records representing instances of the device, and so should not be modified.

uint32_t CUpti_ActivityDevice::numMemcpyEngines

Description

Number of memory copy engines on the device.

uint32_t CUpti_ActivityDevice::numMultiprocessors

Description

Number of multiprocessors on the device.

uint32_t CUpti_ActivityDevice::numThreadsPerWarp

Description

The number of threads per warp on the device.

3.7. CUpti_ActivityEnvironment Struct Reference

The activity record for CUPTI environmental data.

This activity record provides CUPTI environmental data, include power, clocks, and thermals. This information is sampled at various rates and returned in this activity record. The consumer of the record needs to check the environmentKind field to figure out what kind of environmental record this is.

CUpti_EnvironmentClocksThrottleReason CUpti_ActivityEnvironment::clocksThrottleReasons

Description

The clocks throttle reasons.

CUpti_ActivityEnvironment::@6::@10 CUpti_ActivityEnvironment::cooling

Description

Data returned for CUPTI_ACTIVITY_ENVIRONMENT_COOLING environment kind.

uint32_t CUpti_ActivityEnvironment::deviceId

Description

The ID of the device

CUpti_ActivityEnvironmentKind CUpti_ActivityEnvironment::environmentKind

Description

The kind of data reported in this record.

uint32_t CUpti_ActivityEnvironment::fanSpeed

Description

The fan speed as percentage of maximum.

uint32_t CUpti_ActivityEnvironment::gpuTemperature

Description

The GPU temperature in degrees C.

CUpti_ActivityKind CUpti_ActivityEnvironment::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_ENVIRONMENT.

uint32_t CUpti_ActivityEnvironment::memoryClock

Description

The memory frequency in MHz

uint32_t CUpti_ActivityEnvironment::pcieLinkGen

Description

The PCIe link generation.

uint32_t CUpti_ActivityEnvironment::pcieLinkWidth

Description

The PCIe link width.

CUpti_ActivityEnvironment::@6::@9 CUpti_ActivityEnvironment::power

Description

Data returned for CUPTI_ACTIVITY_ENVIRONMENT_POWER environment kind.

uint32_t CUpti_ActivityEnvironment::power

Description

The power in milliwatts consumed by GPU and associated circuitry.

uint32_t CUpti_ActivityEnvironment::powerLimit

Description

The power in milliwatts that will trigger power management algorithm.

uint32_t CUpti_ActivityEnvironment::smClock

Description

The SM frequency in MHz

CUpti_ActivityEnvironment::@6::@7 CUpti_ActivityEnvironment::speed

Description

Data returned for CUPTI_ACTIVITY_ENVIRONMENT_SPEED environment kind.

CUpti_ActivityEnvironment::@6::@8 CUpti_ActivityEnvironment::temperature

Description

Data returned for CUPTI_ACTIVITY_ENVIRONMENT_TEMPERATURE environment kind.

uint64_t CUpti_ActivityEnvironment::timestamp

Description

The timestamp when this sample was retrieved, in ns. A value of 0 indicates that timestamp information could not be collected for the marker.

3.8. CUpti_ActivityEvent Struct Reference

The activity record for a CUPTI event.

This activity record represents a CUPTI event value (CUPTI_ACTIVITY_KIND_EVENT). This activity record kind is not produced by the activity API but is included for completeness and ease-of-use. Profile frameworks built on top of CUPTI that collect event data may choose to use this type to store the collected event data.

uint32_t CUpti_ActivityEvent::correlationId

Description

The correlation ID of the event. Use of this ID is user-defined, but typically this ID value will equal the correlation ID of the kernel for which the event was gathered.

CUpti_EventDomainID CUpti_ActivityEvent::domain

Description

The event domain ID.

CUpti_EventID CUpti_ActivityEvent::id

Description

The event ID.

CUpti_ActivityKind CUpti_ActivityEvent::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_EVENT.

uint64_t CUpti_ActivityEvent::value

Description

The event value.

3.9. CUpti_ActivityEventInstance Struct Reference

The activity record for a CUPTI event with instance information.

This activity record represents the a CUPTI event value for a specific event domain instance (CUPTI_ACTIVITY_KIND_EVENT_INSTANCE). This activity record kind is not produced by the activity API but is included for completeness and ease-of-use. Profile frameworks built on top of CUPTI that collect event data may choose to use this type to store the collected event data. This activity record should be used when event domain instance information needs to be associated with the event.

uint32_t CUpti_ActivityEventInstance::correlationId

Description

The correlation ID of the event. Use of this ID is user-defined, but typically this ID value will equal the correlation ID of the kernel for which the event was gathered.

CUpti_EventDomainID CUpti_ActivityEventInstance::domain

Description

The event domain ID.

CUpti_EventID CUpti_ActivityEventInstance::id

Description

The event ID.

uint32_t CUpti_ActivityEventInstance::instance

Description

The event domain instance.

CUpti_ActivityKind CUpti_ActivityEventInstance::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_EVENT_INSTANCE.

uint32_t CUpti_ActivityEventInstance::pad

Description

Undefined. Reserved for internal use.

uint64_t CUpti_ActivityEventInstance::value

Description

The event value.

3.10. CUpti_ActivityGlobalAccess Struct Reference

The activity record for source-level global access.

This activity records the locations of the global accesses in the source (CUPTI_ACTIVITY_KIND_GLOBAL_ACCESS).

uint32_t CUpti_ActivityGlobalAccess::correlationId

Description

The correlation ID of the kernel to which this result is associated.

uint32_t CUpti_ActivityGlobalAccess::executed

Description

The number of times this instruction was executed

CUpti_ActivityFlag CUpti_ActivityGlobalAccess::flags

Description

The properties of this global access.

CUpti_ActivityKind CUpti_ActivityGlobalAccess::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_GLOBAL_ACCESS.

uint64_t CUpti_ActivityGlobalAccess::l2_transactions

Description

The total number of 32 bytes transactions to L2 cache generated by this access

uint32_t CUpti_ActivityGlobalAccess::pcOffset

Description

The pc offset for the access.

uint32_t CUpti_ActivityGlobalAccess::sourceLocatorId

Description

The ID for source locator.

uint64_t CUpti_ActivityGlobalAccess::threadsExecuted

Description

This increments each time when this instruction is executed by number of threads that executed this instruction

3.11. CUpti_ActivityKernel Struct Reference

The activity record for kernel. (deprecated).

This activity record represents a kernel execution (CUPTI_ACTIVITY_KIND_KERNEL and CUPTI_ACTIVITY_KIND_CONCURRENT_KERNEL) but is no longer generated

by CUPTI. Kernel activities are not reported using the CUpti_ActivityKernel2 activity record.

int32_t CUpti_ActivityKernel::blockX

Description

The X-dimension block size for the kernel.

int32_t CUpti_ActivityKernel::blockY

Description

The Y-dimension block size for the kernel.

int32_t CUpti_ActivityKernel::blockZ

Description

The Z-dimension grid size for the kernel.

uint8_t CUpti_ActivityKernel::cacheConfigExecuted

Description

The cache configuration used for the kernel. The value is one of the CUfunc_cache enumeration values from cuda.h.

uint8_t CUpti_ActivityKernel::cacheConfigRequested

Description

The cache configuration requested by the kernel. The value is one of the CUfunc_cache enumeration values from cuda.h.

uint32_t CUpti_ActivityKernel::contextId

Description

The ID of the context where the kernel is executing.

uint32_t CUpti_ActivityKernel::correlationId

Description

The correlation ID of the kernel. Each kernel execution is assigned a unique correlation ID that is identical to the correlation ID in the driver API activity record that launched the kernel.

uint32_t CUpti_ActivityKernel::deviceId

Description

The ID of the device where the kernel is executing.

int32_t CUpti_ActivityKernel::dynamicSharedMemory

Description

The dynamic shared memory reserved for the kernel, in bytes.

uint64_t CUpti_ActivityKernel::end

Description

The end timestamp for the kernel execution, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the kernel.

int32_t CUpti_ActivityKernel::gridX

Description

The X-dimension grid size for the kernel.

int32_t CUpti_ActivityKernel::gridY

Description

The Y-dimension grid size for the kernel.

int32_t CUpti_ActivityKernel::gridZ

Description

The Z-dimension grid size for the kernel.

CUpti_ActivityKind CUpti_ActivityKernel::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_KERNEL or CUPTI_ACTIVITY_KIND_CONCURRENT_KERNEL.

uint32_t CUpti_ActivityKernel::localMemoryPerThread

Description

The amount of local memory reserved for each thread, in bytes.

uint32_t CUpti_ActivityKernel::localMemoryTotal

Description

The total amount of local memory reserved for the kernel, in bytes.

const char *CUpti_ActivityKernel::name

Description

The name of the kernel. This name is shared across all activity records representing the same kernel, and so should not be modified.

uint32_t CUpti_ActivityKernel::pad

Description

Undefined. Reserved for internal use.

uint16_t CUpti_ActivityKernel::registersPerThread

Description

The number of registers required for each thread executing the kernel.

void *CUpti_ActivityKernel::reserved0

Description

Undefined. Reserved for internal use.

uint32_t CUpti_ActivityKernel::runtimeCorrelationId

Description

The runtime correlation ID of the kernel. Each kernel execution is assigned a unique runtime correlation ID that is identical to the correlation ID in the runtime API activity record that launched the kernel.

uint64_t CUpti_ActivityKernel::start

Description

The start timestamp for the kernel execution, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the kernel.

int32_t CUpti_ActivityKernel::staticSharedMemory

Description

The static shared memory allocated for the kernel, in bytes.

uint32_t CUpti_ActivityKernel::streamId

Description

The ID of the stream where the kernel is executing.

3.12. CUpti_ActivityKernel2 Struct Reference

The activity record for a kernel (CUDA 5.5 onwards).

This activity record represents a kernel execution (CUPTI_ACTIVITY_KIND_KERNEL and CUPTI_ACTIVITY_KIND_CONCURRENT_KERNEL).

int32_t CUpti_ActivityKernel2::blockX

Description

The X-dimension block size for the kernel.

int32_t CUpti_ActivityKernel2::blockY

Description

The Y-dimension block size for the kernel.

int32_t CUpti_ActivityKernel2::blockZ

Description

The Z-dimension grid size for the kernel.

uint64_t CUpti_ActivityKernel2::completed

Description

The completed timestamp for the kernel execution, in ns. It represents the completion of all it's child kernels and the kernel itself. A value of CUPTI_TIMESTAMP_UNKNOWN indicates that the completion time is unknown.

uint32_t CUpti_ActivityKernel2::contextId

Description

The ID of the context where the kernel is executing.

uint32_t CUpti_ActivityKernel2::correlationId

Description

The correlation ID of the kernel. Each kernel execution is assigned a unique correlation ID that is identical to the correlation ID in the driver or runtime API activity record that launched the kernel.

uint32_t CUpti_ActivityKernel2::deviceId

Description

The ID of the device where the kernel is executing.

int32_t CUpti_ActivityKernel2::dynamicSharedMemory

Description

The dynamic shared memory reserved for the kernel, in bytes.

uint64_t CUpti_ActivityKernel2::end

Description

The end timestamp for the kernel execution, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the kernel.

uint8_t CUpti_ActivityKernel2::executed

Description

The cache configuration used for the kernel. The value is one of the CUfunc_cache enumeration values from cuda.h.

int64_t CUpti_ActivityKernel2::gridId

Description

The grid ID of the kernel. Each kernel is assigned a unique grid ID at runtime.

int32_t CUpti_ActivityKernel2::gridX

Description

The X-dimension grid size for the kernel.

int32_t CUpti_ActivityKernel2::gridY

Description

The Y-dimension grid size for the kernel.

int32_t CUpti_ActivityKernel2::gridZ

Description

The Z-dimension grid size for the kernel.

CUpti_ActivityKind CUpti_ActivityKernel2::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_KERNEL or CUPTI_ACTIVITY_KIND_CONCURRENT_KERNEL.

uint32_t CUpti_ActivityKernel2::localMemoryPerThread

Description

The amount of local memory reserved for each thread, in bytes.

uint32_t CUpti_ActivityKernel2::localMemoryTotal

Description

The total amount of local memory reserved for the kernel, in bytes.

const char *CUpti_ActivityKernel2::name

Description

The name of the kernel. This name is shared across all activity records representing the same kernel, and so should not be modified.

uint16_t CUpti_ActivityKernel2::registersPerThread

Description

The number of registers required for each thread executing the kernel.

uint8_t CUpti_ActivityKernel2::requested

Description

The cache configuration requested by the kernel. The value is one of the CUfunc_cache enumeration values from cuda.h.

void *CUpti_ActivityKernel2::reserved0

Description

Undefined. Reserved for internal use.

uint8_t CUpti_ActivityKernel2::sharedMemoryConfig

Description

The shared memory configuration used for the kernel. The value is one of the CUsharedconfig enumeration values from cuda.h.

uint64_t CUpti_ActivityKernel2::start

Description

The start timestamp for the kernel execution, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the kernel.

int32_t CUpti_ActivityKernel2::staticSharedMemory

Description

The static shared memory allocated for the kernel, in bytes.

uint32_t CUpti_ActivityKernel2::streamId

Description

The ID of the stream where the kernel is executing.

3.13. CUpti_ActivityMarker Struct Reference

The activity record providing a marker which is an instantaneous point in time.

The marker is specified with a descriptive name and unique id (CUPTI_ACTIVITY_KIND_MARKER).

CUpti_ActivityFlag CUpti_ActivityMarker::flags

Description

The flags associated with the marker.

See also:

CUpti ActivityFlag

uint32_t CUpti_ActivityMarker::id

Description

The marker ID.

CUpti_ActivityKind CUpti_ActivityMarker::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_MARKER.

const char *CUpti_ActivityMarker::name

Description

The marker name for an instantaneous or start marker. This will be NULL for an end marker.

CUpti_ActivityMarker::objectId

Description

The identifier for the activity object associated with this marker. 'objectKind' indicates which ID is valid for this record.

CUpti_ActivityObjectKind CUpti_ActivityMarker::objectKind

Description

The kind of activity object associated with this marker.

uint64_t CUpti_ActivityMarker::timestamp

Description

The timestamp for the marker, in ns. A value of 0 indicates that timestamp information could not be collected for the marker.

3.14. CUpti_ActivityMarkerData Struct Reference

The activity record providing detailed information for a marker.

The marker data contains color, payload, and category. (CUPTI_ACTIVITY_KIND_MARKER_DATA).

uint32_t CUpti_ActivityMarkerData::category

Description

The category for the marker.

uint32_t CUpti_ActivityMarkerData::color

Description

The color for the marker.

CUpti_ActivityFlag CUpti_ActivityMarkerData::flags

Description

The flags associated with the marker.

See also:

CUpti_ActivityFlag

uint32_t CUpti_ActivityMarkerData::id

Description

The marker ID.

CUpti_ActivityKind CUpti_ActivityMarkerData::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_MARKER_DATA.

CUpti_ActivityMarkerData::payload

Description

The payload value.

CUpti_MetricValueKind CUpti_ActivityMarkerData::payloadKind

Description

Defines the payload format for the value associated with the marker.

3.15. CUpti_ActivityMemcpy Struct Reference

The activity record for memory copies.

This activity record represents a memory copy (CUPTI_ACTIVITY_KIND_MEMCPY).

uint64_t CUpti_ActivityMemcpy::bytes

Description

The number of bytes transferred by the memory copy.

uint32_t CUpti_ActivityMemcpy::contextId

Description

The ID of the context where the memory copy is occurring.

uint8_t CUpti_ActivityMemcpy::copyKind

Description

The kind of the memory copy, stored as a byte to reduce record size.

See also:

CUpti_ActivityMemcpyKind

uint32_t CUpti_ActivityMemcpy::correlationId

Description

The correlation ID of the memory copy. Each memory copy is assigned a unique correlation ID that is identical to the correlation ID in the driver API activity record that launched the memory copy.

uint32_t CUpti_ActivityMemcpy::deviceId

Description

The ID of the device where the memory copy is occurring.

uint8_t CUpti_ActivityMemcpy::dstKind

Description

The destination memory kind read by the memory copy, stored as a byte to reduce record size.

See also:

CUpti_ActivityMemoryKind

uint64_t CUpti_ActivityMemcpy::end

Description

The end timestamp for the memory copy, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the memory copy.

uint8_t CUpti_ActivityMemcpy::flags

Description

The flags associated with the memory copy.

See also:

CUpti_ActivityFlag

CUpti_ActivityKind CUpti_ActivityMemcpy::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_MEMCPY.

void *CUpti_ActivityMemcpy::reserved0

Description

Undefined. Reserved for internal use.

uint32_t CUpti_ActivityMemcpy::runtimeCorrelationId

Description

The runtime correlation ID of the memory copy. Each memory copy is assigned a unique runtime correlation ID that is identical to the correlation ID in the runtime API activity record that launched the memory copy.

uint8_t CUpti_ActivityMemcpy::srcKind

Description

The source memory kind read by the memory copy, stored as a byte to reduce record size.

See also:

CUpti_ActivityMemoryKind

uint64_t CUpti_ActivityMemcpy::start

Description

The start timestamp for the memory copy, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the memory copy.

uint32_t CUpti_ActivityMemcpy::streamId

Description

The ID of the stream where the memory copy is occurring.

3.16. CUpti_ActivityMemcpy2 Struct Reference

The activity record for peer-to-peer memory copies.

This activity record represents a peer-to-peer memory copy (CUPTI_ACTIVITY_KIND_MEMCPY2).

uint64_t CUpti_ActivityMemcpy2::bytes

Description

The number of bytes transferred by the memory copy.

uint32_t CUpti_ActivityMemcpy2::contextId

Description

The ID of the context where the memory copy is occurring.

uint8_t CUpti_ActivityMemcpy2::copyKind

Description

The kind of the memory copy, stored as a byte to reduce record size.

See also:

CUpti_ActivityMemcpyKind

uint32_t CUpti_ActivityMemcpy2::correlationId

Description

The correlation ID of the memory copy. Each memory copy is assigned a unique correlation ID that is identical to the correlation ID in the driver and runtime API activity record that launched the memory copy.

uint32_t CUpti_ActivityMemcpy2::deviceId

Description

The ID of the device where the memory copy is occurring.

uint32_t CUpti_ActivityMemcpy2::dstContextId

Description

The ID of the context owning the memory being copied to.

uint32_t CUpti_ActivityMemcpy2::dstDeviceId

Description

The ID of the device where memory is being copied to.

uint8_t CUpti_ActivityMemcpy2::dstKind

Description

The destination memory kind read by the memory copy, stored as a byte to reduce record size.

See also:

CUpti_ActivityMemoryKind

uint64_t CUpti_ActivityMemcpy2::end

Description

The end timestamp for the memory copy, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the memory copy.

uint8_t CUpti_ActivityMemcpy2::flags

Description

The flags associated with the memory copy.

See also:

CUpti_ActivityFlag

CUpti_ActivityKind CUpti_ActivityMemcpy2::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_MEMCPY2.

uint32_t CUpti_ActivityMemcpy2::pad

Description

Undefined. Reserved for internal use.

void *CUpti_ActivityMemcpy2::reserved0

Description

Undefined. Reserved for internal use.

uint32_t CUpti_ActivityMemcpy2::srcContextId

Description

The ID of the context owning the memory being copied from.

uint32_t CUpti_ActivityMemcpy2::srcDeviceId

Description

The ID of the device where memory is being copied from.

uint8_t CUpti_ActivityMemcpy2::srcKind

Description

The source memory kind read by the memory copy, stored as a byte to reduce record size.

See also:

CUpti_ActivityMemoryKind

uint64_t CUpti_ActivityMemcpy2::start

Description

The start timestamp for the memory copy, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the memory copy.

uint32_t CUpti_ActivityMemcpy2::streamId

Description

The ID of the stream where the memory copy is occurring.

3.17. CUpti_ActivityMemset Struct Reference

The activity record for memset.

This activity record represents a memory set operation (CUPTI_ACTIVITY_KIND_MEMSET).

uint64_t CUpti_ActivityMemset::bytes

Description

The number of bytes being set by the memory set.

uint32_t CUpti_ActivityMemset::contextId

Description

The ID of the context where the memory set is occurring.

uint32_t CUpti_ActivityMemset::correlationId

Description

The correlation ID of the memory set. Each memory set is assigned a unique correlation ID that is identical to the correlation ID in the driver API activity record that launched the memory set.

uint32_t CUpti_ActivityMemset::deviceId

Description

The ID of the device where the memory set is occurring.

uint64_t CUpti_ActivityMemset::end

Description

The end timestamp for the memory set, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the memory set.

CUpti_ActivityKind CUpti_ActivityMemset::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_MEMSET.

void *CUpti_ActivityMemset::reserved0

Description

Undefined. Reserved for internal use.

uint32_t CUpti_ActivityMemset::runtimeCorrelationId

Description

The runtime correlation ID of the memory set. Each memory set is assigned a unique runtime correlation ID that is identical to the correlation ID in the runtime API activity record that launched the memory set.

uint64_t CUpti_ActivityMemset::start

Description

The start timestamp for the memory set, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the memory set.

uint32_t CUpti_ActivityMemset::streamId

Description

The ID of the stream where the memory set is occurring.

uint32_t CUpti_ActivityMemset::value

Description

The value being assigned to memory by the memory set.

3.18. CUpti_ActivityMetric Struct Reference

The activity record for a CUPTI metric.

This activity record represents the collection of a CUPTI metric value (CUPTI_ACTIVITY_KIND_METRIC). This activity record kind is not produced by the activity API but is included for completeness and ease-of-use. Profile frameworks built on top of CUPTI that collect metric data may choose to use this type to store the collected metric data.

uint32_t CUpti_ActivityMetric::correlationId

Description

The correlation ID of the metric. Use of this ID is user-defined, but typically this ID value will equal the correlation ID of the kernel for which the metric was gathered.

uint8_t CUpti_ActivityMetric::flags

Description

The properties of this metric.

See also:

CUpti_ActivityFlag

CUpti_MetricID CUpti_ActivityMetric::id

Description

The metric ID.

CUpti_ActivityKind CUpti_ActivityMetric::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_METRIC.

uint8_t CUpti_ActivityMetric::pad

Description

Undefined. Reserved for internal use.

CUpti_ActivityMetric::value

Description

The metric value.

3.19. CUpti_ActivityMetricInstance Struct Reference

The activity record for a CUPTI metric with instance information. This activity record represents a CUPTI metric value for a specific metric domain instance (CUPTI_ACTIVITY_KIND_METRIC_INSTANCE). This activity record kind is not produced by the activity API but is included for completeness and ease-of-use. Profile frameworks built on top of CUPTI that collect metric data may choose to use this type to store the collected metric data. This activity record should be used when metric domain instance information needs to be associated with the metric.

uint32_t CUpti_ActivityMetricInstance::correlationId

Description

The correlation ID of the metric. Use of this ID is user-defined, but typically this ID value will equal the correlation ID of the kernel for which the metric was gathered.

uint8_t CUpti_ActivityMetricInstance::flags

Description

The properties of this metric.

See also:

CUpti_ActivityFlag

CUpti_MetricID CUpti_ActivityMetricInstance::id

Description

The metric ID.

uint32_t CUpti_ActivityMetricInstance::instance

Description

The metric domain instance.

CUpti_ActivityKind CUpti_ActivityMetricInstance::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_METRIC_INSTANCE.

uint8_t CUpti_ActivityMetricInstance::pad

Description

Undefined. Reserved for internal use.

CUpti_ActivityMetricInstance::value

Description

The metric value.

3.20. CUpti_ActivityName Struct Reference

The activity record providing a name.

This activity record provides a name for a device, context, thread, etc. (CUPTI_ACTIVITY_KIND_NAME).

CUpti_ActivityKind CUpti_ActivityName::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_NAME.

const char *CUpti_ActivityName::name

Description

The name.

CUpti_ActivityName::objectId

Description

The identifier for the activity object. 'objectKind' indicates which ID is valid for this record.

CUpti_ActivityObjectKind CUpti_ActivityName::objectKind

Description

The kind of activity object being named.

3.21. CUpti_ActivityObjectKindId Union Reference

Identifiers for object kinds as specified by CUpti_ActivityObjectKind.

See also:

CUpti_ActivityObjectKind

CUpti_ActivityObjectKindId::@1 CUpti_ActivityObjectKindId::dcs

Description

A device object requires that we identify the device ID. A context object requires that we identify both the device and context ID. A stream object requires that we identify device, context, and stream ID.

CUpti_ActivityObjectKindId::@0 CUpti_ActivityObjectKindId::pt

Description

A process object requires that we identify the process ID. A thread object requires that we identify both the process and thread ID.

3.22. CUpti_ActivityOverhead Struct Reference

The activity record for CUPTI and driver overheads.

This activity record provides CUPTI and driver overhead information (CUPTI_ACTIVITY_OVERHEAD).

uint64_t CUpti_ActivityOverhead::end

Description

The end timestamp for the overhead, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the overhead.

CUpti_ActivityKind CUpti_ActivityOverhead::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_OVERHEAD.

CUpti_ActivityOverhead::objectId

Description

The identifier for the activity object. 'objectKind' indicates which ID is valid for this record.

CUpti_ActivityObjectKind CUpti_ActivityOverhead::objectKind

Description

The kind of activity object that the overhead is associated with.

CUpti_ActivityOverheadKind CUpti_ActivityOverhead::overheadKind

Description

The kind of overhead, CUPTI, DRIVER, COMPILER etc.

uint64_t CUpti_ActivityOverhead::start

Description

The start timestamp for the overhead, in ns. A value of 0 for both the start and end timestamps indicates that timestamp information could not be collected for the overhead.

3.23. CUpti_ActivityPreemption Struct Reference

The activity record for a preemption of a CDP kernel.

This activity record represents a preemption of a CDP kernel.

uint32_t CUpti_ActivityPreemption::blockX

Description

The X-dimension of the block that is preempted

uint32_t CUpti_ActivityPreemption::blockY

Description

The Y-dimension of the block that is preempted

uint32_t CUpti_ActivityPreemption::blockZ

Description

The Z-dimension of the block that is preempted

int64_t CUpti_ActivityPreemption::gridId

Description

The grid-id of the block that is preempted

CUpti_ActivityKind CUpti_ActivityPreemption::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_PREEMPTION

uint32_t CUpti_ActivityPreemption::pad

Description

Undefined. Reserved for internal use.

CUpti_ActivityPreemptionKind CUpti_ActivityPreemption::preemptionKind

Description

kind of the preemption

uint64_t CUpti_ActivityPreemption::timestamp

Description

The timestamp of the preemption, in ns. A value of 0 indicates that timestamp information could not be collected for the preemption.

3.24. CUpti_ActivitySourceLocator Struct Reference

The activity record for source locator.

This activity record represents a source locator (CUPTI_ACTIVITY_KIND_SOURCE_LOCATOR).

const char *CUpti_ActivitySourceLocator::fileName

Description

The path for the file.

uint32_t CUpti_ActivitySourceLocator::id

Description

The ID for the source path, will be used in all the source level results.

CUpti_ActivityKind CUpti_ActivitySourceLocator::kind

Description

The activity record kind, must be CUPTI_ACTIVITY_KIND_SOURCE_LOCATOR.

uint32_t CUpti_ActivitySourceLocator::lineNumber

Description

The line number in the source.

3.25. CUpti_CallbackData Struct Reference

Data passed into a runtime or driver API callback function.

Data passed into a runtime or driver API callback function as the cbdata argument to CUpti_CallbackFunc. The cbdata will be this type for domain equal to CUPTI_CB_DOMAIN_DRIVER_API or CUPTI_CB_DOMAIN_RUNTIME_API. The callback data is valid only within the invocation of the callback function that is passed the data. If you need to retain some data for use outside of the callback, you must make a copy of that data. For example, if you make a shallow copy of CUpti_CallbackData within a callback, you cannot dereference functionParams outside of that callback to

access the function parameters. functionName is an exception: the string pointed to by functionName is a global constant and so may be accessed outside of the callback.

CUpti_ApiCallbackSite CUpti_CallbackData::callbackSite

Description

Point in the runtime or driver function from where the callback was issued.

CUcontext CUpti_CallbackData::context

Description

Driver context current to the thread, or null if no context is current. This value can change from the entry to exit callback of a runtime API function if the runtime initializes a context.

uint32_t CUpti_CallbackData::contextUid

Description

Unique ID for the CUDA context associated with the thread. The UIDs are assigned sequentially as contexts are created and are unique within a process.

uint64_t *CUpti_CallbackData::correlationData

Description

Pointer to data shared between the entry and exit callbacks of a given runtime or drive API function invocation. This field can be used to pass 64-bit values from the entry callback to the corresponding exit callback.

uint32_t CUpti_CallbackData::correlationId

Description

The activity record correlation ID for this callback. For a driver domain callback (i.e. domain CUPTI_CB_DOMAIN_DRIVER_API) this ID will equal the correlation ID in the CUpti_ActivityAPI record corresponding to the CUDA driver function call. For a runtime domain callback (i.e. domain CUPTI_CB_DOMAIN_RUNTIME_API) this ID will equal the correlation ID in the CUpti_ActivityAPI record corresponding to the CUDA runtime function call. Within the callback, this ID can be recorded to correlate user data with the activity record. This field is new in 4.1.

const char *CUpti_CallbackData::functionName

Description

Name of the runtime or driver API function which issued the callback. This string is a global constant and so may be accessed outside of the callback.

const void *CUpti_CallbackData::functionParams

Description

Pointer to the arguments passed to the runtime or driver API call. See generated_cuda_runtime_api_meta.h and generated_cuda_meta.h for structure definitions for the parameters for each runtime and driver API function.

void *CUpti_CallbackData::functionReturnValue

Description

Pointer to the return value of the runtime or driver API call. This field is only valid within the exit::CUPTI_API_EXIT callback. For a runtime API functionReturnValue points to a cudaError_t. For a driver API functionReturnValue points to a CUresult.

const char *CUpti_CallbackData::symbolName

Description

Name of the symbol operated on by the runtime or driver API function which issued the callback. This entry is valid only for driver and runtime launch callbacks, where it returns the name of the kernel.

3.26. CUpti_EventGroupSet Struct Reference

A set of event groups.

A set of event groups. When returned by cuptiEventGroupSetsCreate and cuptiMetricCreateEventGroupSets a set indicates that event groups that can be enabled at the same time (i.e. all the events in the set can be collected simultaneously).

CUpti_EventGroup *CUpti_EventGroupSet::eventGroups

Description

An array of numEventGroups event groups.

uint32_t CUpti_EventGroupSet::numEventGroups

Description

The number of event groups in the set.

3.27. CUpti_EventGroupSets Struct Reference

A set of event group sets.

A set of event group sets. When returned by cuptiEventGroupSetsCreate and cuptiMetricCreateEventGroupSets a CUpti_EventGroupSets indicates the number of passes required to collect all the events, and the event groups that should be collected during each pass.

uint32_t CUpti_EventGroupSets::numSets

Description

Number of event group sets.

CUpti_EventGroupSet *CUpti_EventGroupSets::sets

Description

An array of numSets event group sets.

3.28. CUpti_MetricValue Union Reference

A metric value.

Metric values can be one of several different kinds. Corresponding to each kind is a member of the CUpti_MetricValue union. The metric value returned by cuptiMetricGetValue should be accessed using the appropriate member of that union based on its value kind.

3.29. CUpti_NvtxData Struct Reference

Data passed into a NVTX callback function.

Data passed into a NVTX callback function as the cbdata argument to CUpti_CallbackFunc. The cbdata will be this type for domain equal to CUPTI_CB_DOMAIN_NVTX. Unless otherwise notes, the callback data is valid only within the invocation of the callback function that is passed the data. If you need to retain some data for use outside of the callback, you must make a copy of that data.

const char *CUpti_NvtxData::functionName

Description

Name of the NVTX API function which issued the callback. This string is a global constant and so may be accessed outside of the callback.

const void *CUpti_NvtxData::functionParams

Description

Pointer to the arguments passed to the NVTX API call. See generated_nvtx_meta.h for structure definitions for the parameters for each NVTX API function.

3.30. CUpti_ResourceData Struct Reference

Data passed into a resource callback function.

Data passed into a resource callback function as the cbdata argument to CUpti_CallbackFunc. The cbdata will be this type for domain equal to CUPTI_CB_DOMAIN_RESOURCE. The callback data is valid only within the invocation of the callback function that is passed the data. If you need to retain some data for use outside of the callback, you must make a copy of that data.

CUcontext CUpti_ResourceData::context

Description

For CUPTI_CBID_RESOURCE_CONTEXT_CREATED and CUPTI_CBID_RESOURCE_CONTEXT_DESTROY_STARTING, the context being created or destroyed. For CUPTI_CBID_RESOURCE_STREAM_CREATED and CUPTI_CBID_RESOURCE_STREAM_DESTROY_STARTING, the context containing the stream being created or destroyed.

void *CUpti_ResourceData::resourceDescriptor

Description

Reserved for future use.

CUstream CUpti_ResourceData::stream

Description

For CUPTI_CBID_RESOURCE_STREAM_CREATED and CUPTI_CBID_RESOURCE_STREAM_DESTROY_STARTING, the stream being created or destroyed.

3.31. CUpti_SynchronizeData Struct Reference

Data passed into a synchronize callback function.

Data passed into a synchronize callback function as the cbdata argument to CUpti_CallbackFunc. The cbdata will be this type for domain equal to CUPTI_CB_DOMAIN_SYNCHRONIZE. The callback data is valid only within the invocation of the callback function that is passed the data. If you need to retain some data for use outside of the callback, you must make a copy of that data.

CUcontext CUpti_SynchronizeData::context

Description

The context of the stream being synchronized.

CUstream CUpti_SynchronizeData::stream

Description

The stream being synchronized.

Chapter 4. DATA FIELDS

Here is a list of all documented struct and union fields with links to the struct/union documentation for each field:

```
В
blockX
  CUpti_ActivityKernel
  CUpti_ActivityKernel2
  CUpti_ActivityPreemption
  CUpti_ActivityCdpKernel
blockY
  CUpti_ActivityPreemption
  CUpti_ActivityKernel
  CUpti_ActivityKernel2
  CUpti_ActivityCdpKernel
blockZ
  CUpti_ActivityCdpKernel
  CUpti_ActivityKernel
  CUpti_ActivityKernel2
  CUpti_ActivityPreemption
bytes
  CUpti_ActivityMemset
  CUpti_ActivityMemcpy
  CUpti_ActivityMemcpy2
C
cacheConfigExecuted
  CUpti_ActivityKernel
cacheConfigRequested
  CUpti_ActivityKernel
```

callbackSite CUpti_CallbackData category CUpti_ActivityMarkerData cbid CUpti_ActivityAPI clocksThrottleReasons CUpti_ActivityEnvironment color CUpti_ActivityMarkerData completed CUpti_ActivityKernel2 CUpti_ActivityCdpKernel computeApiKind CUpti_ActivityContext computeCapabilityMajor CUpti_ActivityDevice computeCapabilityMinor CUpti_ActivityDevice constantMemorySize CUpti_ActivityDevice context CUpti_SynchronizeData CUpti_CallbackData CUpti_ResourceData contextId CUpti_ActivityMemcpy CUpti_ActivityMemcpy2 CUpti_ActivityMemset CUpti_ActivityKernel CUpti_ActivityKernel2 CUpti_ActivityCdpKernel CUpti ActivityContext contextUid CUpti_CallbackData cooling CUpti_ActivityEnvironment copyKind CUpti_ActivityMemcpy2 CUpti_ActivityMemcpy coreClockRate CUpti_ActivityDevice

correlationData

CUpti_CallbackData

correlationId

CUpti_ActivityMemset

CUpti_ActivityMetricInstance

CUpti_ActivityCdpKernel

CUpti_ActivityMemcpy

CUpti_ActivityBranch

CUpti_ActivityEventInstance

CUpti_ActivityMetric

CUpti_ActivityKernel2

CUpti_ActivityEvent

CUpti_ActivityGlobalAccess

CUpti_ActivityKernel

CUpti_ActivityAPI

CUpti_CallbackData

CUpti_ActivityMemcpy2

D

dcs

CUpti_ActivityObjectKindId

deviceId

CUpti_ActivityMemcpy

CUpti_ActivityMemset

CUpti_ActivityContext

CUpti_ActivityEnvironment

CUpti_ActivityKernel

CUpti_ActivityMemcpy2

CUpti_ActivityKernel2

CUpti_ActivityCdpKernel

diverged

CUpti_ActivityBranch

domain

CUpti_ActivityEvent

CUpti_ActivityEventInstance

dstContextId

CUpti_ActivityMemcpy2

dstDeviceId

CUpti_ActivityMemcpy2

dstKind

CUpti_ActivityMemcpy2

CUpti_ActivityMemcpy

dynamicSharedMemory CUpti_ActivityCdpKernel CUpti_ActivityKernel2 CUpti_ActivityKernel Ε end CUpti_ActivityMemcpy CUpti_ActivityMemcpy2 CUpti_ActivityKernel CUpti_ActivityOverhead CUpti_ActivityKernel2 CUpti_ActivityMemset CUpti_ActivityCdpKernel CUpti_ActivityAPI environmentKind CUpti_ActivityEnvironment eventGroups CUpti_EventGroupSet executed CUpti_ActivityGlobalAccess CUpti_ActivityKernel2 CUpti_ActivityBranch CUpti_ActivityCdpKernel F fanSpeed CUpti_ActivityEnvironment fileName CUpti_ActivitySourceLocator flags CUpti_ActivityMemcpy2 CUpti_ActivityDevice CUpti_ActivityMarker CUpti_ActivityMetric CUpti_ActivityMarkerData CUpti_ActivityMemcpy CUpti_ActivityMetricInstance CUpti_ActivityGlobalAccess functionName CUpti_NvtxData CUpti_CallbackData

```
functionParams
  CUpti_CallbackData
  CUpti NvtxData
functionReturnValue
  CUpti_CallbackData
G
globalMemoryBandwidth
  CUpti_ActivityDevice
globalMemorySize
  CUpti_ActivityDevice
gpuTemperature
  CUpti_ActivityEnvironment
gridId
  CUpti_ActivityKernel2
  CUpti_ActivityCdpKernel
  CUpti_ActivityPreemption
gridX
  CUpti_ActivityKernel2
  CUpti_ActivityCdpKernel
  CUpti_ActivityKernel
gridY
  CUpti_ActivityKernel2
  CUpti_ActivityKernel
  CUpti_ActivityCdpKernel
gridZ
  CUpti_ActivityKernel
  CUpti_ActivityKernel2
  CUpti_ActivityCdpKernel
id
  CUpti_ActivityEvent
  CUpti_ActivityEventInstance
  CUpti_ActivityMetricInstance
  CUpti_ActivityMarkerData
  CUpti_ActivityMarker
  CUpti_ActivityDevice
  CUpti_ActivitySourceLocator
  CUpti_ActivityMetric
instance
  CUpti_ActivityEventInstance
  CUpti_ActivityMetricInstance
```

K kind CUpti_Activity CUpti_ActivityEnvironment CUpti_ActivityOverhead CUpti_ActivityMarkerData CUpti_ActivityMarker CUpti_ActivityName CUpti_ActivityContext CUpti_ActivityDevice CUpti_ActivityBranch CUpti_ActivityGlobalAccess CUpti_ActivitySourceLocator CUpti_ActivityMetricInstance CUpti_ActivityMetric CUpti_ActivityEventInstance CUpti_ActivityEvent CUpti_ActivityAPI CUpti_ActivityPreemption CUpti_ActivityCdpKernel CUpti_ActivityKernel2 CUpti_ActivityKernel CUpti_ActivityMemset CUpti_ActivityMemcpy2 CUpti_ActivityMemcpy 12_transactions CUpti_ActivityGlobalAccess 12CacheSize CUpti_ActivityDevice lineNumber CUpti ActivitySourceLocator local Memory Per ThreadCUpti_ActivityKernel CUpti_ActivityKernel2 CUpti_ActivityCdpKernel localMemoryTotal CUpti_ActivityCdpKernel CUpti_ActivityKernel

CUpti_ActivityKernel2

M maxBlockDimX CUpti_ActivityDevice maxBlockDimY CUpti_ActivityDevice maxBlockDimZ CUpti_ActivityDevice maxBlocks Per MultiprocessorCUpti_ActivityDevice maxGridDimX CUpti_ActivityDevice maxGridDimY CUpti_ActivityDevice maxGridDimZ CUpti_ActivityDevice maxIPC CUpti_ActivityDevice maxRegistersPerBlock CUpti_ActivityDevice maxSharedMemoryPerBlockCUpti_ActivityDevice maxThreadsPerBlock CUpti ActivityDevice maxWarpsPerMultiprocessorCUpti_ActivityDevice memoryClock CUpti_ActivityEnvironment Ν name CUpti_ActivityKernel CUpti_ActivityKernel2 CUpti_ActivityDevice CUpti_ActivityName CUpti_ActivityCdpKernel CUpti_ActivityMarker num Event GroupsCUpti_EventGroupSet numMemcpyEngines CUpti_ActivityDevice

numMultiprocessors

CUpti_ActivityDevice

```
numSets
  CUpti_EventGroupSets
numThreadsPerWarp
  CUpti_ActivityDevice
0
objectId
  CUpti_ActivityName
  CUpti_ActivityMarker
  CUpti_ActivityOverhead
objectKind
  CUpti_ActivityMarker
  CUpti_ActivityName
  CUpti_ActivityOverhead
overheadKind
  CUpti_ActivityOverhead
Ρ
pad
  CUpti_ActivityMemcpy2
  CUpti_ActivityKernel
  CUpti_ActivityEventInstance
  CUpti_ActivityMetric
  CUpti_ActivityPreemption
  CUpti_ActivityMetricInstance
parentBlockX
  CUpti_ActivityCdpKernel
parentBlockY
  CUpti_ActivityCdpKernel
parentBlockZ
  CUpti_ActivityCdpKernel
parentGridId
  CUpti_ActivityCdpKernel
payload
  CUpti_ActivityMarkerData
payloadKind
  CUpti_ActivityMarkerData
pcieLinkGen
  CUpti_ActivityEnvironment
pcieLinkWidth
  CUpti_ActivityEnvironment
pcOffset
  CUpti_ActivityBranch
```

```
CUpti_ActivityGlobalAccess
power
  CUpti_ActivityEnvironment
powerLimit
  CUpti_ActivityEnvironment
preemptionKind
  CUpti_ActivityPreemption
processId
  CUpti_ActivityAPI
pt
  CUpti_ActivityObjectKindId
Q
queued
  CUpti_ActivityCdpKernel
R
registersPerThread
  CUpti_ActivityKernel
  CUpti_ActivityKernel2
  CUpti_ActivityCdpKernel
requested
  CUpti_ActivityKernel2
  CUpti_ActivityCdpKernel
reserved0
  CUpti_ActivityMemset
  CUpti_ActivityKernel
  CUpti_ActivityKernel2
  CUpti_ActivityMemcpy
  CUpti_ActivityMemcpy2
resourceDescriptor
  CUpti_ResourceData
returnValue
  CUpti_ActivityAPI
runtimeCorrelationId
  CUpti_ActivityMemset
  CUpti_ActivityMemcpy
  CUpti_ActivityKernel
S
sets
  CUpti_EventGroupSets
```

sharedMemoryConfig

CUpti_ActivityKernel2

CUpti_ActivityCdpKernel

smClock

CUpti_ActivityEnvironment

sourceLocatorId

CUpti_ActivityGlobalAccess

CUpti_ActivityBranch

speed

CUpti_ActivityEnvironment

srcContextId

CUpti_ActivityMemcpy2

srcDeviceId

CUpti_ActivityMemcpy2

srcKind

CUpti_ActivityMemcpy

CUpti_ActivityMemcpy2

start

CUpti_ActivityKernel2

CUpti_ActivityCdpKernel

CUpti_ActivityAPI

CUpti_ActivityOverhead

CUpti_ActivityMemcpy

CUpti_ActivityMemcpy2

CUpti_ActivityMemset

CUpti_ActivityKernel

staticSharedMemory

CUpti_ActivityKernel

CUpti_ActivityKernel2

CUpti_ActivityCdpKernel

stream

CUpti_ResourceData

CUpti_SynchronizeData

streamId

CUpti_ActivityCdpKernel

CUpti_ActivityKernel2

CUpti_ActivityKernel

CUpti_ActivityMemcpy2

CUpti_ActivityMemset

CUpti_ActivityMemcpy

submitted

CUpti_ActivityCdpKernel

symbolName

CUpti_CallbackData

Т

temperature

CUpti_ActivityEnvironment

threadId

CUpti_ActivityAPI

threadsExecuted

CUpti_ActivityBranch CUpti_ActivityGlobalAccess

timestamp

CUpti_ActivityEnvironment CUpti_ActivityPreemption CUpti_ActivityMarker

٧

value

CUpti_ActivityMemset CUpti_ActivityMetricInstance CUpti_ActivityMetric CUpti_ActivityEventInstance CUpti_ActivityEvent

Notice

ALL NVIDIA DESIGN SPECIFICATIONS, REFERENCE BOARDS, FILES, DRAWINGS, DIAGNOSTICS, LISTS, AND OTHER DOCUMENTS (TOGETHER AND SEPARATELY, "MATERIALS") ARE BEING PROVIDED "AS IS." NVIDIA MAKES NO WARRANTIES, EXPRESSED, IMPLIED, STATUTORY, OR OTHERWISE WITH RESPECT TO THE MATERIALS, AND EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES OF NONINFRINGEMENT, MERCHANTABILITY, AND FITNESS FOR A PARTICULAR PURPOSE.

Information furnished is believed to be accurate and reliable. However, NVIDIA Corporation assumes no responsibility for the consequences of use of such information or for any infringement of patents or other rights of third parties that may result from its use. No license is granted by implication of otherwise under any patent rights of NVIDIA Corporation. Specifications mentioned in this publication are subject to change without notice. This publication supersedes and replaces all other information previously supplied. NVIDIA Corporation products are not authorized as critical components in life support devices or systems without express written approval of NVIDIA Corporation.

Trademarks

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

Copyright

© 2007-2013 NVIDIA Corporation. All rights reserved.

