# **CON100iB Multiply Interface Converter**


with iButton

### INTRODUCTION

The CON100iB can be used to convert commonly used data formats to Clock & Data(MSR), RS232 or Wiegand format data.

### **FEATURES**

- Converts from Wiegand, RS232, Clock & Data (MSR) or Dallas iButton™ format.
  Converts to RS232, MSR or Wiegand format.
- Can convert to or from Wiegand with up to 64 bits of data, including up to 64 bit site code plus optional start and end
- User programmable setting by software when converting to Wiegand or MSR.
- Reads up to 64 bits from Dallas iButton™ user memory or 56 bits from factory ID.
- Up to 144 characters or digits from/to Track 1, 2 or 3 Clock/Data (MSR) format input/output.
- Auto HEX and DEC convert to MSR Output.
- Much useful setting to fit in with user by software for MSR, Wiegand, RS232.



### **SPECIFICATIONS**

#### **OPERATING**

MSR Reference Standards	ISO7810, ISO 7811, JIS X6301, JIS X6302I	
MSR Decode/Output Method	ISO/JIS-1 : Track 1 IATA , Track 2 ABA , Track 3 THRIFT JIS-II : Track NTT	
Interface Format	Input/Output Interface - RS232C interface : Programmable by DIP Switch or Software (Option). Input / Output Default : 19200 bps, (8,N,1) Wiegand interface : Programmable by DIP Switch or Software (Option). Input Default : 26 Bits Output Default : 26 Bit, Pulse Width:100 \( \mu \) s, Pulse Separation: 2ms MSR interface : Programmable by DIP Switch or Software (Option). Input Default : Decode ABA , 7-BIT,JIS II format card. Output Default : Track2 ABA , Simulate Swipe Card Speed : 40 IPS Input Interface only - iButton : Programmable by DIP Switch or Software (Option). For DS1990A (Unique 48-bits serial number)	

### **ELECTRICAL**

Power Input	8 to 24 VDC , Standby Current 10 mA@12VDC, Limit Current 200mA	
Regulation Output	5 VDC +/- 10 % , 300 mA (max.)	


### **MECHANICAL**

Dimensions	Length: 70 mm / Width: 35 mm / Height: 18 mm (Include Terminal)		
Weight	30 gm (Include Terminal)		
Connectors	5 pin terminal 3.5 mm : for iButton Input, RS232 and Power In/output 7 pin terminal 3.5 mm : for Power Output, Weigand, MSR In/output 2 pin D3.5mm : for Power In/output		
Dip/Tact Switch	8 DIP : for Output Interface,_RS232/Weigand/MSR output Setting Tact Switch : for ISP		

#### **ENVIRONMENTAL**

Temperature	Operating : -10 $^{\circ}$ C to 60 $^{\circ}$ C Storage : -30 $^{\circ}$ C to 70 $^{\circ}$ C	
Humidity	Operating: 10 % to 90 % noncondensing Storage: Up to 90% noncondensing	

# TERMINAL/SETTING/INDICATOR DESCRIPTIONS



# 1 Power Input



# **3 7PIN Terminal**

Description		
+5VDC OUT		
GND		
<b>Data</b>		
Strobe		
Card Present		
Data0		
Data1		

# **2** 5PIN Terminal

Pin	Description		
1	+12VDC		
2	RX (In)		
3	TX (Out)		
4	iBUTTON		
5	GND		

### 4 LED Indicator

LED	Description		
Ð	Power (O)		
$\Box$	Input to Converter(G)		
	Output form Converter(R)		

PS. All LED indicator is On in the ISP mode.

# 6 RESET

SW	Description
Press before power on	ISP
Unpress before power on	
Press after power on	Run
Unpress after power on	

# 5 DIP Switch


IP8	DIP7	Output Interface
OFF	OFF	RS232 ( Default )
OFF	ON	Wiegand
ON	OFF	Magnetic
ON	ON	Software Setting

DIP6	DIP5	RS232 Output Setting
OFF	OFF	19200 ( Default )
OFF	ON	9600
ON	OFF	4800
ON	ON	Software Setting

DIP4	DIP3	MSR Output Setting
OFF	OFF	ABA ( Default )
OFF	ON	7BIT
ON	OFF	JIS2
ON	ON	Software Setting

DIP2	DIP1	Wiegand Output Setting
OFF	OFF	26 bits ( Default )
OFF	ON	34 bits
ON	OFF	42 bits
ON	ON	Software Setting

# CONNECTION



# **SETTING PARAMETER REGISTER**

Address	Item	Default	MARK
000	RS232 Baudrate	FF : 19200 bps	
001	Interface	FF : RS232 Interface	
003	RS232 Data bits	FF : 8 data bits	
004	RS232 Stop bits	FF : 1 stop bits	
005	RS232 Parity	FF : None	
014	Wiegand Output	FF : Normal Output	
017	Wiegand Output Number	FF : 26 bits	Output
018	Wiegand Output Parity	FF : SS (Even) ES (Odd)	Output
019	Wiegand Pulse Width	FF:100us	Output
01A	Wiegand Pulse Interval	FF: 2ms	Output
021	Wiegand Site Code Start Position	FF : Site Code Empty	Input
022	Wiegand Site Code Length	FF: 66 bits	Input
023	Wiegand Serial Number Start Position	02 : 2nd bit	Input
024	Wiegand Serial Number Length	18 : 24 bits	Input
025	Wiegand Site Code Length (DEC)	FF : Site Code Hex Output	Input
026	Wiegand Serial Number Length (DEC)	FF : Serial Number Hex Output	Input
027	Wiegand Field Code	FF : Empty	Input
032	MSR Mark	FF : Empty	
033	MSR Output Start Digit	FF : 1st Digit	
034	MSR Output ID Length	FF : 255 Digit	
035	MSR Output Digit form iButoon	FF : ABA(D) 7BIT(H) JIS2(H)	
037	MSR Input Start Digit	FF : 1st Digit	
038	MSR Intput ID Length	FF : 144 Digit	
039	MSR End Sentinel0	FF : Empty	
03A	MSR End Sentinel1	FF : Empty	
040	iButton Start Sentinel for RS232	FF : Empty	
041	iButton End Sentinel for RS232	FF : Empty	
042	iButton Present Sentinel for RS232	FF : Empty	
043	iButton Release Sentinel for RS232	FF : Empty	
044	iButton Present ID	FF : ID Only	
045	iButton Release ID	00 : ID Only	
050	MSR 7-bit Start Sentinel	FF : Empty	
051	MSR 7-bit End Sentinel	FF : Empty	
052	MSR ABA Start Sentinel	FF : Empty	
053	MSR ABA End Sentinel	FF : Empty	
054	MSR JIS II Start Sentinel	FF : Empty	
055	MSR JIS II End Sentinel	FF : Empty	
05A	MSR leading Zero number	FF: 10 bits zero	
05B	MSR trailing Zero number	FF: 10 bits zero	
05C	MSR Output Start Sentinel	FF: ABA(0Bh) 7BIT(45h) JIS2(FFh)	
05D	MSR Output End Sentinel	FF: ABA(1Fh) 7BIT(1Fh) JIS2(FFh)	
05E	MSR Output Method	FF : ABA	
05F	MSR Strobe Pulse Width	FF: 40 IPS	
060	RS232 Frame Start Code	02 : STX	
061	RS232 Frame End Code 0	0D : CR	
062	RS232 Frame End Code 1	0A:LF	
063	RS232 Frame Check Code	FF : Empty	
064	RS232 Frame End Code	03 : ETX	
067	MSR Swipe Forward code	FF : Empty	
068	MSR Swipe Rearward code	FF : Empty	

Address	Item	Default	Revsion 1.0
080-087	RS232 Output Prefix	FF : Empty	
088-08F	RS232 Output Suffix	FF : Empty	
090-097	MSR Output Prefix	FF : Empty	
098-09F	MSR Output Suffix	FF : Empty	
0A0-0A7	iButton Output Prefix	FF : Empty	
0A8-0AF	iButton Output Suffix	FF : Empty	
0B0-0B7	Wiegand Output Prefix	FF : Empty	
0B8-0BF	Wiegand Output Suffix	FF : Empty	
100	Wiegand Input Parity Position	01 : 1 bits is parity	
101	Wiegand Input Parity Attribute	00 : Even	
102-10F	Wiegand Input Parity Mark Buffer	7Fh,F8h,00h00h	
110	Wiegand Input Parity Position	1A: 26 bits is parity	
111	Wiegand Input Parity Attribute	01 : Odd	
112-11F	Wiegand Input Parity Mark Buffer	00h,07h,FFh,80h,00h00h	

# **APPLICATION NOTE**

## 1. RS232 Convert to MSR and Wiegand (For software setting mode)

#### RS232 Frame Format

STX	'W'	n	Output Data	CR

### Description

Output Interface	n	Format	Output Data Available Character	Taboo Character
	'1'	7BIT	ASCII 20h ~ 5Fh, Max 144 Characters	25h(%), 3Fh (?)
MSR	'2'	JIS2	ASCII 00h ~ 7Fh, Max 144 Characters	02h(STX) , 0Dh(CR) 7Fh(DEL)
	'3'	ABA	ASCII 30h ~ 3Fh , Max 144 Characters	3Bh(;), 3Fh (?)
	'0'	Setting	ASCII 30h ~ 39h, 41h ~ 46h	
Wiegand	'0'	Setting	ASCII 30h ~ 39h, 41h ~ 46h	

- 1. "Setting" mean according to setting of the Con100iB.
- 2. Any Setting of the CON100iB is not effect if n= '1','2','3' in MSR output.
- 3. Only can send '0'~'9','A'~'F' character if n=0 in MSR output.
- 4. The baud rate was fixed at 19200 bps,8N1

### 2. RS232 Convert to Wiegand (For hardware setting mode)

### RS232 Frame Format

STX	Input Data ( HEX characters )	CR	LF	ETX
-----	-------------------------------	----	----	-----

<sup>1.</sup> The baud rate was fixed at 9600 bps,8N1

### Wiegand Output Format

Parity	Data 13/16/21 bits	Data 13/16/21 bits	Parity	
St	ımmed for even parity	Summed for odd parity		

GIGA-TMS INC. This specification is subject to change without prior notice. Doc No.: TM951196-02