Introduction to Fiber optics

Since ancient times man has needed to communicate with others. Prehistoric man made sounds by beating hallow logs with heavy sticks to communicate messages to others. Reed pipes were also used for the same purpose as hollow logs and drums beaten with sticks.

also used for the Communication purposes.

The first optical signals, have been used whenever civilization has spring up. Man used flashes of reflected sunlight by day and lanterns by night. In the earliest civilizations various combinations of torches on high mountain peaks were used to Communicate rapidly over considerable distances. Coded messages to other ships are still transmitted by using powerful blinker lights by Navy Signal men during the periods of radio silence.

used to control white light but this method was not adequate for communication. The discovery of Laser salved this problem. Laser is very intense and coherent beam of light. Now the problem arises how this light is transmitted to others? A wave guide was used to transmitt light from one place to the others so that light signal do not effect by rain, tog and clouds etc.

An 1966, Charles H. Koo

and Greorge A. Hockman gave an idea that glass fibre can be used for the transmission of signals. Earlier there were some minor problems but they were solved successfully. Ultimately, a fibre was formed which thousands of signals were transmitted simul-


of the world to the others high speed from one part of the world to the other such glass fibre is known

optical Fibre principle as optical fibre. propagation of Light in an optical fibre requires that the light should be totally confined within the fibre. This can be achieved by two different ways. (ii) continuous refraction.

is Total internal reflection:

Media through which light can pass are called aptical media. Air is the most effective optical medium through which speed of light has the greatest value. An optical medium in which speed of light is less than that in air is called optical denser medium. Familiar examples are glass, water thin ail or soap film etc. speed of light in an optical denser medium depends on the refractive inde the medium. Repractive index is the votice the speed of light in freespace to that in given medium i:e.

Ats value is nearly equal to unity for air but is greater than unity for all other optical media.



when light enters from a denser medium to a rare medium. Then it bends away from the normal. In this case, the angle of refraction is always greater than angle of incidence. If we increase the angle of incidence, the corresponding angle of refraction also increases. For a particular value of angle of incidence, the corresponding angle of refraction becames 90. So the angle of incidence for which the angle of refraction is 90 is called critical angle. It is denoted by 00. According to Snell's law.

misino = nisino

When $0_1 = \theta_c$ then $0_1 = 90$

So. $n_1 \sin \theta_c = n_1 \sin \theta_0^2$ $n_1 \sin \theta_c = n_1 \cdot 1$

Sin Oc = nz

For glass-air boundary, we have

 $O_c = Sin'(\frac{1}{1.5})$

Oc = Sin' (0.67)

Oc = 41.8°

When in a denser medium the angle of incidence becomes greater than critical angle, then light did not refract but reflection take place from the boundary of two medio as shown in obove fig. Such a phenomenon is known as total internal reflection. For this phenomenon, following conditions must be fulfilled.

1- Light should travel from a denser to

2- Angle of incidence should be greater than the critical angle.


Madulation

ib-continuous Refraction:

method for the propagation of light in optical fibres in which light is continuously refracted

within the fibre.

A core has high refractive index than cladding, so when a light ray passes from a denser medium to the rare, it




is continuously refracted and is reflected from the outer layer as shown in fig. Hence light is transmitted by continuous refraction and total internal reflection.

Structure of optical fibre

In the form of light optical fibre consists of two parts which are.

(i) - Core (ii) - Cladding

(C) Gloss Cove Jacket



The central portion of the optical fibre is called Core. Core is wrapped by Cladding. Both are made of silica Sia. The refractive index of the core is slightly greater than that of cladding. The basic parts of aptical fibre are shown in figurately. Core and cladding is covered by a jacket. The diameter of the core usually ranges from some to soum.

The refractive index of the

core is increased by the dopping of Germanium.

the cladding is made of pure silica as it has low index. However the refractive index refractive index. can be minimized by the dopping of Boron. glass rad all the light rays striking its internal glass rad all the light rays striking us (critical angle).

Surface at angles greater than 42.8 (critical angle). hill be reflected back in to the glass, while those with angles less than 41.8 will escape from the glass as shown in figici. An figure ray a stribes the glass-air boundary at an angle of 30 less than the critical angle and hence it escapes from the rod and is Lost. However, rage striking the glass-air boundary at in angle of 42 greater than critical angle will be reflected back in to the rad. The same is the case with ray 3. Since the angle of reflection equals the angle of incidence, these two rays will continue propagating down the rad along the path determined by the ariginal angles of incidence. Ray 4 is called an axial ray as it moves parallel to the axis of the rad if it is straight rigid rad. However, in a flexible glass fibre as in figid). the ray will be subjected to the laws of reflection. optical fibres which cause propagation of light through total internal reflection are most commonly used.

- Japa Jau

Types of Optical Fibre

on the basis of propagation of light, the optical fibre is classified into three types

1 - single mode step index fibre.

2 - Multi-made Step index fibre.

3 -. Multi-made graded index fibre.

1-Single Mode Step index Fibre:

single mode or mano made step index has a very thin core of sum and has a relatively larger cladding (of glass ar plastic) as shown in fig. class cladding to the refractive indices of core cladding are constant.

As it has a thin

Core, therefore a strong monochromatic light source (Laser source) has to be used for sending light signals through it. It can carry more than 14 TV channels or 14000 phone calls.

2-Multi-Mode step index Fibre:

At has core of

Core n1

71

relatively larger diameter such as soum and it has smaller cladding.

used for carrying white

light but due to dispersion

effect it is useful for a short distance only. The fibre core has a constant refractive index no such as 1.52 from its centre to the boundary with the cladding as shown in fig. The refractive index then decreases from no 1.52 to no = 1.48 which remains constant throughout the thickness of the cladding. It is called step index multimade fibre as the

refractive index step down from 1.52 to 1.48 at the boundary with the cladding.

3- Multi-Mode Graded index Fibre:

. The diameter of the care of such fibre ranges from soum to 1000 um. At has a core of relatively high refractive index which gradually decreases from the middle to the outer suxface of the fibre. There is no clear-

cut boundary between cladding. This type of fibre is called

the multimode graded index fibre as shown

in fig.

At is very useful for long distance and White light is used to carry the signal. The mode of transmission through this type of fibre is due to continuous refraction from the surfaces of uniformly decreasing index of refraction and total internal reflection from the boundary of the outer surface.

Transmission and Conyersion to Sound

The optical fibre communication system has three major components, namely;

1- Transmitter.

2 - aptical fibre.

3 - Receiver

The transmitter converts electrical signals into light signals. These light signals are transmitted through an aptical fibre. The receiver at the other end of the fibre captures the light signals and converts them into electrical signals.

A semiconductor Laser or LED (light emitting diade) can be used as a light source in the transmitter which emits an invisible infra-red signals of typical wave length 13 mm. The infra-red light travels faster than visible or ultra-violet light. The lasers and LEDs used are tiny units of size less than half the size of thumb

nail to match the size of the Fibres.

An order to transmit information by light waves. Whether it is an audio simula a television signal or a computer data signal, it is necessary to modulate the light waves. The most common method of modulation is called difficulty modulation in which the laser or LED is flashed an and aff at an extremely fast rate. A pulse of light represents the number 1 and the absence of light represents zero. So instead of flashes of light travelling in optical fibres, ones (1s) and zeros (as) are travelling down the fibre. With computer type equipment, any communication can be represented by the code of these 1s and 0s.

The receiver is programmed to decode the 1s and 0s, it receives into sound, pictures or data as required. Digital modulation is expressed in bits (binary digit) or megabits (10° bits) per second. Where a bit is a 1 or a 0.

An spite of the ultrapurity (99.99% glass) of the optical fibre, the light signals becomes dim and they are regenerated by repeaters (amplifiers). Repeaters are typically placed about 30 km apart, but in

newer system they may be separated about tooken converts the light signals into electrical signals. which are then amplified and decoded y necessary to reconstruct the signals originally transmitted The power in optical fibre is losses due to the following reasons, which are, 1- By obsorption and scattering: travels along the fibres by multiple reflections, same light is absorbed due to impurities in the glass. Some it is scattered by average of the scattered by a sca It is scattered by groups of atoms which are formed at places such as joints when fibres are joined together. careful manufacturing can reduce the power loss by scattering and absorption. 2- By Dispersion or spreading: Dispersion or Spreading of light signals make the information received withe other end of a fibre inaccurate and faulty. If the light signals are not purely manachromatic, a narrow band of wavelengths are refracted in different directions when the light signals enters the glass fibre and the light spread . As a result different wavelengths present in the Light signals have different paths and when reach the other end of the fibre at different time and we get faulty or distarted signals
as shown in fig. This is the disadvantage of step. index fibre.

Removel of this defect: Graded index fibre has removed this defect to greater extent as shown in Fig (b). In this case the different wavelengths

internal reflection at different Layers.

However, they are focused at the same points

in fig. At is present as shown

the speed of light varies inversly with the index of refraction. Therefore, the blavelength his travels a longer path than his at a greater speed. Inspite of the different dispersion, all the wavelengths arrive at the other end of the fibre at the

Same time.

An step-index fibre the averall time difference is about 33 ns per Km length of the path. However, in a graded-index fibre this time difference is reduced to about ins per Km of path length.

Advantages of optical Fibre

Graham Bell just four years after the invention of the telephone. Bell was able to transmit a voice message via a beam of light. The transmission of light through thin optical fibres is now being used in communication technology. The use of light as a transmission carrier wave in fibre optics has several advantages over radio wave carries.

1- High Bandwidth:

Capacity of a carries wave increases with carrier frequency. In aptical fibre transmission the carrier is light which has several enders of magnitude greater than the highest radio frequencies. Optical fibre can have

The process of combining the low frequency

transfer of data several signals can be transmitted through one fibre Farexample a single fibre has cable.

2. Low. Loss:

optical fibre Suffer less loss
than copper wires. It is due to the fact that
the loss in aptical fibre is independent of
frequency whereas copper cables exhibit high
losses as frequency increases.

3- Immunity to interference:

optical fibres

are fabricated from a dielectric material (glass) and are therefore free from electromagnetic pulses axising from Switching transients.
Thus a fibre cable does not produce any naisy
environment:

4. Cross-talla:

induction of signal into ar from other circuits so that possibilities of crosstalls is virtually eliminated.

5- Small Size and light Weight:

optical fibres

have diameters of the same order as a human hair, so ever when covered with necessary protective coatings they are far smaller and lighter than copper cable.

6-Abundance of You material:

material of aptical fibre is silica which is naturally available in sea sand rockes in form a different chemical compositions of silica of different materials.