

aiDAPTIV+ Pro Suite 2.0 User guide

Version 2.0

Phison Electronics Corporation

Tel: +886-37-586-896 Fax: +886-37-587-868 E-mail: sales@phison.com / suppport@phison.com



Phison may make changes to specifications and product description at any time without notice. PHISON and the Phison logo are trademarks of Phison Electronics Corporation, registered in the United States and other countries. Products and specifications discussed herein are for reference purposes only. Copies of documents which include information of part number or ordering number, or other materials may be obtained by emailing us at sales@phison.com or support@phison.com.

©2024 Phison Electronics Corp. All Rights Reserved.



REVISION HISTORY

Revision	Draft Date	History	Pro Suite Version	Author	
0.1 2024/10/09		Preliminary release	NXUN_2.0.0J	Sean Liou	
0.1	2024/10/09	Premimary release	(beta version)	Seall Llou	
0.2	2024/10/11	Correct typo in p.11 and p.18	NXUN_2.0.0J	Sean Liou	
0.2	2024/10/11		(beta version)	Sean Liou	
		1.Modify p.8 OS version			
1.0	2024/11/15	2.Add example of permission setting on p.36~37	NXUN_2.0.0	Sean Liou	
		3. Add Appendix A and B			
1.1	2024/11/21	Correct typo.	NXUN_2.0.0	Sean Liou	
1.2	2024/12/6	Update Section 3.1	NXUN_2.0.1	Sean Liou	
1.3	2024/12/10	Update Section 4.1	NXUN_2.0.1	Sean Liou	
1.4	2024/12/16	Update Section 4.1.1,& 4.1.2	NXUN_2.0.1	Sean Liou	
1.5	2024/12/25	1.Add Appendix C	NXUN_2.0.2	Coon Lieu	
1.5	2024/12/25	2.Update Pro Suite verison	NOUN_2.0.2	Sean Liou	
1.6	2025/01/10	1.Update Appendix A	NXUN_2.0.2	Coop Liou	
1.6	2025/01/10	2.Table 3-1, Table 3-2	NOUN_2.0.2	Sean Liou	
1.7	7 2025/01/24 Update Pro Suite version	Undata Dra Suita varsian	NXUN_2.0.3	Coop Liou	
1.7	2025/01/24	opuate P10 Suite version	NOUN_2.0.3	Sean Liou	
1.0	2025/02/19	Undata Appandix A	NXUN_2.0.3	Sean Liou	
1.8	2025/02/18	Update Appendix A	NOUN_2.0.3	Sean Liou	
	2025/03/24 2. Update Sect	1. Update Pro Suite version	NVIIN 205		
1.9		2. Update Section 3.1.1.1, 3.2.2, 3.7.2.2 and 4.1	NXUN_2.0.5 Sean	Sean Liou	
		3. Update Appendix A	NOUN_2.0.5		
2.0	2025/05/09	E /OE /OO LITE ALL ADDENIDIN A MADDEL CLIDDOST LIST	NXUN_2.0.5	Sean Liou	
2.0	2023/03/08	Update APPENDIX A – MODEL SUPPORT LIST	NOUN_2.0.5	Sean Liou	



TABLE OF CONTENTS

REV	ISION	N HISTO	ORY		3
TAB	LE OF	CONT	TENTS	.	4
LIST	OF F	IGURE	s		6
LIST	OF T	ABLES			7
1.	EΝ\	/IRONI	MENT	PREPARATION	8
	1.1.		Supp	ported OS and Nvidia driver version	8
	1.2.		Brow	vser suggestion and precaution	8
2.	DES	CRIPTI	ION		8
3.	FUN	NCTION	INTI	RODUCTION	9
	3.1.		Data	set	10
		3.1.1.		Upload	10
		3.1.1.	1.	Dataset upload	10
		3.1.1	2.	Dataset Management	11
		3.1.1.	3.	Example of dataset file format	12
		3.1.2.		aiDAPTIVGuru	13
		3.1.2.	1.	Parameter setting & file upload	14
		3.1.2	2.	Confirm data pre-processing results	14
		3.1.2	3.	Generate Dataset	15
	3.2.		Fine-	-tune	16
		3.2.1.		Hardware specification preview	16
		3.2.2.		Parameter setting	17
		3.2.3.		Confirm hardware configuration and parameter for fine-tuning	18
	3.3.		Mon	itor	19
		3.3.1.		Cancel job	20
		3.3.2.		Remove job	20
	3.4.		Valid	lation	21
		3.4.1.		Put questions	21
		3.4.2.		Compare result	22
	3.5.		Benc	chmark (Option)	23
		3.5.1.		Score	23



		3.5.2.	Scoring Progress	24
		3.5.3.	Data	25
		3.5.4.	Chart	27
	3.6.	In	ference	28
		3.6.1.	Chat	28
		3.6.2.	RAG	30
		3.6.2.1.	Upload new collection	31
		3.6.2.2.	Recommended usage – using with aiDAPTIVGuru	31
	3.7.	M	lodels	32
		3.7.1.	Model upload	32
		3.7.2.	Model list	33
		3.7.2.1.	Enable model	34
		3.7.2.2.	Set model Inference parameters	34
		3.7.2.3.	Pin the resident inference model	35
		3.7.2.4.	Quantized model	36
	3.8.	M	lanagement	37
		3.8.1.	Authorization	37
		3.8.1.1.	Features	37
		3.8.1.2.	Roles	38
		3.8.1.3.	Users	39
		3.8.1.3.	1. Create Account	39
4.	APP	PLICATIO	N	40
	4.1.	ai	DAPTIVInbox (Option)	40
		4.1.1.	EWS (Exchange Web Services)	41
		4.1.2.	SMTP (Simple Mail Transfer Protocol)	41
APP	ENDI	х а – мо	ODEL AVL FOR FINE-TUNE	42
APP	ENDI	X B – RE	COMMENDED CONFIGURATION	43
APP	ENDI	X C – INE	BOX MAIL SERVER TEST	44
	C.1	Pi	recautions before testing	44
	C.2	Ex	kecute test script	44
	C.3	Te	est result	45



LIST OF FIGURES

Figure 3-1 Pro Suite main function	
Figure 3-2 Dataset	10
Figure 3-3 Dataset upload	10
Figure 3-4 Dataset management	11
Figure 3-5 aiDAPTIVGuru pre-processed file management	14
Figure 3-6 Generate dataset	15
Figure 3-7 Dataset generation progress	15
Figure 3-8 Hardware specification preview	16
Figure 3-9 Parameters setting for fine-tuning	17
Figure 3-10 Final confirmation	18
Figure 3-11 Monitor	19
Figure 3-12 Cancel job	20
Figure 3-13 Remove job	20
Figure 3-14 Setting of question	21
Figure 3-15 View result of question	22
Figure 3-16 Compare results from different models	22
Figure 3-17 Parameter setting	23
Figure 3-18 Scoring progress	24
Figure 3-19 Scoring completed	24
Figure 3-20 Scoring data	26
Figure 3-21 Bar chart	27
Figure 3-22 Model and parameter information	27
Figure 3-23 Detail of scoring content	27
Figure 3-24 Chat room	29
Figure 3-25 RAG	30
Figure 3-26 Collection management	31
Figure 3-27 Model upload-method 2	32
Figure 3-28 Model list description	33
Figure 3-29 Inference parameters setting	34
Figure 3-30 Pin model failed	35



Figure 3-31 Pin model failed error log	35
Figure 3-32 Setting of model quantization	36
Figure 3-33 Cancel model quantization	36
Figure 3-34 Feature setting of role	37
Figure 3-35 Role management	38
Figure 3-36 User management	39
Figure 3-37 Create account	40
Figure 4-1 EWS Setting	41
Figure 4-2 SMTP Setting	42
LIST OF TABLES	
Table 3-1 Specification of aiDAPTIVGuru	12
Table 3-2 Specification of RAG	
Table 3-3 Recommended inference parameter settings	
Table 3-4 Recommend setting of authorization	38
Table A-1 Support model list	42
Table B-1 Recommend Configuration	43
Table C-1 Error message definition	45



1. ENVIRONMENT PREPARATION

1.1. Supported OS and Nvidia driver version

Category		Detail
	OS	Ubuntu 22.04 LTS Desktop
	GPU driver	Nvidia driver version 550 or later version

1.2. Browser suggestion and precaution

- Google Chrome (The recommended default browser for use with the Pro Suite service.)
- Mozilla Firefox

Note: When logging in for the first time, you may log in with the following account

Default system administrator account password

Account: admin@aidaptiv.com

Password: Admin8299

2. DESCRIPTION

The aiDAPTIV+ Pro Suite is a web-based GUI program that enables a **No Code** approach to model training. It streamlines the entire process from **Dataset generation**, **Fine-Tuning**, **Validation** to **Inference**. This allows users to quickly convert documents into files that can be used for training their own fine-tuned models, and build their own AI models.



3. FUNCTION INTRODUCTION

Users can access Pro Suite main functions through the tabs at the top of the webpage. Below are detailed instructions for each function.

- 1. Dataset
 - aiDAPTIVGuru
- 2. Fine-tune
- 3. Monitor
- 4. Validation
- 5. Benchmark (Option)
- 6. Inference
- 7. Models
- 8. Management



Figure 3-1 Pro Suite main function



3.1. Dataset

There're 2 main functions in the Dataset tab: Upload and aiDAPTIVGuru. The Upload function allows users to upload an existing dataset to Pro Suite and manage the uploaded datasets. After clicking the Upload tab, users will see the page below. This page is divided into the upload area on the left and list area on the right.




Figure 3-2 Dataset

3.1.1. Upload

3.1.1.1. Dataset upload

- Field description:
 - File upload location: Support JSON, JSONL and Parquet file format. (Upload one file at a time)
- Function description:
 - Upload
 - o im: Remove temporary files from the storage area



Figure 3-3 Dataset upload



- JSONL and Parquet dataset upload
 - Step1: Upload JSONL or Parquet dataset.
 - Step2: Select the corresponding Key values in the Question and Answer fields.



3.1.1.2. Dataset Management

- Function description:
- 2. **!** Download dataset
- 3. 💼 : Delete dataset




Figure 3-4 Dataset management



3.1.1.3. Example of dataset file format

- Instruction Tuning:
 - o Data file name **Should NOT** contain "pretrain".
 - Key: "instruct", "output"

o Pretrain:

o The data file name **Should** contain "pretrain". (For example: pretrain.json)

o Key: "text"



3.1.2. aiDAPTIVGuru

Dataset preparation is a very labor-intensive process. aiDAPTIVGuru is a feature of Pro Suite that enhances the dataset generation. It transforms user-provided documents or files with domain-specific knowledge (such as product manuals, technical documents, specifications...etc) into Q&A sets and will automatically create a training dataset.

• For the best usage of aiDAPTIVGuru, please refer to <u>Section 3.6.2.2</u>

Table 3-1 Specification of aiDAPTIVGuru

Item	aiDAPTIVGuru_ Entry	aiDAPTIVGuru_ Pro (Option)
File Format	pdf · docx · txt	pdf · docx · txt
Supported Model	Llama-3.1-8B-Instruct	Llama-3.1-8B-Instruct
		Llama-3.1-70B-Instruct
Upload multiple files of same/different		
formats at once	Y	Y

Note: aiDAPTIVGuru_Pro is an additional value-added service. For more information on enabling this service, please contact Phison's Sales account.



3.1.2.1. Parameter setting & file upload

aiDAPTIVGuru parameter settings and document upload.

- Field description:
 - 1. Dataset Name
 - 2. Model: The model needs to be pinned first in order to appear in the model list.
 - 3. **Embedding model**: Retrieval model.
 - 4. **QA Pairs Count**: Number of Instruction Dataset data.
 - 5. **Training QA ratio(%)**: The proportion of data in the data set that is used as training data (the remaining proportion is used as scoring data).
 - 6. Chunk Size: Split size of the data file.
 - 7. **Overlap**: The amount of data overlap when the data file is divided into chunks.
 - 8. **Number of reference chunk per question**: Number of reference Chunk for each data instruction.
 - 9. **Chunk Shuffle**: Mix the data chunks or distribute the data evenly.
 - 10. **Language Evaluation**: After activation, the content generated by the Dataset through Guru will refer to the original document's language. Only supports zh-TW, zh-CN, en-US.
 - **Note**: Please upgrade to the aiDAPTIVGuru pro version to support this feature.
 - 11. **Upload File Area**: Domain file upload area when generating a dataset.
- Function description:
 - 1. Remove all: Remove temporary files.
 - 2. **Upload**: Upload the file for pre-processing.

3.1.2.2. Confirm data pre-processing results

Confirm Inspect the data pre-processing results. The user can edit and adjust data online.

- Function description:
- The street is the pre-processed txt file content and edit online.
- Download the temporary txt document.
- Remove all: Delete all temporary txt files.




Figure 3-5 aiDAPTIVGuru pre-processed file management



3.1.2.3. Generate Dataset

Execute aiDAPTIVGuru.

- Function description:
 - o **Generate**: After confirming the pre-processing results, click "Generate".




Figure 3-6 Generate dataset

o Cancel

Monitor the dataset generation progress. Pressing "Cancel" will terminate the operation.



Figure 3-7 Dataset generation progress



3.2. Fine-tune

Until aiDAPTIV+, small and medium-sized businesses have been limited to small, imprecise training models with the ability to scale beyond Llama-2 7b.

Phison's aiDAPTIV+ solution enables the training of significantly larger models, giving you the opportunity to run workloads previously reserved for data-centers.

Pro Suite's fine-tune feature is integrated with Phison's aiDAPTIV+ technology, reducing hardware resources

The function will be divided into three stages, hardware specification preview, parameter setting and final confirmation.

- Number of GPUs = 2ⁿ (n=0,1,2,3,4, GPUs = 1,2,4,8)
- When selecting the number of GPUs, make sure there are enough GPU resources to perform the finetuning.
- Please refer to Appendix A for model support list.
- Please refer to <u>Appendix B</u> for recommended hardware configuration.

3.2.1. Hardware specification preview

System hardware configuration (GPU, VRAM, system memory, aiDAPTIVLink, aiDAPTIVCache, OS...).

Item	Information
GPU	1-NVIDIA RTX 4000 Ada Generation 2-NVIDIA RTX 4000 Ada Generation 3-NVIDIA RTX 4000 Ada Generation 4-NVIDIA RTX 4000 Ada Generation
GPU Count	4
VRAM	80 GB
System Memory	503 GB
aiDAPTIVLink	aidaptiv:vNXUN_2_01_00
aiDAPTIVCache : life remaining	/dev/nvme0n1 (1907.73GB) : 100.00% /dev/nvme1n1 (1907.73GB) : 100.00%
os	Ubuntu 22.04.4 LTS
OS Disk	439 GB

Figure 3-8 Hardware specification preview



3.2.2. Parameter setting

• Field description:

1. **Model**: Select the model to fine-tune. (Only Pre-training and Fine-tune models will be displayed in the list. AWQ quantified models will not be included in this list.)



Note: The model needs to be available first in order to appear in the model list.

- 2. **Dataset**: Select the dataset for fine-tuning.
- 3. Available GPU: GPU model and number to be used for training
- 4. **Epoch**: The number of epochs to train the model. (Range 1 ~ 5, default=1)
- 5. Per Device Train Batch Size: Batch size for each GPU.
- 6. **Per Update Total Batch Size**: Set the total batch size for one update. For example, if you are running on 4 GPUs with per_device_train_batch_size=4 and want to update the model every 80 batches, then you should set the per_update_total_batch_size to 80. The machine will run 80/4/4 = 5 iterations and update the model once. If not divisible, round up to the next whole number.
- Max Seq Length: Define the maximum sequence length.
 Note: Click the *Advice* button to automatically calculate the appropriate Max Seq Length value.
- 8. **Learning Rate**: Set the learning rate.
- 9. **Triton**: Trigger triton training procedure. It can shorten the model training time. (Please refer to Appendix A for the applicable model list.)

Note: If the user selects a model that does not support Triton for training, the following error message will appear after the training begins: "Phison Accelerator does not support," and the training process will be terminated.

- 10. **Job Name:** Allow users to identify different training tasks.
- Function description:
 - 1. Previous: Return to hardware specifications preview
 - 2. Next




Figure 3-9 Parameters setting for fine-tuning



3.2.3. Confirm hardware configuration and parameter for fine-tuning

• Function description:

1. Previous: Return to parameter settings.

2. Run: Execute fine-tune.

Item	Information		
GPU	1-NVIDIA GeForce RTX 4090 2-NVIDIA GeForce RTX 4090 3-NVIDIA GeForce RTX 4090 4-NVIDIA GeForce RTX 4090		
GPU Count	4		
VRAM	96 GB		
System Memory	504 GB		
aiDAPTIVLink	licensesp/aidaptiv:vNXUN_2_01_00		
aiDAPTIVCache : life remaining	/dev/nvme0n1 (1907.73GB) : 100.00% /dev/nvme1n1 (1907.73GB) : 100.00%		
os	Ubuntu 22.04.4 LTS		
OS Disk	3519 GB		
Model	Meta-Llama-3.1-8B-Instruct		
Dataset	sample_instruction_data_1k_public.json		
Selected GPUs	4		
Batch Size	1		
Epoch	1		
Per Update Total Batch Size	128		
Max Seq Length	2048		
Learning Rate	0.000007		
Task Name	aiDAPTIV_20241113		
	Previous Run		

Figure 3-10 Final confirmation



3.3. Monitor

Monitor the fine-tuning status, including basic information, progress, hardware resource usage (aiDAPTIVCache, GPU, system memory...) of each fine-tune job, training loss trend chart and complete log of aiDAPTIVLink are available.

- Field description:
 - 1. List of all finetune jobs (yellow block in the Figure 3-11)
 - 2. Basic information and hardware usage of a single finetune job (red block in the Figure 3-11)
 - 3. Trend chart of training loss in a single finetune job (purple block in the Figure 3-11)
 - 4. Complete Log information of aiDAPTIVCache in a single fine-tune job (orange block in the Figure 3-11)
 - 5. CPU and Memory usage (blue block in the Figure 3-11)




Figure 3-11 Monitor



3.3.1. Cancel job

Only jobs whose status is "Running" can be cancelled. It can take several seconds for the GPU resources to be released when a job has been canceled.




Figure 3-12 Cancel job

3.3.2. Remove job

Only jobs whose status is "Succeeded / Fail" can be removed.



Figure 3-13 Remove job



3.4. Validation

Used to compare the results of the fine-tuned model against the original model or any other models.

Users can ask questions to confirm whether the fine-tuning results meet expectations.

Note: The user can validate up to 4 models simultaneously.

3.4.1. Put questions

- Field description:
 - 1. **Model**: the model to be verified.
 - 2. **System Prompt**: A predefined instruction or message given to a software system to guide its behavior or output. It typically helps set the context, tone, or specific parameters for the interaction
 - 3. **Max tokens**: This parameter specifies the maximum number of tokens that the model can use to generate responses, where a token generally represents a part of a word or a whole word. (Range: $1000 \sim 12000$)
 - 4. **Temperature**: This parameter controls the randomness of the generation process. A higher temperature results in more diverse responses, while a lower temperature makes responses more likely to follow common patterns seen in the training data. (Range: 0 ~ 1)
 - 5. **Top-p**: Similarly, a sampling technique with temperature called nucleus sampling, you can control how deterministic the model is at generating a response. If you are looking for exact and factual answers keep this low. (Range: $0 \sim 1$)
 - 6. **Include chat history**: Determines whether to include previous dialogue interactions in the context for generating current responses.
 - 7. **Input Question area**: Click submit after entering questions.
 - 8. **RAG**: Please refer to section 3.6.2




Figure 3-14 Setting of question



- Function description:
 - 1. **Submit**: Click submit after entering questions.
 - 2. **Cancel**: Can be used to cancel a half-executed task.




Figure 3-15 View result of question

3.4.2. Compare result

- Function description:
 - 1. **Reset**: Reset models, questions and parameters



Figure 3-16 Compare results from different models



3.5. Benchmark (Option)

Score model performance.

Note: This is an additional value-added service. For more information on enabling this service, please contact Phison's Sales account.

3.5.1. Score

Set the parameters of the model.

- Field description:
 - 1. **Model**: the model to be scored
 - 2. Benchmark model: model as a reference
 - 3. **Embedding model**: retrieval model
 - 4. **Dataset**: Dataset used to test the model's answering ability
 - 5. **Temperature**: This parameter controls the randomness of the generation process. A higher temperature results in more diverse responses, while a lower temperature makes responses more likely to follow common patterns seen in the training data.
 - 6. **Max token**: This parameter specifies the maximum number of tokens that the model can use to generate responses, where a token generally represents a part of a word or a whole word. (Range: 1 ~ 12000)
 - 7. **Top-p**: Similarly, a sampling technique with temperature called nucleus sampling, you can control how deterministic the model is at generating a response. If you are looking for exact and factual answers keep this low. (Range: 0 ~ 1)
 - 8. **Recall Size**: Refers to the number of documents retrieved from a database before generating a response. (Range: $1 \sim 40$)
- Function description:
 - 1. Add: Add a new model to be scored
 - 2. Start benchmarking




Figure 3-17 Parameter setting



3.5.2. Scoring Progress

- Field description:
 - 1. Benchmark model
 - 2. Embedding model
 - 3. **Dataset**
 - 4. Temperature
 - 5. **Top-p**
 - 6. Benchmark Grid:
 - 1. **Index**: Serial number
 - 2. **Model**: the model to be scored
 - 3. Status: Scoring status. Pending, Running, Finish, Fail
 - 4. **Progress**: Scoring progress
- Function description:
 - 1. Cancel all unfinished tasks: Cancel unfinished scoring tasks
 - 2. Return to the settings page
 - 3. View Result: View the graphical results of the rating




Figure 3-18 Scoring progress



Figure 3-19 Scoring completed



3.5.3. Data

View all records containing past rating data.

• Field description:

1. Filter

O Model: the model to be scored

O Benchmark model: model as a reference

O **Embedding model**: retrieval model

O Dataset: Dataset to test the model's answering ability

- Temperature: This parameter controls the randomness of the generation process. A higher temperature results in more diverse responses, while a lower temperature makes responses more likely to follow common patterns seen in the training data.
- O **Max token**: This parameter specifies the maximum number of tokens that the model can use to generate responses, where a token generally represents a part of a word or a whole word. (Range: $1 \sim 12000$)
- Top-p: Similarly, a sampling technique with temperature called nucleus sampling, you can
 control how deterministic the model is at generating a response. If you are looking for exact
 and factual answers keep this low. (Range: 0 ~ 1)
- O Status : Scoring status
- Execution time: The date and time the scoring was performed.

2. Benchmark Grid

O Model: the model to be scored

O Benchmark model: model as a reference

O **Embedding model**: retrieval model

Dataset: Dataset to test the model's answering ability

O Parameter: Parameter settings when scoring (Temperature, Max tokens, Top-p)

O Status : Scoring status

• Execution time: The date and time the scoring was performed.



- Function description:
 - 1. Clear filter condition
 - 2. Select the records you want to view. Multiple items can be selected
 - 3. 💼 : Delete scoring record
 - 4. Click to render chart: Turn the scoring data in to a chart




Figure 3-20 Scoring data



3.5.4. Chart

Turn the scoring data into a chart.

- Field description:
 - 1. **QA Pairs**: Number of scoring questions.
 - 2. Max tokens: Max tokens of the model being scored when scoring
 - 3. **Temperature**: Temperature of the model being scored when scoring
 - 4. **Top-p**: Top-p of the rated model when scoring
 - 5. Y axis: number of questions
 - 6. **X axis**: score
- Function description:

Bar chart: Click on the bar chart to view the rating content in detail.




Figure 3-21 Bar chart



Figure 3-22 Model and parameter information




Figure 3-23 Detail of scoring content



3.6. Inference


If the fine-tuned model verification results are satisfactory, you can create a chat room through the Inference function to provide a complete question and answer service.

- Up to 20 chat rooms can be created.
- Number of GPUs = 2ⁿ (n=0,1,2,3,4, GPUs = 1,2,4,8)
- When selecting the number of GPUs, make sure there are enough GPU resources to perform the inference.



3.6.1. Chat

- Field description:
 - 1. **Model:** Select the model to inference.



Note: The model needs to be pinned first in order to appear in the model list.

- 2. **System Prompt**: A predefined instruction or message given to an AI or software system to guide its behavior or output. It typically helps set the context, tone, or specific parameters for the interaction.
- 3. **Max tokens**: This parameter specifies the maximum number of tokens that the model can use to generate responses, where a token generally represents a part of a word or a whole word. (Range: $1000 \sim 12000$)
- 4. **Temperature**: This parameter controls the randomness of the generation process. A higher temperature results in more diverse responses, while a lower temperature makes responses more likely to follow common patterns seen in the training data. (Range: 0 ~ 1)
- 5. **Top-p**: Similarly, a sampling technique with temperature called nucleus sampling, you can control how deterministic the model is at generating a response. If you are looking for exact and factual answers keep this low. (Range: $0 \sim 1$)
- 6. **Include chat history**: Determines whether to include previous dialogue interactions in the context for generating current responses.
- 7. Input Question area



- Function description:
 - 1. New Chat



Figure 3-24 Chat room



3.6.2. RAG

Based on the chat room function, files can be uploaded for RAG (Retrieval-augmented generation). RAG search can be used to improve the accuracy of model answers or conversations.

Table 3-2 Specification of RAG

Item	RAG		
File Format	pdf \ log \ json \ docx \ txt		
Upload multiple files of same/different	V		
formats at once			

- Field description:
 - 1. **Enable RAG**: Whether to enable RAG function
 - 2. **Recall Size**: Refers to the number of documents retrieved from a database before generating a response. (Range: $1 \sim 40$ counts)
 - 3. **Collection list**: The collection uploaded by the user. Only one collection can be selected.
- Function description:
 - 1. Upload new collection: Upload/create new Collection




Figure 3-25 RAG



3.6.2.1. Upload new collection

Upload files to create a Collection

- Field description:
 - 1. Collection Name: Collection name
 - 2. **Chunk Size**: The amount of data contained in each chunk when processing retrieved documents. (Range: $256 \sim 2048$ tokens)
 - 3. **Chunk Overlap**: The amount of data that overlaps between consecutive chunks when processing. (Range: 0 ~ Chunk Size * 0.5 tokens)
 - 4. **Upload File Area**: File upload area for output Collection.
- Function description:




Figure 3-26 Collection management

3.6.2.2. Recommended usage – using with aiDAPTIVGuru

When you generate a dataset using aiDAPTIVGuru, a corresponding collection file is also created.

After training a model using an aiDAPTIVGuru generated dataset, it is recommended that you use this collection file and enable the RAG (Retrieval-Augmented Generation) feature when performing inference with the model to achieve the best results.



3.7. Models

Management of all models.

3.7.1. Model upload

- Function description:
- Method 1: Drag the Model folder directly to the model storage location /usr/local/models/
 Command: sudo cp -r {source Model folder} {destination folder} (ex: sudo cp -r Meta-Llama-3.1-8B-Instruct//usr/local/models/)
- 2. Method 2: Compress the files in the model folder using either **zip** or **tar**, then click or drag them into the window to upload.

Note: The fine-tuned model will automatically appear in the model list and will also be stored in the following path: /opt/phisonai/data/users/{user account}/jobs/{finetune job id}



Figure 3-27 The storage path of trained models



3.7.2. Model list

- Field description:
 - 1. Name: Model name
 - 2. **State**: Model state. If Running is displayed, it means that the model is being Inferenced.
 - 3. **Model type**: If the name ends with AWQ, it indicates a quantized model.
 - a. Pre_Training
 - b. Finetune
 - c. Pre_Training_AWQ
 - d. Finetune_AWQ
 - 4. Create Time: Model upload/output time
- Function description:
 - Available: The model must be checked and activated by the user before it can be seen in the model menus in Pro Suite.
 - 2. Set model Inference parameters
 - 3. Pin Select Model Button
 - 4. # : Button to quantize model




Figure 3-28 Model list description

Note: If a model already been pinned, then it cannot be deleted.



3.7.2.1. Enable model

- It will be automatically enabled(checked) after uploading through **Method 2**.
- If you have uploaded the model using **Method 1**, **after fine-tune** or **manual quantification**, you need to manually check the box to enable it.
- Only enabled models will be displayed in the model menus for Fine-tune, Validation and Inference.

3.7.2.2. Set model Inference parameters

- **GPU**: Number of GPUs used for Inference. Must be in power of 2.
- Max token length: Display the maximum token length according to the configuration of different models. If it is a combination from the table below, the system will automatically set the Max Token Length value. For other combinations, the user will need to set it manually.

Table 3 3 Recommended interence parameter settings				
	Total Remain VRAM Size	GPU utilization	Max Token Length	
Llaws 2.4 OD kastmast	48	0.95	131072	
Llama-3.1-8B-Instruct	20	0.95	14000	
Library 2.4 CD Instruct AMO INTA	48	0.95	131072	
Llama-3.1-8B-Instruct-AWQ-INT4	16	0.95	67000	
Llama-3.1-70B-Instruct	192	0.95	131072	
Library 2.4.700 in street AMO INTA	96	0.95	131072	
Llama-3.1-70B-Instruct-AWQ-INT4	48	0.95	10000	

Table 3-3 Recommended inference parameter settings

• **GPU memory utilization**: The utilization rate of a single GPU. Default value is 0.9.




Figure 3-29 Inference parameters setting



3.7.2.3. Pin the resident inference model

- Only enabled models can be pinned
- After pinning a model the "Running" prompt will be displayed indicating that the pinning process was successful and the model has been loaded into memory.
- Only the pinned model will be displayed in Inference's model menu.
- Model pinning will fail if the GPU resources are insufficient, an error message will appear. You may select "Yes" to view the error log.
- If a "network error" occurs after pinning the model, please refresh the page.




Figure 3-30 Pin model failed




Figure 3-31 Pin model failed error log



3.7.2.4. Quantized model

Quantize the model by converting the model weights into fixed points or integers to reduce the model size, the computing cost, and accelerate the inference of the model. After quantization, the model will be displayed in the model list with a type ending in "AWQ".

- Field description:
 - 1. Available GPU: Sets the GPUs number to be used for quantization. Must be in powers of 2.
 - 2. **Group Size**: Model parameter group size. Larger values will reduce the accuracy of the model, but can improve the quantization efficiency and reduce the model size. Must be in powers of 2.
 - 3. **Bit**: Sets the bit-width for the quantized model parameters. Lower values reduce model size and increase calculation speed but may affect model accuracy. Must be in powers of 2.




Figure 3-32 Setting of model quantization

- Function description:
 - 1. Cancel: Cancel quantization




Figure 3-33 Cancel model quantization



3.8. Management

Note: Only admin accounts will be allowed to use the following features.

3.8.1. Authorization

User account role management.

Default system administrator account password

Account: admin@aidaptiv.com

Password: Admin8299

3.8.1.1. Features

Function settings. Set the permission for Read and Write of each function.

- Field description:
 - 1. **Features**: Pro Suite feature list, click to set the function permissions of each Role.
 - 2. Role Grid:
 - o Role Name
 - O Read: Only has permission to read this function.
 - O Write: Have permission to write and edit this function.
- Function description:
 - 1. Search : Search Role
 - 2. Add: Add role to a specific feature to set permissions




Figure 3-34 Feature setting of role



Example:

Table 3-4 Recommend setting of authorization

Features	Admin		Al Engineer		General User	
	Read	Write	Read	Write	Read	Write
Authority Management	-	Υ	-	N	-	N
Account Management	-	Υ	-	N	-	N
Dataset Upload	Υ	Υ	Υ	Υ	N	N
Guru	-	Υ	-	Υ	-	N
Finetune	-	Υ	-	Υ	-	N
Monitor	-	Υ	-	Υ	-	N
Validation	-	Υ	-	Υ	-	N
Inference	-	Υ	-	Υ	-	Υ
Models	Υ	Υ	Υ	Υ	Υ	N
RAG	-	Υ	-	Υ	-	Υ
AWQ	-	Υ	-	Υ	-	N
KM		Υ		Υ		Υ

Note: The settings for these three roles will be preset in the system.

3.8.1.2. Roles

Character setting. Create a character and set character features.

- Field description:
 - 1. Role Grid:
 - Role Name
 - Enable
- Function description:
 - 1. Search : Search Role
 - 2. Role Grid:
 - Check the users under a specific Role.
 - o : Rename Role name
 - o 🗰 : Delete Role



Figure 3-35 Role management

- A role cannot be deleted if there are accounts that are using it.
- When a role is disabled, the accounts associated with it will not be able to log into

Pro Suite. Forbidden
You don't have permission to access this page.

• When the role name is changed, the associated accounts will also be updated accordingly.



3.8.1.3. Users

User account settings. Create a user account and set the corresponding role.

- Field description:
 - 1. User Grid:
 - O Name: user name
 - O **Email**: User Email. Sign in as a user.
 - O Role: User role. Settings can be switched directly.
 - Enable: enabled state.
 - O Last Login: Last login time.
 - O **Disable Time**: Disable time.
- Action: Reset user password
- Function description:
 - Create account



Figure 3-36 User management

3.8.1.3.1. Create Account

- Field description:
 - 1. **Name**: User's name. Only English and underscores are allowed. Maximum length is 20 characters.
 - 2. **Email**: User's log-in email account. Must be in a valid email format.
 - 3. **Password**: User's password. Maximum length is 20 characters.
 - 4. **Repeat Password**: Confirmation of the user's password. Maximum length is 20 characters.
 - 5. **Role**: Assign a predefined role to the user account.
- Function description:
 - 1. Cancel
 - 2. Submit






Figure 3-37 Create account

4. APPLICATION

4.1. aiDAPTIVInbox (Option)

This function is an additional value-added service. For more information on enabling this service, please contact Phison's Sales account.

For the introduction to aiDAPTIVInbox, please refer to the following document : aiDAPTIVInbox User Manual 092024 v1.1.pdf

aiDAPTIVInbox is an AI Email Assistant created by Phison Electronics Corp. Powered by its AI technology invention solution called aiDAPTIV+, aiDAPTIVInbox is aimed at improving daily work processes, employee efficiency, and enhanced corporate productivity. aiDAPTIVInbox is designed to be deployed as an on-premise solution to ensure the confidentiality of corporate data by keeping all sensitive information securely stored within the organization's own infrastructure, reducing exposure to external threats and maintaining full control over access and data handling. Through aiDAPTIVInbox, employees can significantly reduce working hours, eliminate time-consuming and tedious tasks, and redirect their focus toward innovation and research & development, thereby creating greater opportunities for the enterprise

Note: For pre-installation confirmation and post-installation checks, please refer to <u>Appendix C</u>. **Inbox support server system**: Microsoft Exchange Server 2019, Mail2000, Hgiga(1132)

- Field description:
 - 1. Model: model used by aiDAPTIVInbox inference
 - 2. System Prompt (Constraint): Define the name and role of AI, function description, etc.
 - 3. **Service Status**: Inbox service status
 - 4. Language: Select language. (zh-TW, zh-CN, en-US, ms-MY)
 - 5. **User Mail Account**: the mail account used by the mail assistant
 - 6. User Mail Address: The mail address used by the mail assistant
 - 7. **User Mail Password**: The mail password used by the mail assistant
 - 8. **Domain**: Mail domain. (Please fill in the email format. Should contain "@" and ".")
 - 9. **Answer Presfix**: Letter opening. (ex: This is the reply from the email assistant:)
 - 10. Answer Suffix: Ending of letter. (ex: Thank you)
 - 11. **Open for All Users**: No restrictions on sender domain, anyone can use the Al function to send and receive messages
 - 12. Web Search: Internet search function
 - 13. White List: Open to senders on this list and outside of the configured Domain.
- Function description:
 - 1. Add: Added a whitelist acceptable to Mail Assistant
 - 2. Save and restart: Save Mail Assistant settings and restart the service
 - 3. **Stop**: Stop service



4.1.1. EWS (Exchange Web Services)

- 1. User Mail Address: Please fill in the email format. (Should contain "@" and ".", ex: test @phison.com)
- 2. Mail Server: Only domain name can be filled in, not the IP. (String length: 2~63. Should contain ".", ex: mail.phison.com)
- 3. Office 365: Verification of Office 365 cloud authentication and authorization service usage.
 - Client ID
 - Client Secret
 - Tenant ID




Figure 4-1 EWS Setting

4.1.2. SMTP (Simple Mail Transfer Protocol)

- SMTP Server IP: Server domain for sending emails (Should contain ".", ex: mail.phison.com)
- 2. SMTP Port: Port for sending emails. (Support: 25, 465, 587)
- 3. IMAP Server IP: Server domain for receiving emails. (Should contain ".", ex: mail.phison.com)
- 4. IMAP Port: Port for receiving emails. (Support: 993)






Figure 4-2 SMTP Setting

APPENDIX A – MODEL SUPPORT LIST

Table A-1 Support model list

No	Task Type	Model Name	Model Size (MB/GB)	Support Triton
1	text_generation	<u>Llama-3.1-8B-Instruct</u>	15 GB	Υ
2	text_generation	Llama-3.1-70B-Instruct	132 GB	Υ
3	text_generation	Llama-3-Taiwan-70B-Instruct	132 GB	N
4	text_generation	Qwen2-7B-Instruct	15 GB	N
5	text_generation	Qwen2-72B-Instruct	136 GB	N
6	text_generation	Qwen1.5-7B-Chat	14 GB	N
7	text_generation	Qwen1.5-14B-Chat	27 GB	N
8	text_generation	Qwen1.5-72B-Chat	135 GB	N
9	text_generation	Qwen1.5-110B-Chat	208 GB	N
10	text_generation	chatglm3-6b	11 GB	N
11	text_generation	deepseek-llm-7b-chat	13 GB	N
12	text_generation	deepseek-llm-67b-chat	126 GB	N
13	text_generation	deepseek-moe-16b-chat	31 GB	N
14	text_generation	Breeze-7B-Instruct-v0 1	14 GB	N
15	text_generation	Gemma-2-27b-it	51 GB	N
16	text_generation	<u>Yi-1.5-6B-Chat</u>	12 GB	N
17	text_generation	<u>Yi-1.5-9B-Chat</u>	17 GB	N
18	text_generation	<u>Yi-1.5-34B-Chat</u>	65 GB	N

Note: If the user selects a model that does not support Triton for training and enables Triton, the following error message will appear after the training begins: "Phison Accelerator does not support," and the training process will be terminated.



APPENDIX B - RECOMMENDED CONFIGURATION

DRAM and aiDAPTIVCache with different LLM model size

Table B-1 Recommend Configuration

Table B 1 Neconimena comigaration						
	AITPC	Work Station	Server			
GPU Configuration	NVIDIA 4060Ti (16GB)*1	NVIDIA RTX 4000 Ada *4	NVIDIA RTX A6000 *8			
		NVIDIA RTX A6000 *4				
LLM model size	≤13B	<100B	<200B			
DRAM	DDR5 4800 64GB	DDR5 4800 512GB	DDR5 4800 1024GB			
		DDR5 4800 1024GB				
aiDAPTIVCache capacity	320GB	2TB	2ТВ			
aiDAPTIVCache count	1	2	4			

- Recommend Gen4 or above.
- O Recommend DRAM 2933MHz or above.
- O Recommend DRAM channel number is 8 or more, ex: 16GB x8



APPENDIX C – INBOX MAIL SERVER TEST

The main purpose of this section is to help users perform basic environment checks before installing aiDAPTIVInbox, and to test whether the installation is correct after aiDAPTIVInbox has been installed.

Test script : smtp_imap_connection_test.py

mail account: Account to log in to the mail server

mail address : Complete email address

mail_password : Password to log in to the mail server smtp_server_ip : Server domain for sending emails

smtp_port : Support: 25, 465, 587

imap_server_ip : Server domain for receiving emails.

imap_port : Support: 993

test_mail: Email address for testing. After the script is tested, a test email will be sent to this

email address.

• Test script parameter configuration file: smtp_imap_connection_test.json

C.1 Precautions before testing

- 1. Place *Test script* and *Test script parameter configuration file* in the same folder.
- 2. Enable:
 - SMTP : SMTP_Server_IP, SMTP port
 - IMAP : IMAP_Server_IP, IMAP port
- 3. Confirm that the SMTP and IMAP functions of the mail server are enabled, and the corresponding ports also need to be enabled (Not blocked by the firewall).
- 4. Confirm that the IMAP of the mail server can perform the following operations on the mailbox:
 - Can check mailbox
 - O Have permission to download emails
 - O Can change email status (eg: read, unread)
 - O Have permission to move emails to different email folders

C.2 Execute test script

Enter the following command in the terminal to execute the test script.

python3 smtp_imap_connection_test.py



C.3 Test result

- If the test result is **Pass**: User will recive a e-mail in the test mail. (The subject of the email is: Test subject "Time of program execution")
- If the test result is *Fail*: Users can refer to the errorcode below to troubleshoot the problem.

Table C-1 Error message definition

Error message	Definition	
Account or password incorrect, check account and password	Mail Account	
	Mail Password	
SMTP error: Check the smtp_server_ip and smtp_port	SMTP Server IP	
	SMTP Port	
IMAP error: Check the imap_server_ip and imap_port	IMAP Server IP	
	IMAP Port	