
Zero Energy Cooling Chamber


A sustainable solution to storing excess produce


What is a ZECC?

Side View



Top View






The long red arrow models the change of temperature throughout the layers.

The thick red arrows indicate heat transfer and the thick blue elements indicate mass transfer occurring.

Usage

- Most commonly found in hot, arid climates where access to electricity is sparse
- Often used by small scale farmers to reduce postharvest loss in developing countries

Zero Energy Cooling Chambers (ZECC)



Mission

- Successfully model the mass and heat transfer through system via python code
- Create a GUI (Graphical User Interface) for ease of understanding
- Introduce simple concepts for first year students
- Compare model to real world examples ie. cooling towers, cooling the body via evaporation of sweat

PROBLEM: Find the optimal ZECC design by varying temperatures, relative humidity, and size.

Assumptions

- One metric ton of potatoes is being stored in the center of the inner chamber
- Sand remains saturated throughout the process
- Potatoes respirate, giving off a source of heat that drives the heat and mass transfer out of the system
- Water travels from the wet sand out through the brick, evaporating off of the surface of the outer brick wall, creating a cooling effect at each layer of the chamber (similar to sweat evaporating off skin to cool you down)

Independent Variables

- Inner Chamber Temperature
- Outer Air Temperature
- Outer Air Relative Humidity
- Size of Inner Chamber (length and width varied, fixed height)
- Size of Wet Sand Layer (thickness)

Dependent Variables Calculated by the Model

- Temperatures at each medium interface (HT)
- Dew Point Temperature at outer brick wall (HT)
- Diffusion of Water through the layers to the outer brick wall (MT)
- Evaporation of Water at outer brick surface (MT)
- Liters of Water needed to be added daily to replace lost water via MT
- Annual cost of design (both fixed and variable expenses)

General Balance

- IN + GENERATION = OUT
- IN = water is added into the system to force heat transfer outward
- GENERATION = heat is generated by the potatoes in the center of the storage container
- OUT = heat conducted out, water evaporated out at brick surface

Essential Equations- Heat Transfer

Composite wall heat balance to find temperatures at each interface

$$q = \frac{\left(T_c - T_4\right)}{\frac{1}{h_c \cdot A_c}} = \frac{\left(T_4 - T_3\right)}{\frac{L_{inner\ brick}}{k_{brick} \cdot A_{inner\ brick}}} = \frac{\left(T_3 - T_2\right)}{\frac{L_{wet\ sand}}{k_{wet\ sand}}} = \frac{\left(T_2 - T_1\right)}{\frac{L_{outer\ brick}}{k_{brick} \cdot A_{outer\ brick}}} = \frac{\left(T_1 - T_{bulk}\right)}{\frac{1}{h_{bulk} \cdot A_{bulk}}}$$

q = Heat produced by potato respiration $A_{inner\ brick} = Area\ of\ inner\ brick\ layer$ $T_c = Inner\ Chamber\ Temperature$ h_c = Heat transfer coeff icient inside the chamber $L_{wet \, sand} = Length \, of \, wet \, sand \, layer$ T_A =Inner Chamber / Inner Brick Interf ace Temperature $A_c = Area \ of \ inner \ chamber$ $k_{wet sand} = Thermal conductivity of wet sand$ $T_3 = Inner\ Brick \ / \ Wet\ Sand\ Interf\ ace\ Temperature$ $L_{inner\ brick} = Length\ of\ the\ inner\ brick\ layer$ T_2 = Wet Sand / Outer Brick Interf ace Temperature $A_{wet \, sand} = Area \, of \, wet \, sand \, layer$ k_{brick} = Thermal conductivity of brick $L_{outer\ brick} = Length\ of\ outer\ brick\ layer$ $T_1 = Outer Brick / Bulk Air Interface Temperature$ $h_{bulk} = Heat \ transfer \ coefficient \ of \ outdoor \ air$ $= Area \ of \ outer \ brick \ layer$ T_{bulk} = Temperature of outdoor air

Essential Equations- Heat Transfer

 Magnus Formula to find dew point temperature based on input value of bulk air temperature and relative humidity.

$$T_{dew\ point} = \frac{b\left(\frac{a \cdot T_{bulk}}{b + T_{bulk}} + \ln(RH)\right)}{a - \left(\frac{a \cdot T_{bulk}}{b + T_{bulk}} + \ln(RH)\right)} \ where\ a = 17.27,\ b = 237.7,\ RH = 0 \rightarrow 1$$

 Dew Point temperature is critically dependent on both the design of the chamber and inputted values. If the outer brick wall temperature becomes too low, water will begin to condense on the surface of the brick, and no evaporation will occur, halting the cooling of the inner chamber.

Essential Equations- Mass Transfer

• Antoine equation to calculate pressure at a certain temperature

$$\ln(P^*) = A - \frac{B}{C + T}$$
 where $A = 18.3036$, $B = 3816.44$, $C = -46.13$

ullet Mass balance to calculate the outer mass transfer coefficient ${}^{k}{}_{bulk}$

$$q + h_{bulk} \cdot A_{outer\ brick} \cdot (T_{bulk} - T_1) = \lambda \cdot k_{bulk} \cdot A_{bulk} (P^*(T_1) - P_{bulk})$$

where λ = latent heat of evaporation, q = heat of respiration

Finding the concentration of water moving from the sand through the outer brick

$$\frac{\varepsilon_{brick} \cdot D_{wb} \cdot A_{outer\ brick} \left(C_{sand} - C_{outer\ brick}\right)}{L_{outer\ brick}} = k_{bulk} \cdot A_{bulk} \left(P^* \left(T_1\right) - P_{bulk}\right)$$

Ideal Solution

- The ideal student solution would account for the following
 - Lowest inner chamber temperature
 - Least amount of water added per day
 - Lowest cost to build/maintain
- Introduce Excel to keep track of results and how they change

Excel for Results

Thicknesses:					Temperature:							% Change
Inner Chamber Length	Inner Chamber Width	Inner Brick	Wet Sand	Outer Brick	Inner Chamber	Outer Air	Relative Humidity	Inner Chamber/Brick	Inner Brick/Sand	Sand/ Outer Brick	Outer Brick/Air	
1	1	0.1125	0.025	0.1125	20	31	25%	19.04	11.51	8.36	8.9	N/A
1.01	1	0.1125	0.025	0.1125	20	31	25%	19.04	11.51	8.36	8.9	0
1	1.01	0.1125	0.025	0.1125	20	31	25%	19.04	11.51	8.36	8.9	0
1	1	0.1125	0.035	0.1125	20	31	25%	19.04	11.51	7.11	9.61	7.97752809
Thicknesses:					Water Added	% Change						
Inner Chamber Length	Inner Chamber Width	Inner Brick	Wet Sand	Outer Brick								
1	1	0.1125	0.025	0.1125	20.51	N/A		Increase each layer b	y 10 cm			
1.01	1	0.1125	0.025	0.1125	20.57	0.2925402243						
1	1.01	0.1125	0.025	0.1125	20.55	0.1950268162						
1	1	0.1125	0.035	0.1125	20.61	0.4875670405						
Temperature:			Thicknesses:			Temperature:				% Change	Water Added	% Change
Inner Chamber	Outer Air	Relative Humidity	Inner Chamber Length	Inner Chamber Width	Wet Sand	Inner Chamber/Brick	Inner Brick/Sand	Sand/ Outer Brick	Outer Brick/Air			
20	31	25%	1	1	0.025	19.04	11.51	8.36	8.9	N/A	20.51	N/A
19	31	25%	1	1	0.025	18.04	10.51	7.36	9.46	6.292134831	19.91	2.925402243
20	30	25%	1	1	0.025	19.04	11.51	8.36	8.46	4.943820225	20.26	1.218917601
20	31	24%	1	1	0.025	19.04	11.51	8.36	8.9	0	20.51	0

Food for Thought

- Consider the region and time of year this would be implemented. How does that change the outer air temperature and relative humidity values you will be inputting?
- What is a normal refrigerator temperature? Do potatoes need to be stored at this temperature?
- How much is one metric ton of potatoes in kg? What kind of space might that many potatoes occupy? Will this affect your initial guesses?
- How will changing each variable affect your overall design? Which is the most costly to manipulate and why?
- Is this design useful? Does it make sense to build a ZECC here at Lehigh, or would it be better suited elsewhere? Can this be used year-round?

Additional Comments

- Keep track of your results! Utilizing the excel spreadsheet can be one of your most valuable tools if used properly
- Make educated guesses. Which changes will positively impact your results and how can you maximize them?
- Always ask questions.

How it Works:

See python program