

System model and parameters

The transfer function model for the cruise control problem is given below. Please see the Cruise Control: System Modeling page for the derivation.

$$P(s) = \frac{V(s)}{U(s)} = \frac{1}{ms+b} \qquad \left[\frac{m/s}{N}\right] \tag{1}$$

The parameters used in this example are as follows:


- (m) vehicle mass 1000 kg
- (b) damping coefficient 50 N.s/m
- (r) reference speed 10 m/s

Performance specifications

- Rise time < 5 s
- Overshoot < 10%
- Steady-state error < 2%

PID overview

The block diagram of a typical unity feedback system is shown below.



Recall from the Introduction: PID Controller Design page, the transfer function of a PID controller is

$$C(s) = K_p + \frac{K_i}{s} + K_d s = \frac{K_d s^2 + K_p s + K_i}{s}$$
 (2)

We can define a PID controller in MATLAB using the transfer function directly:

```
Kp = 1;
Ki = 1;
Kd = 1;

s = tf('s');
C = Kp + Ki/s + Kd*s
```

```
C =

S^2 + S + 1
```

Continuous-time transfer function.

Alternatively, we may use MATLAB's **pid controller object** to generate an equivalent continuous time controller as follows:

```
C = pid(Kp,Ki,Kd)
```

C =

with
$$Kp = 1$$
, $Ki = 1$, $Kd = 1$

Continuous-time PID controller in parallel form.

Proportional control

The first thing to do in this problem is to find a closed-loop transfer function with a proportional control ($C=K_p$) added.

By reducing the unity feedback block diagram, the closed-loop transfer function with a proportional controller becomes:

$$T(s) = \frac{Y(s)}{R(s)} = \frac{P(s)C(s)}{1 + P(s)C(s)} = \frac{K_p}{ms + b + K_p}$$
(3)

Recall from the Introduction: PID Controller Design page, a proportional controller, K_p , decreases the rise time, which is desirable in this case.

For now, use K_p equal to 100 and a reference speed of 10 m/s. Create a new m-file and enter the following commands.

```
m = 1000;
b = 50;
r = 10;

s = tf('s');
P_cruise = 1/(m*s + b);

Kp = 100;
C = pid(Kp);


T = feedback(C*P_cruise,1)

t = 0:0.1:20;
step(r*T,t)
axis([0 20 0 10])
```

T =

100 -----1000 s + 150

Continuous-time transfer function.




Note that we have used the MATLAB feedback command to simplify the block diagram reduction of the closed-loop system. Please verify for yourself that the result agrees with the closed-loop transfer function, T, derived above.

Running the m-file in MATLAB should give you the step response above. As you can see from the plot, neither the steady-state error nor the rise time satisfy our design criteria.

You can increase the proportional gain, K_p , to reduce the rise time and the steady-state error. Change the existing m-file so that K_p equals 5000 and rerun it in the MATLAB command window. You should see the following plot.

```
Kp = 5000;
C = pid(Kp);
T = feedback(C*P_cruise,1);
step(r*T,t)
axis([0 20 0 10])
```



The steady-state error is now essentially zero, and the rise time has been reduced substantially. However, this response is unrealistic because a real cruise control system generally can not change the speed of the vehicle from 0 to 10 m/s in less than 0.5 seconds due to power limitations of the engine and drivetrain.

Actuator limitations are very frequently encountered in practice in control systems engineering, and consequently, the required control action must always be considered when proposing a new controller. We will discuss this issue much more in subsequent tutorials.

The solution to this problem in this case is to choose a lower proportional gain, K_p , that will give a reasonable rise time, and add an integral controller to eliminate the steady-state error.

PI control

The closed-loop transfer function of this cruise control system with a PI controller ($C=K_p+K_i/s$) is:


$$T(s) = \frac{Y(s)}{R(s)} = \frac{P(s)C(s)}{1 + P(s)C(s)} = \frac{K_p s + K_i}{m s^2 + (b + K_p)s + K_i}$$
(4)

Recall from the Introduction: PID Controller Design page, an addition of an integral controller to the system eliminates the steady-state error. For now, let K_p equal 600 and K_i equal 1 and see what happens to the response. Change your m-file to the following.

```
Kp = 600;
Ki = 1;
C = pid(Kp,Ki);

T = feedback(C*P_cruise,1);

step(r*T,t)
axis([0 20 0 10])
```




Now adjust both the proportional gain, K_p , and the integral gain, K_i , to obtain the desired response. When you adjust the integral gain, K_i , we suggest you to start with a small value since a large K_i can de-stabilize the response. When K_p equals 800 and K_i equals 40, the step response will look like the following:

```
Kp = 800;
Ki = 40;
C = pid(Kp,Ki);

T = feedback(C*P_cruise,1);

step(r*T,t)
axis([0 20 0 10])
```



PID control

For this particular example, no implementation of a derivative controller was needed to obtain the required output. However, you might want to see how to work with a PID control for the future reference. The closed-loop transfer function for this cruise control system with a PID controller ($C=K_p+K_i/s+K_ds$) is:

$$T(s) = \frac{Y(s)}{R(s)} = \frac{P(s)C(s)}{1 + P(s)C(s)} = \frac{K_d s^2 + K_p s + K_i}{(m + K_d)s^2 + (b + K_p)s + K_i}$$
(5)

Let K_p equal 1, K_i equal 1, and K_d equal 1 and enter the following commands into a new m-file.

```
Kp = 1;
Ki = 1;
Kd = 1;
C = pid(Kp,Ki,Kd);
T = feedback(C*P_cruise,1);
```

Plot the step response and adjust all of K_p , K_d , and K_i until you obtain satisfactory results. We will leave this as an exercise for you to work on.

Suggestion: Usually choosing appropriate gains requires a trial and error process. The best way to attack this tedious process is to adjust one variable (K_p , K_l , or K_d) at a time and observe how changing one variable influences the

system output. The characteristics of $K_p,\,K_i$, and K_d are summarized in the Introduction: PID Controller Design page.

Published with MATLAB® 9.2

All contents licensed under a Creative Commons Attribution-ShareAlike 4.0 ${\bf International\ License.}$

