```
tech
 min2
end
version
  version 0.0
  description "my minimum tech file"
end
planes
 well,w
 active,a
 metal1,m1
end
types
 well nwell,nw
 well pwell,pw
 active ntransistor,nfet
 active ptransistor,pfet
 active transistor, fet
 active ndiffusion,ndiff,green
 active pdiffusion,pdiff,brown
 active ndcontact,ndc
 active pdcontact,pdc
 active psubstratepcontact,pohmiccontact,poc,pwcontact,pwc,psc
 active nsubstratencontact,nohmiccontact,noc,nwcontact,nwc,nsc
 active polysilicon,red,poly,p
 active polycontact,pcontact,polycut,pc
 active psubstratepdiff,pohmicdiff,pod,ppdiff,ppd,psd
 active nsubstratendiff,nohmicdiff,nod,nndiff,nnd,nsd
 metal1 metal1,m1,blue
end
contact
pcontact poly metal1
ndcontact ndiff metal1
pdcontact pdiff metal1
psc psd metal1
nsc nsd metal1
end
styles
styletype mos
 nwell 12
 pwell 13
 metal1 20
 nfet 6
```

```
nfet 7
 pfet 8
 pfet 9
 ndiff 2
 pdiff 4
 ndc 2
 ndc 20
 ndc 32
 pdc 4
 pdc 20
 pdc 32
 nsc 3
 nsc 20
 nsc 32
 psc 5
 psc 20
 psc 32
 poly 1
 pcontact 1
 pcontact 20
 pcontact 32
 error_p 42
 error_s 42
 error_ps 42
end
compose
end
connect
 nwell,nsc/a,nsd nwell,nsc/a,nsd
 pwell,psc/a,psd pwell,psc/a,psd
 m1,ndc/m1,nsc/m1,pdc/m1,psc/m1,pc/m1 m1,ndc/m1,nsc/m1,pdc/m1,psc/m1,pc/m1
 ndiff,nsd,ndc/a,nsc/a,pdiff,psd,pdc/a,psc/a ndiff,nsd,ndc/a,nsc/a,pdiff,psd,pdc/a,psc/a
 poly,nfet,pfet,fet,pc/a poly,nfet,pfet,fet,pc/a
end
cifoutput
end
cifinput
end
# mzrouter
# end
drc
```

```
width poly 2 \
"your poly width is < 2, so flagging DRC error "
overhang poly/a nfet,pfet,fet 3 \
"your poly extension over active is < 3, so flagging DRC error"
overhang *ndiff/a nfet 3 \
"your ndiff extension over nfet is < 3, so flagging DRC error"
overhang *pdiff/a pfet 3 \
"your pdiff extension over pfet is < 3, so flagging DRC error"
spacing nfet,pfet ndc/a,pdc/a 1 touching_illegal \
"your transistor to ndiff and pdiff contacts is < 1 and touching is illegal, so flagging DRC error"
width (ndc,pdc)/m1 4 \
"your ndiff contact and pdiff contact width is < 4, so flagging DRC error"
width *m13 \
"your metal1 width is < 3, so flagging DRC error"
spacing *m1/m1 *m1/m1 3 touching_ok \
"your m1 to m1 spacing is < 3, so flagging DRC error"
spacing ndc/a,pdc/a,psc/a,nsc/a ndc/a,pdc/a,psc/a,nsc/a 2 touching ok \
"your spacing between contacts is < 2, so flagging DRC error"
width ndiff,pdiff,pfet,nfet,ndc/a,nsc/a,pdc/a,psc/a 3 \
"your pdiff or ndiff width is < 3, so flagging DRC error"
spacing nfet,pfet nsc/a,psc/a 1 touching_illegal \
"your transistor to n-substrate and psubstrate contacts is < 1 and touching is illegal, so flagging
DRC error"
spacing poly/a (*ndiff,*pdiff,*nsd,*psd)/a 1 corner_ok nfet,pfet \
"your poly spacing to diffusion is < 1, so flagging DRC error"
##some more rules##
spacing poly,nfet,pfet,fet poly,nfet,pfet,fet 3 touching_ok \
"your poly spacing < 3, so flagging DRC error"
###more contact rules
spacing nsc/m1 pdc/m1 2 touching illegal \
"your nsc to pdc spacing is < 2, so flagging DRC error"
spacing psc/m1 ndc/m1 2 touching_illegal \
"your psc to ndc spacing is < 2, so flagging DRC error"
```

```
width nwell 12 \
"your nwell width is < 12, so flagging DRC error"
spacing nwell nwell 6 touching_ok \
"your nwell to nwell spacing in < 6, so flagging DRC error"
width pwell 12 \
"your pwell width is < 12, so flagging DRC error"
spacing pwell pwell 6 touching ok \
"your pwell to pwell spacing in < 6, so flagging DRC error"
surround (*nsd)/a nwell 2 absence_ok \
"your nwell overlap of n-contact is < 2, so flagging DRC error"
surround (*psd)/a pwell 2 absence ok \
"your pwell overlap of p-contact is < 2, so flagging DRC error"
surround (*pdiff,pfet)/a nwell 5 absence ok \
"your nwell overlap of pdiffusion is < 5, so flagging DRC error"
surround (*ndiff,nfet)/a pwell 5 absence_ok \
"your pwell overlap of ndffusion is < 5, so flagging DRC error"
spacing (*ndiff,nfet)/a (*pdiff,pfet)/a 8 touching illegal \
"your ndiff to pdiff spacing is < 8, so flagging DRC error"
spacing *nsd *psd 4 touching_illegal \
"your n-type spacing to p-type < 4, so flagging DRC error"
spacing ndiff,nfet,nsd,pdiff,pfet,psd,ndc/a,nsc/a,pdc/a,psc/a,nfet,pfet ndc/a,pdc/a,psc/a,nsc/a 4
touching ok \
"your active area or diffusion spacing to active or diffusion contact is < 4, so flagging DRC error"
spacing ndiff,nfet,nsd,pdiff,pfet,psd,ndc/a,nsc/a,pdc/a,psc/a
ndiff,nfet,nsd,pdiff,pfet,psd,ndc/a,nsc/a,pdc/a,psc/a 3 touching ok \
"your spacing between diffusion is < 3, so flagging DRC error"
end
extract
style lambda=0.09
lambda 9
step 100
sidehalo 4
substrate (*psd)/active,(pwell)/well,space/well well
```

```
planeorder well 0
planeorder active 1
planeorder metal1 2
# All resistance and contact values are in milliohms per square
resist (*ndiff,nsd)/active 8000
resist (*pdiff,*psd)/active 8000
resist (nwell)/well 900000
resist (pwell)/well 900000
resist (*poly,pfet,nfet)/active 7400
resist (*m1)/metal1 80
contact ndc,nsc 10000
contact pdc,psc 10000
contact pc 10000
#-----
# Parasitic capacitance values
#-----
# This uses the new "default" definitions that determine the intervening
# planes from the planeorder stack, take care of the reflexive sideoverlap
# definitions, and generally clean up the section and make it more readable.
# Remember that device capacitances to substrate are taken care of by the
# models. Thus, active and poly definitions ignore all "fet" types.
# However, fet types are included when computing parasitic capacitance to
# poly and active from layers above them.
# All perimeter capacitance values are in aF/um
# All area capacitance values are in aF/um^2
# (determined by the value of "lambda" and "units" above)
#n-well
defaultareacap nwell well 0.502
#n-active
defaultareacap
                *ndiff,*nsd active 15.163
defaultperimeter *ndiff,*nsd active 39.600
#p-active
defaultareacap
                 *pdiff,*psd active 15.204
defaultperimeter *pdiff,*psd active 31.680
vloq#
```

12.714

defaultsidewall \*poly active

```
defaultareacap
                 *poly active well 0.786
defaultperimeter *poly active well 2.316
#metal1
defaultsidewall *m1 metal1
                               23.087
defaultareacap *m1 metal1 well 0.308
defaultperimeter *m1 metal1 well 2.070
#metal1->diff
                *m1 metal1 *ndiff,*nsd,*pdiff,*psd active 0.405
defaultoverlap
defaultsideoverlap *m1 metal1 *ndiff,*nsd,*pdiff,*psd active 2.070
#metal1->poly
defaultoverlap
                *m1 metal1 *poly,pfet,nfet active 0.510
defaultsideoverlap *m1 metal1 *poly,pfet,nfet active 6.300
device mosfet pmos pfet pdiff,pdc nwell error 50 46
device mosfet nmos nfet ndiff,ndc pwell,space/well error 50 46
fetresis pfet linear 40000
fetresis pfet saturation 40000
fetresis nfet linear 9000
fetresis nfet saturation 9000
variant *
end
# wiring
# end
# router
# end
# plowing
# end
# plot
# end
```